

# Rittal – The System.

Faster – better – everywhere.



**Filterlüfter**  
**Fan-and-filter unit**  
**Ventilateur à filtre**  
**Ventilator**  
**Filterfläkt**  
**Ventilatore-filtro**  
**Ventilador con filtro**  
**フィルターファン**

3237.xxx	3241.xxx
3238.xxx	3243.xxx
3239.xxx	3244.xxx
3240.xxx	3245.xxx

**Montage-, Installations- und Bedienungsanleitung**  
**Assembly and operating instructions**  
**Notice d'emploi, d'installation et de montage**  
**Montage- en bedieningshandleiding**  
**Montage- och hanteringsanvisning**  
**Istruzioni di montaggio e funzionamento**  
**Instrucciones de montaje y funcionamiento**  
**取扱説明書**



в Беларуси Заказ г.Минск +375447584780 Viber telegram whatsapp Skype email 2005646@tut.by

## Contents

EN

<b>1 Notes on documentation . . . . .</b>	<b>4</b>	<b>5 Carrying out the electrical connection . . . . .</b>	<b>9</b>
1.1 Other applicable documents .	4	5.1 Connecting the power supply	9
1.2 Retention of documents . . . . .	4	5.2 Rotating the voltage connection . . . . .	9
1.3 Symbols used . . . . .	4	5.3 Changing the direction of airflow . . . . .	10
<b>2 Safety notes . . . . .</b>	<b>5</b>	<b>6 Commissioning . . . . .</b>	<b>10</b>
<b>3 Device description . . . . .</b>	<b>5</b>	<b>7 Installing and changing the filter . . . . .</b>	<b>10</b>
3.1 Functional description . . . . .	5	8 Inspection and maintenance. . . . .	11
3.1.1 Main components . . . . .	5	9 Storage and disposal . . . . .	11
3.1.2 Control . . . . .	6	10 Technical specifications . . . . .	12
3.1.3 Safety equipment . . . . .	6	11 Cut-out/drilling dimensions . . . . .	16
3.1.4 Filter mats . . . . .	6	12 EMC fan/outlet filter. . . . .	17
3.2 Proper use . . . . .	6	13 Connection diagrams . . . . .	18
3.3 Scope of supply . . . . .	6	14 EC declaration of conformity . . . . .	20
<b>4 Assembly and connection . . . . .</b>	<b>7</b>		
4.1 Choosing the installation site . . . . .	7		
4.2 Assembly instructions . . . . .	7		
4.2.1 General . . . . .	7		
4.2.2 Layout of the components in the enclosure. . . . .	7		
4.3 Fitting the fan-and-filter unit or outlet filter . . . . .	7		
4.3.1 Cutting out the enclosure . . . . .	7		
4.3.2 Fitting the fan-and-filter unit . . . . .	8		
4.4 Notes on electrical connection . . . . .	8		
4.4.1 Connection data . . . . .	8		
4.4.2 Overvoltage protection and supply line load . . . . .	9		
4.4.3 PE conductor connection . . . . .	9		

# 1 Notes on documentation

## 1 Notes on documentation

These assembly instructions are aimed at

- tradespersons who are familiar with assembly and installation of the fan-and-filter unit
- trained specialists who are familiar with operation of the fan-and-filter unit

### 1.1 Other applicable documents

Assembly and operating instructions exist as paper documents and/or on CD-ROM for the unit types described here and are enclosed with the equipment.

We cannot accept any liability for damage associated with failure to observe these instructions. Where applicable, the instructions for any accessories used also apply.

### 1.2 Retention of documents

These instructions and all associated documents constitute an integral part of the product. They must be given to the plant operator. The operator is responsible for storage of the documents so they are readily available when needed.

## 1.3 Symbols used

- The bullet point indicates an action to be performed.



**Danger!**  
Immediate danger to life and limb!



**Caution!**  
Potential threat to the product and its environment.



**Note:**  
Useful information and special features.

## 2 Safety notes

### 2 Safety notes

Please observe the following safety notes when assembling and operating the unit:

- Assembly, installation and servicing may only be performed by properly trained specialists
- Do not obstruct the air inlet and outlet of the fan-and-filter unit inside and outside the enclosure (see also section “4.2.2 Layout of the components in the enclosure”, page 7)
- The heat loss of the components installed in the enclosure must not exceed the specific air throughput of the fan-and-filter unit
- The louvres must always have their opening pointing downwards
- Use only original spare parts and accessories
- Do not make any changes to the fan-and-filter unit other than those described in these and other applicable instructions
- The fan-and-filter unit must only be connected to the mains with the system de-energised. Connect the pre-fuse specified on the rating plate
- Changes to the direction of airflow must only be carried out with the system de-energised
- Changes to the positioning of the mains connection must only be carried out with the system de-energised
- Never insert your fingers into the rotating fan blade
- Electrical connection and any repairs may only be carried out by authorised specialist personnel

### 3 Device description

Depending on the model chosen, your fan-and-filter unit may vary in appearance from the illustrations contained in these instructions. However, the functions are identical in principle.




Fig. 1: Device description

#### Key

- |   |  |
|---|--|
| 1 | Function logo<br>(to release the louvred grille) |
| 2 | Louvred grille                                   |
| 3 | Filter box with filter mat                       |
| 4 | Fan housing                                      |
| 5 | Variable electrical connection                   |

### 3.1 Functional description

The fan-and-filter unit in conjunction with the corresponding outlet filter(s) is used to dissipate heat loss from enclosures, ventilate the enclosure and protect temperature-sensitive components. This is achieved via the direct infeed of ambient air, the temperature of which must be less than the admissible enclosure interior temperature. The system is fitted into prepared cut-outs.

#### 3.1.1 Main components

The fan-and-filter unit is comprised of the following four main components: Fan motor, filter box, louvred grille with function logo and filter medium.

EN

# 3 Device description

## 3.1.2 Control

Rittal fan-and-filter units may be controlled more efficiently using a thermostat (Model No. 3110.000), digital temperature display (Model No. 3114.200), temperature-dependent speed control (Model No. 3120.200, 3235.440, 3235.450) and/or hygrostat (Model No. 3118.000).



### Note:

The control unit 3120.200 can only be used with single-phase AC units. The control units 3235.440 and 3235.450 can only be used with fan-and-filter units with integrated control interface (EC fan-and-filter units and fan-and-filter units with EMC shielding from an air throughput of 180 m<sup>3</sup>/h. Model No. 3240.500/600, 3241.500/600, 3243.500/600, 3244.500/600, 3245.500/600.

## 3.1.3 Safety equipment

The fan is equipped with thermal winding protection devices for protection against excess current and, in some cases, against overtemperature. For rotary current fans, the winding protection is located in the star earthing of the motor.

## 3.1.4 Filter mats

The fan-and-filter unit/outlet filter is supplied with a standard filter mat already installed. The filter must be checked regularly in accordance with the level of dust exposure and replaced as necessary.

In order to increase the protection category, and in the case of dust with a grain size of < 10 µm, we recommend the use of fine filter mats.



### Note:

The air throughput volume will be reduced.  
Special filter mats are required for EMC fan-and-filter units (see accessories).

## 3.2 Proper use

Rittal fan-and-filter units were developed and designed in accordance with the state of the art and the recognised rules governing technical safety. Nevertheless, if used improperly, they may pose a threat to life and limb or cause damage to property. The unit is only intended for ventilating enclosures and electronic cases. Any other use is deemed improper. The manufacturer will not be liable for any damages caused as a result of improper use, or for incorrect assembly, installation and use. All risk is borne solely by the user. Proper usage also includes the observation of all valid documents and compliance with the inspection and servicing conditions.

## 3.3 Scope of supply

The fan is supplied in a packaging unit in a fully assembled state and ready to connect.

Please check the scope of supply for completeness.

Qty.	Description
1	Fan-and-filter unit
4	– Mounting screws (not for 3237.1xx to 3239.1xx)
1	– Assembly, installation and operating instructions
1	Drilling template, self-adhesive
1	Standard or EMC filter mat

Tab. 1: Scope of supply

# 4 Assembly and connection

## 4 Assembly and connection

### 4.1 Choosing the installation site

When choosing the installation site for the enclosure, please observe the following:

- The site for the enclosure, and hence the arrangement of the fan-and-filter unit, must be carefully selected so as to ensure good ventilation
- The site must be free from excessive dirt and moisture
- Fan-and-filter units must always be installed on vertical panels (door or walls)
- The ambient temperature must be lower than the permissible enclosure interior temperature
- The mains connection data as stated on the rating plate of the unit must be guaranteed

### 4.2 Assembly instructions

#### 4.2.1 General

- Check the packaging carefully for signs of damage. Any packaging damage may be the cause of a subsequent functional failure
- The fan-and-filter and outlet filter must always be mounted on an enclosure in order to ensure air exchange



#### Note:

The outlet filter should be at least the same size as the fan-and-filter unit.

- The enclosure must be sealed on all sides (IP 54). If the enclosure has a leak, unfiltered, contaminated air may enter the enclosure, depending on the direction of airflow of the fan
- If two or more fan-and-filter units are arranged one above the other, a minimum spacing of 15 mm should be observed (between drilling templates). Only then is it guaranteed that the louvered grille can be opened without restriction.

#### 4.2.2 Layout of the components in the enclosure

Observe the air flows from the internal fans of installed electronic components. For installation, it is important to ensure that the airflows of fans and built-in electronic components do not have a negative influence on one another (air short-circuit). The corresponding minimum distances between the fan and component must be observed in order to ensure unhindered air circulation.

### 4.3 Fitting the fan-and-filter unit or outlet filter

The fan-and-filter unit or outlet filter is mounted on a vertical panel of the enclosure:

- For this purpose, the appropriate door, side or rear panel must be cut out using the supplied drilling template.

The fan-and-filter unit is generally fitted in the lower part of the enclosure, and the outlet filter in the upper part.

#### 4.3.1 Cutting out the enclosure

- Stick the self-adhesive drilling template supplied to the envisaged position on the door, side or rear panel of the enclosure.

Lines indicating the dimensions of cut-outs and drilling specifications for mounting and fixing of the fan (only necessary for sheet metal thickness 2.5 mm and above) are to be found on the drilling template. See also fig. 8 and fig. 9 on page 16.



#### Risk of injury!

**Carefully deburr all cut-outs to prevent injuries caused by sharp edges.**

- Make the cut-outs including the line width as per the drilling template. Deburr the cut-outs.

# 4 Assembly and connection

## 4.3.2 Fitting the fan-and-filter unit

- The fan may be fitted without tools, by simply snapping into the preconfigured mounting cut-out
- Make sure that the clips have snapped into place properly to guarantee secure mounting
- From a sheet metal thickness of 2 mm, the clips should be pressed in individually
- From a sheet metal thickness of 2.5 mm, the fan-and-filter unit must be screw-fastened in addition
- To drill the lower holes, it is necessary to remove the louvred grille as shown in fig. 2




Fig. 2: Release the louvred grille

- If transporting, it is necessary that you screw-fasten the fan to prevent it from falling out of the mounting cut-out.
- The fan-and-filter unit is a rotating component that may transfer vibrations and oscillations. Appropriate measures to decouple vibration must be taken in advance by the company responsible for the overall plant or system.

- The protection category can be increased by means of the following accessories:
  - IP 55 by using an additional fine filter mat or hose-proof hood
  - IP 56 by using a hose-proof hood



### Note:

To increase the protection category, an additional fine filter mat or hose-proof hood must be used in both the fan-and-filter unit and the outlet filter.

## 4.4 Notes on electrical connection

When performing the electrical connection, it is important to observe all valid national and regional regulations as well as the provisions of the responsible power supply company. Electrical connection must only be carried out by a qualified electrician who is responsible for compliance with the existing standards and regulations.

### 4.4.1 Connection data

- The voltage and frequency of the connection must correspond to the values stated on the rating plate
- Electrical connection and any repairs may only be carried out by authorised specialist personnel  
Use only original spare parts!
- For 1~ and 24 V (DC) fans, install the pre-fuse prescribed on the rating plate (circuit-breaker or slow fuse) to protect against short-circuiting
- With the rotary current variant, install the pre-fuse prescribed on the rating plate or a circuit-breaker/back-up protection to protect against short-circuiting, and set it to the prescribed rating value
- The direction of airflow and the direction of rotation are each marked on the motor housing with an arrow
- If a phase is missing, the fan will not start. If the rotary field is incorrect, the fan will run backwards

# Electrical connection

EN

## 4.4.2 Overvoltage protection and supply line load

The unit does not have its own overvoltage protection. Measures must be taken by the operator at the supply end to ensure effective lightning and overvoltage protection. The mains voltage must not exceed a tolerance of  $\pm 10\%$ .

## 4.4.3 PE conductor connection

The PE conductor connection must be connected to the PE conductor system of the overall system.

## 5 Carrying out the electrical connection

### 5.1 Connecting the power supply

- Complete the electrical connection by following the wiring plans.

#### Note:



For technical data, refer to the rating plate.

- Remove the red cover from the electrical connection.




Fig. 3: Access the electrical connection

- Insert the connection cable with wire end ferrules into the screwless spring terminals. Choose an appropriate pre-fuse according to the line cross-section ( $2 \times 0.75 - 2.5 \text{ mm}^2$  multi-wire,  $2 \times 1.5 - 2.5 \text{ mm}^2$  fine-wire soldered).



#### Caution!

If no wire end ferrules are used, the insulation of the individual wires should be stripped to a max. of 9 mm (to comply with clearance and creepage distances).

- Re-attach the electrical connection cover.



#### Note:

Fan-and-filter unit 3237.xxx is connected by way of two single wires which are led out of the unit.

### 5.2 Rotating the voltage connection

If the position of the voltage connection is not ideally accessible, it may be rotated through  $90^\circ$  and snapped into position. To this end, press down on the release button of the bayonet connection at the rear of the fan. Units 3238.xxx to 3239.xxx are released by pulling out the clip (see fig. 4) of the bayonet connection.




Fig. 4: Release the bayonet connection

Units 3240.xxx, 3241.xxx, 3243.xxx to 3245.xxx are released by pressing the release button of the bayonet connection (see fig. 5), located on the opposite corner from the connection terminal.

EN

# 6 Commissioning




Fig. 5: Release the bayonet connection

## 5.3 Changing the direction of airflow

The direction of airflow blows into the enclosure from the outside as standard. Should it become necessary to change the direction of airflow for technical reasons (space, specific component air routing etc.), this is easily achieved. Simply release the fan housing and rotate it through 180°. To release, please follow the same procedure as described under "5.2 Rotating the voltage connection", page 9.

Please also observe the instructions outlined under "4.2.1 General", page 7.

# 6 Commissioning

The fan-and-filter unit operates automatically, in other words, the fan will start up once the power has been switched on.

Depending on the model, the following voltage variants are supported:

- 24 V DC
- 115 V, 1~
- 230 V, 1~
- 400/460 V, 3-phase

## 7 Installing and changing the filter

The fan-and-filter unit and outlet filter are supplied as standard with a standard filter mat for the pre-filtering of dry, coarse dust and lint. In order to increase the protection category, and in the case of dust with a grain size of < 10 µm, we recommend the use of fine filter mats (optionally available). The filter should be checked at regular intervals in accordance with the level of dust exposure (recommended: at the latest after 2,000 operating hours) and replaced as necessary.



### Note:

Use only original Rittal filters which bear the Rittal logo in order to safeguard the designated protection category, air throughout and operating approvals.



### Risk of injury!

**Only change the filter mat while the fan rotor is stationary.**  
**Never insert your fingers into the fan rotor.**

To insert or replace the filter, proceed as follows (direction of airflow: drawing from outside and blowing into the enclosure):

- First press the catch of the louvred grill (Rittal logo) up slightly with one finger (see fig. 6)
- Once it is released, the louvred grille can be dropped open by approx. 70° or 90°
- If necessary, first place the fine filter mat into the housing
- Ensure that the open (roughened) side faces towards the louvred grille
- Then insert the enclosed standard filter mat
- Here again, ensure that the open side (without Rittal logo) faces towards the louvred grille (see fig. 7)
- Now push the louvred grille back onto the enclosure until it snaps audibly into position.

## 8 Inspection and maintenance




Fig. 6: Release the louvred grille




Fig. 7: Installing the standard filter mat



### Note:

If it becomes necessary to change the direction of the airflow (see 5.3 "Changing the direction of airflow", page 10), the installation is reversed accordingly.

## 8 Inspection and maintenance



**Risk of electric shock!**  
**The unit is live.**  
**Switch off the power supply before opening, and take suitable precautions against it being accidentally switched back on.**

The built-in, maintenance-free fan is mounted on a friction bearing (3237.xxx, 3238.xxx and 3239.xxx) or ball bearing (3240.xxx, 3241.xxx, 3243.xxx to 3245.xxx), and is protected against humidity and dust, and equipped with a temperature monitor.

The life expectancy is at least 40,000 operating hours (L10, 40°C). The fan-and-filter unit is thus largely maintenance free.

From time to time, the components may need to be cleaned using a vacuum cleaner or compressed air if they become visibly dirty.

Any stubborn, oily stains may be removed using a non-flammable detergent, such as degreaser.



**Caution!**  
**Risk of fire!**  
**Never use flammable liquids for cleaning.**

Sequence of maintenance measures:

- Check the level of dirt.
- Filter soiling?  
Replace the filter.
- Fan membranes soiled?  
Clean.
- Check the noise generation of the fan.
- Compressed air cleaning

## 9 Storage and disposal



**Caution!**  
**Risk of damage!**  
**The fan unit must not be stored at temperatures above +70°C or below -30°C.**

Disposal can be performed at the Rittal plant.

Please contact us for advice.

# 10 Technical specifications

EN

## 10 Technical specifications

- Observe the mains connection data (voltage and frequency) as per the rating plate
- Observe the pre-fuse as per the specifications on the rating plate

	Unit	Model No.							
<b>Fan-and-filter unit, RAL 7035</b>	–	<b>3237.100</b>	<b>3237.110</b>	<b>3237.124</b>	<b>3238.100</b>	<b>3238.110</b>	<b>3238.124</b>		
<b>EMC fan-and-filter unit, RAL 7035</b>	–	<b>3237.600</b>	–	–	<b>3238.600</b>	–	–		
Rated operating voltage	V Hz	230, 1~, 50/60	115, 1~, 50/60	24 (DC)	230, 1~, 50/60	115, 1~, 50/60	24 (DC)		
Rated current max.	A	0.065/0.052	0.12/0.1	0.125	0.12/0.11	0.24/0.22	0.24		
Power consumption	W	11/9		3	19/18		5.5		
Pre-fuse T	A	2							
Dimensions									
Width (B1) x height (H1)	mm	116.5 x 116.5			148.5 x 148.5				
Required mounting cut-out (B2 x H2)	mm	92 x 92			124 x 124				
Depth (T1)	mm	16							
Max. installation depth (T2)	mm	43			58.5				
Air throughput, unimpeded airflow	m <sup>3</sup> /h	20/25		20	55/66	55			
Air throughput with outlet filter including standard filter mat	m <sup>3</sup> /h	1 x 3237.200: 15/18			1 x 3238.200: 43/50				
		–			2 x 3238.200: 46/56				
<b>Outlet filter</b>	–	<b>3237.200</b>			<b>3238.200</b>				
<b>EMC outlet filter</b>	–	<b>3237.060</b>			<b>3238.060</b>				
Fan	–	Axial, self-starting shaded pole motor	Axial, DC motor	Axial, self-starting shaded pole motor	Axial, DC motor				
Noise pressure level	dB (A)	38/43	38	46/49	46				
Operating temperature	°C	-15...+55							
Storage temperature	°C	-30...+70							
Protection category (to IEC 60 529)	–	IP 54 standard IP 55 with hose-proof hood IP 56 with hose-proof hood			IP 54 standard IP 54 with additional fine filter mat IP 56 with hose-proof hood				

Tab. 2: Technical specifications

Technical modifications reserved.

# 10 Technical specifications

EN

	Unit	Model No.		
<b>Fan-and-filter unit, RAL 7035</b>	–	<b>3239.100</b>	<b>3239.110</b>	<b>3239.124</b>
<b>EMC fan-and-filter unit, RAL 7035</b>	–	<b>3239.600</b>	–	–
Rated operating voltage	V Hz	230, 1~, 50/60	115, 1~, 50/60	24 (DC)
Rated current max.	A	0.12/0.11	0.24/0.22	0.23
Power consumption	W	19/18		5.5
Pre-fuse T	A	2		
Dimensions				
Width (B1) x height (H1)	mm	204 x 204		
Required mounting cut-out (B2 x H2)	mm	177 x 177		
Depth (T1)	mm	24		
Max. installation depth (T2)	mm	90		
Air throughput, unimpeded airflow	m <sup>3</sup> /h	105/120		105
Air throughput with outlet filter including standard filter mat	m <sup>3</sup> /h	1 x 3239.200: 87/100 2 x 3239.200: 93/108 1 x 3240.200: 98/111		
<b>Outlet filter</b>	–	<b>3239.200</b>		
<b>EMC outlet filter</b>	–	<b>3239.060</b>		
Fan		Axial, self-starting shaded pole motor		Axial, DC motor
Noise pressure level	dB (A)	46/49		46
Operating temperature	°C	-15....+55		
Storage temperature	°C	-30....+70		
Protection category (to IEC 60 529)	–	IP 54 standard IP 55 with additional fine filter mat or hose-proof hood IP 56 with hose-proof hood		

Tab. 3: Technical specifications

Technical modifications reserved.

# 10 Technical specifications

EN

	Unit	Model No.								
<b>Fan-and-filter unit, RAL 7035</b>	–	<b>3240.100</b>	<b>3240.110</b>	<b>3240.124</b>	<b>3241.100</b>	<b>3241.110</b>	<b>3241.124</b>			
<b>EMC fan-and-filter unit, RAL 7035</b>	–	<b>3240.600</b>	–	–	<b>3241.600</b>	–	–			
Rated operating voltage	V Hz	230, 1~, 50/60	115, 1~, 50/60	24 (DC)	230, 1~, 50/60	115, 1~, 50/60	24 (DC)			
Rated current max.	A	0.21/0.19	0.42/0.38	0.43	0.26/0.24	0.52/0.48	0.8			
Power consumption	W	35/34		10	40/42	40/42	19			
Pre-fuse T	A	2	4	2	4		2			
Dimensions										
Width (B1) x height (H1)	mm	255 x 255								
Required mounting cut-out (B2 x H2)	mm	224 x 224								
Depth (T1)	mm	25								
Max. installation depth (T2)	mm	107								
Air throughput, unimpeded airflow	m <sup>3</sup> /h	180/160		180	230/250	230				
Air throughput with outlet filter including standard filter mat	m <sup>3</sup> /h	1 x 3240.200: 138/121			1 x 3240.200: 183/205					
		2 x 3240.200: 165/140			2 x 3240.200: 203/230					
		1 x 3243.200: 165/140			1 x 3243.200: 203/230					
<b>Outlet filter</b>	–	<b>3240.200</b>								
<b>EMC outlet filter</b>	–	<b>3240.060</b>								
Fan	–	Diagonal, self-starting shaded pole motor		Diagonal, DC motor	Diagonal, self-starting shaded pole motor	Diagonal, DC motor				
Noise pressure level	dB (A)	51/46		51	54/56	54				
Operating temperature	°C	-30...+55								
Storage temperature	°C	-30...+70								
Protection category (to IEC 60 529)	–	IP 54 standard IP 55 with additional fine filter mat or hose-proof hood IP 56 with hose-proof hood								

Tab. 4: Technical specifications

Technical modifications reserved.

# 10 Technical specifications

**EN**

	<b>Unit</b>	<b>Model No.</b>							
<b>Fan-and-filter unit, RAL 7035</b>	–	3243.100	3243.110	3244.100	3244.110	3244.140	3245.500	3245.510	
<b>EMC fan-and-filter unit, RAL 7035</b>	–	3243.600	–	3244.600	–	–	3245.600	–	
Rated operating voltage	V Hz	230, 1~, 50/60	115, 1~, 50/60	230, 1~, 50/60	115, 1~, 50/60	400/460, 3~, 50/60	200...240, 1~, 50/60	100...130, 1~, 50/60	
Rated current max.	A	0.37/ 0.39	0.78/0.8	0.43/0.6	0.9/1.25	0.17/0.21	1.33	2.1	
Power consumption	W	70/87	75/90	95/135	100/145	93/140	165	165	
Pre-fuse T	A	4	6	4	6	Motor circuit-breaker	4	6	

## Dimensions

Width (B1) x height (H1)	mm	323 x 323								
Required mounting cut-out (B2 x H2)	mm	292 x 292								
Depth (T1)	mm	25								
Max. installation depth (T2)	mm	118.5		130.5		130.5				
Air throughput, unimpeded airflow	m <sup>3</sup> /h	550/600		700/770		900				
Air throughput with outlet filter including standard filter mat	m <sup>3</sup> /h	1 x 3243.200: 465/510	1 x 3243.200: 544/587		1 x 3243.200: 680					
		2 x 3243.200: 508/548	2 x 3243.200: 630/690		2 x 3243.200: 820					
<b>Outlet filter</b>	–	<b>3243.200</b>								
<b>EMC outlet filter</b>	–	<b>3243.060</b>								
Fan	–	Diagonal, capacitor motor			Diagonal, rotary current motor	Diagonal, EC motor				
Noise pressure level	dB (A)	59/61	65/66		67/70	72				
Operating temperature	°C	-30...+55								
Storage temperature	°C	-30...+70								
Protection category (to IEC 60 529)	–	IP 54 standard IP 55 with additional fine filter mat or hose-proof hood IP 56 with hose-proof hood			IP 51 standard IP 52 with additional fine filter mat IP 56 with hose-proof hood					

Tab. 5: *Technical specifications*

Technical modifications reserved.

# 11 Cut-out/drilling dimensions

EN

## 11 Cut-out/drilling dimensions




Fig. 8: Cut-out dimensions

B = Width, T = Depth



### Note:

From a certain wall thickness, a slightly larger cut-out is required (see the enclosed drilling template).

Model No.	B2 x H2 mm	T2 mm
<b>3237.xxx</b>	92 x 92	43
<b>3238.xxx</b>	124 x 124	58.5
<b>3239.xxx</b>	177 x 177	90
<b>3240.xxx</b>	224 x 224	107
<b>3241.xxx</b>	224 x 224	107
<b>3243.xxx</b>	292 x 292	118.5
<b>3244.xxx</b>	292 x 292	130.5
<b>3245.xxx</b>	292 x 292	130.5

Tab. 6: Cut-out dimensions









Fig. 9: Drilling pattern

Model No.	$\emptyset$ mm	F mm
<b>3237.xxx</b>	3.5	100.5
<b>3238.xxx</b>	3.5	132.5
<b>3239.xxx</b>	4.5	185
<b>3240.xxx</b>	4.5	234
<b>3241.xxx</b>	4.5	234
<b>3243.xxx</b>	4.5	302
<b>3244.xxx</b>	4.5	302
<b>3245.xxx</b>	4.5	302

Tab. 7: Drilling dimensions



# 12 EMC fan/outlet filter

## 12 EMC fan/outlet filter

EN

To achieve EMC protection, the EMC fans and EMC outlet filters should be snapped into the mounting cut-out and screw-fastened using the screws supplied. Next, the four contact foils should be stuck on all-round between the fan-and-filter unit and the inside of the enclosure as shown in the following illustration.




Fig. 10: EMC contact foils




**Note:**

EMC protection can only be guaranteed when using original Rittal EMC filter media (Model Nos. 3237.066, 3238.066, 3239.066, 3240.066, 3243.066).


# 13 Connection diagrams

EN


## 13 Connection diagrams




3237.100/.110/.600  
3238.100/.110/.600  
3239.100/.110/.600




3243.100/.110/.600  
3244.100/.110/.600




3245.500/.510/.600  
Details,  
see page 19



3240.100/.110/.600  
3241.100/.110/.600



3244.140



3237.124  
3238.124  
3239.124  
3240.124  
3241.124

Fig. 11: Connection diagrams

# 13 Connection diagrams

EN


**For SK 3245 only!**

Fig. 12: Connection diagram 3245

- 1** Max. speed (as delivered)
- 2** Adjustable speed
- 3** Adjustable speed via PWM 1 – 10 kHz
- 4** Adjustable speed via potentiometer

No.	Connection	Function/Assignment
CON10	L	Power supply 200...240 V AC, 50...60 Hz
CON11	N	Neutral conductor
CON12	PE	PE conductor
1	GND	GND connection of the control interface
2	0...10 V/PWM	Control input 0...10 V or PWM, galvanically isolated, impedance 100 kΩ
3	+10 V	Voltage output 10 V max. 1.1 mA, galvanically isolated, not short circuit-protected
4	Speed	Speed output Open Collector, 1 pulse per revolution, galvanically isolated

Tab. 8: Explanations to fig. 12

# 14 EC declaration of conformity

EN

## 14 EC declaration of conformity

EG-Konformitätserklärung  
Maschinenrichtlinie 2006/42/EG Anhang II A  
*EC Declaration of Conformity*  
*Machinery Directive 2006/42/EC Annex II A*

Reg.-Nr.: 3 527 009 – 3



Hiermit erklären wir, (We)

Rittal GmbH & Co. KG, Auf dem Stützelberg, D-35745 Herborn

dass die Filter-Lüfter: (*that the Filter Fans:*)

SK 3237.xxx<sup>1)</sup> SK 3238.xxx<sup>1)</sup> SK 3239.xxx<sup>1)</sup>  
SK 3240.xxx SK 3241.xxx SK 3243.xxx SK 3244.xxx SK 3245.xxx

"xxx" steht für (*applies to*):

100, 109, 110, 124<sup>1)</sup>, 140, 500, 510, 600, 609, 610

E-Schaltplan, Zusammenbauzeichnung und Beschreibung siehe Montageanleitung  
(*Wiring diagram, assembly drawing and specification, see assembly instructions!*)

folgender Richtlinie entspricht: (*conforms to the following Directives*)

**Maschinenrichtlinie 2006/42/EG (Machinery Directive 2006/42/EC)<sup>2)</sup>**

Zusätzlich entsprechen die oben genannten Produkte auch folgenden Richtlinien:  
(*In addition, the above mentioned products also conform to the following Directives*)

**Elektromagnetische Verträglichkeit 2004/108/EG (Electromagnetic compatibility 2004/108/EC)**

Angewandte harmonisierte Normen: (*Applied harmonised standards*)

EN ISO 12100	Sicherheit von Maschinen ( <i>Safety of machinery</i> )
EN ISO 13857,	Sicherheitsabstände gegen das Erreichen von Gefährzungsbereichen mit den oberen und unteren Gliedmaßen ( <i>Safety distances to prevent hazard zones being reached by upper and lower limbs</i> )
EN 60335-1	Sicherheit elektrischer Geräte für den Haushalt und ähnliche Zwecke - Teil 1: Allgemeine Anforderungen ( <i>Household and similar electrical appliances - Safety - Part 1: General requirements</i> )
EN 60950-1 <sup>A)</sup>	Einrichtungen der Informationstechnik - Sicherheit - Teil 1: Allgemeine Anforderungen ( <i>Information technology equipment - Safety - Part 1: General requirements</i> )
EN 61000-6-2	Elektromagnetische Verträglichkeit (EMV) - Teil 6-2: Fachgrundnormen - Störfestigkeit für Industriebereiche ( <i>Electromagnetic compatibility (EMC) - Part 6-2: Generic standards - Immunity for industrial environments</i> )
EN 61000-6-3	Elektromagnetische Verträglichkeit (EMV) - Teil 6-3: Fachgrundnormen - Störaussendung für Wohnbereich, Geschäfts- und Gewerbebereiche sowie Kleinbetriebe ( <i>Electromagnetic compatibility (EMC) - Part 6-3: Generic standards - Emission standard for residential, commercial and light-industrial environments</i> )

Bei einer nicht mit uns abgestimmten Änderung der Maschine verliert diese EG-Konformitätserklärung ihre Gültigkeit.

*This declaration of EC conformity shall become null and void when the assembly is subjected to any modification that has not met with our approval.*

Verantwortlich für Dokumentation  
(*Responsible for documentation*)

Herborn, 31.7.2012

  
Frank Himmelhuber, Bereichsleiter FuE  
Senior Vice President R&D

Rittal GmbH & Co. KG  
Auf dem Stützelberg  
D-35745 Herborn

<sup>1)</sup> 24 VDC Version; nicht nach NpRL 2006/95/EG (does not conform to LVD 2006/95/EC)

<sup>2)</sup> Die Konformitätsbewertung nach der Maschinenrichtlinie schließt gemäß Anhang I, Nummer 1.5.1 die Schutzziele der Niederspannungsrichtlinie ein.  
*The conformity assessment according to Annex I, 1.5.1 of the Machinery Directive includes the safety objectives of the Low Voltage Directive.*

# Rittal - The System.

Faster – better – everywhere.

- Enclosures
- Power Distribution
- Climate Control
- IT Infrastructure
- Software & Services

RITTAL GmbH & Co. KG  
Postfach 1662 • D-35726 Herborn  
Phone +49(0)2772 505-0 • Fax +49(0)2772 505-2319  
E-mail: info@rittal.de • www.rittal.com



FRIEDHELM LÖH GROUP

# Rittal – The System.

Faster – better – everywhere.

## ► TopTherm fan-and-filter units – SK 3238.100

Date : Mar 24, 2021

ENCLOSURES

POWER DISTRIBUTION

CLIMATE CONTROL

IT INFRASTRUCTURE

SOFTWARE & SERVICES

FRIEDHELM LOH GROUP



# TopTherm fan-and-filter units – SK 3238.100

created: 24.03.2021 on www.ittal.com/com-en



## Product description

<b>Protection category IP to IEC 60 529:</b>	IP 54 with standard filter and additional fine filter mat: IP 54 with standard filter and hose-proof hood: IP 56
<b>Protection category NEMA:</b>	Type 12 with standard filter and additional fine filter mat: Type 12 with standard filter and hose-proof hood: Type 3, 3R, 4, 4X
<b>Supply includes:</b>	Complete unit ready to install, including filter mat
<b>Note:</b>	With the fan-and-filter unit 3237.XXX, electrical connection is made via two single wires on the unit. For all other fan-and-filter units, a screwless spring terminal is used.

## Product description

<b>Air throughput (unimpeded air flow):</b>	At 50 Hz: 55 m <sup>3</sup> /h At 60 Hz: 66 m <sup>3</sup> /h
<b>Air throughput with outlet filter including standard filter mat (quantity x order number, output 50/60 Hz):</b>	1 x 3238200: 43/50 m <sup>3</sup> /h 2 x 3238200: 46/56 m <sup>3</sup> /h
<b>Rated operating voltage:</b>	230 V, 1~, 50 Hz/60 Hz
<b>Dimensions:</b>	Width: 148.5 mm Height: 148.5 mm
<b>Required mounting cut-out:</b>	Width: 124 mm Height: 124 mm

<b>Build depth:</b>	16 mm
<b>Installation depth:</b>	58.5 mm
<b>Temperature range:</b>	Bearing: -30 °C...+70 °C Operation (environment): -15 °C...+55 °C
<b>Power consumption P<sub>el</sub>:</b>	At 50 Hz: 19 W At 60 Hz: 18 W
<b>Rated current max.:</b>	At 50 Hz: 0.12 A At 60 Hz: 0.11 A
<b>Miniature circuit- breaker/fuse:</b>	2 A
<b>Service life at 50 Hz:</b>	68200 h
<b>Service life at 60 Hz:</b>	68200 h
<b>Noise level:</b>	At 50 Hz: 46 dB(A) At 60 Hz: 49 dB(A)
<b>Colour:</b>	RAL 7035
<b>Fan:</b>	Axial, shaded pole motor
<b>eCl@ss 8.0/8.1:</b>	27180716
<b>Packs of:</b>	1 pc(s).
<b>Weight/pack:</b>	0.8 kg
<b>EAN:</b>	4028177651692
<b>Customs tariff number:</b>	84145915
<b>ETIM 7.0:</b>	EC000320
<b>ETIM 6.0:</b>	EC000320
<b>eCl@ss 8.0/8.1:</b>	27180716
<b>eCl@ss 6.0/6.1:</b>	27180716
<b>Product description:</b>	SK fan and filter units TopTherm, 55/66 m <sup>3</sup> /h, 230 V, 1~, 50/60 Hz, WHD: 148.5 x 148.5 x 16 mm

## Approvals

**Approvals:** Approval overview  
CCC exception letter  
CSA  
UL + C-UL - FTTA  
UR + C-UR

---

**Certificates:** EAC

---

**Declarations:** Declaration of conformity

---




# 11938MB (4715MS)

119<sup>□</sup> x 38<sup>L</sup>

## AC Axial Fan




### Outline



\* Only flange type casing is available.

### Characteristic Curves



### Material

Casing	: Aluminum (Black)
Impeller	: Plastic (Black)
Bearing	UL94V-0 : Ball Bearing
Terminal	: Faston #110 or Equiv

Lead Wire type is also available.  
Lead Wire : UL3266, AWG22

### Specifications

Model	Product No.	Rating Voltage	Frequency	Starting Voltage	Current	Input Power	Speed	Max. Air Flow		Max. Static Pressure	Noise	Mass (g)	
		(V)	(Hz)	(V)	(A) <sup>*2</sup>	(W) <sup>+10%/-20%</sup>	(min <sup>-1</sup> ) <sup>*3</sup>	(m <sup>3</sup> /min) <sup>*3</sup>	(CFM) <sup>*3</sup>	(Pa) <sup>*3</sup>	(In H <sub>2</sub> O) <sup>*3</sup>		
11938MB-A0N-EA-	00	100		50	65	0.270	15.0	2600	2.50	89.3	64.7	0.26	37.0
				60		0.230	14.0	2900	2.90	103.6	76.4	0.31	41.0
11938MB-A1N-EA-	00	115		50	65	0.250	15.5	2600	2.50	89.3	64.7	0.26	37.0
				60		0.210	14.5	2900	2.90	103.6	76.4	0.31	41.0
11938MB-B0N-EA-	00	200		50	130	0.140	15.0	2600	2.50	89.3	64.7	0.26	37.0
				60		0.120	13.0	2900	2.90	103.6	76.5	0.31	41.0
11938MB-B2N-EA-	00	220		50	145	0.120	14.0	2600	2.50	89.3	63.8	0.26	37.0
				60		0.100	13.0	2900	2.90	103.6	75.6	0.30	41.0
11938MB-B3N-EA-	00	230		50	175	0.120	15.0	2600	2.50	89.3	63.8	0.26	37.0
				60		0.100	14.0	2900	2.90	103.6	70.7	0.28	41.0
11938MB-B4N-EA-	00	240		50	140	0.110	14.0	2600	2.50	89.3	63.8	0.26	37.0
				60		0.100	13.0	2900	2.90	103.6	65.7	0.26	41.0

Rotation: Counterclockwise as seen from the label side

Airflow Outlet: Label side

\*1: Average Values in Free Air

\*2: Maximum Values in Free Air

\*3: Minimum Values in Free Air

# 11938MB (Special Edition)


119<sup>□</sup> x 38<sup>L</sup>

## AC Axial Fan



Reference Spec

### Outline




в Беларусь Заказ г.Минск +375447584780 Viber telegram whatsapp Skype email 2005646@tut.by

\* Only flange type casing is available.

\* The structure tubing can be seen from name plate side.

### Characteristic Curves



### General Specifications


Motor Structure	Shaded Pole Induction Motor
Motor Protection	Impedance Protection
Insulation Resistance	Min 100MΩ by DC 500V Megger
Dielectric Withstand Voltage	: AC1800V 3s
Allowable Ambient	: - 10°C ~ + 70°C (Operating)
Temperature Range	- 40°C ~ + 70°C (Storage) non-condensing environment

### Expected Life ※ Failure Rate: 10% (L10 Life)

25°C 100,000 (Hours)

### Panel Out-cuts

(Inlet Side) / (Outlet Side)



### Material

Casing	: Aluminum (No Paint)
Impeller	: Plastic (Black) UL94V-0
Bearing	: Ball Bearing
Terminal	: Faston#110 or Equiv

Lead Wire type is also available.

Lead Wire : UL3266, AWG22

AC FAN

### Specifications

Model	Product No.	Rating Voltage	Frequency	Starting Voltage	Current	Input Power	Speed	Max. Air Flow		Max. Static Pressure	Noise	Mass (g)
		(V)	(Hz)	(V)	(A)* <sup>2</sup>	(W)* <sup>10%~20%</sup>	(min')* <sup>3</sup>	(m³/min)* <sup>3</sup>	(CFM)* <sup>3</sup>	(Pa)* <sup>3</sup>	(In H <sub>2</sub> O)* <sup>3</sup>	
11938MB-A0N-EA-	L0	100	50	65	0.270	15.0	2600	2.50	89.3	64.7	0.26	37.0
					0.230	14.0	2900	2.90	103.6	76.4	0.31	41.0
11938MB-A1N-EA-	L0	115	50	65	0.250	15.5	2600	2.50	89.3	64.7	0.26	37.0
					0.210	14.5	2900	2.90	103.6	76.4	0.31	41.0
11938MB-B0N-EA-	L0	200	50	130	0.140	15.0	2600	2.50	89.3	64.7	0.26	37.0
					0.120	13.0	2900	2.90	103.6	76.5	0.31	41.0
11938MB-B2N-EA-	L0	220	50	145	0.120	14.0	2600	2.50	89.3	63.8	0.26	37.0
					0.100	13.0	2900	2.90	103.6	75.6	0.30	41.0
11938MB-B3N-EA-	L0	230	50	175	0.120	15.0	2600	2.50	89.3	63.8	0.26	37.0
					0.100	14.0	2900	2.90	103.6	70.7	0.28	41.0
11938MB-B4N-EA-	L0	240	50	140	0.110	14.0	2600	2.50	89.3	63.8	0.26	37.0
					0.100	13.0	2900	2.90	103.6	65.7	0.26	41.0

Rotation: Counterclockwise as seen from the label side

Airflow Outlet: Label side

This information is reference spec, so final spec may change.

\*1: Average Values in Free Air

\*2: Maximum Values in Free Air

\*3: Minimum Values in Free Air

rittal-3139100, rittal: вентилятор: dc; крышный; 220?240vdc; 525м3/ч; 54дба; ip21,ip55  
rittal-3139110, rittal: вентилятор: ac; крышный; 115vas; 500м3/ч; 54дба; ip21,ip55  
rittal-3140100, rittal: вентилятор: ac; крышный; 220/240vas; 873м3/ч; 60дба; ip21,ip55  
rittal-3140110, rittal: вентилятор: ac; крышный; 115vas; 873м3/ч; 60дба; ip21,ip55  
rittal-3140140, rittal: вентилятор: ac; крышный; 400/480vas; 863м3/ч; 58дба; ip21,ip55  
rittal-3140500, rittal: вентилятор: ec; крышный; 220/240vas; 1069м3/ч; 60дба; ip21,ip55  
rittal-3140510, rittal: вентилятор: ec; крышный; 115vas; 1069м3/ч; 63дба; ip21,ip55  
rittal-3171100, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 17мм; 5шт.  
rittal-3171105, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 17мм; 50шт.  
rittal-3172100, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 17мм; 5шт.  
rittal-3172105, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 17мм; 50шт.  
rittal-3173100, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 17мм; 5шт.  
rittal-3173105, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 17мм; 50шт.  
rittal-3174100, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 17мм; 12шт.  
rittal-3181100, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 12мм; 5шт.  
rittal-3182100, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 12мм; 5шт.  
rittal-3183100, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 12мм; 5шт.  
rittal-3237060, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 16мм; 1шт.  
rittal-3237066, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 10мм; 5шт.  
rittal-3237080, rittal: решетка; мат-л: силикон,нержавеющая сталь  
rittal-3237100, rittal: вентилятор: ac; вентиляторная панель; 230vas; 25м3/ч; 43дба; ip54  
rittal-3237110, rittal: вентилятор: ac; вентиляторная панель; 115vas; 25м3/ч; 43дба; ip54  
rittal-3237124, rittal: вентилятор: dc; вентиляторная панель; 24vdc; 20м3/ч; 38дба; ip54  
rittal-3237200, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 16мм; 1шт.  
rittal-3237600, rittal: вентилятор: ac; вентиляторная панель; 230vas; 25м3/ч; 43дба; ip54  
rittal-3238055, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 12мм; 5шт.  
rittal-3238060, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 24мм; 1шт.  
rittal-3238066, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 12мм; 5шт.  
rittal-3238080, rittal: решетка; мат-л: силикон,нержавеющая сталь

rittal-3238100, rittal: вентилятор: ac; вентиляторная панель; 230вас; 66м3/ч; 49дба; ip54  
rittal-3238110, rittal: вентилятор: ac; вентиляторная панель; 115вас; 66м3/ч; 49дба; ip54  
rittal-3238124, rittal: вентилятор: dc; вентиляторная панель; 24bdc; 55м3/ч; 46дба; ip54  
rittal-3238200, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 24мм; 1шт.  
rittal-3238500, rittal: вентилятор: ec; 200/240vas; 55м3/ч; 49дба; ip54,ip56; цвет: белый  
rittal-3238600, rittal: вентилятор: ac; вентиляторная панель; 230vas; 66м3/ч; 49дба; ip54  
rittal-3239060, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 24мм; 1шт.  
rittal-3239066, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 17мм; 5шт.  
rittal-3239080, rittal: решетка; мат-л: силикон,нержавеющая сталь  
rittal-3239100, rittal: вентилятор: ac; вентиляторная панель; 230vas; 120м3/ч; 49дба; ip54  
rittal-3239110, rittal: вентилятор: ac; вентиляторная панель; 115vas; 120м3/ч; 49дба; ip54  
rittal-3239124, rittal: вентилятор: dc; вентиляторная панель; 24bdc; 105м3/ч; 46дба; ip54  
rittal-3239200, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 24мм; 1шт.  
rittal-3239500, rittal: вентилятор: ec; 200/240vas; 105м3/ч; 53дба; ip54,ip55,ip56  
rittal-3239600, rittal: вентилятор: ac; вентиляторная панель; 230vas; 120м3/ч; 49дба; ip54  
rittal-3240060, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 25мм; 1шт.  
rittal-3240066, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 17мм; 5шт.  
rittal-3240080, rittal: решетка; мат-л: силикон,нержавеющая сталь  
rittal-3240100, rittal: вентилятор: ac; вентиляторная панель; 230vas; 160м3/ч; 46дба; ip54  
rittal-3240110, rittal: вентилятор: ac; вентиляторная панель; 115vas; 160м3/ч; 46дба; ip54  
rittal-3240124, rittal: вентилятор: dc; вентиляторная панель; 24bdc; 180м3/ч; 51дба; ip54  
rittal-3240200, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 25мм; 1шт.  
rittal-3240500, rittal: вентилятор: ec; 200/240vas; 180м3/ч; 47дба; ip54,ip55,ip56  
rittal-3240600, rittal: вентилятор: ac; вентиляторная панель; 230vas; 160м3/ч; 46дба; ip54  
rittal-3241100, rittal: вентилятор: ac; вентиляторная панель; 230vas; 250м3/ч; 56дба; ip54  
rittal-3241110, rittal: вентилятор: ac; вентиляторная панель; 115vas; 250м3/ч; 56дба; ip54  
rittal-3241124, rittal: вентилятор: dc; вентиляторная панель; 24bdc; 230м3/ч; 54дба; ip54  
rittal-3241500, rittal: вентилятор: ec; 200/240vas; 230м3/ч; 52дба; ip54,ip55,ip56  
rittal-3241600, rittal: вентилятор: ac; вентиляторная панель; 230vas; 250м3/ч; 56дба; ip54

rittal-3243060, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 25мм; 1шт.

rittal-3243066, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 17мм; 5шт.

rittal-3243080, rittal: решетка; мат-л: силикон,нержавеющая сталь

rittal-3243100, rittal: вентилятор: ac; вентиляторная панель; 230вас; 600м3/ч; 61дба; ip54

rittal-3243110, rittal: вентилятор: ac; вентиляторная панель; 115вас; 600м3/ч; 61дба; ip54

rittal-3243200, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 25мм; 1шт.

rittal-3243500, rittal: вентилятор: ec; 200/240vas; 550м3/ч; 63дба; ip54,ip55,ip56

rittal-3243600, rittal: вентилятор: ac; вентиляторная панель; 230vas; 600м3/ч; 61дба; ip54

rittal-3244100, rittal: вентилятор: ac; вентиляторная панель; 230vas; 770м3/ч; 66дба; ip54

rittal-3244110, rittal: вентилятор: ac; вентиляторная панель; 115vas; 770м3/ч; 66дба; ip54

rittal-3244140, rittal: вентилятор: dc; вентиляторная панель; 460bdc; 770м3/ч; 70дба; ip54

rittal-3244500, rittal: вентилятор: ec; 200/240vas; 700м3/ч; 64дба; ip54,ip55,ip56

rittal-3244600, rittal: вентилятор: ac; вентиляторная панель; 230vas; 770м3/ч; 66дба; ip54

rittal-3245080, rittal: решетка; мат-л: силикон,нержавеющая сталь

rittal-3245500, rittal: вентилятор: ac; вентиляторная панель; 200/240vas; 900м3/ч; 72дба

rittal-3245510, rittal: вентилятор: ac; вентиляторная панель; 100/130vas; 900м3/ч; 72дба

rittal-3245600, rittal: вентилятор: ac; вентиляторная панель; 200/240vas; 900м3/ч; 72дба

rittal-3321700, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 10мм; 5шт.

rittal-3321705, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 10мм; 50шт.

rittal-3322700, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 12мм; 5шт.

rittal-3322705, rittal: аксессуары для вент: фильтр; вентиляторы; thk: 12мм; 50шт.

3sx5210-2a spare parts pack for position switch 3se5282 fa. rittal

dk7077.000 (rittal)

dk7078.000 (rittal)

dk7097.000 (rittal)

dk7097.220 (rittal)

dk7097.260 (rittal)

ps4170.000 (rittal)

ps4171.000 (rittal)

ps4179.000 (rittal)

ps4583.000 (rittal)

ps4943.000 (rittal )

ps4944.000 (rittal )

rtc термоэлектрический охладитель rittal

sk быстросъемная рама rittal top therm

sk nori diag ii для rittal toptherm 1шт

sk потолочный агрегат rittal toptevrm plus 1000 вт

so2819.000 (rittal )

sv rittal power engineering

sz2334.000 (rittal )

sz2335.000 (rittal )

sz2353.000 (rittal)

sz2356.000 (rittal)

sz2358.000 (rittal)

sz2564.000 (rittal )

sz2567.000 (rittal )

sz2570.000 (rittal)

ts4164.000 (rittal)

1002.600 /rittal/

1002600 /rittal/

1004.600 /rittal/

1030500 /rittal/

1031.000 /rittal/

1031500 /rittal/

1033500 /rittal/

1034500 /rittal/

1035500 /rittal/

1037.500 /rittal/

1038500 /rittal/

1039500 /rittal/

1045.000 /rittal/

1045500 /rittal/

1050.000 /rittal/

1050500 /rittal/

1060500 /rittal/

1077.500 /rittal/

1158500 /rittal/

1180.000 /rittal/

1302.600 /rittal/

1339.500 /rittal/

1350500 /rittal/

1360500 /rittal/

1380500 /rittal/

1423.500 /rittal/

1434.000 /rittal/

1444.000 /rittal/

1446.000 /rittal/

1446500 /rittal/

1484001 /rittal/

1500.510 /rittal/

1500510 /rittal/

1501510 /rittal/

1502510 /rittal/

1503510 /rittal/

1504.510 /rittal/

1505.000 /rittal/

1508510 /rittal/

1509.000 /rittal/

1511510 /rittal/

1514510 /rittal/

1516510 /rittal/

1517510 /rittal/

1521.010 /rittal/

1522.010 /rittal/

1523.010 /rittal/

1524.010 /rittal/

1525.010 /rittal/

1526.010 /rittal/

1527.010 /rittal/

1528.010 /rittal/

1529.010 /rittal/

1530.010 /rittal/

1530.510 /rittal/

1531.000 /rittal/

1536.510 /rittal/

1538.510 /rittal/

1541.510 /rittal/

1542.510 /rittal/

1545.000 /rittal/

1546.000 /rittal/

1547.000 /rittal/

1547.500 /rittal/

1548500 /rittal/

1549500 /rittal/

1550.000 /rittal/

1551.000 /rittal/

1551500 /rittal/

1552.000 /rittal/

1553.000 /rittal/

1554500 /rittal/

1555.000 /rittal/

1555500 /rittal/

1556.000 /rittal/

1558510 /rittal/

1560700 /rittal/

1561700 /rittal/

1562700 /rittal/

1563700 /rittal/

1564700 /rittal/

1565700 /rittal/

1566700 /rittal/

1567700 /rittal/

1568700 /rittal/

1569700 /rittal/

1570.700 /rittal/

1570700 /rittal/

1571700 /rittal/

1572700 /rittal/

1573700 /rittal/

1574.000 /rittal/

1574700 /rittal/

1575.000 /rittal/

1575700 /rittal/

1576700 /rittal/

1577.000 /rittal/

1577500 /rittal/

1578.450 /rittal/

1578.530 /rittal/

1579.450 /rittal/

1579500 /rittal/

1580000 /rittal/

1590000 /rittal/

1591000 /rittal/

1592000 /rittal/

1592200 /rittal/

1752500 /rittal/

1755500 /rittal/

2304000 /rittal/

2309000 /rittal/

2314000 /rittal/

2315000 /rittal/

2316000 /rittal/

2317000 /rittal/

2318000 /rittal/

2319000 /rittal/

2325000 /rittal/

2326000 /rittal/

2383210 /rittal/

2383250 /rittal/

2383350 /rittal/

2384010 /rittal/

2384020 /rittal/

2384030 /rittal/

2384040 /rittal/

2410010 /rittal/

2410030 /rittal/

2411.601 /rittal/

2411.611 /rittal/

2411.621 /rittal/

2411.631 /rittal/

2411.641 /rittal/

2411.651 /rittal/

2411.661 /rittal/

2411.671 /rittal/

2411.801 /rittal/

2411.811 /rittal/

2411.821 /rittal/

2411.831 /rittal/

2411.841 /rittal/

2411.851 /rittal/

2411.861 /rittal/

2411.871 /rittal/

2420000 /rittal/

2466000 /rittal/

2467000 /rittal/

2468000 /rittal/

2469000 /rittal/

2508010 /rittal/

2508100 /rittal/

2514500 /rittal/

2514600 /rittal/

2514800 /rittal/

2519000 /rittal/

2531000 /rittal/

2533000 /rittal/

2545000 /rittal/

2549.000 /rittal/

2549500 /rittal/

2549600 /rittal/

2570100 /rittal/

2571000 /rittal/

2576000 /rittal/

3105310 /rittal/

3110000 /rittal/

3128100 /rittal/

3139.100 /rittal/

3139110 /rittal/

3140.100 /rittal/

3140110 /rittal/

3171.100 /rittal/

3171100 /rittal/

3172.100 /rittal/

3172100 /rittal/

3173.100 /rittal/

3173100 /rittal/

3181.100 /rittal/

3181100 /rittal/

3182.100 /rittal/

3182100 /rittal/

3183.100 /rittal/

3183100 /rittal/

3201200 /rittal/

3237.066 /ittal/

3237.080 /ittal/

3237.100 /ittal/

3237.124 /ittal/

3237.200 /ittal/

3237080 /ittal/

3237100 /ittal/

3237110 /ittal/

3237124 /ittal/

3237200 /ittal/

3238.055 /ittal/

3238.080 /ittal/

3238.100 /ittal/

3238.110 /ittal/

3238.124 /ittal/

3238.200 /ittal/

3238.500 /ittal/

3238080 /ittal/

3238100 /ittal/

3238110 /ittal/

3238124 /ittal/

3238200 /ittal/

3239.100 /ittal/

3239.500 /ittal/

3239080 /ittal/

3239100 /ittal/

3239110 /ittal/

3239124 /ittal/

3239200 /ittal/

3240.066 /ittal/

3240.080 /ittal/

3240.100 /ittal/

3240.200 /ittal/

3240.500 /ittal/

3240080 /ittal/

3240110 /ittal/

3240124 /ittal/

3240200 /ittal/

3241.100 /ittal/

3241.500 /ittal/

3241100 /ittal/

3241110 /ittal/

3241124 /ittal/

3243.200 /ittal/

3243080 /ittal/

3243100 /ittal/

3243110 /ittal/

3243200 /ittal/

3244.100 /ittal/

3244100 /ittal/

3244110 /ittal/

3244140 /ittal/

3245.080 /ittal/

3286400 /ittal/

3286410 /ittal/

3302100 /ittal/

3302110 /ittal/

3303500 /ittal/

3303510 /rittal/

3305540 /rittal/

3321.700 /rittal/

3321700 /rittal/

3322.700 /rittal/

3322700 /rittal/

3361500 /rittal/

3396059 /rittal/

3396666 /rittal/

3396667 /rittal/

3397490 /rittal/

3397533 /rittal/

3650310 /rittal/

3652030 /rittal/

3652050 /rittal/

3652210 /rittal/

3684891 /rittal/

3684907 /rittal/

3684917 /rittal/

3688045 /rittal/

3688046 /rittal/

3688117 /rittal/

4127010 /rittal/

4140840 /rittal/

4155510 /rittal/

4315810 /rittal/

5501705 /rittal/

6218200 /rittal/

6501130 /rittal/

7113000 /rittal/

7151305 /rittal/

7685000 /rittal/

7698000 /rittal/

7827201 /rittal/

7829200 /rittal/

8017727 /rittal/

8611020 /rittal/

8611190 /rittal/

8611290 /rittal/

8611370 /rittal/

8612060 /rittal/

8800020 /rittal/

9101.210 /rittal/

9102.210 /rittal/

9104.210 /rittal/

9105.210 /rittal/

9106.210 /rittal/

9107.210 /rittal/

9108.210 /rittal/

9108210 /rittal/

9111.210 /rittal/

9113.210 /rittal/

9113700 /rittal/

9114.210 /rittal/

9116.210 /rittal/

9117.210 /rittal/

9118.210 /rittal/

9119.210 /rittal/

9121160 /rittal/

9500.000 /rittal/

9502.000 /rittal/

9504.000 /rittal/

9505.000 /rittal/

9506.000 /rittal/

9507.000 /rittal/

9508.000 /rittal/

9508.050 /rittal/

9509.000 /rittal/

9510.000 /rittal/

9510000 /rittal/

9511.000 /rittal/

9513.000 /rittal/

9514,100 /rittal/

9514.000 /rittal/

9514.050 /rittal/

9514000 /rittal/

9515.000 /rittal/

9515.100 /rittal/

9516.000 /rittal/

9516.100 /rittal/

9517.000 /rittal/

9517.100 /rittal/

9517000 /rittal/

9518.000 /rittal/

9518000 /rittal/

9519.000 /rittal/

9519.100 /rittal/

9520.000 /ittal/

9520.100 /ittal/

9521.000 /ittal/

9521.050 /ittal/

9521.100 /ittal/

9522.000 /ittal/

9522.100 /ittal/

9522000 /ittal/

9522100 /ittal/

9523.000 /ittal/

9523.100 /ittal/

9524.000 /ittal/

9524.100 /ittal/

9548000 /ittal/

9549000 /ittal/

9550000 /ittal/

9581000 /ittal/

9583000 /ittal/

9851500 /ittal/

9851501 /ittal/

9851503 /ittal/

9851504 /ittal/

9851514 /ittal/

ae1004 /ittal/

ae1006 /ittal/

ae1032 /ittal/

ae1033 /ittal/

ae1034 /ittal/

ae1038 /ittal/

ae1045 /rittal/

ae1050 /rittal/

ae1057 /rittal/

ae1060 /rittal/

ae1350 /rittal/

ae1360 /rittal/

ae1380 /rittal/

eb1550 /rittal/

eb1555 /rittal/

eb1556 /rittal/

jb060404hc /rittal/

jb060604hc /rittal/

jb080604h6 /rittal/

jb080606hc /rittal/

jb100804hc /rittal/

jb100806h4 /rittal/

jb100806hc /rittal/

jb101006hc /rittal/

jb121005hc /rittal/

jb121006hc /rittal/

jb121008h4 /rittal/

jb121008hc /rittal/

jb121206hc /rittal/

jb141206hc /rittal/

jb161408hc /rittal/

jb161410hc /rittal/

jbmp0806 /rittal/

jbmp0808 /rittal/

jbmp1008 /rittal/

jbmp1010 /rittal/

jbmp1210 /rittal/

jbmp1412 /rittal/

jbmp1614 /rittal/

kl1502 /rittal/

kl1503 /rittal/

kl1507 /rittal/

kl1539510 /rittal/

ohs050c /rittal/

ohs0756 /rittal/

ohs075c /rittal/

ohs150c /rittal/

ohsmpb6 /rittal/

ohsmpbc /rittal/

ohsspbc /rittal/

pb01225m1c /rittal/

pb02225m1c /rittal/

pb03225m1c /rittal/

pb12225m34 /rittal/

sk 3114.200 /rittal/

sk 3182.100 /rittal/

sk 3183.100 /rittal/

sk2542235 /rittal/

wm121206nc /rittal/

wm161208nc /rittal/

wm161606nc /rittal/

wm162006nc /rittal/

wm162008nc /rittal/

wm201606nc /rittal/

wm201608nc /rittal/

wm202008n4 /rittal/

wm202008nc /rittal/

wm202012nc /rittal/

wm202408nc /rittal/

wm241608nc /rittal/

wm242008nc /rittal/

wm242010nc /rittal/

wm242408nc /rittal/

wm242410nc /rittal/

wm242412n4 /rittal/

wm242412nc /rittal/

wm302408nc /rittal/

wm302412nc /rittal/

вентилятор внутренний 24 dc, 160м<sup>3</sup>/ч sk 3108.024 rittal

вентилятор потолочный 230 в, 50/60 гц, 360 м куб./час код: sk 3149.007 ф."rittal

вентилятор фильтрующий sk 3239.124 rittal

вентилятор фильтрующий sk 3241.100 rittal

вентилятор фильтрующий sk 3241.124 rittal

вентилятор фильтрующий sk 3326.607 rittal

вентилятор фильтрующий 230 в, 50/60 гц, 160/160 м3/час sk3240.100 ф."rittal"