

CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3Y2C5	YELLOW/2C/LED 5V	S16PRT-H3Y2C5, YELLOW/2C/LED 5V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3YC5	YELLOW/1C/LED 5V	S16PRT-H3YC5, YELLOW/1C/LED 5V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4B		S16PRT-H4B, , GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4B2C12	BLUE/2C/LED 12V	S16PRT-H4B2C12, BLUE/2C/LED 12V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4B2C24	BLUE/2C/LED 24V	S16PRT-H4B2C24, BLUE/2C/LED 24V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4B2C5	BLUE/2C/LED 5V	S16PRT-H4B2C5, BLUE/2C/LED 5V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4BC5	BLUE/1C/LED 5V	S16PRT-H4BC5, BLUE/1C/LED 5V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4G2C12	GREEN/2C/LED 12V	S16PRT-H4G2C12, GREEN/2C/LED 12V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4G2C24	GREEN/2C/LED 24V	S16PRT-H4G2C24, GREEN/2C/LED 24V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4G2C5	GREEN/2C/LED 5V	S16PRT-H4G2C5, GREEN/2C/LED 5V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4W2C12	WHITE/2C/LED 12V	S16PRT-H4W2C12, WHITE/2C/LED 12V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4W2C24	WHITE/2C/LED 24V	S16PRT-H4W2C24, WHITE/2C/LED 24V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4W2C5	WHITE/2C/LED 5V	S16PRT-H4W2C5, WHITE/2C/LED 5V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4WC5	WHITE/1C/LED 5V	S16PRT-H4WC5, WHITE/1C/LED 5V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4Y2C12	YELLOW/2C/LED 12V	S16PRT-H4Y2C12, YELLOW/2C/LED 12V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4Y2C24	YELLOW/2C/LED 24V	S16PRT-H4Y2C24, YELLOW/2C/LED 24V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4Y2C5	YELLOW/2C/LED 5V	S16PRT-H4Y2C5, YELLOW/2C/LED 5V, GL
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4YC5	YELLOW/1C/LED 5V	S16PRT-H4YC5, YELLOW/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1B		S16SR-L1B, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1B2C12	BLUE/2(0-R)/2C/LED 12V	S16SR-L1B2C12, BLUE/2(0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1B2C24	BLUE/2(0-R)/2C/LED 24V	S16SR-L1B2C24, BLUE/2(0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1B2C5	BLUE/2(0-R)/2C/LED 5V	S16SR-L1B2C5, BLUE/2(0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1BC12	BLUE/2(0-R)/1C/LED 12V	S16SR-L1BC12, BLUE/2(0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1BC24	BLUE/2(0-R)/1C/LED 24V	S16SR-L1BC24, BLUE/2(0-R)/1C/LED 24V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1BC5	BLUE/2(0-R)/1C/LED 5V	S16SR-L1BC5, BLUE/2(0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1G		S16SR-L1G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1G2C12	GREEN/2(0-R)/2C/LED 12V	S16SR-L1G2C12, GREEN/2(0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1G2C24	GREEN/2(0-R)/2C/LED 24V	S16SR-L1G2C24, GREEN/2(0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1G2C5	GREEN/2(0-R)/2C/LED 5V	S16SR-L1G2C5, GREEN/2(0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1W		S16SR-L1W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1W2C12	WHITE/2(0-R)/2C/LED 12V	S16SR-L1W2C12, WHITE/2(0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1W2C24	WHITE/2(0-R)/2C/LED 24V	S16SR-L1W2C24, WHITE/2(0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1W2C5	WHITE/2(0-R)/2C/LED 5V	S16SR-L1W2C5, WHITE/2(0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1WC12	WHITE/2(0-R)/1C/LED 12V	S16SR-L1WC12, WHITE/2(0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1WC24	WHITE/2(0-R)/1C/LED 24V	S16SR-L1WC24, WHITE/2(0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1WC5	WHITE/2(0-R)/1C/LED 5V	S16SR-L1WC5, WHITE/2(0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1Y		S16SR-L1Y, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1Y2C12	YELLOW/2(0-R)/2C/LED 12V	S16SR-L1Y2C12, YELLOW/2(0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1Y2C24	YELLOW/2(0-R)/2C/LED 24V	S16SR-L1Y2C24, YELLOW/2(0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1Y2C5	YELLOW/2(0-R)/2C/LED 5V	S16SR-L1Y2C5, YELLOW/2(0-R)/2C/LED 5V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1YC12	YELLOW/2(0-R)/1C/LED 12V	S16SR-L1YC12, YELLOW/2(0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1YC24	YELLOW/2(0-R)/1C/LED 24V	S16SR-L1YC24, YELLOW/2(0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1YC5	YELLOW/2(0-R)/1C/LED 5V	S16SR-L1YC5, YELLOW/2(0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2B		S16SR-L2B, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2B2C12	BLUE/2(0-S)/2C/LED 12V	S16SR-L2B2C12, BLUE/2(0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2B2C24	BLUE/2(0-S)/2C/LED 24V	S16SR-L2B2C24, BLUE/2(0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2B2C5	BLUE/2(0-S)/2C/LED 5V	S16SR-L2B2C5, BLUE/2(0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2BC12	BLUE/2(0-S)/1C/LED 12V	S16SR-L2BC12, BLUE/2(0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2BC24	BLUE/2(0-S)/1C/LED 24V	S16SR-L2BC24, BLUE/2(0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2BC5	BLUE/2(0-S)/1C/LED 5V	S16SR-L2BC5, BLUE/2(0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2G		S16SR-L2G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2G2C12	GREEN/2(0-S)/2C/LED 12V	S16SR-L2G2C12, GREEN/2(0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2G2C24	GREEN/2(0-S)/2C/LED 24V	S16SR-L2G2C24, GREEN/2(0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2G2C5	GREEN/2(0-S)/2C/LED 5V	S16SR-L2G2C5, GREEN/2(0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2W		S16SR-L2W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2W2C12	WHITE/2(0-S)/2C/LED 12V	S16SR-L2W2C12, WHITE/2(0-S)/2C/LED 12V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2W2C24	WHITE/2(0-S)/2C/LED 24V	S16SR-L2W2C24, WHITE/2(0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2W2C5	WHITE/2(0-S)/2C/LED 5V	S16SR-L2W2C5, WHITE/2(0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2WC12	WHITE/2(0-S)/1C/LED 12V	S16SR-L2WC12, WHITE/2(0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2WC24	WHITE/2(0-S)/1C/LED 24V	S16SR-L2WC24, WHITE/2(0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2WC5	WHITE/2(0-S)/1C/LED 5V	S16SR-L2WC5, WHITE/2(0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2Y		S16SR-L2Y, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2Y2C12	YELLOW/2(0-S)/2C/LED 12V	S16SR-L2Y2C12, YELLOW/2(0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2Y2C24	YELLOW/2(0-S)/2C/LED 24V	S16SR-L2Y2C24, YELLOW/2(0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2Y2C5	YELLOW/2(0-S)/2C/LED 5V	S16SR-L2Y2C5, YELLOW/2(0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2YC12	YELLOW/2(0-S)/1C/LED 12V	S16SR-L2YC12, YELLOW/2(0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2YC24	YELLOW/2(0-S)/1C/LED 24V	S16SR-L2YC24, YELLOW/2(0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2YC5	YELLOW/2(0-S)/1C/LED 5V	S16SR-L2YC5, YELLOW/2(0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3B		S16SR-L3B, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3B2C12	BLUE/2(R-0-R)/2C/LED 12V	S16SR-L3B2C12, BLUE/2(R-0-R)/2C/LED 12V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3B2C24	BLUE/2(R-0-R)/2C/LED 24V	S16SR-L3B2C24, BLUE/2(R-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3B2C5	BLUE/2(R-0-R)/2C/LED 5V	S16SR-L3B2C5, BLUE/2(R-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3BC12	BLUE/2(R-0-R)/1C/LED 12V	S16SR-L3BC12, BLUE/2(R-0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3BC24	BLUE/2(R-0-R)/1C/LED 24V	S16SR-L3BC24, BLUE/2(R-0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3BC5	BLUE/2(R-0-R)/1C/LED 5V	S16SR-L3BC5, BLUE/2(R-0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3G		S16SR-L3G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3G2C12	GREEN/2(R-0-R)/2C/LED 12V	S16SR-L3G2C12, GREEN/2(R-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3G2C24	GREEN/2(R-0-R)/2C/LED 24V	S16SR-L3G2C24, GREEN/2(R-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3G2C5	GREEN/2(R-0-R)/2C/LED 5V	S16SR-L3G2C5, GREEN/2(R-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3W		S16SR-L3W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3W2C12	WHITE/2(R-0-R)/2C/LED 12V	S16SR-L3W2C12, WHITE/2(R-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3W2C24	WHITE/2(R-0-R)/2C/LED 24V	S16SR-L3W2C24, WHITE/2(R-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3W2C5	WHITE/2(R-0-R)/2C/LED 5V	S16SR-L3W2C5, WHITE/2(R-0-R)/2C/LED 5V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3WC12	WHITE/2(R-0-R)/1C/LED 12V	S16SR-L3WC12, WHITE/2(R-0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3WC24	WHITE/2(R-0-R)/1C/LED 24V	S16SR-L3WC24, WHITE/2(R-0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3WC5	WHITE/2(R-0-R)/1C/LED 5V	S16SR-L3WC5, WHITE/2(R-0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3Y		S16SR-L3Y, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3Y2C12	YELLOW/2(R-0-R)/2C/LED 12V	S16SR-L3Y2C12, YELLOW/2(R-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3Y2C24	YELLOW/2(R-0-R)/2C/LED 24V	S16SR-L3Y2C24, YELLOW/2(R-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3Y2C5	YELLOW/2(R-0-R)/2C/LED 5V	S16SR-L3Y2C5, YELLOW/2(R-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3YC12	YELLOW/2(R-0-R)/1C/LED 12V	S16SR-L3YC12, YELLOW/2(R-0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3YC24	YELLOW/2(R-0-R)/1C/LED 24V	S16SR-L3YC24, YELLOW/2(R-0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3YC5	YELLOW/2(R-0-R)/1C/LED 5V	S16SR-L3YC5, YELLOW/2(R-0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4B		S16SR-L4B, , GL

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4B2C12	BLUE/2(S-0-S)/2C/LED 12V	S16SR-L4B2C12, BLUE/2(S-0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4B2C24	BLUE/2(S-0-S)/2C/LED 24V	S16SR-L4B2C24, BLUE/2(S-0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4B2C5	BLUE/2(S-0-S)/2C/LED 5V	S16SR-L4B2C5, BLUE/2(S-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4BC12	BLUE/2(S-0-S)/1C/LED 12V	S16SR-L4BC12, BLUE/2(S-0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4BC24	BLUE/2(S-0-S)/1C/LED 24V	S16SR-L4BC24, BLUE/2(S-0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4BC5	BLUE/2(S-0-S)/1C/LED 5V	S16SR-L4BC5, BLUE/2(S-0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4G		S16SR-L4G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4G2C12	GREEN/2(S-0-S)/2C/LED 12V	S16SR-L4G2C12, GREEN/2(S-0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4G2C24	GREEN/2(S-0-S)/2C/LED 24V	S16SR-L4G2C24, GREEN/2(S-0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4G2C5	GREEN/2(S-0-S)/2C/LED 5V	S16SR-L4G2C5, GREEN/2(S-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4W		S16SR-L4W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4W2C12	WHITE/2(S-0-S)/2C/LED 12V	S16SR-L4W2C12, WHITE/2(S-0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4W2C24	WHITE/2(S-0-S)/2C/LED 24V	S16SR-L4W2C24, WHITE/2(S-0-S)/2C/LED 24V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4W2C5	WHITE/2(S-0-S)/2C/LED 5V	S16SR-L4W2C5, WHITE/2(S-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4WC12	WHITE/2(S-0-S)/1C/LED 12V	S16SR-L4WC12, WHITE/2(S-0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4WC24	WHITE/2(S-0-S)/1C/LED 24V	S16SR-L4WC24, WHITE/2(S-0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4WC5	WHITE/2(S-0-S)/1C/LED 5V	S16SR-L4WC5, WHITE/2(S-0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4Y		S16SR-L4Y, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4Y2C12	YELLOW/2(S-0-S)/2C/LED 12V	S16SR-L4Y2C12, YELLOW/2(S-0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4Y2C24	YELLOW/2(S-0-S)/2C/LED 24V	S16SR-L4Y2C24, YELLOW/2(S-0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4Y2C5	YELLOW/2(S-0-S)/2C/LED 5V	S16SR-L4Y2C5, YELLOW/2(S-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4YC12	YELLOW/2(S-0-S)/1C/LED 12V	S16SR-L4YC12, YELLOW/2(S-0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4YC24	YELLOW/2(S-0-S)/1C/LED 24V	S16SR-L4YC24, YELLOW/2(S-0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4YC5	YELLOW/2(S-0-S)/1C/LED 5V	S16SR-L4YC5, YELLOW/2(S-0-S)/1C/LED 5V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5B		S16SR-L5B, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5B2C12	BLUE/2(S-0-R)/2C/LED 12V	S16SR-L5B2C12, BLUE/2(S-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5B2C24	BLUE/2(S-0-R)/2C/LED 24V	S16SR-L5B2C24, BLUE/2(S-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5B2C5	BLUE/2(S-0-R)/2C/LED 5V	S16SR-L5B2C5, BLUE/2(S-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5BC12	BLUE/2(S-0-R)/1C/LED 12V	S16SR-L5BC12, BLUE/2(S-0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5BC24	BLUE/2(S-0-R)/1C/LED 24V	S16SR-L5BC24, BLUE/2(S-0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5BC5	BLUE/2(S-0-R)/1C/LED 5V	S16SR-L5BC5, BLUE/2(S-0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5G		S16SR-L5G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5G2C12	GREEN/2(S-0-R)/2C/LED 12V	S16SR-L5G2C12, GREEN/2(S-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5G2C24	GREEN/2(S-0-R)/2C/LED 24V	S16SR-L5G2C24, GREEN/2(S-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5G2C5	GREEN/2(S-0-R)/2C/LED 5V	S16SR-L5G2C5, GREEN/2(S-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5W		S16SR-L5W, , GL

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5W2C12	WHITE/2(S-0-R)/2C/LED 12V	S16SR-L5W2C12, WHITE/2(S-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5W2C24	WHITE/2(S-0-R)/2C/LED 24V	S16SR-L5W2C24, WHITE/2(S-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5W2C5	WHITE/2(S-0-R)/2C/LED 5V	S16SR-L5W2C5, WHITE/2(S-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5WC12	WHITE/2(S-0-R)/1C/LED 12V	S16SR-L5WC12, WHITE/2(S-0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5WC24	WHITE/2(S-0-R)/1C/LED 24V	S16SR-L5WC24, WHITE/2(S-0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5WC5	WHITE/2(S-0-R)/1C/LED 5V	S16SR-L5WC5, WHITE/2(S-0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5Y		S16SR-L5Y, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5Y2C12	YELLOW/2(S-0-R)/2C/LED 12V	S16SR-L5Y2C12, YELLOW/2(S-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5Y2C24	YELLOW/2(S-0-R)/2C/LED 24V	S16SR-L5Y2C24, YELLOW/2(S-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5Y2C5	YELLOW/2(S-0-R)/2C/LED 5V	S16SR-L5Y2C5, YELLOW/2(S-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5YC12	YELLOW/2(S-0-R)/1C/LED 12V	S16SR-L5YC12, YELLOW/2(S-0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5YC24	YELLOW/2(S-0-R)/1C/LED 24V	S16SR-L5YC24, YELLOW/2(S-0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5YC5	YELLOW/2(S-0-R)/1C/LED 5V	S16SR-L5YC5, YELLOW/2(S-0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6B		S16SR-L6B, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6B2C12	BLUE/2(R-0-S)/2C/LED 12V	S16SR-L6B2C12, BLUE/2(R-0-S)/2C/LED 12V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6B2C24	BLUE/2(R-0-S)/2C/LED 24V	S16SR-L6B2C24, BLUE/2(R-0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6B2C5	BLUE/2(R-0-S)/2C/LED 5V	S16SR-L6B2C5, BLUE/2(R-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6BC12	BLUE/2(R-0-S)/1C/LED 12V	S16SR-L6BC12, BLUE/2(R-0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6BC24	BLUE/2(R-0-S)/1C/LED 24V	S16SR-L6BC24, BLUE/2(R-0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6BC5	BLUE/2(R-0-S)/1C/LED 5V	S16SR-L6BC5, BLUE/2(R-0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6G		S16SR-L6G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6G2C12	GREEN/2(R-0-S)/2C/LED 12V	S16SR-L6G2C12, GREEN/2(R-0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6G2C24	GREEN/2(R-0-S)/2C/LED 24V	S16SR-L6G2C24, GREEN/2(R-0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6G2C5	GREEN/2(R-0-S)/2C/LED 5V	S16SR-L6G2C5, GREEN/2(R-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6W		S16SR-L6W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6W2C12	WHITE/2(R-0-S)/2C/LED 12V	S16SR-L6W2C12, WHITE/2(R-0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6W2C24	WHITE/2(R-0-S)/2C/LED 24V	S16SR-L6W2C24, WHITE/2(R-0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6W2C5	WHITE/2(R-0-S)/2C/LED 5V	S16SR-L6W2C5, WHITE/2(R-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6WC12	WHITE/2(R-0-S)/1C/LED 12V	S16SR-L6WC12, WHITE/2(R-0-S)/1C/LED 12V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6WC24	WHITE/2(R-0-S)/1C/LED 24V	S16SR-L6WC24, WHITE/2(R-0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6WC5	WHITE/2(R-0-S)/1C/LED 5V	S16SR-L6WC5, WHITE/2(R-0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6Y		S16SR-L6Y, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6Y2C12	YELLOW/2(R-0-S)/2C/LED 12V	S16SR-L6Y2C12, YELLOW/2(R-0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6Y2C24	YELLOW/2(R-0-S)/2C/LED 24V	S16SR-L6Y2C24, YELLOW/2(R-0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6Y2C5	YELLOW/2(R-0-S)/2C/LED 5V	S16SR-L6Y2C5, YELLOW/2(R-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6YC12	YELLOW/2(R-0-S)/1C/LED 12V	S16SR-L6YC12, YELLOW/2(R-0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6YC24	YELLOW/2(R-0-S)/1C/LED 24V	S16SR-L6YC24, YELLOW/2(R-0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6YC5	YELLOW/2(R-0-S)/1C/LED 5V	S16SR-L6YC5, YELLOW/2(R-0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1B		S16SR-S1B, , GL

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1B2C	BLUE/2(0-R)/2C	S16SR-S1B2C, BLUE/2(0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1B3C	BLUE/2(0-R)/3C	S16SR-S1B3C, BLUE/2(0-R)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1BC	BLUE/2(0-R)/1C	S16SR-S1BC, BLUE/2(0-R)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1G		S16SR-S1G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1G2C	GREEN/2(0-R)/2C	S16SR-S1G2C, GREEN/2(0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1G3C	GREEN/2(0-R)/3C	S16SR-S1G3C, GREEN/2(0-R)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1W		S16SR-S1W, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1W2C	WHITE/2(0-R)/2C	S16SR-S1W2C, WHITE/2(0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1W3C	WHITE/2(0-R)/3C	S16SR-S1W3C, WHITE/2(0-R)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1Y		S16SR-S1Y, , GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1Y2C	YELLOW/2(0-R)/2C	S16SR-S1Y2C, YELLOW/2(0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1Y3C	YELLOW/2(0-R)/3C	S16SR-S1Y3C, YELLOW/2(0-R)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1YC	YELLOW/2(0-R)/1C	S16SR-S1YC, YELLOW/2(0-R)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2B		S16SR-S2B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2B2C	BLUE/2(0-S)/2C	S16SR-S2B2C, BLUE/2(0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2B3C	BLUE/2(0-S)/3C	S16SR-S2B3C, BLUE/2(0-S)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2BC	BLUE/2(0-S)/1C	S16SR-S2BC, BLUE/2(0-S)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2G		S16SR-S2G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2G2C	GREEN/2(0-S)/2C	S16SR-S2G2C, GREEN/2(0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2G3C	GREEN/2(0-S)/3C	S16SR-S2G3C, GREEN/2(0-S)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2W		S16SR-S2W, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2W3C	WHITE/2(0-S)/3C	S16SR-S2W3C, WHITE/2(0-S)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2Y		S16SR-S2Y, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2Y2C	YELLOW/2(0-S)/2C	S16SR-S2Y2C, YELLOW/2(0-S)/2C, GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2Y3C	YELLOW/2(0-S)/3C	S16SR-S2Y3C, YELLOW/2(0-S)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2YC	YELLOW/2(0-S)/1C	S16SR-S2YC, YELLOW/2(0-S)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S3B		S16SR-S3B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S3B2C	BLUE/3(R-0-R)/2C	S16SR-S3B2C, BLUE/3(R-0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S3G		S16SR-S3G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S3G2C	GREEN/3(R-0-R)/2C	S16SR-S3G2C, GREEN/3(R-0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S3W		S16SR-S3W, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S3WC	WHITE/3(R-0-R)/1C	S16SR-S3WC, WHITE/3(R-0-R)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S3Y		S16SR-S3Y, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S3Y2C	YELLOW/3(R-0-R)/2C	S16SR-S3Y2C, YELLOW/3(R-0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S4B		S16SR-S4B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S4B2C	BLUE/3(S-0-S)/2C	S16SR-S4B2C, BLUE/3(S-0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S4G		S16SR-S4G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S4G2C	GREEN/3(S-0-S)/2C	S16SR-S4G2C, GREEN/3(S-0-S)/2C, GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S4W		S16SR-S4W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S4Y		S16SR-S4Y, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S4Y2C	YELLOW/3(S-0-S)/2C	S16SR-S4Y2C, YELLOW/3(S-0-S)/2C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S5B		S16SR-S5B, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S5B2C	BLUE/3(S-0-R)/2C	S16SR-S5B2C, BLUE/3(S-0-R)/2C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S5G		S16SR-S5G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S5G2C	GREEN/3(S-0-R)/2C	S16SR-S5G2C, GREEN/3(S-0-R)/2C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S5W		S16SR-S5W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S5W2C	WHITE/3(S-0-R)/2C	S16SR-S5W2C, WHITE/3(S-0-R)/2C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S5WC	WHITE/3(S-0-R)/1C	S16SR-S5WC, WHITE/3(S-0-R)/1C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S5Y		S16SR-S5Y, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S5Y2C	YELLOW/3(S-0-R)/2C	S16SR-S5Y2C, YELLOW/3(S-0-R)/2C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S6B		S16SR-S6B, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S6B2C	BLUE/3(R-0-S)/2C	S16SR-S6B2C, BLUE/3(R-0-S)/2C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S6G		S16SR-S6G, , GL

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S6G2C	GREEN/3(R-0-S)/2C	S16SR-S6G2C, GREEN/3(R-0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S6W		S16SR-S6W, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S6WC	WHITE/3(R-0-S)/1C	S16SR-S6WC, WHITE/3(R-0-S)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S6Y		S16SR-S6Y, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S6Y2C	YELLOW/3(R-0-S)/2C	S16SR-S6Y2C, YELLOW/3(R-0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1B		S16SRS-L1B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1B2C12	BLUE/2(0-R)/2C/LED 12V	S16SRS-L1B2C12, BLUE/2(0-R)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1B2C24	BLUE/2(0-R)/2C/LED 24V	S16SRS-L1B2C24, BLUE/2(0-R)/2C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1B2C5	BLUE/2(0-R)/2C/LED 5V	S16SRS-L1B2C5, BLUE/2(0-R)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1BC12	BLUE/2(0-R)/1C/LED 12V	S16SRS-L1BC12, BLUE/2(0-R)/1C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1BC24	BLUE/2(0-R)/1C/LED 24V	S16SRS-L1BC24, BLUE/2(0-R)/1C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1BC5	BLUE/2(0-R)/1C/LED 5V	S16SRS-L1BC5, BLUE/2(0-R)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1G		S16SRS-L1G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1G2C12	GREEN/2(0-R)/2C/LED 12V	S16SRS-L1G2C12, GREEN/2(0-R)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1G2C24	GREEN/2(0-R)/2C/LED 24V	S16SRS-L1G2C24, GREEN/2(0-R)/2C/LED 24V, GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1G2C5	GREEN/2(0-R)/2C/LED 5V	S16SRS-L1G2C5, GREEN/2(0-R)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1W		S16SRS-L1W, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1W2C12	WHITE/2(0-R)/2C/LED 12V	S16SRS-L1W2C12, WHITE/2(0-R)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1W2C24	WHITE/2(0-R)/2C/LED 24V	S16SRS-L1W2C24, WHITE/2(0-R)/2C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1W2C5	WHITE/2(0-R)/2C/LED 5V	S16SRS-L1W2C5, WHITE/2(0-R)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1WC12	WHITE/2(0-R)/1C/LED 12V	S16SRS-L1WC12, WHITE/2(0-R)/1C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1WC24	WHITE/2(0-R)/1C/LED 24V	S16SRS-L1WC24, WHITE/2(0-R)/1C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1WC5	WHITE/2(0-R)/1C/LED 5V	S16SRS-L1WC5, WHITE/2(0-R)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1Y		S16SRS-L1Y, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1Y2C12	YELLOW/2(0-R)/2C/LED 12V	S16SRS-L1Y2C12, YELLOW/2(0-R)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1Y2C24	YELLOW/2(0-R)/2C/LED 24V	S16SRS-L1Y2C24, YELLOW/2(0-R)/2C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1Y2C5	YELLOW/2(0-R)/2C/LED 5V	S16SRS-L1Y2C5, YELLOW/2(0-R)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1YC12	YELLOW/2(0-R)/1C/LED 12V	S16SRS-L1YC12, YELLOW/2(0-R)/1C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1YC24	YELLOW/2(0-R)/1C/LED 24V	S16SRS-L1YC24, YELLOW/2(0-R)/1C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1YC5	YELLOW/2(0-R)/1C/LED 5V	S16SRS-L1YC5, YELLOW/2(0-R)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2B		S16SRS-L2B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2B2C12	BLUE/2(0-S)/2C/LED 12V	S16SRS-L2B2C12, BLUE/2(0-S)/2C/LED 12V, GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2B2C24	BLUE/2(0-S)/2C/LED 24V	S16SRS-L2B2C24, BLUE/2(0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2B2C5	BLUE/2(0-S)/2C/LED 5V	S16SRS-L2B2C5, BLUE/2(0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2BC12	BLUE/2(0-S)/1C/LED 12V	S16SRS-L2BC12, BLUE/2(0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2BC24	BLUE/2(0-S)/1C/LED 24V	S16SRS-L2BC24, BLUE/2(0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2BC5	BLUE/2(0-S)/1C/LED 5V	S16SRS-L2BC5, BLUE/2(0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2G		S16SRS-L2G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2G2C12	GREEN/2(0-S)/2C/LED 12V	S16SRS-L2G2C12, GREEN/2(0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2G2C24	GREEN/2(0-S)/2C/LED 24V	S16SRS-L2G2C24, GREEN/2(0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2G2C5	GREEN/2(0-S)/2C/LED 5V	S16SRS-L2G2C5, GREEN/2(0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2W		S16SRS-L2W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2W2C12	WHITE/2(0-S)/2C/LED 12V	S16SRS-L2W2C12, WHITE/2(0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2W2C24	WHITE/2(0-S)/2C/LED 24V	S16SRS-L2W2C24, WHITE/2(0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2W2C5	WHITE/2(0-S)/2C/LED 5V	S16SRS-L2W2C5, WHITE/2(0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2WC12	WHITE/2(0-S)/1C/LED 12V	S16SRS-L2WC12, WHITE/2(0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2WC24	WHITE/2(0-S)/1C/LED 24V	S16SRS-L2WC24, WHITE/2(0-S)/1C/LED 24V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2WC5	WHITE/2(0-S)/1C/LED 5V	S16SRS-L2WC5, WHITE/2(0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2Y		S16SRS-L2Y, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2Y2C12	YELLOW/2(0-S)/2C/LED 12V	S16SRS-L2Y2C12, YELLOW/2(0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2Y2C24	YELLOW/2(0-S)/2C/LED 24V	S16SRS-L2Y2C24, YELLOW/2(0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2Y2C5	YELLOW/2(0-S)/2C/LED 5V	S16SRS-L2Y2C5, YELLOW/2(0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2YC12	YELLOW/2(0-S)/1C/LED 12V	S16SRS-L2YC12, YELLOW/2(0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2YC24	YELLOW/2(0-S)/1C/LED 24V	S16SRS-L2YC24, YELLOW/2(0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2YC5	YELLOW/2(0-S)/1C/LED 5V	S16SRS-L2YC5, YELLOW/2(0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3B		S16SRS-L3B, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3B2C12	BLUE/2(R-0-R)/2C/LED 12V	S16SRS-L3B2C12, BLUE/2(R-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3B2C24	BLUE/2(R-0-R)/2C/LED 24V	S16SRS-L3B2C24, BLUE/2(R-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3B2C5	BLUE/2(R-0-R)/2C/LED 5V	S16SRS-L3B2C5, BLUE/2(R-0-R)/2C/LED 5V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3BC12	BLUE/2(R-0-R)/1C/LED 12V	S16SRS-L3BC12, BLUE/2(R-0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3BC24	BLUE/2(R-0-R)/1C/LED 24V	S16SRS-L3BC24, BLUE/2(R-0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3BC5	BLUE/2(R-0-R)/1C/LED 5V	S16SRS-L3BC5, BLUE/2(R-0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3G		S16SRS-L3G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3G2C12	GREEN/2(R-0-R)/2C/LED 12V	S16SRS-L3G2C12, GREEN/2(R-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3G2C24	GREEN/2(R-0-R)/2C/LED 24V	S16SRS-L3G2C24, GREEN/2(R-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3G2C5	GREEN/2(R-0-R)/2C/LED 5V	S16SRS-L3G2C5, GREEN/2(R-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3W		S16SRS-L3W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3W2C12	WHITE/2(R-0-R)/2C/LED 12V	S16SRS-L3W2C12, WHITE/2(R-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3W2C24	WHITE/2(R-0-R)/2C/LED 24V	S16SRS-L3W2C24, WHITE/2(R-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3W2C5	WHITE/2(R-0-R)/2C/LED 5V	S16SRS-L3W2C5, WHITE/2(R-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3WC12	WHITE/2(R-0-R)/1C/LED 12V	S16SRS-L3WC12, WHITE/2(R-0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3WC24	WHITE/2(R-0-R)/1C/LED 24V	S16SRS-L3WC24, WHITE/2(R-0-R)/1C/LED 24V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3WC5	WHITE/2(R-0-R)/1C/LED 5V	S16SRS-L3WC5, WHITE/2(R-0-R)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3Y		S16SRS-L3Y, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3Y2C12	YELLOW/2(R-0-R)/2C/LED 12V	S16SRS-L3Y2C12, YELLOW/2(R-0-R)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3Y2C24	YELLOW/2(R-0-R)/2C/LED 24V	S16SRS-L3Y2C24, YELLOW/2(R-0-R)/2C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3Y2C5	YELLOW/2(R-0-R)/2C/LED 5V	S16SRS-L3Y2C5, YELLOW/2(R-0-R)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3YC12	YELLOW/2(R-0-R)/1C/LED 12V	S16SRS-L3YC12, YELLOW/2(R-0-R)/1C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3YC24	YELLOW/2(R-0-R)/1C/LED 24V	S16SRS-L3YC24, YELLOW/2(R-0-R)/1C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3YC5	YELLOW/2(R-0-R)/1C/LED 5V	S16SRS-L3YC5, YELLOW/2(R-0-R)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4B		S16SRS-L4B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4B2C12	BLUE/2(S-0-S)/2C/LED 12V	S16SRS-L4B2C12, BLUE/2(S-0-S)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4B2C24	BLUE/2(S-0-S)/2C/LED 24V	S16SRS-L4B2C24, BLUE/2(S-0-S)/2C/LED 24V, GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4B2C5	BLUE/2(S-0-S)/2C/LED 5V	S16SRS-L4B2C5, BLUE/2(S-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4BC12	BLUE/2(S-0-S)/1C/LED 12V	S16SRS-L4BC12, BLUE/2(S-0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4BC24	BLUE/2(S-0-S)/1C/LED 24V	S16SRS-L4BC24, BLUE/2(S-0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4BC5	BLUE/2(S-0-S)/1C/LED 5V	S16SRS-L4BC5, BLUE/2(S-0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4G		S16SRS-L4G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4G2C12	GREEN/2(S-0-S)/2C/LED 12V	S16SRS-L4G2C12, GREEN/2(S-0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4G2C24	GREEN/2(S-0-S)/2C/LED 24V	S16SRS-L4G2C24, GREEN/2(S-0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4G2C5	GREEN/2(S-0-S)/2C/LED 5V	S16SRS-L4G2C5, GREEN/2(S-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4W		S16SRS-L4W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4W2C12	WHITE/2(S-0-S)/2C/LED 12V	S16SRS-L4W2C12, WHITE/2(S-0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4W2C24	WHITE/2(S-0-S)/2C/LED 24V	S16SRS-L4W2C24, WHITE/2(S-0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4W2C5	WHITE/2(S-0-S)/2C/LED 5V	S16SRS-L4W2C5, WHITE/2(S-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4WC12	WHITE/2(S-0-S)/1C/LED 12V	S16SRS-L4WC12, WHITE/2(S-0-S)/1C/LED 12V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4WC24	WHITE/2(S-0-S)/1C/LED 24V	S16SRS-L4WC24, WHITE/2(S-0-S)/1C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4WC5	WHITE/2(S-0-S)/1C/LED 5V	S16SRS-L4WC5, WHITE/2(S-0-S)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4Y		S16SRS-L4Y, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4Y2C12	YELLOW/2(S-0-S)/2C/LED 12V	S16SRS-L4Y2C12, YELLOW/2(S-0-S)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4Y2C24	YELLOW/2(S-0-S)/2C/LED 24V	S16SRS-L4Y2C24, YELLOW/2(S-0-S)/2C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4Y2C5	YELLOW/2(S-0-S)/2C/LED 5V	S16SRS-L4Y2C5, YELLOW/2(S-0-S)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4YC12	YELLOW/2(S-0-S)/1C/LED 12V	S16SRS-L4YC12, YELLOW/2(S-0-S)/1C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4YC24	YELLOW/2(S-0-S)/1C/LED 24V	S16SRS-L4YC24, YELLOW/2(S-0-S)/1C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4YC5	YELLOW/2(S-0-S)/1C/LED 5V	S16SRS-L4YC5, YELLOW/2(S-0-S)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5B		S16SRS-L5B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5B2C12	BLUE/2(S-0-R)/2C/LED 12V	S16SRS-L5B2C12, BLUE/2(S-0-R)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5B2C24	BLUE/2(S-0-R)/2C/LED 24V	S16SRS-L5B2C24, BLUE/2(S-0-R)/2C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5B2C5	BLUE/2(S-0-R)/2C/LED 5V	S16SRS-L5B2C5, BLUE/2(S-0-R)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5BC12	BLUE/2(S-0-R)/1C/LED 12V	S16SRS-L5BC12, BLUE/2(S-0-R)/1C/LED 12V, GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5BC24	BLUE/2(S-0-R)/1C/LED 24V	S16SRS-L5BC24, BLUE/2(S-0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5BC5	BLUE/2(S-0-R)/1C/LED 5V	S16SRS-L5BC5, BLUE/2(S-0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5G		S16SRS-L5G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5G2C12	GREEN/2(S-0-R)/2C/LED 12V	S16SRS-L5G2C12, GREEN/2(S-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5G2C24	GREEN/2(S-0-R)/2C/LED 24V	S16SRS-L5G2C24, GREEN/2(S-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5G2C5	GREEN/2(S-0-R)/2C/LED 5V	S16SRS-L5G2C5, GREEN/2(S-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5W		S16SRS-L5W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5W2C12	WHITE/2(S-0-R)/2C/LED 12V	S16SRS-L5W2C12, WHITE/2(S-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5W2C24	WHITE/2(S-0-R)/2C/LED 24V	S16SRS-L5W2C24, WHITE/2(S-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5W2C5	WHITE/2(S-0-R)/2C/LED 5V	S16SRS-L5W2C5, WHITE/2(S-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5WC12	WHITE/2(S-0-R)/1C/LED 12V	S16SRS-L5WC12, WHITE/2(S-0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5WC24	WHITE/2(S-0-R)/1C/LED 24V	S16SRS-L5WC24, WHITE/2(S-0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5WC5	WHITE/2(S-0-R)/1C/LED 5V	S16SRS-L5WC5, WHITE/2(S-0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5Y		S16SRS-L5Y, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5Y2C12	YELLOW/2(S-0-R)/2C/LED 12V	S16SRS-L5Y2C12, YELLOW/2(S-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5Y2C24	YELLOW/2(S-0-R)/2C/LED 24V	S16SRS-L5Y2C24, YELLOW/2(S-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5Y2C5	YELLOW/2(S-0-R)/2C/LED 5V	S16SRS-L5Y2C5, YELLOW/2(S-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5YC12	YELLOW/2(S-0-R)/1C/LED 12V	S16SRS-L5YC12, YELLOW/2(S-0-R)/1C/LED 12V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5YC24	YELLOW/2(S-0-R)/1C/LED 24V	S16SRS-L5YC24, YELLOW/2(S-0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5YC5	YELLOW/2(S-0-R)/1C/LED 5V	S16SRS-L5YC5, YELLOW/2(S-0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6B		S16SRS-L6B, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6B2C12	BLUE/2(R-0-S)/2C/LED 12V	S16SRS-L6B2C12, BLUE/2(R-0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6B2C24	BLUE/2(R-0-S)/2C/LED 24V	S16SRS-L6B2C24, BLUE/2(R-0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6B2C5	BLUE/2(R-0-S)/2C/LED 5V	S16SRS-L6B2C5, BLUE/2(R-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6BC12	BLUE/2(R-0-S)/1C/LED 12V	S16SRS-L6BC12, BLUE/2(R-0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6BC24	BLUE/2(R-0-S)/1C/LED 24V	S16SRS-L6BC24, BLUE/2(R-0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6BC5	BLUE/2(R-0-S)/1C/LED 5V	S16SRS-L6BC5, BLUE/2(R-0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6G		S16SRS-L6G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6G2C12	GREEN/2(R-0-S)/2C/LED 12V	S16SRS-L6G2C12, GREEN/2(R-0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6G2C24	GREEN/2(R-0-S)/2C/LED 24V	S16SRS-L6G2C24, GREEN/2(R-0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6G2C5	GREEN/2(R-0-S)/2C/LED 5V	S16SRS-L6G2C5, GREEN/2(R-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6W		S16SRS-L6W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6W2C12	WHITE/2(R-0-S)/2C/LED 12V	S16SRS-L6W2C12, WHITE/2(R-0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6W2C24	WHITE/2(R-0-S)/2C/LED 24V	S16SRS-L6W2C24, WHITE/2(R-0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6W2C5	WHITE/2(R-0-S)/2C/LED 5V	S16SRS-L6W2C5, WHITE/2(R-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6WC12	WHITE/2(R-0-S)/1C/LED 12V	S16SRS-L6WC12, WHITE/2(R-0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6WC24	WHITE/2(R-0-S)/1C/LED 24V	S16SRS-L6WC24, WHITE/2(R-0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6WC5	WHITE/2(R-0-S)/1C/LED 5V	S16SRS-L6WC5, WHITE/2(R-0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6Y		S16SRS-L6Y, , GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6Y2C12	YELLOW/2(R-0-S)/2C/LED 12V	S16SRS-L6Y2C12, YELLOW/2(R-0-S)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6Y2C24	YELLOW/2(R-0-S)/2C/LED 24V	S16SRS-L6Y2C24, YELLOW/2(R-0-S)/2C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6Y2C5	YELLOW/2(R-0-S)/2C/LED 5V	S16SRS-L6Y2C5, YELLOW/2(R-0-S)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6YC12	YELLOW/2(R-0-S)/1C/LED 12V	S16SRS-L6YC12, YELLOW/2(R-0-S)/1C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6YC24	YELLOW/2(R-0-S)/1C/LED 24V	S16SRS-L6YC24, YELLOW/2(R-0-S)/1C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6YC5	YELLOW/2(R-0-S)/1C/LED 5V	S16SRS-L6YC5, YELLOW/2(R-0-S)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1B		S16SRS-S1B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1B2C	BLUE/2(0-R)/2C	S16SRS-S1B2C, BLUE/2(0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1B3C	BLUE/2(0-R)/3C	S16SRS-S1B3C, BLUE/2(0-R)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1BC	BLUE/2(0-R)/1C	S16SRS-S1BC, BLUE/2(0-R)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1G		S16SRS-S1G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1G2C	GREEN/2(0-R)/2C	S16SRS-S1G2C, GREEN/2(0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1G3C	GREEN/2(0-R)/3C	S16SRS-S1G3C, GREEN/2(0-R)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1W		S16SRS-S1W, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1W2C	WHITE/2(0-R)/2C	S16SRS-S1W2C, WHITE/2(0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1W3C	WHITE/2(0-R)/3C	S16SRS-S1W3C, WHITE/2(0-R)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1WC	WHITE/2(0-R)/1C	S16SRS-S1WC, WHITE/2(0-R)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1Y		S16SRS-S1Y, , GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1Y2C	YELLOW/2(0-R)/2C	S16SRS-S1Y2C, YELLOW/2(0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1Y3C	YELLOW/2(0-R)/3C	S16SRS-S1Y3C, YELLOW/2(0-R)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1YC	YELLOW/2(0-R)/1C	S16SRS-S1YC, YELLOW/2(0-R)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2B		S16SRS-S2B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2B2C	BLUE/2(0-S)/2C	S16SRS-S2B2C, BLUE/2(0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2B3C	BLUE/2(0-S)/3C	S16SRS-S2B3C, BLUE/2(0-S)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2BC	BLUE/2(0-S)/1C	S16SRS-S2BC, BLUE/2(0-S)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2G		S16SRS-S2G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2G2C	GREEN/2(0-S)/2C	S16SRS-S2G2C, GREEN/2(0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2G3C	GREEN/2(0-S)/3C	S16SRS-S2G3C, GREEN/2(0-S)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2W		S16SRS-S2W, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2W3C	WHITE/2(0-S)/3C	S16SRS-S2W3C, WHITE/2(0-S)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2WC	WHITE/2(0-S)/1C	S16SRS-S2WC, WHITE/2(0-S)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2Y		S16SRS-S2Y, , GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2Y2C	YELLOW/2(0-S)/2C	S16SRS-S2Y2C, YELLOW/2(0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2Y3C	YELLOW/2(0-S)/3C	S16SRS-S2Y3C, YELLOW/2(0-S)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2YC	YELLOW/2(0-S)/1C	S16SRS-S2YC, YELLOW/2(0-S)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S3B		S16SRS-S3B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S3B2C	BLUE/3(R-0-R)/2C	S16SRS-S3B2C, BLUE/3(R-0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S3G		S16SRS-S3G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S3G2C	GREEN/3(R-0-R)/2C	S16SRS-S3G2C, GREEN/3(R-0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S3W		S16SRS-S3W, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S3W2C	WHITE/3(R-0-R)/2C	S16SRS-S3W2C, WHITE/3(R-0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S3WC	WHITE/3(R-0-R)/1C	S16SRS-S3WC, WHITE/3(R-0-R)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S3Y		S16SRS-S3Y, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S3Y2C	YELLOW/3(R-0-R)/2C	S16SRS-S3Y2C, YELLOW/3(R-0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S4B		S16SRS-S4B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S4B2C	BLUE/3(S-0-S)/2C	S16SRS-S4B2C, BLUE/3(S-0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S4G		S16SRS-S4G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S4G2C	GREEN/3(S-0-S)/2C	S16SRS-S4G2C, GREEN/3(S-0-S)/2C, GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S4W		S16SRS-S4W , , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S4WC	WHITE/3(S-0-S)/1C	S16SRS-S4WC, WHITE/3(S-0-S)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S4Y		S16SRS-S4Y , , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S4Y2C	YELLOW/3(S-0-S)/2C	S16SRS-S4Y2C, YELLOW/3(S-0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S5B		S16SRS-S5B , , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S5B2C	BLUE/3(S-0-R)/2C	S16SRS-S5B2C, BLUE/3(S-0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S5G		S16SRS-S5G , , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S5G2C	GREEN/3(S-0-R)/2C	S16SRS-S5G2C, GREEN/3(S-0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S5W		S16SRS-S5W , , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S5W2C	WHITE/3(S-0-R)/2C	S16SRS-S5W2C, WHITE/3(S-0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S5WC	WHITE/3(S-0-R)/1C	S16SRS-S5WC, WHITE/3(S-0-R)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S5Y		S16SRS-S5Y , , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S5Y2C	YELLOW/3(S-0-R)/2C	S16SRS-S5Y2C, YELLOW/3(S-0-R)/2C, GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S6B		S16SRS-S6B, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S6B2C	BLUE/3(R-0-S)/2C	S16SRS-S6B2C, BLUE/3(R-0-S)/2C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S6G		S16SRS-S6G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S6G2C	GREEN/3(R-0-S)/2C	S16SRS-S6G2C, GREEN/3(R-0-S)/2C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S6W		S16SRS-S6W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S6W2C	WHITE/3(R-0-S)/2C	S16SRS-S6W2C, WHITE/3(R-0-S)/2C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S6WC	WHITE/3(R-0-S)/1C	S16SRS-S6WC, WHITE/3(R-0-S)/1C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S6Y		S16SRS-S6Y, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S6Y2C	YELLOW/3(R-0-S)/2C	S16SRS-S6Y2C, YELLOW/3(R-0-S)/2C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1B		S16SRT-L1B, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1B2C12	BLUE/2(0-R)/2C/LED 12V	S16SRT-L1B2C12, BLUE/2(0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1B2C24	BLUE/2(0-R)/2C/LED 24V	S16SRT-L1B2C24, BLUE/2(0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1B2C5	BLUE/2(0-R)/2C/LED 5V	S16SRT-L1B2C5, BLUE/2(0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1BC12	BLUE/2(0-R)/1C/LED 12V	S16SRT-L1BC12, BLUE/2(0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1BC24	BLUE/2(0-R)/1C/LED 24V	S16SRT-L1BC24, BLUE/2(0-R)/1C/LED 24V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1BC5	BLUE/2(0-R)/1C/LED 5V	S16SRT-L1BC5, BLUE/2(0-R)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1G		S16SRT-L1G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1G2C12	GREEN/2(0-R)/2C/LED 12V	S16SRT-L1G2C12, GREEN/2(0-R)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1G2C24	GREEN/2(0-R)/2C/LED 24V	S16SRT-L1G2C24, GREEN/2(0-R)/2C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1G2C5	GREEN/2(0-R)/2C/LED 5V	S16SRT-L1G2C5, GREEN/2(0-R)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1W		S16SRT-L1W, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1W2C12	WHITE/2(0-R)/2C/LED 12V	S16SRT-L1W2C12, WHITE/2(0-R)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1W2C24	WHITE/2(0-R)/2C/LED 24V	S16SRT-L1W2C24, WHITE/2(0-R)/2C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1W2C5	WHITE/2(0-R)/2C/LED 5V	S16SRT-L1W2C5, WHITE/2(0-R)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1WC12	WHITE/2(0-R)/1C/LED 12V	S16SRT-L1WC12, WHITE/2(0-R)/1C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1WC24	WHITE/2(0-R)/1C/LED 24V	S16SRT-L1WC24, WHITE/2(0-R)/1C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1WC5	WHITE/2(0-R)/1C/LED 5V	S16SRT-L1WC5, WHITE/2(0-R)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1Y		S16SRT-L1Y, , GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1Y2C12	YELLOW/2(0-R)/2C/LED 12V	S16SRT-L1Y2C12, YELLOW/2(0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1Y2C24	YELLOW/2(0-R)/2C/LED 24V	S16SRT-L1Y2C24, YELLOW/2(0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1Y2C5	YELLOW/2(0-R)/2C/LED 5V	S16SRT-L1Y2C5, YELLOW/2(0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1YC12	YELLOW/2(0-R)/1C/LED 12V	S16SRT-L1YC12, YELLOW/2(0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1YC24	YELLOW/2(0-R)/1C/LED 24V	S16SRT-L1YC24, YELLOW/2(0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1YC5	YELLOW/2(0-R)/1C/LED 5V	S16SRT-L1YC5, YELLOW/2(0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2B		S16SRT-L2B, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2B2C12	BLUE/2(0-S)/2C/LED 12V	S16SRT-L2B2C12, BLUE/2(0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2B2C24	BLUE/2(0-S)/2C/LED 24V	S16SRT-L2B2C24, BLUE/2(0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2B2C5	BLUE/2(0-S)/2C/LED 5V	S16SRT-L2B2C5, BLUE/2(0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2BC12	BLUE/2(0-S)/1C/LED 12V	S16SRT-L2BC12, BLUE/2(0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2BC24	BLUE/2(0-S)/1C/LED 24V	S16SRT-L2BC24, BLUE/2(0-S)/1C/LED 24V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2BC5	BLUE/2(0-S)/1C/LED 5V	S16SRT-L2BC5, BLUE/2(0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2G		S16SRT-L2G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2G2C12	GREEN/2(0-S)/2C/LED 12V	S16SRT-L2G2C12, GREEN/2(0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2G2C24	GREEN/2(0-S)/2C/LED 24V	S16SRT-L2G2C24, GREEN/2(0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2G2C5	GREEN/2(0-S)/2C/LED 5V	S16SRT-L2G2C5, GREEN/2(0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2W		S16SRT-L2W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2W2C12	WHITE/2(0-S)/2C/LED 12V	S16SRT-L2W2C12, WHITE/2(0-S)/2C/LED 12V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2W2C24	WHITE/2(0-S)/2C/LED 24V	S16SRT-L2W2C24, WHITE/2(0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2W2C5	WHITE/2(0-S)/2C/LED 5V	S16SRT-L2W2C5, WHITE/2(0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2WC12	WHITE/2(0-S)/1C/LED 12V	S16SRT-L2WC12, WHITE/2(0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2WC24	WHITE/2(0-S)/1C/LED 24V	S16SRT-L2WC24, WHITE/2(0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2WC5	WHITE/2(0-S)/1C/LED 5V	S16SRT-L2WC5, WHITE/2(0-S)/1C/LED 5V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2Y		S16SRT-L2Y, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2Y2C12	YELLOW/2(0-S)/2C/LED 12V	S16SRT-L2Y2C12, YELLOW/2(0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2Y2C24	YELLOW/2(0-S)/2C/LED 24V	S16SRT-L2Y2C24, YELLOW/2(0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2Y2C5	YELLOW/2(0-S)/2C/LED 5V	S16SRT-L2Y2C5, YELLOW/2(0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2YC12	YELLOW/2(0-S)/1C/LED 12V	S16SRT-L2YC12, YELLOW/2(0-S)/1C/LED 12V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2YC24	YELLOW/2(0-S)/1C/LED 24V	S16SRT-L2YC24, YELLOW/2(0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2YC5	YELLOW/2(0-S)/1C/LED 5V	S16SRT-L2YC5, YELLOW/2(0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3B		S16SRT-L3B, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3B2C12	BLUE/2(R-0-R)/2C/LED 12V	S16SRT-L3B2C12, BLUE/2(R-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3B2C24	BLUE/2(R-0-R)/2C/LED 24V	S16SRT-L3B2C24, BLUE/2(R-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3B2C5	BLUE/2(R-0-R)/2C/LED 5V	S16SRT-L3B2C5, BLUE/2(R-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3BC12	BLUE/2(R-0-R)/1C/LED 12V	S16SRT-L3BC12, BLUE/2(R-0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3BC24	BLUE/2(R-0-R)/1C/LED 24V	S16SRT-L3BC24, BLUE/2(R-0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3BC5	BLUE/2(R-0-R)/1C/LED 5V	S16SRT-L3BC5, BLUE/2(R-0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3G		S16SRT-L3G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3G2C12	GREEN/2(R-0-R)/2C/LED 12V	S16SRT-L3G2C12, GREEN/2(R-0-R)/2C/LED 12V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3G2C24	GREEN/2(R-0-R)/2C/LED 24V	S16SRT-L3G2C24, GREEN/2(R-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3G2C5	GREEN/2(R-0-R)/2C/LED 5V	S16SRT-L3G2C5, GREEN/2(R-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3W		S16SRT-L3W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3W2C12	WHITE/2(R-0-R)/2C/LED 12V	S16SRT-L3W2C12, WHITE/2(R-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3W2C24	WHITE/2(R-0-R)/2C/LED 24V	S16SRT-L3W2C24, WHITE/2(R-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3W2C5	WHITE/2(R-0-R)/2C/LED 5V	S16SRT-L3W2C5, WHITE/2(R-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3WC12	WHITE/2(R-0-R)/1C/LED 12V	S16SRT-L3WC12, WHITE/2(R-0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3WC24	WHITE/2(R-0-R)/1C/LED 24V	S16SRT-L3WC24, WHITE/2(R-0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3WC5	WHITE/2(R-0-R)/1C/LED 5V	S16SRT-L3WC5, WHITE/2(R-0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3Y		S16SRT-L3Y, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3Y2C12	YELLOW/2(R-0-R)/2C/LED 12V	S16SRT-L3Y2C12, YELLOW/2(R-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3Y2C24	YELLOW/2(R-0-R)/2C/LED 24V	S16SRT-L3Y2C24, YELLOW/2(R-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3Y2C5	YELLOW/2(R-0-R)/2C/LED 5V	S16SRT-L3Y2C5, YELLOW/2(R-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3YC12	YELLOW/2(R-0-R)/1C/LED 12V	S16SRT-L3YC12, YELLOW/2(R-0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3YC24	YELLOW/2(R-0-R)/1C/LED 24V	S16SRT-L3YC24, YELLOW/2(R-0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3YC5	YELLOW/2(R-0-R)/1C/LED 5V	S16SRT-L3YC5, YELLOW/2(R-0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4B		S16SRT-L4B, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4B2C12	BLUE/2(S-0-S)/2C/LED 12V	S16SRT-L4B2C12, BLUE/2(S-0-S)/2C/LED 12V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4B2C24	BLUE/2(S-0-S)/2C/LED 24V	S16SRT-L4B2C24, BLUE/2(S-0-S)/2C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4B2C5	BLUE/2(S-0-S)/2C/LED 5V	S16SRT-L4B2C5, BLUE/2(S-0-S)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4BC12	BLUE/2(S-0-S)/1C/LED 12V	S16SRT-L4BC12, BLUE/2(S-0-S)/1C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4BC24	BLUE/2(S-0-S)/1C/LED 24V	S16SRT-L4BC24, BLUE/2(S-0-S)/1C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4BC5	BLUE/2(S-0-S)/1C/LED 5V	S16SRT-L4BC5, BLUE/2(S-0-S)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4G		S16SRT-L4G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4G2C12	GREEN/2(S-0-S)/2C/LED 12V	S16SRT-L4G2C12, GREEN/2(S-0-S)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4G2C24	GREEN/2(S-0-S)/2C/LED 24V	S16SRT-L4G2C24, GREEN/2(S-0-S)/2C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4G2C5	GREEN/2(S-0-S)/2C/LED 5V	S16SRT-L4G2C5, GREEN/2(S-0-S)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4W		S16SRT-L4W, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4W2C12	WHITE/2(S-0-S)/2C/LED 12V	S16SRT-L4W2C12, WHITE/2(S-0-S)/2C/LED 12V, GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4W2C24	WHITE/2(S-0-S)/2C/LED 24V	S16SRT-L4W2C24, WHITE/2(S-0-S)/2C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4W2C5	WHITE/2(S-0-S)/2C/LED 5V	S16SRT-L4W2C5, WHITE/2(S-0-S)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4WC12	WHITE/2(S-0-S)/1C/LED 12V	S16SRT-L4WC12, WHITE/2(S-0-S)/1C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4WC24	WHITE/2(S-0-S)/1C/LED 24V	S16SRT-L4WC24, WHITE/2(S-0-S)/1C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4WC5	WHITE/2(S-0-S)/1C/LED 5V	S16SRT-L4WC5, WHITE/2(S-0-S)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4Y		S16SRT-L4Y, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4Y2C12	YELLOW/2(S-0-S)/2C/LED 12V	S16SRT-L4Y2C12, YELLOW/2(S-0-S)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4Y2C24	YELLOW/2(S-0-S)/2C/LED 24V	S16SRT-L4Y2C24, YELLOW/2(S-0-S)/2C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4Y2C5	YELLOW/2(S-0-S)/2C/LED 5V	S16SRT-L4Y2C5, YELLOW/2(S-0-S)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4YC12	YELLOW/2(S-0-S)/1C/LED 12V	S16SRT-L4YC12, YELLOW/2(S-0-S)/1C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4YC24	YELLOW/2(S-0-S)/1C/LED 24V	S16SRT-L4YC24, YELLOW/2(S-0-S)/1C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4YC5	YELLOW/2(S-0-S)/1C/LED 5V	S16SRT-L4YC5, YELLOW/2(S-0-S)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5B		S16SRT-L5B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5B2C12	BLUE/2(S-0-R)/2C/LED 12V	S16SRT-L5B2C12, BLUE/2(S-0-R)/2C/LED 12V, GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5B2C24	BLUE/2(S-0-R)/2C/LED 24V	S16SRT-L5B2C24, BLUE/2(S-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5B2C5	BLUE/2(S-0-R)/2C/LED 5V	S16SRT-L5B2C5, BLUE/2(S-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5BC12	BLUE/2(S-0-R)/1C/LED 12V	S16SRT-L5BC12, BLUE/2(S-0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5BC24	BLUE/2(S-0-R)/1C/LED 24V	S16SRT-L5BC24, BLUE/2(S-0-R)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5BC5	BLUE/2(S-0-R)/1C/LED 5V	S16SRT-L5BC5, BLUE/2(S-0-R)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5G		S16SRT-L5G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5G2C12	GREEN/2(S-0-R)/2C/LED 12V	S16SRT-L5G2C12, GREEN/2(S-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5G2C24	GREEN/2(S-0-R)/2C/LED 24V	S16SRT-L5G2C24, GREEN/2(S-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5G2C5	GREEN/2(S-0-R)/2C/LED 5V	S16SRT-L5G2C5, GREEN/2(S-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5W		S16SRT-L5W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5W2C12	WHITE/2(S-0-R)/2C/LED 12V	S16SRT-L5W2C12, WHITE/2(S-0-R)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5W2C24	WHITE/2(S-0-R)/2C/LED 24V	S16SRT-L5W2C24, WHITE/2(S-0-R)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5W2C5	WHITE/2(S-0-R)/2C/LED 5V	S16SRT-L5W2C5, WHITE/2(S-0-R)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5WC12	WHITE/2(S-0-R)/1C/LED 12V	S16SRT-L5WC12, WHITE/2(S-0-R)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5WC24	WHITE/2(S-0-R)/1C/LED 24V	S16SRT-L5WC24, WHITE/2(S-0-R)/1C/LED 24V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5WC5	WHITE/2(S-0-R)/1C/LED 5V	S16SRT-L5WC5, WHITE/2(S-0-R)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5Y		S16SRT-L5Y, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5Y2C12	YELLOW/2(S-0-R)/2C/LED 12V	S16SRT-L5Y2C12, YELLOW/2(S-0-R)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5Y2C24	YELLOW/2(S-0-R)/2C/LED 24V	S16SRT-L5Y2C24, YELLOW/2(S-0-R)/2C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5Y2C5	YELLOW/2(S-0-R)/2C/LED 5V	S16SRT-L5Y2C5, YELLOW/2(S-0-R)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5YC12	YELLOW/2(S-0-R)/1C/LED 12V	S16SRT-L5YC12, YELLOW/2(S-0-R)/1C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5YC24	YELLOW/2(S-0-R)/1C/LED 24V	S16SRT-L5YC24, YELLOW/2(S-0-R)/1C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5YC5	YELLOW/2(S-0-R)/1C/LED 5V	S16SRT-L5YC5, YELLOW/2(S-0-R)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6B		S16SRT-L6B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6B2C12	BLUE/2(R-0-S)/2C/LED 12V	S16SRT-L6B2C12, BLUE/2(R-0-S)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6B2C24	BLUE/2(R-0-S)/2C/LED 24V	S16SRT-L6B2C24, BLUE/2(R-0-S)/2C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6B2C5	BLUE/2(R-0-S)/2C/LED 5V	S16SRT-L6B2C5, BLUE/2(R-0-S)/2C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6BC12	BLUE/2(R-0-S)/1C/LED 12V	S16SRT-L6BC12, BLUE/2(R-0-S)/1C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6BC24	BLUE/2(R-0-S)/1C/LED 24V	S16SRT-L6BC24, BLUE/2(R-0-S)/1C/LED 24V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6BC5	BLUE/2(R-0-S)/1C/LED 5V	S16SRT-L6BC5, BLUE/2(R-0-S)/1C/LED 5V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6G		S16SRT-L6G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6G2C12	GREEN/2(R-0-S)/2C/LED 12V	S16SRT-L6G2C12, GREEN/2(R-0-S)/2C/LED 12V, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6G2C24	GREEN/2(R-0-S)/2C/LED 24V	S16SRT-L6G2C24, GREEN/2(R-0-S)/2C/LED 24V, GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6G2C5	GREEN/2(R-0-S)/2C/LED 5V	S16SRT-L6G2C5, GREEN/2(R-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6W		S16SRT-L6W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6W2C12	WHITE/2(R-0-S)/2C/LED 12V	S16SRT-L6W2C12, WHITE/2(R-0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6W2C24	WHITE/2(R-0-S)/2C/LED 24V	S16SRT-L6W2C24, WHITE/2(R-0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6W2C5	WHITE/2(R-0-S)/2C/LED 5V	S16SRT-L6W2C5, WHITE/2(R-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6WC12	WHITE/2(R-0-S)/1C/LED 12V	S16SRT-L6WC12, WHITE/2(R-0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6WC24	WHITE/2(R-0-S)/1C/LED 24V	S16SRT-L6WC24, WHITE/2(R-0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6WC5	WHITE/2(R-0-S)/1C/LED 5V	S16SRT-L6WC5, WHITE/2(R-0-S)/1C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6Y		S16SRT-L6Y, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6Y2C12	YELLOW/2(R-0-S)/2C/LED 12V	S16SRT-L6Y2C12, YELLOW/2(R-0-S)/2C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6Y2C24	YELLOW/2(R-0-S)/2C/LED 24V	S16SRT-L6Y2C24, YELLOW/2(R-0-S)/2C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6Y2C5	YELLOW/2(R-0-S)/2C/LED 5V	S16SRT-L6Y2C5, YELLOW/2(R-0-S)/2C/LED 5V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6YC12	YELLOW/2(R-0-S)/1C/LED 12V	S16SRT-L6YC12, YELLOW/2(R-0-S)/1C/LED 12V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6YC24	YELLOW/2(R-0-S)/1C/LED 24V	S16SRT-L6YC24, YELLOW/2(R-0-S)/1C/LED 24V, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6YC5	YELLOW/2(R-0-S)/1C/LED 5V	S16SRT-L6YC5, YELLOW/2(R-0-S)/1C/LED 5V, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1B		S16SRT-S1B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1B2C	BLUE/2(0-R)/2C	S16SRT-S1B2C, BLUE/2(0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1B3C	BLUE/2(0-R)/3C	S16SRT-S1B3C, BLUE/2(0-R)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1BC	BLUE/2(0-R)/1C	S16SRT-S1BC, BLUE/2(0-R)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1G		S16SRT-S1G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1G2C	GREEN/2(0-R)/2C	S16SRT-S1G2C, GREEN/2(0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1G3C	GREEN/2(0-R)/3C	S16SRT-S1G3C, GREEN/2(0-R)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1W		S16SRT-S1W, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1W2C	WHITE/2(0-R)/2C	S16SRT-S1W2C, WHITE/2(0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1W3C	WHITE/2(0-R)/3C	S16SRT-S1W3C, WHITE/2(0-R)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1WC	WHITE/2(0-R)/1C	S16SRT-S1WC, WHITE/2(0-R)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1Y		S16SRT-S1Y, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1Y2C	YELLOW/2(0-R)/2C	S16SRT-S1Y2C, YELLOW/2(0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1Y3C	YELLOW/2(0-R)/3C	S16SRT-S1Y3C, YELLOW/2(0-R)/3C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1YC	YELLOW/2(0-R)/1C	S16SRT-S1YC, YELLOW/2(0-R)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2B		S16SRT-S2B, , GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2B2C	BLUE/2(0-S)/2C	S16SRT-S2B2C, BLUE/2(0-S)/2C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2B3C	BLUE/2(0-S)/3C	S16SRT-S2B3C, BLUE/2(0-S)/3C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2BC	BLUE/2(0-S)/1C	S16SRT-S2BC, BLUE/2(0-S)/1C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2G		S16SRT-S2G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2G2C	GREEN/2(0-S)/2C	S16SRT-S2G2C, GREEN/2(0-S)/2C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2G3C	GREEN/2(0-S)/3C	S16SRT-S2G3C, GREEN/2(0-S)/3C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2W		S16SRT-S2W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2W3C	WHITE/2(0-S)/3C	S16SRT-S2W3C, WHITE/2(0-S)/3C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2Y		S16SRT-S2Y, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2Y2C	YELLOW/2(0-S)/2C	S16SRT-S2Y2C, YELLOW/2(0-S)/2C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2Y3C	YELLOW/2(0-S)/3C	S16SRT-S2Y3C, YELLOW/2(0-S)/3C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2YC	YELLOW/2(0-S)/1C	S16SRT-S2YC, YELLOW/2(0-S)/1C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S3B		S16SRT-S3B, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S3B2C	BLUE/3(R-0-R)/2C	S16SRT-S3B2C, BLUE/3(R-0-R)/2C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S3G		S16SRT-S3G, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S3G2C	GREEN/3(R-0-R)/2C	S16SRT-S3G2C, GREEN/3(R-0-R)/2C, GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S3W		S16SRT-S3W, , GL
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S3W2C	WHITE/3(R-0-R)/2C	S16SRT-S3W2C, WHITE/3(R-0-R)/2C, GL

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S3WC	WHITE/3(R-0-R)/1C	S16SRT-S3WC, WHITE/3(R-0-R)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S3Y		S16SRT-S3Y, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S3Y2C	YELLOW/3(R-0-R)/2C	S16SRT-S3Y2C, YELLOW/3(R-0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S4B		S16SRT-S4B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S4B2C	BLUE/3(S-0-S)/2C	S16SRT-S4B2C, BLUE/3(S-0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S4G		S16SRT-S4G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S4G2C	GREEN/3(S-0-S)/2C	S16SRT-S4G2C, GREEN/3(S-0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S4W		S16SRT-S4W, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S4Y		S16SRT-S4Y, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S4Y2C	YELLOW/3(S-0-S)/2C	S16SRT-S4Y2C, YELLOW/3(S-0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S5B		S16SRT-S5B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S5B2C	BLUE/3(S-0-R)/2C	S16SRT-S5B2C, BLUE/3(S-0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S5G		S16SRT-S5G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S5G2C	GREEN/3(S-0-R)/2C	S16SRT-S5G2C, GREEN/3(S-0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S5W		S16SRT-S5W, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S5W2C	WHITE/3(S-0-R)/2C	S16SRT-S5W2C, WHITE/3(S-0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S5WC	WHITE/3(S-0-R)/1C	S16SRT-S5WC, WHITE/3(S-0-R)/1C, GL	

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S5Y		S16SRT-S5Y, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S5Y2C	YELLOW/3(S-0-R)/2C	S16SRT-S5Y2C, YELLOW/3(S-0-R)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S6B		S16SRT-S6B, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S6B2C	BLUE/3(R-0-S)/2C	S16SRT-S6B2C, BLUE/3(R-0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S6G		S16SRT-S6G, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S6G2C	GREEN/3(R-0-S)/2C	S16SRT-S6G2C, GREEN/3(R-0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S6W		S16SRT-S6W, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S6W2C	WHITE/3(R-0-S)/2C	S16SRT-S6W2C, WHITE/3(R-0-S)/2C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S6WC	WHITE/3(R-0-S)/1C	S16SRT-S6WC, WHITE/3(R-0-S)/1C, GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S6Y		S16SRT-S6Y, , GL	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S6Y2C	YELLOW/3(R-0-S)/2C	S16SRT-S6Y2C, YELLOW/3(R-0-S)/2C, GL	
CONTROL SWITCH	EMERGENCY SWITCH	S16ER SERIES	S16ER-E1R2B	CONTACT BLOCK(B) 2EA	S16ER-E1R2B, CONTACT BLOCK(B) 2EA,	
CONTROL SWITCH	EMERGENCY SWITCH	S16ER SERIES	S16ER-E1RB	CONTACT BLOCK(B) 1EA	S16ER-E1RB, CONTACT BLOCK(B) 1EA,	Аварийный выключатель, позиция:Ø16,блокировка нажатием, сброс поворотом/вытаскиванием, С подсветкой:D30 (с короткой кнопкой, без подсветки),красный, Блок контактов: контакт: B:1
CONTROL SWITCH	EMERGENCY SWITCH	S16ER SERIES	S16ER-E3R		S16ER-E3R, ,	
CONTROL SWITCH	EMERGENCY SWITCH	S16ER SERIES	S16ER-E3R2B24	(LED24 VAC/DC)	S16ER-E3R2B24, (LED24 VAC/DC), CONTACT BLOCK(B)2EA	

CONTROL SWITCH	EMERGENCY SWITCH	S16ER SERIES	S16ER-E3RB12	(LED12 VAC/DC)C-BLOCK(B) 1EA	S16ER-E3RB12, (LED12 VAC/DC)C-BLOCK(B) 1EA,	
CONTROL SWITCH	EMERGENCY SWITCH	S16ER SERIES	S16ER-E3RB24	(LED24 VAC/DC)C-BLOCK(B) 1EA	S16ER-E3RB24, (LED24 VAC/DC)C-BLOCK(B) 1EA,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-1AK		S16KR-1AK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-1AK2C	2(0-R)/L/2C	S16KR-1AK2C, 2(0-R)/L/2C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-1AK3C	2(0-R)/L/3C	S16KR-1AK3C, 2(0-R)/L/3C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-1AKC	2(0-R)/L/1C	S16KR-1AKC, 2(0-R)/L/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-2AK		S16KR-2AK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-2AK2C	2(0-S)/L/2C	S16KR-2AK2C, 2(0-S)/L/2C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-2AK3C	2(0-S)/L/3C	S16KR-2AK3C, 2(0-S)/L/3C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-2AKC	2(0-S)/L/1C	S16KR-2AKC, 2(0-S)/L/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-2BK		S16KR-2BK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-2BK2C	2(0-S)/L+R/2C	S16KR-2BK2C, 2(0-S)/L+R/2C,	Селекторный переключатель с ключом, круглые, позиция: Ø16, рабочее положение: 2-х позиционный, без возврата, положение извлечения ключа: лев.+прав., черный, блок контактов: контакт C:2
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-2BK3C	2(0-S)/L+R/3C	S16KR-2BK3C, 2(0-S)/L+R/3C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-2BKC	2(0-S)/L+R/1C	S16KR-2BKC, 2(0-S)/L+R/1C,	Селекторный переключатель с ключом, круглые, позиция: Ø16, рабочее положение: 2-х позиционный, без возврата, положение извлечения ключа: лев.+прав., черный, блок контактов: контакт C:1
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-2DK		S16KR-2DK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-2DK2C	2(0-S)/R/2C	S16KR-2DK2C, 2(0-S)/R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-2DK3C	2(0-S)/R/3C	S16KR-2DK3C, 2(0-S)/R/3C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-2DKC	2(0-S)/R/1C	S16KR-2DKC, 2(0-S)/R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-3EK		S16KR-3EK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-3EK2C	2(R-0-R)/C/2C	S16KR-3EK2C, 2(R-0-R)/C/2C,	

CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-3EKC	2(R-0-R)/C/1C	S16KR-3EKC, 2(R-0-R)/C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4AK		S16KR-4AK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4AK2C	2(S-0-S)/L/2C	S16KR-4AK2C, 2(S-0-S)/L/2C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4AKC	2(S-0-S)/L/1C	S16KR-4AKC, 2(S-0-S)/L/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4BK		S16KR-4BK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4BK2C	2(S-0-S)/L+R/2C	S16KR-4BK2C, 2(S-0-S)/L+R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4BKC	2(S-0-S)/L+R/1C	S16KR-4BKC, 2(S-0-S)/L+R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4CK		S16KR-4CK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4CK2C	2(S-0-S)/L+C+R/2C	S16KR-4CK2C, 2(S-0-S)/L+C+R/2C,	Селекторный переключатель с ключом,, круглые, позиция:Ø16, рабочее положение: 3-х позиционный, без возврата, положение извлечения ключа:лев.+центр.+прав., черный, блок контактов: контакт С:2
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4CKC	2(S-0-S)/L+C+R/1C	S16KR-4CKC, 2(S-0-S)/L+C+R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4DK		S16KR-4DK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4DK2C	2(S-0-S)/R/2C	S16KR-4DK2C, 2(S-0-S)/R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4DKC	2(S-0-S)/R/1C	S16KR-4DKC, 2(S-0-S)/R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4EK		S16KR-4EK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4EK2C	2(S-0-S)/C/2C	S16KR-4EK2C, 2(S-0-S)/C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4EKC	2(S-0-S)/C/1C	S16KR-4EKC, 2(S-0-S)/C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4FK		S16KR-4FK, ,	

CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4FK2C	2(S-0-S)/C+R/2C	S16KR-4FK2C, 2(S-0-S)/C+R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4FKC	2(S-0-S)/C+R/1C	S16KR-4FKC, 2(S-0-S)/C+R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4GK		S16KR-4GK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4GK2C	2(S-0-S)/L+C/2C	S16KR-4GK2C, 2(S-0-S)/L+C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-4GKC	2(S-0-S)/L+C/1C	S16KR-4GKC, 2(S-0-S)/L+C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-5AK		S16KR-5AK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-5AK2C	2(S-0-R)/L/2C	S16KR-5AK2C, 2(S-0-R)/L/2C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-5AKC	2(S-0-R)/L/1C	S16KR-5AKC, 2(S-0-R)/L/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-5EK		S16KR-5EK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-5EK2C	2(S-0-R)/C/2C	S16KR-5EK2C, 2(S-0-R)/C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-5EKC	2(S-0-R)/C/1C	S16KR-5EKC, 2(S-0-R)/C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-5GK		S16KR-5GK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-5GK2C	2(S-0-R)/L+C/2C	S16KR-5GK2C, 2(S-0-R)/L+C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-5GKC	2(S-0-R)/L+C/1C	S16KR-5GKC, 2(S-0-R)/L+C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-6DK		S16KR-6DK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-6DK2C	2(R-0-S)/R/2C	S16KR-6DK2C, 2(R-0-S)/R/2C,	

CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-6DKC	2(R-0-S)/R/1C	S16KR-6DKC, 2(R-0-S)/R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-6EK		S16KR-6EK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-6EK2C	2(R-0-S)/C/2C	S16KR-6EK2C, 2(R-0-S)/C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-6EKC	2(R-0-S)/C/1C	S16KR-6EKC, 2(R-0-S)/C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-6FK		S16KR-6FK, ,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-6FK2C	2(R-0-S)/C+R/2C	S16KR-6FK2C, 2(R-0-S)/C+R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KR SERIES	S16KR-6FKC	2(R-0-S)/C+R/1C	S16KR-6FKC, 2(R-0-S)/C+R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-1AK		S16KRS-1AK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-1AK2C	2(0-R)/L/2C	S16KRS-1AK2C, 2(0-R)/L/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-1AK3C	2(0-R)/L/3C	S16KRS-1AK3C, 2(0-R)/L/3C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-1AKC	2(0-R)/L/1C	S16KRS-1AKC, 2(0-R)/L/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-2AK		S16KRS-2AK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-2AK2C	2(0-S)/L/2C	S16KRS-2AK2C, 2(0-S)/L/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-2AK3C	2(0-S)/L/3C	S16KRS-2AK3C, 2(0-S)/L/3C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-2AKC	2(0-S)/L/1C	S16KRS-2AKC, 2(0-S)/L/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-2BK		S16KRS-2BK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-2BK2C	2(0-S)/L+R/2C	S16KRS-2BK2C, 2(0-S)/L+R/2C,	Селекторный переключатель с ключом, квадратные, позиция: Ø16, рабочее положение: 2-х позиционный, без возврата, положение извлечения ключа: лев.+ прав., черный, блок контактов: контакт С:2

CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-2BK3C	2(0-S)/L+R/3C	S16KRS-2BK3C, 2(0-S)/L+R/3C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-2BKC	2(0-S)/L+R/1C	S16KRS-2BKC, 2(0-S)/L+R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-2DK		S16KRS-2DK ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-2DK2C	2(0-S)/R/2C	S16KRS-2DK2C, 2(0-S)/R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-2DK3C	2(0-S)/R/3C	S16KRS-2DK3C, 2(0-S)/R/3C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-2DKC	2(0-S)/R/1C	S16KRS-2DKC, 2(0-S)/R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-3EK		S16KRS-3EK ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-3EK2C	2(R-0-R)/C/2C	S16KRS-3EK2C, 2(R-0-R)/C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-3EKC	2(R-0-R)/C/1C	S16KRS-3EKC, 2(R-0-R)/C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4AK		S16KRS-4AK ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4AK2C	2(S-0-S)/L/2C	S16KRS-4AK2C, 2(S-0-S)/L/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4AKC	2(S-0-S)/L/1C	S16KRS-4AKC, 2(S-0-S)/L/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4BK		S16KRS-4BK ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4BK2C	2(S-0-S)/L+R/2C	S16KRS-4BK2C, 2(S-0-S)/L+R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4BKC	2(S-0-S)/L+R/1C	S16KRS-4BKC, 2(S-0-S)/L+R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4CK		S16KRS-4CK ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4CK2C	2(S-0-S)/L+C+R/2C	S16KRS-4CK2C, 2(S-0-S)/L+C+R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4CKC	2(S-0-S)/L+C+R/1C	S16KRS-4CKC, 2(S-0-S)/L+C+R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4DK		S16KRS-4DK ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4DK2C	2(S-0-S)/R/2C	S16KRS-4DK2C, 2(S-0-S)/R/2C,	

CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4DKC	2(S-0-S)/R/1C	S16KRS-4DKC, 2(S-0-S)/R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4EK		S16KRS-4EK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4EK2C	2(S-0-S)/C/2C	S16KRS-4EK2C, 2(S-0-S)/C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4EKC	2(S-0-S)/C/1C	S16KRS-4EKC, 2(S-0-S)/C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4FK		S16KRS-4FK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4FK2C	2(S-0-S)/C+R/2C	S16KRS-4FK2C, 2(S-0-S)/C+R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4FKC	2(S-0-S)/C+R/1C	S16KRS-4FKC, 2(S-0-S)/C+R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4GK		S16KRS-4GK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4GK2C	2(S-0-S)/L+C/2C	S16KRS-4GK2C, 2(S-0-S)/L+C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-4GKC	2(S-0-S)/L+C/1C	S16KRS-4GKC, 2(S-0-S)/L+C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-5AK		S16KRS-5AK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-5AK2C	2(S-0-R)/L/2C	S16KRS-5AK2C, 2(S-0-R)/L/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-5AKC	2(S-0-R)/L/1C	S16KRS-5AKC, 2(S-0-R)/L/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-5EK		S16KRS-5EK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-5EK2C	2(S-0-R)/C/2C	S16KRS-5EK2C, 2(S-0-R)/C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-5EKC	2(S-0-R)/C/1C	S16KRS-5EKC, 2(S-0-R)/C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-5GK		S16KRS-5GK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-5GK2C	2(S-0-R)/L+C/2C	S16KRS-5GK2C, 2(S-0-R)/L+C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-5GKC	2(S-0-R)/L+C/1C	S16KRS-5GKC, 2(S-0-R)/L+C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-6DK		S16KRS-6DK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-6DK2C	2(R-0-S)/R/2C	S16KRS-6DK2C, 2(R-0-S)/R/2C,	

CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-6DKC	2(R-0-S)/R/1C	S16KRS-6DKC, 2(R-0-S)/R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-6EK		S16KRS-6EK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-6EK2C	2(R-0-S)/C/2C	S16KRS-6EK2C, 2(R-0-S)/C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-6EKC	2(R-0-S)/C/1C	S16KRS-6EKC, 2(R-0-S)/C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-6FK		S16KRS-6FK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-6FK2C	2(R-0-S)/C+R/2C	S16KRS-6FK2C, 2(R-0-S)/C+R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRS SERIES	S16KRS-6FKC	2(R-0-S)/C+R/1C	S16KRS-6FKC, 2(R-0-S)/C+R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-1AK		S16KRT-1AK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-1AK2C	2(0-R)/L/2C	S16KRT-1AK2C, 2(0-R)/L/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-1AK3C	2(0-R)/L/3C	S16KRT-1AK3C, 2(0-R)/L/3C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-1AKC	2(0-R)/L/1C	S16KRT-1AKC, 2(0-R)/L/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-2AK		S16KRT-2AK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-2AK2C	2(0-S)/L/2C	S16KRT-2AK2C, 2(0-S)/L/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-2AK3C	2(0-S)/L/3C	S16KRT-2AK3C, 2(0-S)/L/3C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-2AKC	2(0-S)/L/1C	S16KRT-2AKC, 2(0-S)/L/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-2BK		S16KRT-2BK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-2BK2C	2(0-S)/L+R/2C	S16KRT-2BK2C, 2(0-S)/L+R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-2BK3C	2(0-S)/L+R/3C	S16KRT-2BK3C, 2(0-S)/L+R/3C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-2BKC	2(0-S)/L+R/1C	S16KRT-2BKC, 2(0-S)/L+R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-2DK		S16KRT-2DK, ,	

CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-2DK2C	2(0-S)/R/2C	S16KRT-2DK2C, 2(0-S)/R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-2DK3C	2(0-S)/R/3C	S16KRT-2DK3C, 2(0-S)/R/3C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-2DKC	2(0-S)/R/1C	S16KRT-2DKC, 2(0-S)/R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-3EK		S16KRT-3EK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-3EK2C	2(R-0-R)/C/2C	S16KRT-3EK2C, 2(R-0-R)/C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-3EKC	2(R-0-R)/C/1C	S16KRT-3EKC, 2(R-0-R)/C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4AK		S16KRT-4AK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4AK2C	2(S-0-S)/L/2C	S16KRT-4AK2C, 2(S-0-S)/L/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4AKC	2(S-0-S)/L/1C	S16KRT-4AKC, 2(S-0-S)/L/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4BK		S16KRT-4BK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4BK2C	2(S-0-S)/L+R/2C	S16KRT-4BK2C, 2(S-0-S)/L+R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4BKC	2(S-0-S)/L+R/1C	S16KRT-4BKC, 2(S-0-S)/L+R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4CK		S16KRT-4CK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4CK2C	2(S-0-S)/L+C+R/2C	S16KRT-4CK2C, 2(S-0-S)/L+C+R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4CKC	2(S-0-S)/L+C+R/1C	S16KRT-4CKC, 2(S-0-S)/L+C+R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4DK		S16KRT-4DK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4DK2C	2(S-0-S)/R/2C	S16KRT-4DK2C, 2(S-0-S)/R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4DKC	2(S-0-S)/R/1C	S16KRT-4DKC, 2(S-0-S)/R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4EK		S16KRT-4EK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4EK2C	2(S-0-S)/C/2C	S16KRT-4EK2C, 2(S-0-S)/C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4EKC	2(S-0-S)/C/1C	S16KRT-4EKC, 2(S-0-S)/C/1C,	

CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4FK		S16KRT-4FK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4FK2C	2(S-0-S)/C+R/2C	S16KRT-4FK2C, 2(S-0-S)/C+R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4FKC	2(S-0-S)/C+R/1C	S16KRT-4FKC, 2(S-0-S)/C+R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4GK		S16KRT-4GK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4GK2C	2(S-0-S)/L+C/2C	S16KRT-4GK2C, 2(S-0-S)/L+C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-4GKC	2(S-0-S)/L+C/1C	S16KRT-4GKC, 2(S-0-S)/L+C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-5AK		S16KRT-5AK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-5AK2C	2(S-0-R)/L/2C	S16KRT-5AK2C, 2(S-0-R)/L/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-5AKC	2(S-0-R)/L/1C	S16KRT-5AKC, 2(S-0-R)/L/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-5EK		S16KRT-5EK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-5EK2C	2(S-0-R)/C/2C	S16KRT-5EK2C, 2(S-0-R)/C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-5EKC	2(S-0-R)/C/1C	S16KRT-5EKC, 2(S-0-R)/C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-5GK		S16KRT-5GK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-5GK2C	2(S-0-R)/L+C/2C	S16KRT-5GK2C, 2(S-0-R)/L+C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-5GKC	2(S-0-R)/L+C/1C	S16KRT-5GKC, 2(S-0-R)/L+C/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-6DK		S16KRT-6DK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-6DK2C	2(R-0-S)/R/2C	S16KRT-6DK2C, 2(R-0-S)/R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-6DKC	2(R-0-S)/R/1C	S16KRT-6DKC, 2(R-0-S)/R/1C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-6EK		S16KRT-6EK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-6EK2C	2(R-0-S)/C/2C	S16KRT-6EK2C, 2(R-0-S)/C/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-6EKC	2(R-0-S)/C/1C	S16KRT-6EKC, 2(R-0-S)/C/1C,	

CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-6FK		S16KRT-6FK, ,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-6FK2C	2(R-0-S)/C+R/2C	S16KRT-6FK2C, 2(R-0-S)/C+R/2C,	
CONTROL SWITCH	Key Selector Switch	S16KRT SERIES	S16KRT-6FKC	2(R-0-S)/C+R/1C	S16KRT-6FKC, 2(R-0-S)/C+R/1C,	
CONTROL SWITCH	MUSHROOM-HEAD PUSH BUTTON SWITCH	S16BR SERIES	S16BR-H1GC	GREEN/1C	S16BR-H1GC, GREEN/1C,	Пусковой кнопочный выключатель, позиция:Ø16, размер кнопки:23,5, без подсветки,цвет: зеленый, блок контактов:контакт С:1
CONTROL SWITCH	MUSHROOM-HEAD PUSH BUTTON SWITCH	S16BR SERIES	S16BR-H1R		S16BR-H1R, ,	
CONTROL SWITCH	MUSHROOM-HEAD PUSH BUTTON SWITCH	S16BR SERIES	S16BR-H1R2C	RED/2C	S16BR-H1R2C, RED/2C,	
CONTROL SWITCH	MUSHROOM-HEAD PUSH BUTTON SWITCH	S16BR SERIES	S16BR-H1R3C	RED/3C	S16BR-H1R3C, RED/3C,	
CONTROL SWITCH	MUSHROOM-HEAD PUSH BUTTON SWITCH	S16BR SERIES	S16BR-H1RC	RED/1C	S16BR-H1RC, RED/1C,	Пусковой кнопочный выключатель, позиция:Ø16, размер кнопки:23,5, без подсветки,цвет: красный, блок контактов:контакт С:1
CONTROL SWITCH	MUSHROOM-HEAD PUSH BUTTON SWITCH	S16BR SERIES	S16BR-H3GC12	GREEN/1C/LED 12V	S16BR-H3GC12, GREEN/1C/LED 12V,	
CONTROL SWITCH	MUSHROOM-HEAD PUSH BUTTON SWITCH	S16BR SERIES	S16BR-H3GC24	GREEN/1C/LED 24V	S16BR-H3GC24, GREEN/1C/LED 24V,	
CONTROL SWITCH	MUSHROOM-HEAD PUSH BUTTON SWITCH	S16BR SERIES	S16BR-H3GC5	GREEN/1C/LED 5V	S16BR-H3GC5, GREEN/1C/LED 5V,	
CONTROL SWITCH	MUSHROOM-HEAD PUSH BUTTON SWITCH	S16BR SERIES	S16BR-H3R		S16BR-H3R, ,	
CONTROL SWITCH	MUSHROOM-HEAD PUSH BUTTON SWITCH	S16BR SERIES	S16BR-H3R2C12	RED/2C/LED 12V	S16BR-H3R2C12, RED/2C/LED 12V,	
CONTROL SWITCH	MUSHROOM-HEAD PUSH BUTTON SWITCH	S16BR SERIES	S16BR-H3R2C24	RED/2C/LED 24V	S16BR-H3R2C24, RED/2C/LED 24V,	
CONTROL SWITCH	MUSHROOM-HEAD PUSH BUTTON SWITCH	S16BR SERIES	S16BR-H3R2C5	RED/2C/LED 5V	S16BR-H3R2C5, RED/2C/LED 5V,	
CONTROL SWITCH	MUSHROOM-HEAD PUSH BUTTON SWITCH	S16BR SERIES	S16BR-H3RC12	RED/1C/LED 12V	S16BR-H3RC12, RED/1C/LED 12V,	
CONTROL SWITCH	MUSHROOM-HEAD PUSH BUTTON SWITCH	S16BR SERIES	S16BR-H3RC24	RED/1C/LED 24V	S16BR-H3RC24, RED/1C/LED 24V,	
CONTROL SWITCH	MUSHROOM-HEAD PUSH BUTTON SWITCH	S16BR SERIES	S16BR-H3RC5	RED/1C/LED 5V	S16BR-H3RC5, RED/1C/LED 5V,	
CONTROL SWITCH	PILOT LAMP	L16RR SERIES	L16RR-EB		L16RR-EB, ,	Сигнальная лампа, плоская,круглая, выступающая, Ø16, голубой

CONTROL SWITCH	PILOT LAMP	L16RR SERIES	L16RR-EG		L16RR-EG, ,	Сигнальная лампа, плоская, круглая, выступающая, Ø16, зеленый
CONTROL SWITCH	PILOT LAMP	L16RR SERIES	L16RR-EG24	GREEN 24V	L16RR-EG24, GREEN 24V,	Сигнальная лампа, плоская, круглая, выступающая, Ø16, зеленый
CONTROL SWITCH	PILOT LAMP	L16RR SERIES	L16RR-ER		L16RR-ER, ,	
CONTROL SWITCH	PILOT LAMP	L16RR SERIES	L16RR-ER12	RED 12V	L16RR-ER12, RED 12V,	
CONTROL SWITCH	PILOT LAMP	L16RR SERIES	L16RR-ER24	RED 24V	L16RR-ER24, RED 24V,	Сигнальная лампа, плоская, круглая, выступающая, Ø16, красный
CONTROL SWITCH	PILOT LAMP	L16RR SERIES	L16RR-ER5	RED 5V	L16RR-ER5, RED 5V,	
CONTROL SWITCH	PILOT LAMP	L16RR SERIES	L16RR-EW		L16RR-EW, ,	Сигнальная лампа, плоская, круглая, выступающая, Ø16, белый
CONTROL SWITCH	PILOT LAMP	L16RR SERIES	L16RR-EW24	WHITE 24V	L16RR-EW24, WHITE 24V,	
CONTROL SWITCH	PILOT LAMP	L16RR SERIES	L16RR-EY		L16RR-EY, ,	Сигнальная лампа, плоская, круглая, выступающая, Ø16, желтый
CONTROL SWITCH	PILOT LAMP	L16RR SERIES	L16RR-EY24	YELLOW 24V	L16RR-EY24, YELLOW 24V,	Сигнальная лампа, плоская, круглая, выступающая, Ø16, желтый 24В=
CONTROL SWITCH	PILOT LAMP	L16RRS SERIES	L16RRS-HB		L16RRS-HB, ,	Сигнальная лампа, плоская, квадратная (с ограждением с 2 сторон) выступающая, Ø16, голубой
CONTROL SWITCH	PILOT LAMP	L16RRS SERIES	L16RRS-HG		L16RRS-HG, ,	Сигнальная лампа, плоская, квадратная (с ограждением с 2 сторон) выступающая, Ø16, зеленый
CONTROL SWITCH	PILOT LAMP	L16RRS SERIES	L16RRS-HR		L16RRS-HR, ,	
CONTROL SWITCH	PILOT LAMP	L16RRS SERIES	L16RRS-HR12	RED 12V	L16RRS-HR12, RED 12V,	
CONTROL SWITCH	PILOT LAMP	L16RRS SERIES	L16RRS-HR24	RED 24V	L16RRS-HR24, RED 24V,	
CONTROL SWITCH	PILOT LAMP	L16RRS SERIES	L16RRS-HR5	RED 5V	L16RRS-HR5, RED 5V,	
CONTROL SWITCH	PILOT LAMP	L16RRS SERIES	L16RRS-HW		L16RRS-HW, ,	Сигнальная лампа, плоская, квадратная (с ограждением с 2 сторон) выступающая, Ø16, белый
CONTROL SWITCH	PILOT LAMP	L16RRS SERIES	L16RRS-HY		L16RRS-HY, ,	Сигнальная лампа, плоская, квадратная (с ограждением с 2 сторон) выступающая, Ø16, желтый
CONTROL SWITCH	PILOT LAMP	L16RRT SERIES	L16RRT-HB		L16RRT-HB, ,	Сигнальная лампа, плоская, прямоугольная (с ограждением с 2 сторон) выступающая, Ø16, голубой

CONTROL SWITCH	PILOT LAMP	L16RRT SERIES	L16RRT-HG		L16RRT-HG, ,	Сигнальная лампа, плоская, прямоугольная (с ограждением с 2 сторон) выступающая, Ø16, зеленый
CONTROL SWITCH	PILOT LAMP	L16RRT SERIES	L16RRT-HR		L16RRT-HR, ,	
CONTROL SWITCH	PILOT LAMP	L16RRT SERIES	L16RRT-HR12	RED 12V	L16RRT-HR12, RED 12V,	
CONTROL SWITCH	PILOT LAMP	L16RRT SERIES	L16RRT-HR24	RED 24V	L16RRT-HR24, RED 24V,	
CONTROL SWITCH	PILOT LAMP	L16RRT SERIES	L16RRT-HR5	RED 5V	L16RRT-HR5, RED 5V,	
CONTROL SWITCH	PILOT LAMP	L16RRT SERIES	L16RRT-HW		L16RRT-HW, ,	Сигнальная лампа, плоская, прямоугольная (с ограждением с 2 сторон) выступающая, Ø16, белый
CONTROL SWITCH	PILOT LAMP	L16RRT SERIES	L16RRT-HY		L16RRT-HY, ,	Сигнальная лампа, плоская, прямоугольная (с ограждением с 2 сторон) выступающая, Ø16, желтый
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1B2C	BLUE/2C	S16PR-E1B2C, BLUE/2C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1B3C	BLUE/3C	S16PR-E1B3C, BLUE/3C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1BC	BLUE/1C	S16PR-E1BC, BLUE/1C,	Кнопочный выключатель, круглые, позиция: Ø16, тип ограждения: выступающие, тип эксплуатации: возврат, синий, блок контактов: контакт C:1
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1G2C	GREEN/2C	S16PR-E1G2C, GREEN/2C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1G3C	GREEN/3C	S16PR-E1G3C, GREEN/3C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1GC	GREEN/1C	S16PR-E1GC, GREEN/1C,	Кнопочный выключатель, круглые, позиция: Ø16, тип ограждения: выступающие, тип эксплуатации: возврат, зеленый, блок контактов: контакт C:1
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1R		S16PR-E1R, ,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1R		S16PR-E1R, ,	Кнопочный выключатель, Ø16, круглые, выступающие, возврат, красный
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1R2C	RED/2C	S16PR-E1R2C, RED/2C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1R3C	RED/3C	S16PR-E1R3C, RED/3C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1RC	RED/1C	S16PR-E1RC, RED/1C,	Кнопочный выключатель, круглые, позиция: Ø16, тип ограждения: выступающие, тип эксплуатации: возврат, красный, блок контактов: контакт C:1
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1W2C	WHITE/2C	S16PR-E1W2C, WHITE/2C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1W3C	WHITE/3C	S16PR-E1W3C, WHITE/3C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1WC	WHITE/1C	S16PR-E1WC, WHITE/1C,	Кнопочный выключатель, круглые, позиция: Ø16, тип ограждения: выступающие, тип эксплуатации: возврат, белый, блок контактов: контакт C:1

CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1Y2C	YELLOW/2C	S16PR-E1Y2C, YELLOW/2C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1Y3C	YELLOW/3C	S16PR-E1Y3C, YELLOW/3C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E1YC	YELLOW/1C	S16PR-E1YC, YELLOW/1C,	Кнопочный выключатель, круглые, позиция:Ø16, тип ограждения: выступающие, тип эксплуатации: возврат, желтый, блок контактов: контакт C:1
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2B2C	BLUE/2C	S16PR-E2B2C, BLUE/2C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2B3C	BLUE/3C	S16PR-E2B3C, BLUE/3C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2BC	BLUE/1C	S16PR-E2BC, BLUE/1C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2G2C	GREEN/2C	S16PR-E2G2C, GREEN/2C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2G3C	GREEN/3C	S16PR-E2G3C, GREEN/3C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2GC	GREEN/1C	S16PR-E2GC, GREEN/1C,	Круглый кнопочный выключатель Ø16,выступающие кнопки, фиксируемые, зеленый
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2R		S16PR-E2R, ,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2R		S16PR-E2R, ,	Кнопочный выключатель,Ø16,круглые,выступающие, фиксируемые,красный
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2R2C	RED/2C	S16PR-E2R2C, RED/2C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2R3C	RED/3C	S16PR-E2R3C, RED/3C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2RC	RED/1C	S16PR-E2RC, RED/1C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2W2C	WHITE/2C	S16PR-E2W2C, WHITE/2C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2W3C	WHITE/3C	S16PR-E2W3C, WHITE/3C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2WC	WHITE/1C	S16PR-E2WC, WHITE/1C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2Y2C	YELLOW/2C	S16PR-E2Y2C, YELLOW/2C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2Y3C	YELLOW/3C	S16PR-E2Y3C, YELLOW/3C,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E2YC	YELLOW/1C	S16PR-E2YC, YELLOW/1C,	Круглый кнопочный выключатель Ø16,выступающие кнопки, фиксируемые, желтый
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3BC12	BLUE/1C/LED 12V	S16PR-E3BC12, BLUE/1C/LED 12V,	

CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3BC24	BLUE/1C/LED 24V	S16PR-E3BC24, BLUE/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3G	GREEN	S16PR-E3G, GREEN,	Кнопочный выключатель, круглые, позиция:Ø16,тип ограждения: выступающие, тип эксплуатации: с возвратом (с подсветкой), зеленый
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3GC12	GREEN/1C/LED 12V	S16PR-E3GC12, GREEN/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3GC24	GREEN/1C/LED 24V	S16PR-E3GC24, GREEN/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3GC5	GREEN/1C/LED 5V	S16PR-E3GC5, GREEN/1C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3R		S16PR-E3R, ,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3R	RED	S16PR-E3R, RED,	Кнопочный выключатель, круглые, позиция:Ø16,тип ограждения: выступающие, тип эксплуатации: с возвратом (с подсветкой), красный
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3R2C12	RED/2C/LED 12V	S16PR-E3R2C12, RED/2C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3R2C24	RED/2C/LED 24V	S16PR-E3R2C24, RED/2C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3R2C5	RED/2C/LED 5V	S16PR-E3R2C5, RED/2C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3RC12	RED/1C/LED 12V	S16PR-E3RC12, RED/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3RC24	RED/1C/LED 24V	S16PR-E3RC24, RED/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3RC5	RED/1C/LED 5V	S16PR-E3RC5, RED/1C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3W	WHITE	S16PR-E3W, WHITE,	Кнопочный выключатель, круглые, позиция:Ø16,тип ограждения: выступающие, тип эксплуатации: с возвратом (с подсветкой), белый
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3WC12	WHITE/1C/LED 12V	S16PR-E3WC12, WHITE/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3WC24	WHITE/1C/LED 24V	S16PR-E3WC24, WHITE/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3Y	YELLOW	S16PR-E3Y, YELLOW,	Кнопочный выключатель, круглые, позиция:Ø16,тип ограждения: выступающие, тип эксплуатации: с возвратом (с подсветкой), желтый
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3YC12	YELLOW/1C/LED 12V	S16PR-E3YC12, YELLOW/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E3YC24	YELLOW/1C/LED 24V	S16PR-E3YC24, YELLOW/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4BC12	BLUE/1C/LED 12V	S16PR-E4BC12, BLUE/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4BC24	BLUE/1C/LED 24V	S16PR-E4BC24, BLUE/1C/LED 24V,	

CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4G	GREEN	S16PR-E4G, GREEN,	Кнопочный выключатель, круглые, позиция:Ø16,тип ограждения: выступающие, тип эксплуатации: фиксируемый (с подсветкой), зеленый
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4GC12	GREEN/1C/LED 12V	S16PR-E4GC12, GREEN/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4GC24	GREEN/1C/LED 24V	S16PR-E4GC24, GREEN/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4GC5	GREEN/1C/LED 5V	S16PR-E4GC5, GREEN/1C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4R		S16PR-E4R, ,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4R	RED	S16PR-E4R, RED,	Кнопочный выключатель, круглые, позиция:Ø16,тип ограждения: выступающие, тип эксплуатации: фиксируемый (с подсветкой), красный
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4R2C12	RED/2C/LED 12V	S16PR-E4R2C12, RED/2C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4R2C24	RED/2C/LED 24V	S16PR-E4R2C24, RED/2C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4R2C5	RED/2C/LED 5V	S16PR-E4R2C5, RED/2C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4RC12	RED/1C/LED 12V	S16PR-E4RC12, RED/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4RC24	RED/1C/LED 24V	S16PR-E4RC24, RED/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4RC5	RED/1C/LED 5V	S16PR-E4RC5, RED/1C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4W	WHITE	S16PR-E4W, WHITE,	Кнопочный выключатель, круглые, позиция:Ø16,тип ограждения: выступающие, тип эксплуатации: фиксируемый (с подсветкой), белый
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4WC12	WHITE/1C/LED 12V	S16PR-E4WC12, WHITE/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4WC24	WHITE/1C/LED 24V	S16PR-E4WC24, WHITE/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4YC12	YELLOW/1C/LED 12V	S16PR-E4YC12, YELLOW/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PR SERIES	S16PR-E4YC24	YELLOW/1C/LED 24V	S16PR-E4YC24, YELLOW/1C/LED 24V,	Круглый кнопочный выключатель Ø16,выступающие кнопки (с подсветкой), фиксируемые, желтый, 24В=
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H1BC	BLUE/1C	S16PRS-H1BC, BLUE/1C,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: возврат, синий,блок контакта: контакт С:1
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H1GC	GREEN/1C	S16PRS-H1GC, GREEN/1C,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: возврат, зеленый, блок контакта: контакт С:1
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H1R		S16PRS-H1R, ,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H1R2C	RED/2C	S16PRS-H1R2C, RED/2C,	

CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H1R3C	RED/3C	S16PRS-H1R3C, RED/3C,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H1RC	RED/1C	S16PRS-H1RC, RED/1C,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: возврат, красный, блок контакта: контакт С:1
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H1WC	WHITE/1C	S16PRS-H1WC, WHITE/1C,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: возврат, белый, блок контакта: контакт С:1
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H1YC	YELLOW/1C	S16PRS-H1YC, YELLOW/1C,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: возврат, желтый, блок контакта: контакт С:1
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H2BC	BLUE/1C	S16PRS-H2BC, BLUE/1C,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H2GC	GREEN/1C	S16PRS-H2GC, GREEN/1C,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H2R		S16PRS-H2R, ,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H2R2C	RED/2C	S16PRS-H2R2C, RED/2C,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H2R3C	RED/3C	S16PRS-H2R3C, RED/3C,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H2RC	RED/1C	S16PRS-H2RC, RED/1C,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H2WC	WHITE/1C	S16PRS-H2WC, WHITE/1C,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H2YC	YELLOW/1C	S16PRS-H2YC, YELLOW/1C,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3B	BLUE	S16PRS-H3B, BLUE,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: с возвратом (с подсветкой), синий
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3BC12	BLUE/1C/LED 12V	S16PRS-H3BC12, BLUE/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3BC24	BLUE/1C/LED 24V	S16PRS-H3BC24, BLUE/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3G	GREEN	S16PRS-H3G, GREEN,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: с возвратом (с подсветкой), зеленый
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3GC12	GREEN/1C/LED 12V	S16PRS-H3GC12, GREEN/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3GC24	GREEN/1C/LED 24V	S16PRS-H3GC24, GREEN/1C/LED 24V,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: с возвратом (с подсветкой), зеленый, 1 НО+ 1НЗ контакта, коммутация до 250 VAC,3A, СИД 24В=
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3GC5	GREEN/1C/LED 5V	S16PRS-H3GC5, GREEN/1C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3R		S16PRS-H3R, ,	

CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3R	RED	S16PRS-H3R, RED,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: с возвратом (с подсветкой), красный
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3R2C12	RED/2C/LED 12V	S16PRS-H3R2C12, RED/2C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3R2C24	RED/2C/LED 24V	S16PRS-H3R2C24, RED/2C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3R2C5	RED/2C/LED 5V	S16PRS-H3R2C5, RED/2C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3RC12	RED/1C/LED 12V	S16PRS-H3RC12, RED/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3RC24	RED/1C/LED 24V	S16PRS-H3RC24, RED/1C/LED 24V,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: с возвратом (с подсветкой), красный, 1 НО+ 1НЗ контакта, коммутация до 250 VAC,3A, СИД 24В=
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3RC5	RED/1C/LED 5V	S16PRS-H3RC5, RED/1C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3W	WHITE	S16PRS-H3W, WHITE,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: с возвратом (с подсветкой), белый
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3WC12	WHITE/1C/LED 12V	S16PRS-H3WC12, WHITE/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3WC24	WHITE/1C/LED 24V	S16PRS-H3WC24, WHITE/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3Y	YELLOW	S16PRS-H3Y, YELLOW,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: с возвратом (с подсветкой), желтый
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3YC12	YELLOW/1C/LED 12V	S16PRS-H3YC12, YELLOW/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H3YC24	YELLOW/1C/LED 24V	S16PRS-H3YC24, YELLOW/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4B	BLUE	S16PRS-H4B, BLUE,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: фиксируемые (с подсветкой), синий
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4BC12	BLUE/1C/LED 12V	S16PRS-H4BC12, BLUE/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4BC24	BLUE/1C/LED 24V	S16PRS-H4BC24, BLUE/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4GC12	GREEN/1C/LED 12V	S16PRS-H4GC12, GREEN/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4GC24	GREEN/1C/LED 24V	S16PRS-H4GC24, GREEN/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4GC5	GREEN/1C/LED 5V	S16PRS-H4GC5, GREEN/1C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4R		S16PRS-H4R, ,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4R	RED	S16PRS-H4R, RED,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: фиксируемые (с подсветкой), красный

CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4R2C12	RED/2C/LED 12V	S16PRS-H4R2C12, RED/2C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4R2C24	RED/2C/LED 24V	S16PRS-H4R2C24, RED/2C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4R2C5	RED/2C/LED 5V	S16PRS-H4R2C5, RED/2C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4RC12	RED/1C/LED 12V	S16PRS-H4RC12, RED/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4RC24	RED/1C/LED 24V	S16PRS-H4RC24, RED/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4RC5	RED/1C/LED 5V	S16PRS-H4RC5, RED/1C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4W	WHITE	S16PRS-H4W, WHITE,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: фиксируемые (с подсветкой), белый
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4WC12	WHITE/1C/LED 12V	S16PRS-H4WC12, WHITE/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4WC24	WHITE/1C/LED 24V	S16PRS-H4WC24, WHITE/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4Y	YELLOW	S16PRS-H4Y, YELLOW,	Кнопочный выключатель, квадратный, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: фиксируемые (с подсветкой), желтый
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4YC12	YELLOW/1C/LED 12V	S16PRS-H4YC12, YELLOW/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRS SERIES	S16PRS-H4YC24	YELLOW/1C/LED 24V	S16PRS-H4YC24, YELLOW/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H1BC	BLUE/1C	S16PRT-H1BC, BLUE/1C,	Кнопочный выключатель, прямоугольные, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации:возврат, синий, Блок контактов: контакт C:1
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H1GC	GREEN/1C	S16PRT-H1GC, GREEN/1C,	Кнопочный выключатель, прямоугольные, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации:возврат, зеленый, Блок контактов: контакт C:1
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H1R		S16PRT-H1R, ,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H1R2C	RED/2C	S16PRT-H1R2C, RED/2C,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H1R3C	RED/3C	S16PRT-H1R3C, RED/3C,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H1RC	RED/1C	S16PRT-H1RC, RED/1C,	Кнопочный выключатель, прямоугольные, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации:возврат, красный, Блок контактов: контакт C:1
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H1WC	WHITE/1C	S16PRT-H1WC, WHITE/1C,	Кнопочный выключатель, прямоугольные, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации:возврат, белый, Блок контактов: контакт C:1
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H1YC	YELLOW/1C	S16PRT-H1YC, YELLOW/1C,	Кнопочный выключатель, прямоугольные, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации:возврат, желтый, Блок контактов: контакт C:1
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H2BC	BLUE/1C	S16PRT-H2BC, BLUE/1C,	

CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H2GC	GREEN/1C	S16PRT-H2GC, GREEN/1C,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H2R		S16PRT-H2R, ,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H2R2C	RED/2C	S16PRT-H2R2C, RED/2C,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H2R3C	RED/3C	S16PRT-H2R3C, RED/3C,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H2RC	RED/1C	S16PRT-H2RC, RED/1C,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H2WC	WHITE/1C	S16PRT-H2WC, WHITE/1C,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H2YC	YELLOW/1C	S16PRT-H2YC, YELLOW/1C,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3B	BLUE	S16PRT-H3B, BLUE,	Кнопочный выключатель, прямоугольные, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: с возвратом (с подсветкой), синий
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3BC12	BLUE/1C/LED 12V	S16PRT-H3BC12, BLUE/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3BC24	BLUE/1C/LED 24V	S16PRT-H3BC24, BLUE/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3G	GREEN	S16PRT-H3G, GREEN,	Кнопочный выключатель, прямоугольные, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: с возвратом (с подсветкой), зеленый
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3G2C24	GREEN/2C/LED 24V	S16PRT-H3G2C24, GREEN/2C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3GC12	GREEN/1C/LED 12V	S16PRT-H3GC12, GREEN/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3GC24	GREEN/1C/LED 24V	S16PRT-H3GC24, GREEN/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3GC5	GREEN/1C/LED 5V	S16PRT-H3GC5, GREEN/1C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3R		S16PRT-H3R, ,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3R	RED	S16PRT-H3R, RED,	Кнопочный выключатель, прямоугольные, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: с возвратом (с подсветкой), красный
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3R2C12	RED/2C/LED 12V	S16PRT-H3R2C12, RED/2C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3R2C24	RED/2C/LED 24V	S16PRT-H3R2C24, RED/2C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3R2C5	RED/2C/LED 5V	S16PRT-H3R2C5, RED/2C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3RC12	RED/1C/LED 12V	S16PRT-H3RC12, RED/1C/LED 12V,	

CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3RC24	RED/1C/LED 24V	S16PRT-H3RC24, RED/1C/LED 24V,	Прямоугольный кнопочный выключатель, Ø16, с ограждением с 2 сторон (с подсветкой),красный, возвратные, 24В=
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3RC5	RED/1C/LED 5V	S16PRT-H3RC5, RED/1C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3W	WHITE	S16PRT-H3W, WHITE,	Кнопочный выключатель, прямоугольные, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: с возвратом (с подсветкой), белый
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3WC12	WHITE/1C/LED 12V	S16PRT-H3WC12, WHITE/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3WC24	WHITE/1C/LED 24V	S16PRT-H3WC24, WHITE/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3Y	YELLOW	S16PRT-H3Y, YELLOW,	Кнопочный выключатель, прямоугольные, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: с возвратом (с подсветкой), желтый
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3Y2C24	YELLOW/2C/LED 24V	S16PRT-H3Y2C24, YELLOW/2C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3YC12	YELLOW/1C/LED 12V	S16PRT-H3YC12, YELLOW/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H3YC24	YELLOW/1C/LED 24V	S16PRT-H3YC24, YELLOW/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4BC12	BLUE/1C/LED 12V	S16PRT-H4BC12, BLUE/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4BC24	BLUE/1C/LED 24V	S16PRT-H4BC24, BLUE/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4G	GREEN	S16PRT-H4G, GREEN,	Кнопочный выключатель, прямоугольные, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: фиксируемый (с подсветкой), зеленый
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4GC12	GREEN/1C/LED 12V	S16PRT-H4GC12, GREEN/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4GC24	GREEN/1C/LED 24V	S16PRT-H4GC24, GREEN/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4GC5	GREEN/1C/LED 5V	S16PRT-H4GC5, GREEN/1C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4R		S16PRT-H4R, ,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4R	RED	S16PRT-H4R, RED,	Кнопочный выключатель, прямоугольные, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: фиксируемый (с подсветкой), красный
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4R2C12	RED/2C/LED 12V	S16PRT-H4R2C12, RED/2C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4R2C24	RED/2C/LED 24V	S16PRT-H4R2C24, RED/2C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4R2C5	RED/2C/LED 5V	S16PRT-H4R2C5, RED/2C/LED 5V,	

CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4RC12	RED/1C/LED 12V	S16PRT-H4RC12, RED/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4RC24	RED/1C/LED 24V	S16PRT-H4RC24, RED/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4RC5	RED/1C/LED 5V	S16PRT-H4RC5, RED/1C/LED 5V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4W	WHITE	S16PRT-H4W, WHITE,	Кнопочный выключатель, прямоугольные, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: фиксируемый (с подсветкой), белый
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4WC12	WHITE/1C/LED 12V	S16PRT-H4WC12, WHITE/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4WC24	WHITE/1C/LED 24V	S16PRT-H4WC24, WHITE/1C/LED 24V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4Y	YELLOW	S16PRT-H4Y, YELLOW,	Кнопочный выключатель, прямоугольные, позиция:Ø16,тип ограждения: с ограждением с 2 сторон, тип эксплуатации: фиксируемый (с подсветкой), желтый
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4YC12	YELLOW/1C/LED 12V	S16PRT-H4YC12, YELLOW/1C/LED 12V,	
CONTROL SWITCH	Push Button Switch	S16PRT SERIES	S16PRT-H4YC24	YELLOW/1C/LED 24V	S16PRT-H4YC24, YELLOW/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1GC12	GREEN/2(0-R)/1C/LED 12V	S16SR-L1GC12, GREEN/2(0-R)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1GC24	GREEN/2(0-R)/1C/LED 24V	S16SR-L1GC24, GREEN/2(0-R)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1GC5	GREEN/2(0-R)/1C/LED 5V	S16SR-L1GC5, GREEN/2(0-R)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1R		S16SR-L1R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1R2C12	RED/2(0-R)/2C/LED 12V	S16SR-L1R2C12, RED/2(0-R)/2C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1R2C24	RED/2(0-R)/2C/LED 24V	S16SR-L1R2C24, RED/2(0-R)/2C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1R2C5	RED/2(0-R)/2C/LED 5V	S16SR-L1R2C5, RED/2(0-R)/2C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1RC12	RED/2(0-R)/1C/LED 12V	S16SR-L1RC12, RED/2(0-R)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1RC24	RED/2(0-R)/1C/LED 24V	S16SR-L1RC24, RED/2(0-R)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L1RC5	RED/2(0-R)/1C/LED 5V	S16SR-L1RC5, RED/2(0-R)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2GC12	GREEN/2(0-S)/1C/LED 12V	S16SR-L2GC12, GREEN/2(0-S)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2GC24	GREEN/2(0-S)/1C/LED 24V	S16SR-L2GC24, GREEN/2(0-S)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2GC5	GREEN/2(0-S)/1C/LED 5V	S16SR-L2GC5, GREEN/2(0-S)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2R		S16SR-L2R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2R2C12	RED/2(0-S)/2C/LED 12V	S16SR-L2R2C12, RED/2(0-S)/2C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2R2C24	RED/2(0-S)/2C/LED 24V	S16SR-L2R2C24, RED/2(0-S)/2C/LED 24V,	

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2R2C5	RED/2(0-S)/2C/LED 5V	S16SR-L2R2C5, RED/2(0-S)/2C/LED 5V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2RC12	RED/2(0-S)/1C/LED 12V	S16SR-L2RC12, RED/2(0-S)/1C/LED 12V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2RC24	RED/2(0-S)/1C/LED 24V	S16SR-L2RC24, RED/2(0-S)/1C/LED 24V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L2RC5	RED/2(0-S)/1C/LED 5V	S16SR-L2RC5, RED/2(0-S)/1C/LED 5V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3GC12	GREEN/2(R-0-R)/1C/LED 12V	S16SR-L3GC12, GREEN/2(R-0-R)/1C/LED 12V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3GC24	GREEN/2(R-0-R)/1C/LED 24V	S16SR-L3GC24, GREEN/2(R-0-R)/1C/LED 24V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3GC5	GREEN/2(R-0-R)/1C/LED 5V	S16SR-L3GC5, GREEN/2(R-0-R)/1C/LED 5V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3R		S16SR-L3R, ,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3R2C12	RED/2(R-0-R)/2C/LED 12V	S16SR-L3R2C12, RED/2(R-0-R)/2C/LED 12V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3R2C24	RED/2(R-0-R)/2C/LED 24V	S16SR-L3R2C24, RED/2(R-0-R)/2C/LED 24V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3R2C5	RED/2(R-0-R)/2C/LED 5V	S16SR-L3R2C5, RED/2(R-0-R)/2C/LED 5V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3RC12	RED/2(R-0-R)/1C/LED 12V	S16SR-L3RC12, RED/2(R-0-R)/1C/LED 12V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3RC24	RED/2(R-0-R)/1C/LED 24V	S16SR-L3RC24, RED/2(R-0-R)/1C/LED 24V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L3RC5	RED/2(R-0-R)/1C/LED 5V	S16SR-L3RC5, RED/2(R-0-R)/1C/LED 5V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4GC12	GREEN/2(S-0-S)/1C/LED 12V	S16SR-L4GC12, GREEN/2(S-0-S)/1C/LED 12V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4GC24	GREEN/2(S-0-S)/1C/LED 24V	S16SR-L4GC24, GREEN/2(S-0-S)/1C/LED 24V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4GC5	GREEN/2(S-0-S)/1C/LED 5V	S16SR-L4GC5, GREEN/2(S-0-S)/1C/LED 5V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4R		S16SR-L4R, ,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4R2C12	RED/2(S-0-S)/2C/LED 12V	S16SR-L4R2C12, RED/2(S-0-S)/2C/LED 12V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4R2C24	RED/2(S-0-S)/2C/LED 24V	S16SR-L4R2C24, RED/2(S-0-S)/2C/LED 24V,

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4R2C5	RED/2(S-0-S)/2C/LED 5V	S16SR-L4R2C5, RED/2(S-0-S)/2C/LED 5V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4RC12	RED/2(S-0-S)/1C/LED 12V	S16SR-L4RC12, RED/2(S-0-S)/1C/LED 12V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4RC24	RED/2(S-0-S)/1C/LED 24V	S16SR-L4RC24, RED/2(S-0-S)/1C/LED 24V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L4RC5	RED/2(S-0-S)/1C/LED 5V	S16SR-L4RC5, RED/2(S-0-S)/1C/LED 5V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5GC12	GREEN/2(S-0-R)/1C/LED 12V	S16SR-L5GC12, GREEN/2(S-0-R)/1C/LED 12V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5GC24	GREEN/2(S-0-R)/1C/LED 24V	S16SR-L5GC24, GREEN/2(S-0-R)/1C/LED 24V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5GC5	GREEN/2(S-0-R)/1C/LED 5V	S16SR-L5GC5, GREEN/2(S-0-R)/1C/LED 5V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5R		S16SR-L5R, ,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5R2C12	RED/2(S-0-R)/2C/LED 12V	S16SR-L5R2C12, RED/2(S-0-R)/2C/LED 12V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5R2C24	RED/2(S-0-R)/2C/LED 24V	S16SR-L5R2C24, RED/2(S-0-R)/2C/LED 24V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5R2C5	RED/2(S-0-R)/2C/LED 5V	S16SR-L5R2C5, RED/2(S-0-R)/2C/LED 5V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5RC12	RED/2(S-0-R)/1C/LED 12V	S16SR-L5RC12, RED/2(S-0-R)/1C/LED 12V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5RC24	RED/2(S-0-R)/1C/LED 24V	S16SR-L5RC24, RED/2(S-0-R)/1C/LED 24V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L5RC5	RED/2(S-0-R)/1C/LED 5V	S16SR-L5RC5, RED/2(S-0-R)/1C/LED 5V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6GC12	GREEN/2(R-0-S)/1C/LED 12V	S16SR-L6GC12, GREEN/2(R-0-S)/1C/LED 12V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6GC24	GREEN/2(R-0-S)/1C/LED 24V	S16SR-L6GC24, GREEN/2(R-0-S)/1C/LED 24V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6GC5	GREEN/2(R-0-S)/1C/LED 5V	S16SR-L6GC5, GREEN/2(R-0-S)/1C/LED 5V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6R		S16SR-L6R, ,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6R2C12	RED/2(R-0-S)/2C/LED 12V	S16SR-L6R2C12, RED/2(R-0-S)/2C/LED 12V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6R2C24	RED/2(R-0-S)/2C/LED 24V	S16SR-L6R2C24, RED/2(R-0-S)/2C/LED 24V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6R2C5	RED/2(R-0-S)/2C/LED 5V	S16SR-L6R2C5, RED/2(R-0-S)/2C/LED 5V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6RC12	RED/2(R-0-S)/1C/LED 12V	S16SR-L6RC12, RED/2(R-0-S)/1C/LED 12V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6RC24	RED/2(R-0-S)/1C/LED 24V	S16SR-L6RC24, RED/2(R-0-S)/1C/LED 24V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-L6RC5	RED/2(R-0-S)/1C/LED 5V	S16SR-L6RC5, RED/2(R-0-S)/1C/LED 5V,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1GC	GREEN/2(0-R)/1C	S16SR-S1GC, GREEN/2(0-R)/1C,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1R		S16SR-S1R, ,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1R2C	RED/2(0-R)/2C	S16SR-S1R2C, RED/2(0-R)/2C,
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1R3C	RED/2(0-R)/3C	S16SR-S1R3C, RED/2(0-R)/3C,

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1RC	RED/2(0-R)/1C	S16SR-S1RC, RED/2(0-R)/1C,	Селекторный переключатель, круглый, позиция:Ø16, без подсветки, рабочее положение: 2-х позиционный самовозврат, красный, блок контактов: контакт С:1
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S1WC	WHITE/2(0-R)/1C	S16SR-S1WC, WHITE/2(0-R)/1C,	Селекторный переключатель, круглый, позиция:Ø16, без подсветки, рабочее положение: 2-х позиционный самовозврат, белый, блок контактов: контакт С:1
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2GC	GREEN/2(0-S)/1C	S16SR-S2GC, GREEN/2(0-S)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2R		S16SR-S2R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2R2C	RED/2(0-S)/2C	S16SR-S2R2C, RED/2(0-S)/2C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2R3C	RED/2(0-S)/3C	S16SR-S2R3C, RED/2(0-S)/3C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2RC	RED/2(0-S)/1C	S16SR-S2RC, RED/2(0-S)/1C,	Селекторный переключатель, круглый, позиция:Ø16, без подсветки, рабочее положение: 2-х позиционный без возврата, красный, блок контактов: контакт С:1
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2W2C	WHITE/2(0-S)/2C	S16SR-S2W2C, WHITE/2(0-S)/2C,	Селекторный переключатель, круглый, позиция:Ø16, без подсветки, рабочее положение: 2-х позиционный без возврата, белый, блок контактов: контакт С:2
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S2WC	WHITE/2(0-S)/1C	S16SR-S2WC, WHITE/2(0-S)/1C,	Селекторный переключатель, круглый, позиция:Ø16, без подсветки, рабочее положение: 2-х позиционный без возврата, белый, блок контактов: контакт С:1
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S3R		S16SR-S3R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S3R2C	RED/3(R-0-R)/2C	S16SR-S3R2C, RED/3(R-0-R)/2C,	Селекторный переключатель, круглый, позиция:Ø16, без подсветки, рабочее положение: 3-х позиционный пружинный самовозврат из 2 положений, красный, блок контактов: контакт С:2
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S3RC	RED/3(R-0-R)/1C	S16SR-S3RC, RED/3(R-0-R)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S3W2C	WHITE/3(R-0-R)/2C	S16SR-S3W2C, WHITE/3(R-0-R)/2C,	Селекторный переключатель, круглый, позиция:Ø16, без подсветки, рабочее положение: 3-х позиционный пружинный самовозврат из 2 положений, белый, блок контактов: контакт С:2
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S4R		S16SR-S4R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S4R2C	RED/3(S-0-S)/2C	S16SR-S4R2C, RED/3(S-0-S)/2C,	Селекторный переключатель, круглый, позиция:Ø16, без подсветки, рабочее положение: 3-х позиционный, без возврата, красный, блок контактов: контакт С:2
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S4RC	RED/3(S-0-S)/1C	S16SR-S4RC, RED/3(S-0-S)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S4W2C	WHITE/3(S-0-S)/2C	S16SR-S4W2C, WHITE/3(S-0-S)/2C,	Селекторный переключатель, круглый, позиция:Ø16, без подсветки, рабочее положение: 3-х позиционный, без возврата, белый, блок контактов: контакт С:2
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S4WC	WHITE/3(S-0-S)/1C	S16SR-S4WC, WHITE/3(S-0-S)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S5R		S16SR-S5R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S5R2C	RED/3(S-0-R)/2C	S16SR-S5R2C, RED/3(S-0-R)/2C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S5RC	RED/3(S-0-R)/1C	S16SR-S5RC, RED/3(S-0-R)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S6R		S16SR-S6R, ,	

CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S6R2C	RED/3(R-0-S)/2C	S16SR-S6R2C, RED/3(R-0-S)/2C,	Селекторный переключатель, круглый, позиция:Ø16, без подсветки, рабочее положение: позиционный, пружинный самовозврат из левого положения, красный, блок контактов: контакт С:2
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S6RC	RED/3(R-0-S)/1C	S16SR-S6RC, RED/3(R-0-S)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SR SERIES	S16SR-S6W2C	WHITE/3(R-0-S)/2C	S16SR-S6W2C, WHITE/3(R-0-S)/2C,	Селекторный переключатель, круглый, позиция:Ø16, без подсветки, рабочее положение: позиционный, пружинный самовозврат из левого положения, белый, блок контактов: контакт С:2
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1GC12	GREEN/2(0-R)/1C/LED 12V	S16SRS-L1GC12, GREEN/2(0-R)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1GC24	GREEN/2(0-R)/1C/LED 24V	S16SRS-L1GC24, GREEN/2(0-R)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1GC5	GREEN/2(0-R)/1C/LED 5V	S16SRS-L1GC5, GREEN/2(0-R)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1R		S16SRS-L1R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1R2C12	RED/2(0-R)/2C/LED 12V	S16SRS-L1R2C12, RED/2(0-R)/2C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1R2C24	RED/2(0-R)/2C/LED 24V	S16SRS-L1R2C24, RED/2(0-R)/2C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1R2C5	RED/2(0-R)/2C/LED 5V	S16SRS-L1R2C5, RED/2(0-R)/2C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1RC12	RED/2(0-R)/1C/LED 12V	S16SRS-L1RC12, RED/2(0-R)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1RC24	RED/2(0-R)/1C/LED 24V	S16SRS-L1RC24, RED/2(0-R)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L1RC5	RED/2(0-R)/1C/LED 5V	S16SRS-L1RC5, RED/2(0-R)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2GC12	GREEN/2(0-S)/1C/LED 12V	S16SRS-L2GC12, GREEN/2(0-S)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2GC24	GREEN/2(0-S)/1C/LED 24V	S16SRS-L2GC24, GREEN/2(0-S)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2GC5	GREEN/2(0-S)/1C/LED 5V	S16SRS-L2GC5, GREEN/2(0-S)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2R		S16SRS-L2R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2R2C12	RED/2(0-S)/2C/LED 12V	S16SRS-L2R2C12, RED/2(0-S)/2C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2R2C24	RED/2(0-S)/2C/LED 24V	S16SRS-L2R2C24, RED/2(0-S)/2C/LED 24V,	Селекторный выключатель, квадратный, позиция:Ø16,выступающий, тип эксплуатации: 2-х позиционный, 90 градусов, с фиксацией, красный, 2 НО+ 2НЗ контакта, коммутация до 250 VAC,3А, СИД 24В=
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2R2C5	RED/2(0-S)/2C/LED 5V	S16SRS-L2R2C5, RED/2(0-S)/2C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2RC12	RED/2(0-S)/1C/LED 12V	S16SRS-L2RC12, RED/2(0-S)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2RC24	RED/2(0-S)/1C/LED 24V	S16SRS-L2RC24, RED/2(0-S)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L2RC5	RED/2(0-S)/1C/LED 5V	S16SRS-L2RC5, RED/2(0-S)/1C/LED 5V,	

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3GC12	GREEN/2(R-0-R)/1C/LED 12V	S16SRS-L3GC12, GREEN/2(R-0-R)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3GC24	GREEN/2(R-0-R)/1C/LED 24V	S16SRS-L3GC24, GREEN/2(R-0-R)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3GC5	GREEN/2(R-0-R)/1C/LED 5V	S16SRS-L3GC5, GREEN/2(R-0-R)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3R		S16SRS-L3R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3R2C12	RED/2(R-0-R)/2C/LED 12V	S16SRS-L3R2C12, RED/2(R-0-R)/2C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3R2C24	RED/2(R-0-R)/2C/LED 24V	S16SRS-L3R2C24, RED/2(R-0-R)/2C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3R2C5	RED/2(R-0-R)/2C/LED 5V	S16SRS-L3R2C5, RED/2(R-0-R)/2C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3RC12	RED/2(R-0-R)/1C/LED 12V	S16SRS-L3RC12, RED/2(R-0-R)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3RC24	RED/2(R-0-R)/1C/LED 24V	S16SRS-L3RC24, RED/2(R-0-R)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L3RC5	RED/2(R-0-R)/1C/LED 5V	S16SRS-L3RC5, RED/2(R-0-R)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4GC12	GREEN/2(S-0-S)/1C/LED 12V	S16SRS-L4GC12, GREEN/2(S-0-S)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4GC24	GREEN/2(S-0-S)/1C/LED 24V	S16SRS-L4GC24, GREEN/2(S-0-S)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4GC5	GREEN/2(S-0-S)/1C/LED 5V	S16SRS-L4GC5, GREEN/2(S-0-S)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4R		S16SRS-L4R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4R2C12	RED/2(S-0-S)/2C/LED 12V	S16SRS-L4R2C12, RED/2(S-0-S)/2C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4R2C24	RED/2(S-0-S)/2C/LED 24V	S16SRS-L4R2C24, RED/2(S-0-S)/2C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4R2C5	RED/2(S-0-S)/2C/LED 5V	S16SRS-L4R2C5, RED/2(S-0-S)/2C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4RC12	RED/2(S-0-S)/1C/LED 12V	S16SRS-L4RC12, RED/2(S-0-S)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4RC24	RED/2(S-0-S)/1C/LED 24V	S16SRS-L4RC24, RED/2(S-0-S)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L4RC5	RED/2(S-0-S)/1C/LED 5V	S16SRS-L4RC5, RED/2(S-0-S)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5GC12	GREEN/2(S-0-R)/1C/LED 12V	S16SRS-L5GC12, GREEN/2(S-0-R)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5GC24	GREEN/2(S-0-R)/1C/LED 24V	S16SRS-L5GC24, GREEN/2(S-0-R)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5GC5	GREEN/2(S-0-R)/1C/LED 5V	S16SRS-L5GC5, GREEN/2(S-0-R)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5R		S16SRS-L5R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5R2C12	RED/2(S-0-R)/2C/LED 12V	S16SRS-L5R2C12, RED/2(S-0-R)/2C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5R2C24	RED/2(S-0-R)/2C/LED 24V	S16SRS-L5R2C24, RED/2(S-0-R)/2C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5R2C5	RED/2(S-0-R)/2C/LED 5V	S16SRS-L5R2C5, RED/2(S-0-R)/2C/LED 5V,	

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5RC12	RED/2(S-0-R)/1C/LED 12V	S16SRS-L5RC12, RED/2(S-0-R)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5RC24	RED/2(S-0-R)/1C/LED 24V	S16SRS-L5RC24, RED/2(S-0-R)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L5RC5	RED/2(S-0-R)/1C/LED 5V	S16SRS-L5RC5, RED/2(S-0-R)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6GC12	GREEN/2(R-0-S)/1C/LED 12V	S16SRS-L6GC12, GREEN/2(R-0-S)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6GC24	GREEN/2(R-0-S)/1C/LED 24V	S16SRS-L6GC24, GREEN/2(R-0-S)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6GC5	GREEN/2(R-0-S)/1C/LED 5V	S16SRS-L6GC5, GREEN/2(R-0-S)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6R		S16SRS-L6R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6R2C12	RED/2(R-0-S)/2C/LED 12V	S16SRS-L6R2C12, RED/2(R-0-S)/2C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6R2C24	RED/2(R-0-S)/2C/LED 24V	S16SRS-L6R2C24, RED/2(R-0-S)/2C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6R2C5	RED/2(R-0-S)/2C/LED 5V	S16SRS-L6R2C5, RED/2(R-0-S)/2C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6RC12	RED/2(R-0-S)/1C/LED 12V	S16SRS-L6RC12, RED/2(R-0-S)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6RC24	RED/2(R-0-S)/1C/LED 24V	S16SRS-L6RC24, RED/2(R-0-S)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-L6RC5	RED/2(R-0-S)/1C/LED 5V	S16SRS-L6RC5, RED/2(R-0-S)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1GC	GREEN/2(0-R)/1C	S16SRS-S1GC, GREEN/2(0-R)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1R		S16SRS-S1R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1R2C	RED/2(0-R)/2C	S16SRS-S1R2C, RED/2(0-R)/2C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1R3C	RED/2(0-R)/3C	S16SRS-S1R3C, RED/2(0-R)/3C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S1RC	RED/2(0-R)/1C	S16SRS-S1RC, RED/2(0-R)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2GC	GREEN/2(0-S)/1C	S16SRS-S2GC, GREEN/2(0-S)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2R		S16SRS-S2R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2R2C	RED/2(0-S)/2C	S16SRS-S2R2C, RED/2(0-S)/2C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2R3C	RED/2(0-S)/3C	S16SRS-S2R3C, RED/2(0-S)/3C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2RC	RED/2(0-S)/1C	S16SRS-S2RC, RED/2(0-S)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S2W2C	WHITE/2(0-S)/2C	S16SRS-S2W2C, WHITE/2(0-S)/2C,	Селекторный переключатель, квадратный, позиция:Ø16, без подсветки, рабочее положение: 2-позиционный, без возврата, белый, блок контактов: контакт С:2
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S3R		S16SRS-S3R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S3R2C	RED/3(R-0-R)/2C	S16SRS-S3R2C, RED/3(R-0-R)/2C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S3RC	RED/3(R-0-R)/1C	S16SRS-S3RC, RED/3(R-0-R)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S4R		S16SRS-S4R, ,	

CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S4R2C	RED/3(S-0-S)/2C	S16SRS-S4R2C, RED/3(S-0-S)/2C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S4RC	RED/3(S-0-S)/1C	S16SRS-S4RC, RED/3(S-0-S)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S4W2C	WHITE/3(S-0-S)/2C	S16SRS-S4W2C, WHITE/3(S-0-S)/2C,	Селекторный переключатель, квадратный, позиция: Ø16, без подсветки, рабочее положение: 3-позиционный, без возврата, белый, блок контактов: контакт C:2
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S5R		S16SRS-S5R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S5R2C	RED/3(S-0-R)/2C	S16SRS-S5R2C, RED/3(S-0-R)/2C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S5RC	RED/3(S-0-R)/1C	S16SRS-S5RC, RED/3(S-0-R)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S6R		S16SRS-S6R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S6R2C	RED/3(R-0-S)/2C	S16SRS-S6R2C, RED/3(R-0-S)/2C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRS SERIES	S16SRS-S6RC	RED/3(R-0-S)/1C	S16SRS-S6RC, RED/3(R-0-S)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1GC12	GREEN/2(0-R)/1C/LED 12V	S16SRT-L1GC12, GREEN/2(0-R)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1GC24	GREEN/2(0-R)/1C/LED 24V	S16SRT-L1GC24, GREEN/2(0-R)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1GC5	GREEN/2(0-R)/1C/LED 5V	S16SRT-L1GC5, GREEN/2(0-R)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1R		S16SRT-L1R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1R2C12	RED/2(0-R)/2C/LED 12V	S16SRT-L1R2C12, RED/2(0-R)/2C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1R2C24	RED/2(0-R)/2C/LED 24V	S16SRT-L1R2C24, RED/2(0-R)/2C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1R2C5	RED/2(0-R)/2C/LED 5V	S16SRT-L1R2C5, RED/2(0-R)/2C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1RC12	RED/2(0-R)/1C/LED 12V	S16SRT-L1RC12, RED/2(0-R)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1RC24	RED/2(0-R)/1C/LED 24V	S16SRT-L1RC24, RED/2(0-R)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L1RC5	RED/2(0-R)/1C/LED 5V	S16SRT-L1RC5, RED/2(0-R)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2GC12	GREEN/2(0-S)/1C/LED 12V	S16SRT-L2GC12, GREEN/2(0-S)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2GC24	GREEN/2(0-S)/1C/LED 24V	S16SRT-L2GC24, GREEN/2(0-S)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2GC5	GREEN/2(0-S)/1C/LED 5V	S16SRT-L2GC5, GREEN/2(0-S)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2R		S16SRT-L2R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2R2C12	RED/2(0-S)/2C/LED 12V	S16SRT-L2R2C12, RED/2(0-S)/2C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2R2C24	RED/2(0-S)/2C/LED 24V	S16SRT-L2R2C24, RED/2(0-S)/2C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2R2C5	RED/2(0-S)/2C/LED 5V	S16SRT-L2R2C5, RED/2(0-S)/2C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2RC12	RED/2(0-S)/1C/LED 12V	S16SRT-L2RC12, RED/2(0-S)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2RC24	RED/2(0-S)/1C/LED 24V	S16SRT-L2RC24, RED/2(0-S)/1C/LED 24V,	

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L2RC5	RED/2(0-S)/1C/LED 5V	S16SRT-L2RC5, RED/2(0-S)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3GC12	GREEN/2(R-0-R)/1C/LED 12V	S16SRT-L3GC12, GREEN/2(R-0-R)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3GC24	GREEN/2(R-0-R)/1C/LED 24V	S16SRT-L3GC24, GREEN/2(R-0-R)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3GC5	GREEN/2(R-0-R)/1C/LED 5V	S16SRT-L3GC5, GREEN/2(R-0-R)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3R		S16SRT-L3R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3R2C12	RED/2(R-0-R)/2C/LED 12V	S16SRT-L3R2C12, RED/2(R-0-R)/2C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3R2C24	RED/2(R-0-R)/2C/LED 24V	S16SRT-L3R2C24, RED/2(R-0-R)/2C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3R2C5	RED/2(R-0-R)/2C/LED 5V	S16SRT-L3R2C5, RED/2(R-0-R)/2C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3RC12	RED/2(R-0-R)/1C/LED 12V	S16SRT-L3RC12, RED/2(R-0-R)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3RC24	RED/2(R-0-R)/1C/LED 24V	S16SRT-L3RC24, RED/2(R-0-R)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L3RC5	RED/2(R-0-R)/1C/LED 5V	S16SRT-L3RC5, RED/2(R-0-R)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4GC12	GREEN/2(S-0-S)/1C/LED 12V	S16SRT-L4GC12, GREEN/2(S-0-S)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4GC24	GREEN/2(S-0-S)/1C/LED 24V	S16SRT-L4GC24, GREEN/2(S-0-S)/1C/LED 24V,	Селекторный переключатель, Ø16, стандартный выступающий переключатель с короткой ручкой (с подсветкой), 3-позиционный, без возврата, зеленый,, 24В= блок контактов: контакт С:1, коммутация до 110В~/5А, 250В~/3А
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4GC5	GREEN/2(S-0-S)/1C/LED 5V	S16SRT-L4GC5, GREEN/2(S-0-S)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4R		S16SRT-L4R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4R2C12	RED/2(S-0-S)/2C/LED 12V	S16SRT-L4R2C12, RED/2(S-0-S)/2C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4R2C24	RED/2(S-0-S)/2C/LED 24V	S16SRT-L4R2C24, RED/2(S-0-S)/2C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4R2C5	RED/2(S-0-S)/2C/LED 5V	S16SRT-L4R2C5, RED/2(S-0-S)/2C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4RC12	RED/2(S-0-S)/1C/LED 12V	S16SRT-L4RC12, RED/2(S-0-S)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4RC24	RED/2(S-0-S)/1C/LED 24V	S16SRT-L4RC24, RED/2(S-0-S)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L4RC5	RED/2(S-0-S)/1C/LED 5V	S16SRT-L4RC5, RED/2(S-0-S)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5GC12	GREEN/2(S-0-R)/1C/LED 12V	S16SRT-L5GC12, GREEN/2(S-0-R)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5GC24	GREEN/2(S-0-R)/1C/LED 24V	S16SRT-L5GC24, GREEN/2(S-0-R)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5GC5	GREEN/2(S-0-R)/1C/LED 5V	S16SRT-L5GC5, GREEN/2(S-0-R)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5R		S16SRT-L5R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5R2C12	RED/2(S-0-R)/2C/LED 12V	S16SRT-L5R2C12, RED/2(S-0-R)/2C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5R2C24	RED/2(S-0-R)/2C/LED 24V	S16SRT-L5R2C24, RED/2(S-0-R)/2C/LED 24V,	

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5R2C5	RED/2(S-0-R)/2C/LED 5V	S16SRT-L5R2C5, RED/2(S-0-R)/2C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5RC12	RED/2(S-0-R)/1C/LED 12V	S16SRT-L5RC12, RED/2(S-0-R)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5RC24	RED/2(S-0-R)/1C/LED 24V	S16SRT-L5RC24, RED/2(S-0-R)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L5RC5	RED/2(S-0-R)/1C/LED 5V	S16SRT-L5RC5, RED/2(S-0-R)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6GC12	GREEN/2(R-0-S)/1C/LED 12V	S16SRT-L6GC12, GREEN/2(R-0-S)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6GC24	GREEN/2(R-0-S)/1C/LED 24V	S16SRT-L6GC24, GREEN/2(R-0-S)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6GC5	GREEN/2(R-0-S)/1C/LED 5V	S16SRT-L6GC5, GREEN/2(R-0-S)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6R		S16SRT-L6R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6R2C12	RED/2(R-0-S)/2C/LED 12V	S16SRT-L6R2C12, RED/2(R-0-S)/2C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6R2C24	RED/2(R-0-S)/2C/LED 24V	S16SRT-L6R2C24, RED/2(R-0-S)/2C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6R2C5	RED/2(R-0-S)/2C/LED 5V	S16SRT-L6R2C5, RED/2(R-0-S)/2C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6RC12	RED/2(R-0-S)/1C/LED 12V	S16SRT-L6RC12, RED/2(R-0-S)/1C/LED 12V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6RC24	RED/2(R-0-S)/1C/LED 24V	S16SRT-L6RC24, RED/2(R-0-S)/1C/LED 24V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-L6RC5	RED/2(R-0-S)/1C/LED 5V	S16SRT-L6RC5, RED/2(R-0-S)/1C/LED 5V,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1GC	GREEN/2(0-R)/1C	S16SRT-S1GC, GREEN/2(0-R)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1R		S16SRT-S1R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1R2C	RED/2(0-R)/2C	S16SRT-S1R2C, RED/2(0-R)/2C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1R3C	RED/2(0-R)/3C	S16SRT-S1R3C, RED/2(0-R)/3C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S1RC	RED/2(0-R)/1C	S16SRT-S1RC, RED/2(0-R)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2GC	GREEN/2(0-S)/1C	S16SRT-S2GC, GREEN/2(0-S)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2R		S16SRT-S2R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2R2C	RED/2(0-S)/2C	S16SRT-S2R2C, RED/2(0-S)/2C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2R3C	RED/2(0-S)/3C	S16SRT-S2R3C, RED/2(0-S)/3C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2RC	RED/2(0-S)/1C	S16SRT-S2RC, RED/2(0-S)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2W2C	WHITE/2(0-S)/2C	S16SRT-S2W2C, WHITE/2(0-S)/2C,	Селекторный переключатель, прямоугольный, позиция:Ø16, без подсветки, рабочее положение: 2-позиционный, без возврата, белый, блок контактов: контакт C:2
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S2WC	WHITE/2(0-S)/1C	S16SRT-S2WC, WHITE/2(0-S)/1C,	Селекторный переключатель, прямоугольный, позиция:Ø16, без подсветки, рабочее положение: 2-позиционный, без возврата, белый, блок контактов: контакт C:1
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S3R		S16SRT-S3R, ,	

CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S3R2C	RED/3(R-0-R)/2C	S16SRT-S3R2C, RED/3(R-0-R)/2C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S3RC	RED/3(R-0-R)/1C	S16SRT-S3RC, RED/3(R-0-R)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S4R		S16SRT-S4R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S4R2C	RED/3(S-0-S)/2C	S16SRT-S4R2C, RED/3(S-0-S)/2C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S4RC	RED/3(S-0-S)/1C	S16SRT-S4RC, RED/3(S-0-S)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S4W2C	WHITE/3(S-0-S)/2C	S16SRT-S4W2C, WHITE/3(S-0-S)/2C,	Селекторный переключатель, прямоугольный, позиция: Ø16, без подсветки, рабочее положение: 3-позиционный, без возврата, белый, блок контактов: контакт C:2
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S4WC	WHITE/3(S-0-S)/1C	S16SRT-S4WC, WHITE/3(S-0-S)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S5R		S16SRT-S5R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S5R2C	RED/3(S-0-R)/2C	S16SRT-S5R2C, RED/3(S-0-R)/2C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S5RC	RED/3(S-0-R)/1C	S16SRT-S5RC, RED/3(S-0-R)/1C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S6R		S16SRT-S6R, ,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S6R2C	RED/3(R-0-S)/2C	S16SRT-S6R2C, RED/3(R-0-S)/2C,	
CONTROL SWITCH	SELECTOR SWITCH	S16SRT SERIES	S16SRT-S6RC	RED/3(R-0-S)/1C	S16SRT-S6RC, RED/3(R-0-S)/1C,	

22мм управляющие переключатели

Артикул	Категория продукции 1 (Группа товаров)	Категория продукции 2 (Серия)	Категория продукции 3 (Подсерия)	Наименование модели	Спецификация (1)	Спецификация (2)	Наименование модели + Спецификация	Описание товара
H5550013434	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1ES	2(0-R)/C	GL	S2KR-1ES, 2(0-R)/C, GL	
H5550013450	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1ES2A	2(0-R)/C/A2	GL	S2KR-1ES2A, 2(0-R)/C/A2, GL	
H5550013451	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1ES2AM	2(0-R)/C/A2	GL	S2KR-1ES2AM, 2(0-R)/C/A2, GL	
H5550013454	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1ES2B	2(0-R)/C/B2	GL	S2KR-1ES2B, 2(0-R)/C/B2, GL	
H5550013455	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1ES2BM	2(0-R)/C/B2	GL	S2KR-1ES2BM, 2(0-R)/C/B2, GL	
H5550013448	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1ESA	2(0-R)/C/A1	GL	S2KR-1ESA, 2(0-R)/C/A1, GL	
H5550013456	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1ESAB	2(O-R)/C/A1B1	GL	S2KR-1ESAB, 2(O-R)/C/A1B1, GL	
H5550013457	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1ESABM	2(O-R)/C/A1B1	GL	S2KR-1ESABM, 2(O-R)/C/A1B1, GL	
H5550013449	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1ESAM	2(0-R)/C/A1	GL	S2KR-1ESAM, 2(0-R)/C/A1, GL	
H5550013452	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1ESB	2(0-R)/C/B1	GL	S2KR-1ESB, 2(0-R)/C/B1, GL	
H5550013453	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1ESBM	2(0-R)/C/B1	GL	S2KR-1ESBM, 2(0-R)/C/B1, GL	

H5550013435	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DS	2(0-S)/R	GL	S2KR-2DS, 2(0-S)/R, GL
H5550013460	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DS2A	2(0-S)/R/A2	GL	S2KR-2DS2A, 2(0-S)/R/A2, GL
H5550013461	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DS2AM	2(0-S)/R/A2	GL	S2KR-2DS2AM, 2(0-S)/R/A2, GL
H5550013464	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DS2B	2(0-S)/R/B2	GL	S2KR-2DS2B, 2(0-S)/R/B2, GL
H5550013465	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DS2BM	2(0-S)/R/B2	GL	S2KR-2DS2BM, 2(0-S)/R/B2, GL
H5550013458	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DSA	2(0-S)/R/A1	GL	S2KR-2DSA, 2(0-S)/R/A1, GL
H5550013466	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DSAB	2(0-S)/R/A1B1	GL	S2KR-2DSAB, 2(0-S)/R/A1B1, GL
H5550013467	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DSABM	2(0-S)/R/A1B1	GL	S2KR-2DSABM, 2(0-S)/R/A1B1, GL
H5550013459	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DSAM	2(0-S)/R/A1	GL	S2KR-2DSAM, 2(0-S)/R/A1, GL
H5550013462	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DSB	2(0-S)/R/B1	GL	S2KR-2DSB, 2(0-S)/R/B1, GL
H5550013463	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DSBM	2(0-S)/R/B1	GL	S2KR-2DSBM, 2(0-S)/R/B1, GL
H5550013436	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2ES	2(0-S)/C	GL	S2KR-2ES, 2(0-S)/C, GL
H5550013470	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2ES2A	2(0-S)/C/A2	GL	S2KR-2ES2A, 2(0-S)/C/A2, GL
H5550013471	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2ES2AM	2(0-S)/C/A2	GL	S2KR-2ES2AM, 2(0-S)/C/A2, GL
H5550013474	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2ES2B	2(0-S)/C/B2	GL	S2KR-2ES2B, 2(0-S)/C/B2, GL
H5550013475	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2ES2BM	2(0-S)/C/B2	GL	S2KR-2ES2BM, 2(0-S)/C/B2, GL
H5550013468	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2ESA	2(0-S)/C/A1	GL	S2KR-2ESA, 2(0-S)/C/A1, GL
H5550013476	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2ESAB	2(0-S)/C/A1B1	GL	S2KR-2ESAB, 2(0-S)/C/A1B1, GL
H5550013477	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2ESABM	2(0-S)/C/A1B1	GL	S2KR-2ESABM, 2(0-S)/C/A1B1, GL
H5550013469	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2ESAM	2(0-S)/C/A1	GL	S2KR-2ESAM, 2(0-S)/C/A1, GL
H5550013472	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2ESB	2(0-S)/C/B1	GL	S2KR-2ESB, 2(0-S)/C/B1, GL
H5550013473	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2ESBM	2(0-S)/C/B1	GL	S2KR-2ESBM, 2(0-S)/C/B1, GL
H5550013437	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FS	2(0-S)/C	GL	S2KR-2FS, 2(0-S)/C, GL
H5550013480	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FS2A	2(0-S)/C+R/A2	GL	S2KR-2FS2A, 2(0-S)/C+R/A2, GL
H5550013481	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FS2AM	2(0-S)/C+R/A2	GL	S2KR-2FS2AM, 2(0-S)/C+R/A2, GL
H5550013484	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FS2B	2(0-S)/C+R/B2	GL	S2KR-2FS2B, 2(0-S)/C+R/B2, GL
H5550013485	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FS2BM	2(0-S)/C+R/B2	GL	S2KR-2FS2BM, 2(0-S)/C+R/B2, GL
H5550013478	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FSA	2(0-S)/C+R/A1	GL	S2KR-2FSA, 2(0-S)/C+R/A1, GL

H5550013486	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FSAB	2(0-S)/C+R/A1B1	GL	S2KR-2FSAB, 2(0-S)/C+R/A1B1, GL	
H5550013487	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FSABM	2(0-S)/C+R/A1B1	GL	S2KR-2FSABM, 2(0-S)/C+R/A1B1, GL	
H5550013479	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FSAM	2(0-S)/C+R/A1	GL	S2KR-2FSAM, 2(0-S)/C+R/A1, GL	
H5550013482	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FSB	2(0-S)/C+R/B1	GL	S2KR-2FSB, 2(0-S)/C+R/B1, GL	
H5550013483	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FSBM	2(0-S)/C+R/B1	GL	S2KR-2FSBM, 2(0-S)/C+R/B1, GL	
H5550009359	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-3EK2A	3(R-0-R)/C/A2	GL	S2KR-3EK2A, 3(R-0-R)/C/A2, GL	Селекторный переключатель с ключом выступающего типа, 22/25, 3 положения с возвратом, Снятие ключа в центральной позиции, Чёрный, Нормальный открытый, Одноуровневый
H5550009362	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-3EK2B	3(R-0-R)/C/B2	GL	S2KR-3EK2B, 3(R-0-R)/C/B2, GL	
H5550009363	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-3EK2BM	3(R-0-R)/C/B2	GL	S2KR-3EK2BM, 3(R-0-R)/C/B2, GL	
H5550009364	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-3EKAB	3(R-0-R)/C/A1B1	GL	S2KR-3EKAB, 3(R-0-R)/C/A1B1, GL	
H5550009365	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-3EKABM	3(R-0-R)/C/A1B1	GL	S2KR-3EKABM, 3(R-0-R)/C/A1B1, GL	
H5550013438	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-3ES	3(R-0-R)/C	GL	S2KR-3ES, 3(R-0-R)/C, GL	
H5550013488	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-3ES2A	3(R-0-R)/C/A2	GL	S2KR-3ES2A, 3(R-0-R)/C/A2, GL	
H5550013489	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-3ES2AM	3(R-0-R)/C/A2	GL	S2KR-3ES2AM, 3(R-0-R)/C/A2, GL	
H5550013490	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-3ES2B	3(R-0-R)/C/B2	GL	S2KR-3ES2B, 3(R-0-R)/C/B2, GL	
H5550013491	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-3ES2BM	3(R-0-R)/C/B2	GL	S2KR-3ES2BM, 3(R-0-R)/C/B2, GL	
H5550013492	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-3ESAB	3(R-0-R)/C/A1B1	GL	S2KR-3ESAB, 3(R-0-R)/C/A1B1, GL	
H5550013493	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-3ESABM	3(R-0-R)/C/A1B1	GL	S2KR-3ESABM, 3(R-0-R)/C/A1B1, GL	
H5550013439	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4BS	3(S-0-S)/L+R	GL	S2KR-4BS, 3(S-0-S)/L+R, GL	
H5550013494	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4BS2A	3(S-0-S)/L+R/A2	GL	S2KR-4BS2A, 3(S-0-S)/L+R/A2, GL	
H5550013495	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4BS2AM	3(S-0-S)/L+R/A2	GL	S2KR-4BS2AM, 3(S-0-S)/L+R/A2, GL	
H5550013496	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4BS2B	3(S-0-S)/L+R/B2	GL	S2KR-4BS2B, 3(S-0-S)/L+R/B2, GL	
H5550013497	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4BS2BM	3(S-0-S)/L+R/B2	GL	S2KR-4BS2BM, 3(S-0-S)/L+R/B2, GL	
H5550013498	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4BSAB	3(S-0-S)/L+R/B2	GL	S2KR-4BSAB, 3(S-0-S)/L+R/B2, GL	
H5550013499	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4BSABM	3(S-0-S)/L+R/A1B1	GL	S2KR-4BSABM, 3(S-0-S)/L+R/A1B1, GL	
H5550013440	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4CS	3(S-0-S)/L+C+R	GL	S2KR-4CS, 3(S-0-S)/L+C+R, GL	
H5550013500	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4CS2A	3(S-0-S)/L+C+R/A2	GL	S2KR-4CS2A, 3(S-0-S)/L+C+R/A2, GL	
H5550013501	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4CS2AM	3(S-0-S)/L+C+R/A2	GL	S2KR-4CS2AM, 3(S-0-S)/L+C+R/A2, GL	

H5550013502	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4CS2B	3(S-0-S)/L+C+R/B2	GL	S2KR-4CS2B, 3(S-0-S)/L+C+R/B2, GL
H5550013503	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4CS2BM	3(S-0-S)/L+C+R/B2	GL	S2KR-4CS2BM, 3(S-0-S)/L+C+R/B2, GL
H5550013504	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4CSAB	3(S-0-S)/L+C+R/A1B1	GL	S2KR-4CSAB, 3(S-0-S)/L+C+R/A1B1, GL
H5550013505	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4CSABM	3(S-0-S)/L+C+R/A1B1	GL	S2KR-4CSABM, 3(S-0-S)/L+C+R/A1B1, GL
H5550013441	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4ES	3(S-0-S)/C	GL	S2KR-4ES, 3(S-0-S)/C, GL
H5550013506	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4ES2A	3(S-0-S)/C/A2	GL	S2KR-4ES2A, 3(S-0-S)/C/A2, GL
H5550013507	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4ES2AM	3(S-0-S)/C/A2	GL	S2KR-4ES2AM, 3(S-0-S)/C/A2, GL
H5550013508	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4ES2B	3(S-0-S)/C/B2	GL	S2KR-4ES2B, 3(S-0-S)/C/B2, GL
H5550013509	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4ES2BM	3(S-0-S)/C/B2	GL	S2KR-4ES2BM, 3(S-0-S)/C/B2, GL
H5550013510	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4ESAB	3(S-0-S)/C/A1B1	GL	S2KR-4ESAB, 3(S-0-S)/C/A1B1, GL
H5550013511	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4ESABM	3(S-0-S)/C/A1B1	GL	S2KR-4ESABM, 3(S-0-S)/C/A1B1, GL
H5550013442	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5AS	3(S-0-R)/L	GL	S2KR-5AS, 3(S-0-R)/L, GL
H5550013512	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5AS2A	3(S-0-R)/L/A2	GL	S2KR-5AS2A, 3(S-0-R)/L/A2, GL
H5550013513	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5AS2AM	3(S-0-R)/L/A2	GL	S2KR-5AS2AM, 3(S-0-R)/L/A2, GL
H5550013514	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5AS2B	3(S-0-R)/L/B2	GL	S2KR-5AS2B, 3(S-0-R)/L/B2, GL
H5550013515	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5AS2BM	3(S-0-R)/L/B2	GL	S2KR-5AS2BM, 3(S-0-R)/L/B2, GL
H5550013516	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5ASAB	3(S-0-R)/L/A1B1	GL	S2KR-5ASAB, 3(S-0-R)/L/A1B1, GL
H5550013517	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5ASABM	3(S-0-R)/L/A1B1	GL	S2KR-5ASABM, 3(S-0-R)/L/A1B1, GL
H5550013443	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5ES	3(S-0-R)/C	GL	S2KR-5ES, 3(S-0-R)/C, GL
H5550013518	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5ES2A	3(S-0-R)/C/A2	GL	S2KR-5ES2A, 3(S-0-R)/C/A2, GL
H5550013519	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5ES2AM	3(S-0-R)/C/A2	GL	S2KR-5ES2AM, 3(S-0-R)/C/A2, GL
H5550013520	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5ES2B	3(S-0-R)/C/B2	GL	S2KR-5ES2B, 3(S-0-R)/C/B2, GL
H5550013521	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5ES2BM	3(S-0-R)/C/B2	GL	S2KR-5ES2BM, 3(S-0-R)/C/B2, GL
H5550013522	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5ESAB	3(S-0-R)/C/A1B1	GL	S2KR-5ESAB, 3(S-0-R)/C/A1B1, GL
H5550013523	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5ESABM	3(S-0-R)/C/A1B1	GL	S2KR-5ESABM, 3(S-0-R)/C/A1B1, GL
H5550013444	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5GS	3(S-0-R)/L+C	GL	S2KR-5GS, 3(S-0-R)/L+C, GL
H5550013524	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5GS2A	3(S-0-R)/L+C/A2	GL	S2KR-5GS2A, 3(S-0-R)/L+C/A2, GL
H5550013525	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5GS2AM	3(S-0-R)/L+C/A2	GL	S2KR-5GS2AM, 3(S-0-R)/L+C/A2, GL

H5550013526	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5GS2B	3(S-0-R)/L+C/B2	GL	S2KR-5GS2B, 3(S-0-R)/L+C/B2, GL	
H5550013527	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5GS2BM	3(S-0-R)/L+C/B2	GL	S2KR-5GS2BM, 3(S-0-R)/L+C/B2, GL	
H5550013528	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5GSAB	3(S-0-R)/L+C/A1B1	GL	S2KR-5GSAB, 3(S-0-R)/L+C/A1B1, GL	
H5550013529	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5GSABM	3(S-0-R)/L+C/A1B1	GL	S2KR-5GSABM, 3(S-0-R)/L+C/A1B1, GL	
H5550013445	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6DS	3(R-0-S)/R	GL	S2KR-6DS, 3(R-0-S)/R, GL	
H5550013530	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6DS2A	3(R-0-S)/R/A2	GL	S2KR-6DS2A, 3(R-0-S)/R/A2, GL	
H5550013531	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6DS2AM	3(R-0-S)/R/A2	GL	S2KR-6DS2AM, 3(R-0-S)/R/A2, GL	
H5550013532	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6DS2B	3(R-0-S)/R/B2	GL	S2KR-6DS2B, 3(R-0-S)/R/B2, GL	
H5550013533	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6DS2BM	3(R-0-S)/R/B2	GL	S2KR-6DS2BM, 3(R-0-S)/R/B2, GL	
H5550013534	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6DSAB	3(R-0-S)/R/A1B1	GL	S2KR-6DSAB, 3(R-0-S)/R/A1B1, GL	
H5550013535	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6DSABM	3(R-0-S)/R/A1B1	GL	S2KR-6DSABM, 3(R-0-S)/R/A1B1, GL	
H5550013446	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6ES	3(R-0-S)/C	GL	S2KR-6ES, 3(R-0-S)/C, GL	
H5550013536	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6ES2A	3(R-0-S)/C/A2	GL	S2KR-6ES2A, 3(R-0-S)/C/A2, GL	
H5550013537	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6ES2AM	3(R-0-S)/C/A2	GL	S2KR-6ES2AM, 3(R-0-S)/C/A2, GL	
H5550013538	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6ES2B	3(R-0-S)/C/B2	GL	S2KR-6ES2B, 3(R-0-S)/C/B2, GL	
H5550013539	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6ES2BM	3(R-0-S)/C/B2	GL	S2KR-6ES2BM, 3(R-0-S)/C/B2, GL	
H5550013540	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6ESAB	3(R-0-S)/C/A1B1	GL	S2KR-6ESAB, 3(R-0-S)/C/A1B1, GL	
H5550013541	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6ESABM	3(R-0-S)/C/A1B1	GL	S2KR-6ESABM, 3(R-0-S)/C/A1B1, GL	
H5550013447	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6FS	3(R-0-S)/C+R	GL	S2KR-6FS, 3(R-0-S)/C+R, GL	
H5550013542	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6FS2A	3(R-0-S)/C+R/A2	GL	S2KR-6FS2A, 3(R-0-S)/C+R/A2, GL	
H5550013543	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6FS2AM	3(R-0-S)/C+R/A2	GL	S2KR-6FS2AM, 3(R-0-S)/C+R/A2, GL	
H5550013544	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6FS2B	3(R-0-S)/C+R/B2	GL	S2KR-6FS2B, 3(R-0-S)/C+R/B2, GL	
H5550013545	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6FS2BM	3(R-0-S)/C+R/B2	GL	S2KR-6FS2BM, 3(R-0-S)/C+R/B2, GL	
H5550013546	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6FSAB	3(R-0-S)/C+R/A1B1	GL	S2KR-6FSAB, 3(R-0-S)/C+R/A1B1, GL	
H5550013547	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6FSABM	3(R-0-S)/C+R/A1B1	GL	S2KR-6FSABM, 3(R-0-S)/C+R/A1B1, GL	
H5550009545	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1BD	BLUE	GL	L2RR-L1BD, BLUE, GL	Сигнальная лампа 22/25, Синий, сферическая головка, СИД 12-30 В=В~
H5550009612	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1BDM	BLUE	GL	L2RR-L1BDM, BLUE, GL	
H5550009575	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1BL	BLUE	GL	L2RR-L1BL, BLUE, GL	Сигнальная лампа 22/25, Синий, сферическая головка, СИД 100-220В~

H5550009646	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1BLM	BLUE	GL	L2RR-L1BLM, BLUE, GL	
H5550009614	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1GDM	GREEN	GL	L2RR-L1GDM, GREEN, GL	
H5550009647	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1GLM	GREEN	GL	L2RR-L1GLM, GREEN, GL	
H5550009618	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1WDM	WHITE	GL	L2RR-L1WDM, WHITE, GL	
H5550009649	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1WLM	WHITE	GL	L2RR-L1WLM, WHITE, GL	
H5550009616	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1YDM	YELLOW	GL	L2RR-L1YDM, YELLOW, GL	
H5550009648	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1YLM	YELLOW	GL	L2RR-L1YLM, YELLOW, GL	
H5550009555	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2BD	BLUE	GL	L2RR-L2BD, BLUE, GL	Сигнальная лампа 22/25, Синий, коническая головка, СИД 12-30 В=В~
H5550009622	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2BDM	BLUE	GL	L2RR-L2BDM, BLUE, GL	
H5550009585	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2BL	BLUE	GL	L2RR-L2BL, BLUE, GL	Сигнальная лампа 22/25, Синий, коническая головка, СИД 100-220В~
H5550009651	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2BLM	BLUE	GL	L2RR-L2BLM, BLUE, GL	
H5550009624	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2GDM	GREEN	GL	L2RR-L2GDM, GREEN, GL	
H5550009652	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2GLM	GREEN	GL	L2RR-L2GLM, GREEN, GL	
H5550009561	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2WD	WHITE	GL	L2RR-L2WD, WHITE, GL	Сигнальная лампа 22/25, Белый, коническая головка, СИД 12-30 В=В~
H5550009628	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2WDM	WHITE	GL	L2RR-L2WDM, WHITE, GL	
H5550009654	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2WLM	WHITE	GL	L2RR-L2WLM, WHITE, GL	
H5550009559	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2YD	YELLOW	GL	L2RR-L2YD, YELLOW, GL	Сигнальная лампа 22/25, Желтый, коническая головка, СИД 12-30 В=В~
H5550009626	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2YDM	YELLOW	GL	L2RR-L2YDM, YELLOW, GL	
H5550009653	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2YLM	YELLOW	GL	L2RR-L2YLM, YELLOW, GL	
H5550009633	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3BDM	BLUE	GL	L2RR-L3BDM, BLUE, GL	
H5550009656	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3BLM	BLUE	GL	L2RR-L3BLM, BLUE, GL	
H5550009636	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3GDM	GREEN	GL	L2RR-L3GDM, GREEN, GL	
H5550009657	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3GLM	GREEN	GL	L2RR-L3GLM, GREEN, GL	
H5550009642	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3WDM	WHITE	GL	L2RR-L3WDM, WHITE, GL	
H5550009659	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3WLM	WHITE	GL	L2RR-L3WLM, WHITE, GL	
H5550009639	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3YDM	YELLOW	GL	L2RR-L3YDM, YELLOW, GL	
H5550009658	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3YLM	YELLOW	GL	L2RR-L3YLM, YELLOW, GL	
H5550009665	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4BDM	BLUE LED(DC)	GL	L2RR-L4BDM, BLUE LED(DC), GL	

H5550009683	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4BLM	BLUE LED(AC)	GL	L2RR-L4BLM, BLUE LED(AC), GL	
H5550009669	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4GDM	GREEN LED(DC)	GL	L2RR-L4GDM, GREEN LED(DC), GL	
H5550009685	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4GLM	GREEN LED(AC)	GL	L2RR-L4GLM, GREEN LED(AC), GL	
H5550009677	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4WDM	WHITE LED(DC)	GL	L2RR-L4WDM, WHITE LED(DC), GL	
H5550009689	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4WLM	WHITE LED(AC)	GL	L2RR-L4WLM, WHITE LED(AC), GL	
H5550009673	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4YDM	YELLOW LED(DC)	GL	L2RR-L4YDM, YELLOW LED(DC), GL	
H5550009687	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4YLM	YELLOW LED(AC)	GL	L2RR-L4YLM, YELLOW LED(AC), GL	
H5550009635	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RRU-L3B	BLUE(NO PRINTING)	GL	L2RRU-L3B, BLUE(NO PRINTING), GL	
H5550009638	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RRU-L3G	GREEN(NO PRINTING)	GL	L2RRU-L3G, GREEN(NO PRINTING), GL	
H5550009644	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RRU-L3W	WHITE(NO PRINTING)	GL	L2RRU-L3W, WHITE(NO PRINTING), GL	
H5550009641	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RRU-L3Y	YELLOW(NO PRINTING)	GL	L2RRU-L3Y, YELLOW(NO PRINTING), GL	
H5550009667	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RRU-L4B	BLUE	GL	L2RRU-L4B, BLUE, GL	
H5550009671	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RRU-L4G	GREEN	GL	L2RRU-L4G, GREEN, GL	
H5550009679	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RRU-L4W	WHITE	GL	L2RRU-L4W, WHITE, GL	
H5550009675	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RRU-L4Y	YELLOW	GL	L2RRU-L4Y, YELLOW, GL	
H5550006898	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1G2A	GREEN A2	GL	S2BR-P1G2A, GREEN A2, GL	Пусковой кнопочный выключатель, С самовозвратом, 22/25, Зеленый, Нормально открытый, Нормально открытый, 110В~/10А, 220В~/5А
H5550006907	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1G2AB	GREEN A2 B1	GL	S2BR-P1G2AB, GREEN A2 B1, GL	Пусковой кнопочный выключатель, С самовозвратом, 22/25, Зеленый, 2 нормально открытых, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550006928	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1G2ABM	GREEN A2 B1	GL	S2BR-P1G2ABM, GREEN A2 B1, GL	
H5550006922	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1G2AM	GREEN A2	GL	S2BR-P1G2AM, GREEN A2, GL	
H5550006903	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1G2B	GREEN B2	GL	S2BR-P1G2B, GREEN B2, GL	Пусковой кнопочный выключатель, С самовозвратом, 22/25, Зеленый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550006925	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1G2BM	GREEN B2	GL	S2BR-P1G2BM, GREEN B2, GL	
H5550002328	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1G3A	GREEN A3	GL	S2BR-P1G3A, GREEN A3, GL	
H5550006923	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1G3AM	GREEN A3	GL	S2BR-P1G3AM, GREEN A3, GL	
H5550006904	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1G3B	GREEN B3	GL	S2BR-P1G3B, GREEN B3, GL	Пусковой кнопочный выключатель, С самовозвратом, 22/25, Зеленый, 3 нормально закрытых, 110В~/10А, 220В~/5А
H5550006926	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1G3BM	GREEN B3	GL	S2BR-P1G3BM, GREEN B3, GL	

H5550006909	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1GA2B	GREEN A1 B2	GL	S2BR-P1GA2B, GREEN A1 B2, GL	Пусковой кнопочный выключатель, С самовозвратом, 22/25, Зеленый, 1 нормально открытый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550006929	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1GA2BM	GREEN A1 B2	GL	S2BR-P1GA2BM, GREEN A1 B2, GL	
H5550006927	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1GABM	GREEN A1 B1	GL	S2BR-P1GABM, GREEN A1 B1, GL	
H5550006910	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1GAM	GREEN A1	GL	S2BR-P1GAM, GREEN A1, GL	Пусковой кнопочный выключатель, С самовозвратом, 22/25, Зеленый, Нормально открытый, многоуровневый, 110В~/10А, 220В~/5А
H5550006924	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1GBM	GREEN B1	GL	S2BR-P1GBM, GREEN B1, GL	
H5550004745	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1B2A	BLUE A2	GL	S2PR-E1B2A, BLUE A2, GL	
H5550004805	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1B2AB	BLUE A2 B1	GL	S2PR-E1B2AB, BLUE A2 B1, GL	
H5550004806	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1B2ABM	BLUE A2 B1	GL	S2PR-E1B2ABM, BLUE A2 B1, GL	
H5550004746	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1B2AM	BLUE A2	GL	S2PR-E1B2AM, BLUE A2, GL	
H5550004775	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1B2B	BLUE B2	GL	S2PR-E1B2B, BLUE B2, GL	
H5550004776	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1B2BM	BLUE B2	GL	S2PR-E1B2BM, BLUE B2, GL	
H5550004755	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1B3A	BLUE A3	GL	S2PR-E1B3A, BLUE A3, GL	
H5550004756	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1B3AM	BLUE A3	GL	S2PR-E1B3AM, BLUE A3, GL	
H5550004785	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1B3B	BLUE B3	GL	S2PR-E1B3B, BLUE B3, GL	
H5550004786	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1B3BM	BLUE B3	GL	S2PR-E1B3BM, BLUE B3, GL	
H5550004815	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1BA2B	BLUE A1 B2	GL	S2PR-E1BA2B, BLUE A1 B2, GL	
H5550004816	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1BA2BM	BLUE A1 B2	GL	S2PR-E1BA2BM, BLUE A1 B2, GL	
H5550004795	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1BAB	BLUE A1 B1	GL	S2PR-E1BAB, BLUE A1 B1, GL	
H5550004796	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1BABM	BLUE A1 B1	GL	S2PR-E1BABM, BLUE A1 B1, GL	
H5550004732	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1BAM	BLUE A1	GL	S2PR-E1BAM, BLUE A1, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, с выступающей головкой, Синий, Нормально открытый, Модульный тип, 110В~/10А, 220В~/5А
H5550004766	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1BBM	BLUE B1	GL	S2PR-E1BBM, BLUE B1, GL	
H5550004747	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1G2A	GREEN A2	GL	S2PR-E1G2A, GREEN A2, GL	
H5550004808	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1G2ABM	GREEN A2 B1	GL	S2PR-E1G2ABM, GREEN A2 B1, GL	
H5550004748	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1G2AM	GREEN A2	GL	S2PR-E1G2AM, GREEN A2, GL	
H5550004777	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1G2B	GREEN B2	GL	S2PR-E1G2B, GREEN B2, GL	
H5550004778	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1G2BM	GREEN B2	GL	S2PR-E1G2BM, GREEN B2, GL	

H5550004757	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1G3A	GREEN A3	GL	S2PR-E1G3A, GREEN A3, GL	
H5550004758	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1G3AM	GREEN A3	GL	S2PR-E1G3AM, GREEN A3, GL	
H5550004787	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1G3B	GREEN B3	GL	S2PR-E1G3B, GREEN B3, GL	
H5550004788	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1G3BM	GREEN B3	GL	S2PR-E1G3BM, GREEN B3, GL	
H5550004817	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1GA2B	GREEN A1 B2	GL	S2PR-E1GA2B, GREEN A1 B2, GL	
H5550004818	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1GA2BM	GREEN A1 B2	GL	S2PR-E1GA2BM, GREEN A1 B2, GL	
H5550004797	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1GAB	GREEN A1 B1	GL	S2PR-E1GAB, GREEN A1 B1, GL	
H5550004798	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1GABM	GREEN A1 B1	GL	S2PR-E1GABM, GREEN A1 B1, GL	
H5550004735	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1GAM	GREEN A1	GL	S2PR-E1GAM, GREEN A1, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, с выступающей головкой, Зеленый, Нормально открытый, Модульный тип, 110В~/10А, 220В~/5А
H5550004768	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1GBM	GREEN B1	GL	S2PR-E1GBM, GREEN B1, GL	
H5550004751	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1K2A	BLACK A2	GL	S2PR-E1K2A, BLACK A2, GL	
H5550004811	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1K2AB	BLACK A2 B1	GL	S2PR-E1K2AB, BLACK A2 B1, GL	
H5550004812	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1K2ABM	BLACK A2 B1	GL	S2PR-E1K2ABM, BLACK A2 B1, GL	
H5550004752	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1K2AM	BLACK A2	GL	S2PR-E1K2AM, BLACK A2, GL	
H5550004781	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1K2B	BLACK B2	GL	S2PR-E1K2B, BLACK B2, GL	
H5550004782	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1K2BM	BLACK B2	GL	S2PR-E1K2BM, BLACK B2, GL	
H5550004761	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1K3A	BLACK A3	GL	S2PR-E1K3A, BLACK A3, GL	
H5550004762	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1K3AM	BLACK A3	GL	S2PR-E1K3AM, BLACK A3, GL	
H5550004791	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1K3B	BLACK B3	GL	S2PR-E1K3B, BLACK B3, GL	
H5550004792	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1K3BM	BLACK B3	GL	S2PR-E1K3BM, BLACK B3, GL	
H5550004821	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1KA2B	BLACK A1 B2	GL	S2PR-E1KA2B, BLACK A1 B2, GL	
H5550004822	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1KA2BM	BLACK A1 B2	GL	S2PR-E1KA2BM, BLACK A1 B2, GL	
H5550004801	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1KAB	BLACK A1 B1	GL	S2PR-E1KAB, BLACK A1 B1, GL	
H5550004802	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1KABM	BLACK A1 B1	GL	S2PR-E1KABM, BLACK A1 B1, GL	
H5550004741	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1KAM	BLACK A1	GL	S2PR-E1KAM, BLACK A1, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, с выступающей головкой, Чёрный, Нормально открытый, Модульный тип, 110В~/10А, 220В~/5А
H5550004772	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1KBM	BLACK B1	GL	S2PR-E1KBM, BLACK B1, GL	
H5550004749	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1Y2A	YELLOW A2	GL	S2PR-E1Y2A, YELLOW A2, GL	

H5550004809	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1Y2AB	YELLOW A2 B1	GL	S2PR-E1Y2AB, YELLOW A2 B1, GL	
H5550004810	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1Y2ABM	YELLOW A2 B1	GL	S2PR-E1Y2ABM, YELLOW A2 B1, GL	
H5550004750	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1Y2AM	YELLOW A2	GL	S2PR-E1Y2AM, YELLOW A2, GL	
H5550004779	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1Y2B	YELLOW B2	GL	S2PR-E1Y2B, YELLOW B2, GL	
H5550004780	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1Y2BM	YELLOW B2	GL	S2PR-E1Y2BM, YELLOW B2, GL	
H5550004759	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1Y3A	YELLOW A3	GL	S2PR-E1Y3A, YELLOW A3, GL	
H5550004760	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1Y3AM	YELLOW A3	GL	S2PR-E1Y3AM, YELLOW A3, GL	
H5550004789	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1Y3B	YELLOW B3	GL	S2PR-E1Y3B, YELLOW B3, GL	
H5550004790	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1Y3BM	YELLOW B3	GL	S2PR-E1Y3BM, YELLOW B3, GL	
H5550004819	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1YA2B	YELLOW A1 B2	GL	S2PR-E1YA2B, YELLOW A1 B2, GL	
H5550004820	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1YA2BM	YELLOW A1 B2	GL	S2PR-E1YA2BM, YELLOW A1 B2, GL	
H5550004799	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1YAB	YELLOW A1 B1	GL	S2PR-E1YAB, YELLOW A1 B1, GL	
H5550004800	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1YABM	YELLOW A1 B1	GL	S2PR-E1YABM, YELLOW A1 B1, GL	
H5550004738	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1YAM	YELLOW A1	GL	S2PR-E1YAM, YELLOW A1, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, с выступающей головкой, Yellow, Нормально открытый, Модульный тип, 110В~/10А, 220В~/5А
H5550004770	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1YBM	YELLOW B1	GL	S2PR-E1YBM, YELLOW B1, GL	
H5550004840	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3B2AD	BLUE A2 LED(DC)	GL	S2PR-E3B2AD, BLUE A2 LED(DC), GL	
H5550004841	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3B2ADM	BLUE A2 LED(DC)	GL	S2PR-E3B2ADM, BLUE A2 LED(DC), GL	
H5550004860	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3B2AL	BLUE A2 LED(AC)	GL	S2PR-E3B2AL, BLUE A2 LED(AC), GL	
H5550004861	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3B2ALM	BLUE A2 LED(AC)	GL	S2PR-E3B2ALM, BLUE A2 LED(AC), GL	
H5550004880	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3B2BD	BLUE B2 LED(DC)	GL	S2PR-E3B2BD, BLUE B2 LED(DC), GL	
H5550004881	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3B2BDM	BLUE B2 LED(DC)	GL	S2PR-E3B2BDM, BLUE B2 LED(DC), GL	
H5550004900	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3B2BL	BLUE B2 LED(AC)	GL	S2PR-E3B2BL, BLUE B2 LED(AC), GL	
H5550004901	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3B2BLM	BLUE B2 LED(AC)	GL	S2PR-E3B2BLM, BLUE B2 LED(AC), GL	
H5550004910	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3BABD	BLUE A1 B1 LED(DC)	GL	S2PR-E3BABD, BLUE A1 B1 LED(DC), GL	
H5550004911	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3BABDM	BLUE A1 B1 LED(DC)	GL	S2PR-E3BABDM, BLUE A1 B1 LED(DC), GL	
H5550004920	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3BABL	BLUE A1 B1 LED(AC)	GL	S2PR-E3BABL, BLUE A1 B1 LED(AC), GL	
H5550004921	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3BABLM	BLUE A1 B1 LED(AC)	GL	S2PR-E3BABLM, BLUE A1 B1 LED(AC), GL	

H5550004826	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3BAD	BLUE A1 LED(DC)	GL	S2PR-E3BAD, BLUE A1 LED(DC), GL
H5550004827	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3BADM	BLUE A1 LED(DC)	GL	S2PR-E3BADM, BLUE A1 LED(DC), GL
H5550004850	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3BAL	BLUE A1 LED(AC)	GL	S2PR-E3BAL, BLUE A1 LED(AC), GL
H5550004851	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3BALM	BLUE A1 LED(AC)	GL	S2PR-E3BALM, BLUE A1 LED(AC), GL
H5550004870	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3BBD	BLUE B1 LED(DC)	GL	S2PR-E3BBD, BLUE B1 LED(DC), GL
H5550004871	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3BBDM	BLUE B1 LED(DC)	GL	S2PR-E3BBDM, BLUE B1 LED(DC), GL
H5550004890	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3BBL	BLUE B1 LED(AC)	GL	S2PR-E3BBL, BLUE B1 LED(AC), GL
H5550004891	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3BBLM	BLUE B1 LED(AC)	GL	S2PR-E3BBLM, BLUE B1 LED(AC), GL
H5550004842	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3G2AD	GREEN A2 LED(DC)	GL	S2PR-E3G2AD, GREEN A2 LED(DC), GL
H5550004843	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3G2ADM	GREEN A2 LED(DC)	GL	S2PR-E3G2ADM, GREEN A2 LED(DC), GL
H5550004862	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3G2AL	GREEN A2 LED(AC)	GL	S2PR-E3G2AL, GREEN A2 LED(AC), GL
H5550004863	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3G2ALM	GREEN A2 LED(AC)	GL	S2PR-E3G2ALM, GREEN A2 LED(AC), GL
H5550004882	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3G2BD	GREEN B2 LED(DC)	GL	S2PR-E3G2BD, GREEN B2 LED(DC), GL
H5550004883	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3G2BDM	GREEN B2 LED(DC)	GL	S2PR-E3G2BDM, GREEN B2 LED(DC), GL
H5550004902	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3G2BL	GREEN B2 LED(AC)	GL	S2PR-E3G2BL, GREEN B2 LED(AC), GL
H5550004903	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3G2BLM	GREEN B2 LED(AC)	GL	S2PR-E3G2BLM, GREEN B2 LED(AC), GL
H5550004912	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3GABD	GREEN A1 B1 LED(DC)	GL	S2PR-E3GABD, GREEN A1 B1 LED(DC), GL
H5550004913	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3GABDM	GREEN A1 B1 LED(DC)	GL	S2PR-E3GABDM, GREEN A1 B1 LED(DC), GL
H5550004922	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3GABL	GREEN A1 B1 LED(AC)	GL	S2PR-E3GABL, GREEN A1 B1 LED(AC), GL
H5550004923	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3GABLM	GREEN A1 B1 LED(AC)	GL	S2PR-E3GABLM, GREEN A1 B1 LED(AC), GL
H5550004830	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3GADM	GREEN A1 LED(DC)	GL	S2PR-E3GADM, GREEN A1 LED(DC), GL
H5550004853	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3GALM	GREEN A1 LED(AC)	GL	S2PR-E3GALM, GREEN A1 LED(AC), GL
H5550004873	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3GBDM	GREEN B1 LED(DC)	GL	S2PR-E3GBDM, GREEN B1 LED(DC), GL
H5550004893	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3GBLM	GREEN B1 LED(AC)	GL	S2PR-E3GBLM, GREEN B1 LED(AC), GL
H5550004846	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3W2AD	WHITE A2 LED(DC)	GL	S2PR-E3W2AD, WHITE A2 LED(DC), GL
H5550004847	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3W2ADM	WHITE A2 LED(DC)	GL	S2PR-E3W2ADM, WHITE A2 LED(DC), GL
H5550004866	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3W2AL	WHITE A2 LED(AC)	GL	S2PR-E3W2AL, WHITE A2 LED(AC), GL
H5550004867	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3W2ALM	WHITE A2 LED(AC)	GL	S2PR-E3W2ALM, WHITE A2 LED(AC), GL

H5550004886	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3W2BD	WHITE B2 LED(DC)	GL	S2PR-E3W2BD, WHITE B2 LED(DC), GL	
H5550004887	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3W2BDM	WHITE B2 LED(DC)	GL	S2PR-E3W2BDM, WHITE B2 LED(DC), GL	
H5550004906	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3W2BL	WHITE B2 LED(AC)	GL	S2PR-E3W2BL, WHITE B2 LED(AC), GL	
H5550004907	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3W2BLM	WHITE B2 LED(AC)	GL	S2PR-E3W2BLM, WHITE B2 LED(AC), GL	
H5550004916	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3WABD	WHITE A1 B1 LED(DC)	GL	S2PR-E3WABD, WHITE A1 B1 LED(DC), GL	
H5550004917	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3WABDM	WHITE A1 B1 LED(DC)	GL	S2PR-E3WABDM, WHITE A1 B1 LED(DC), GL	
H5550004926	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3WABL	WHITE A1 B1 LED(AC)	GL	S2PR-E3WABL, WHITE A1 B1 LED(AC), GL	
H5550004927	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3WABLM	WHITE A1 B1 LED(AC)	GL	S2PR-E3WABLM, WHITE A1 B1 LED(AC), GL	
H5550004835	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3WAD	WHITE A1 LED(DC)	GL	S2PR-E3WAD, WHITE A1 LED(DC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, белый, Нормально открытый, СИД 12-30 В=В-
H5550004836	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3WADM	WHITE A1 LED(DC)	GL	S2PR-E3WADM, WHITE A1 LED(DC), GL	
H5550004856	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3WAL	WHITE A1 LED(AC)	GL	S2PR-E3WAL, WHITE A1 LED(AC), GL	
H5550004857	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3WALM	WHITE A1 LED(AC)	GL	S2PR-E3WALM, WHITE A1 LED(AC), GL	
H5550004876	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3WBD	WHITE B1 LED(DC)	GL	S2PR-E3WBD, WHITE B1 LED(DC), GL	
H5550004877	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3WBDM	WHITE B1 LED(DC)	GL	S2PR-E3WBDM, WHITE B1 LED(DC), GL	
H5550004896	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3WBL	WHITE B1 LED(AC)	GL	S2PR-E3WBL, WHITE B1 LED(AC), GL	
H5550004897	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3WBLM	WHITE B1 LED(AC)	GL	S2PR-E3WBLM, WHITE B1 LED(AC), GL	
H5550004844	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3Y2AD	YELLOW A2 LED(DC)	GL	S2PR-E3Y2AD, YELLOW A2 LED(DC), GL	
H5550004845	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3Y2ADM	YELLOW A2 LED(DC)	GL	S2PR-E3Y2ADM, YELLOW A2 LED(DC), GL	
H5550004864	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3Y2AL	YELLOW A2 LED(AC)	GL	S2PR-E3Y2AL, YELLOW A2 LED(AC), GL	
H5550004865	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3Y2ALM	YELLOW A2 LED(AC)	GL	S2PR-E3Y2ALM, YELLOW A2 LED(AC), GL	
H5550004884	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3Y2BD	YELLOW B2 LED(DC)	GL	S2PR-E3Y2BD, YELLOW B2 LED(DC), GL	
H5550004885	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3Y2BDM	YELLOW B2 LED(DC)	GL	S2PR-E3Y2BDM, YELLOW B2 LED(DC), GL	
H5550004904	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3Y2BL	YELLOW B2 LED(DC)	GL	S2PR-E3Y2BL, YELLOW B2 LED(DC), GL	
H5550004905	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3Y2BLM	YELLOW B2 LED(DC)	GL	S2PR-E3Y2BLM, YELLOW B2 LED(DC), GL	
H5550004914	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3YABD	YELLOW A1 B1 LED(DC)	GL	S2PR-E3YABD, YELLOW A1 B1 LED(DC), GL	
H5550004915	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3YABDM	YELLOW A1 B1 LED(DC)	GL	S2PR-E3YABDM, YELLOW A1 B1 LED(DC), GL	
H5550004924	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3YABL	YELLOW A1 B1 LED(AC)	GL	S2PR-E3YABL, YELLOW A1 B1 LED(AC), GL	
H5550004925	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3YABLM	YELLOW A1 B1 LED(AC)	GL	S2PR-E3YABLM, YELLOW A1 B1 LED(AC), GL	

H5550004832	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3YAD	YELLOW A1 LED(DC)	GL	S2PR-E3YAD, YELLOW A1 LED(DC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, желтый, Нормально открытый, СИД 12-30 В=В-
H5550004833	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3YADM	YELLOW A1 LED(DC)	GL	S2PR-E3YADM, YELLOW A1 LED(DC), GL	
H5550004854	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3YAL	YELLOW A1 LED(AC)	GL	S2PR-E3YAL, YELLOW A1 LED(AC), GL	
H5550004855	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3YALM	YELLOW A1 LED(AC)	GL	S2PR-E3YALM, YELLOW A1 LED(AC), GL	
H5550004874	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3YBD	YELLOW B1 LED(DC)	GL	S2PR-E3YBD, YELLOW B1 LED(DC), GL	
H5550004875	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3YBDM	YELLOW B1 LED(DC)	GL	S2PR-E3YBDM, YELLOW B1 LED(DC), GL	
H5550004894	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3YBL	YELLOW B1 LED(AC)	GL	S2PR-E3YBL, YELLOW B1 LED(AC), GL	
H5550004895	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3YBLM	YELLOW B1 LED(AC)	GL	S2PR-E3YBLM, YELLOW B1 LED(AC), GL	
H5550004498	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1B2A	BLUE A2	GL	S2PR-P1B2A, BLUE A2, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Синий, 2 нормально открытых, 110В~/10А, 220В~/5А
H5550004674	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1B2ABM	BLUE A2 B1	GL	S2PR-P1B2ABM, BLUE A2 B1, GL	
H5550004649	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1B2AM	BLUE A2	GL	S2PR-P1B2AM, BLUE A2, GL	
H5550004510	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1B2B	BLUE B2	GL	S2PR-P1B2B, BLUE B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Синий, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550004659	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1B2BM	BLUE B2	GL	S2PR-P1B2BM, BLUE B2, GL	
H5550004504	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1B3A	BLUE A3	GL	S2PR-P1B3A, BLUE A3, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Синий, 3 нормально открытых, 110В~/10А, 220В~/5А
H5550004654	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1B3AM	BLUE A3	GL	S2PR-P1B3AM, BLUE A3, GL	
H5550004515	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1B3B	BLUE B3	GL	S2PR-P1B3B, BLUE B3, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Синий, 3 нормально закрытых, 110В~/10А, 220В~/5А
H5550004664	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1B3BM	BLUE B3	GL	S2PR-P1B3BM, BLUE B3, GL	
H5550004535	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1BA2B	BLUE A1 B2	GL	S2PR-P1BA2B, BLUE A1 B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Синий, 1 нормально открытый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550004679	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1BA2BM	BLUE A1 B2	GL	S2PR-P1BA2BM, BLUE A1 B2, GL	
H5550004669	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1BABM	BLUE A1 B1	GL	S2PR-P1BABM, BLUE A1 B1, GL	
H5550004724	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1BBM	BLUE B1	GL	S2PR-P1BBM, BLUE B1, GL	
H5550004499	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1G2A	GREEN A2	GL	S2PR-P1G2A, GREEN A2, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Зеленый, 2 нормально открытых, 110В~/10А, 220В~/5А
H5550004675	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1G2ABM	GREEN A2 B1	GL	S2PR-P1G2ABM, GREEN A2 B1, GL	
H5550004650	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1G2AM	GREEN A2	GL	S2PR-P1G2AM, GREEN A2, GL	
H5550004511	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1G2B	GREEN B2	GL	S2PR-P1G2B, GREEN B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Зеленый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550004660	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1G2BM	GREEN B2	GL	S2PR-P1G2BM, GREEN B2, GL	
H5550004505	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1G3A	GREEN A3	GL	S2PR-P1G3A, GREEN A3, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Зеленый, 3 нормально открытых, 110В~/10А, 220В~/5А

H5550004655	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1G3AM	GREEN A3	GL	S2PR-P1G3AM, GREEN A3, GL	
H5550004516	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1G3B	GREEN B3	GL	S2PR-P1G3B, GREEN B3, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Зеленый, 1 нормально закрытых, 110В~/10А, 220В~/5А
H5550004665	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1G3BM	GREEN B3	GL	S2PR-P1G3BM, GREEN B3, GL	
H5550004536	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1GA2B	GREEN A1 B2	GL	S2PR-P1GA2B, GREEN A1 B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Зеленый, 1 нормально открытый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550004680	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1GA2BM	GREEN A1 B2	GL	S2PR-P1GA2BM, GREEN A1 B2, GL	
H5550004670	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1GABM	GREEN A1 B1	GL	S2PR-P1GABM, GREEN A1 B1, GL	
H5550000020	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1K2A	BLACK A2	GL	S2PR-P1K2A, BLACK A2, GL	
H5550004533	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1K2AB	BLACK A2 B1	GL	S2PR-P1K2AB, BLACK A2 B1, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Черный, 2 нормально открытых, 110В~/10А, 220В~/5А
H5550004677	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1K2ABM	BLACK A2 B1	GL	S2PR-P1K2ABM, BLACK A2 B1, GL	
H5550004513	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1K2B	BLACK B2	GL	S2PR-P1K2B, BLACK B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Черный, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550004662	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1K2BM	BLACK B2	GL	S2PR-P1K2BM, BLACK B2, GL	
H5550004507	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1K3A	BLACK A3	GL	S2PR-P1K3A, BLACK A3, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Черный, 3 нормально открытых, 110В~/10А, 220В~/5А
H5550004657	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1K3AM	BLACK A3	GL	S2PR-P1K3AM, BLACK A3, GL	
H5550004518	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1K3B	BLACK B3	GL	S2PR-P1K3B, BLACK B3, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Черный, 3 нормально закрытых, 110В~/10А, 220В~/5А
H5550004667	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1K3BM	BLACK B3	GL	S2PR-P1K3BM, BLACK B3, GL	
H5550004538	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1KA2B	BLACK A1 B2	GL	S2PR-P1KA2B, BLACK A1 B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Черный, 1 нормально открытый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550004682	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1KA2BM	BLACK A1 B2	GL	S2PR-P1KA2BM, BLACK A1 B2, GL	
H5550004672	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1KABM	BLACK A1 B1	GL	S2PR-P1KABM, BLACK A1 B1, GL	
H5550004727	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1KBM	BLACK B1	GL	S2PR-P1KBM, BLACK B1, GL	
H5550000019	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1Y2A	YELLOW A2	GL	S2PR-P1Y2A, YELLOW A2, GL	
H5550000044	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1Y2AB	YELLOW A2 B1	GL	S2PR-P1Y2AB, YELLOW A2 B1, GL	
H5550004676	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1Y2ABM	YELLOW A2 B1	GL	S2PR-P1Y2ABM, YELLOW A2 B1, GL	
H5550004651	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1Y2AM	YELLOW A2	GL	S2PR-P1Y2AM, YELLOW A2, GL	
H5550004512	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1Y2B	YELLOW B2	GL	S2PR-P1Y2B, YELLOW B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Желтый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550004661	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1Y2BM	YELLOW B2	GL	S2PR-P1Y2BM, YELLOW B2, GL	

H5550004506	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1Y3A	YELLOW A3	GL	S2PR-P1Y3A, YELLOW A3, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Желтый, 3 нормально открытых, 110В~/10А, 220В~/5А
H5550004656	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1Y3AM	YELLOW A3	GL	S2PR-P1Y3AM, YELLOW A3, GL	
H5550004517	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1Y3B	YELLOW B3	GL	S2PR-P1Y3B, YELLOW B3, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Желтый, 3 нормально закрытых, 110В~/10А, 220В~/5А
H5550004666	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1Y3BM	YELLOW B3	GL	S2PR-P1Y3BM, YELLOW B3, GL	
H5550004537	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1YA2B	YELLOW A1 B2	GL	S2PR-P1YA2B, YELLOW A1 B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Желтый, 1 нормально открытый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550004681	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1YA2BM	YELLOW A1 B2	GL	S2PR-P1YA2BM, YELLOW A1 B2, GL	
H5550004671	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1YABM	YELLOW A1 B1	GL	S2PR-P1YABM, YELLOW A1 B1, GL	
H5550004726	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1YBM	YELLOW B1	GL	S2PR-P1YBM, YELLOW B1, GL	
H5550004540	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3B2AD	BLUE A2 LED(DC)	GL	S2PR-P3B2AD, BLUE A2 LED(DC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Синий, 2 нормально открытых, СИД 12-30 В=В~
H5550004684	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3B2ADM	BLUE A2 LED(DC)	GL	S2PR-P3B2ADM, BLUE A2 LED(DC), GL	
H5550004573	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3B2AL	BLUE A2 LED(AC)	GL	S2PR-P3B2AL, BLUE A2 LED(AC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Синий, 2 нормально открытых, СИД 100-220В~
H5550004704	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3B2ALM	BLUE A2 LED(AC)	GL	S2PR-P3B2ALM, BLUE A2 LED(AC), GL	
H5550004557	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3B2BD	BLUE B2 LED(DC)	GL	S2PR-P3B2BD, BLUE B2 LED(DC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Синий, 2 нормально закрытых, СИД 12-30 В=В~
H5550004694	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3B2BDM	BLUE B2 LED(DC)	GL	S2PR-P3B2BDM, BLUE B2 LED(DC), GL	
H5550004591	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3B2BL	BLUE B2 LED(AC)	GL	S2PR-P3B2BL, BLUE B2 LED(AC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Синий, 2 нормально закрытых, СИД 100-220В~
H5550004714	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3B2BLM	BLUE B2 LED(AC)	GL	S2PR-P3B2BLM, BLUE B2 LED(AC), GL	
H5550004699	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3BABDM	BLUE A1 B1 LED(DC)	GL	S2PR-P3BABDM, BLUE A1 B1 LED(DC), GL	
H5550004719	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3BABLM	BLUE A1 B1 LED(AC)	GL	S2PR-P3BABLM, BLUE A1 B1 LED(AC), GL	
H5550004548	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3BBD	BLUE B1 LED(DC)	GL	S2PR-P3BBD, BLUE B1 LED(DC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Синий, Нормально закрытый, СИД 12-30 В=В~
H5550004689	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3BBDM	BLUE B1 LED(DC)	GL	S2PR-P3BBDM, BLUE B1 LED(DC), GL	

H5550004582	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3BBL	BLUE B1 LED(AC)	GL	S2PR-P3BBL, BLUE B1 LED(AC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Синий, Нормально закрытый, СИД 100-220В~
H5550004709	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3BBLM	BLUE B1 LED(AC)	GL	S2PR-P3BBLM, BLUE B1 LED(AC), GL	
H5550004542	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3G2AD	GREEN A2 LED(DC)	GL	S2PR-P3G2AD, GREEN A2 LED(DC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Зеленый, 2 нормально открытых, СИД 12-30 В=В~
H5550004685	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3G2ADM	GREEN A2 LED(DC)	GL	S2PR-P3G2ADM, GREEN A2 LED(DC), GL	
H5550004574	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3G2AL	GREEN A2 LED(AC)	GL	S2PR-P3G2AL, GREEN A2 LED(AC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Зеленый, 2 нормально открытых, СИД 100-220В~
H5550004705	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3G2ALM	GREEN A2 LED(AC)	GL	S2PR-P3G2ALM, GREEN A2 LED(AC), GL	
H5550000063	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3G2BD	GREEN B2 LED(DC)	GL	S2PR-P3G2BD, GREEN B2 LED(DC), GL	
H5550004695	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3G2BDM	GREEN B2 LED(DC)	GL	S2PR-P3G2BDM, GREEN B2 LED(DC), GL	
H5550004592	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3G2BL	GREEN B2 LED(AC)	GL	S2PR-P3G2BL, GREEN B2 LED(AC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Зеленый, 2 нормально закрытых, СИД 100-220В~
H5550004715	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3G2BLM	GREEN B2 LED(AC)	GL	S2PR-P3G2BLM, GREEN B2 LED(AC), GL	
H5550004700	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3GABDM	GREEN A1 B1 LED(DC)	GL	S2PR-P3GABDM, GREEN A1 B1 LED(DC), GL	
H5550004690	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3GBDM	GREEN B1 LED(DC)	GL	S2PR-P3GBDM, GREEN B1 LED(DC), GL	
H5550004710	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3GBLM	GREEN B1 LED(AC)	GL	S2PR-P3GBLM, GREEN B1 LED(AC), GL	
H5550004545	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3W2AD	WHITE A2 LED(DC)	GL	S2PR-P3W2AD, WHITE A2 LED(DC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Белый, 2 нормально открытых, СИД 12-30 В=В~
H5550004687	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3W2ADM	WHITE A2 LED(DC)	GL	S2PR-P3W2ADM, WHITE A2 LED(DC), GL	
H5550004707	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3W2ALM	WHITE A2 LED(AC)	GL	S2PR-P3W2ALM, WHITE A2 LED(AC), GL	
H5550004560	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3W2BD	WHITE B2 LED(DC)	GL	S2PR-P3W2BD, WHITE B2 LED(DC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Белый, 2 нормально закрытых, СИД 12-30 В=В~
H5550004697	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3W2BDM	WHITE B2 LED(DC)	GL	S2PR-P3W2BDM, WHITE B2 LED(DC), GL	
H5550004594	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3W2BL	WHITE B2 LED(AC)	GL	S2PR-P3W2BL, WHITE B2 LED(AC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Белый, 2 нормально закрытых, СИД 100-220В~
H5550004717	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3W2BLM	WHITE B2 LED(AC)	GL	S2PR-P3W2BLM, WHITE B2 LED(AC), GL	
H5550004702	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3WABDM	WHITE A1 B1 LED(DC)	GL	S2PR-P3WABDM, WHITE A1 B1 LED(DC), GL	
H5550004605	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3WABL	WHITE A1 B1 LED(AC)	GL	S2PR-P3WABL, WHITE A1 B1 LED(AC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Белый, 1 нормально открытый, 1 нормально закрытый, СИД 100-220В~
H5550004722	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3WABLM	WHITE A1 B1 LED(AC)	GL	S2PR-P3WABLM, WHITE A1 B1 LED(AC), GL	
H5550004640	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3WADM	WHITE	GL	S2PR-P3WADM, WHITE, GL	
H5550004712	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3WBML	WHITE B1 LED(AC)	GL	S2PR-P3WBML, WHITE B1 LED(AC), GL	

H5550004544	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3Y2AD	YELLOW A2 LED(DC)	GL	S2PR-P3Y2AD, YELLOW A2 LED(DC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Желтый, 2 нормально открытых, СИД 12-30 В=В~
H5550004686	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3Y2ADM	YELLOW A2 LED(DC)	GL	S2PR-P3Y2ADM, YELLOW A2 LED(DC), GL	
H5550004576	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3Y2AL	YELLOW A2 LED(AC)	GL	S2PR-P3Y2AL, YELLOW A2 LED(AC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Желтый, 2 нормально открытых, СИД 100-220В~
H5550004706	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3Y2ALM	YELLOW A2 LED(AC)	GL	S2PR-P3Y2ALM, YELLOW A2 LED(AC), GL	
H5550004559	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3Y2BD	YELLOW B2 LED(DC)	GL	S2PR-P3Y2BD, YELLOW B2 LED(DC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Желтый, 2 нормально закрытых, СИД 12-30 В=В~
H5550004696	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3Y2BDM	YELLOW B2 LED(DC)	GL	S2PR-P3Y2BDM, YELLOW B2 LED(DC), GL	
H5550004593	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3Y2BL	YELLOW B2 LED(AC)	GL	S2PR-P3Y2BL, YELLOW B2 LED(AC), GL	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Желтый, 2 нормально закрытых, СИД 100-220В~
H5550004716	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3Y2BLM	YELLOW B2 LED(AC)	GL	S2PR-P3Y2BLM, YELLOW B2 LED(AC), GL	
H5550004701	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3YABDM	YELLOW A1 B1 LED(DC)	GL	S2PR-P3YABDM, YELLOW A1 B1 LED(DC), GL	
H5550004721	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3YABLM	YELLOW A1 B1 LED(AC)	GL	S2PR-P3YABLM, YELLOW A1 B1 LED(AC), GL	
H5550004637	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3YADM	YELLOW	GL	S2PR-P3YADM, YELLOW, GL	
H5550004691	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3YBDM	YELLOW B1 LED(DC)	GL	S2PR-P3YBDM, YELLOW B1 LED(DC), GL	
H5550004711	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3YBLM	YELLOW B1 LED(AC)	GL	S2PR-P3YBLM, YELLOW B1 LED(AC), GL	
H5550004945	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1B2A	BLUE A2	GL	S2PRS-P1B2A, BLUE A2, GL	
H5550005005	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1B2AB	BLUE A2 B1	GL	S2PRS-P1B2AB, BLUE A2 B1, GL	
H5550005006	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1B2ABM	BLUE A2 B1	GL	S2PRS-P1B2ABM, BLUE A2 B1, GL	
H5550004946	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1B2AM	BLUE A2	GL	S2PRS-P1B2AM, BLUE A2, GL	
H5550004975	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1B2B	BLUE B2	GL	S2PRS-P1B2B, BLUE B2, GL	
H5550004976	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1B2BM	BLUE B2	GL	S2PRS-P1B2BM, BLUE B2, GL	
H5550004955	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1B3A	BLUE A3	GL	S2PRS-P1B3A, BLUE A3, GL	
H5550004956	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1B3AM	BLUE A3	GL	S2PRS-P1B3AM, BLUE A3, GL	
H5550004985	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1B3B	BLUE B3	GL	S2PRS-P1B3B, BLUE B3, GL	
H5550004986	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1B3BM	BLUE B3	GL	S2PRS-P1B3BM, BLUE B3, GL	
H5550005015	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1BA2B	BLUE A1 B2	GL	S2PRS-P1BA2B, BLUE A1 B2, GL	
H5550005016	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1BA2BM	BLUE A1 B2	GL	S2PRS-P1BA2BM, BLUE A1 B2, GL	
H5550004995	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1BAB	BLUE A1 B1	GL	S2PRS-P1BAB, BLUE A1 B1, GL	

H5550004996	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1BAM	BLUE A1 B1	GL	S2PRS-P1BAM, BLUE A1 B1, GL	
H5550004932	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1BAM	BLUE A1	GL	S2PRS-P1BAM, BLUE A1, GL	Квадратный кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Синий, Нормально открытый, Модульный тип
H5550004965	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1BB	BLUE B1	GL	S2PRS-P1BB, BLUE B1, GL	
H5550004966	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1BBM	BLUE B1	GL	S2PRS-P1BBM, BLUE B1, GL	
H5550004947	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1G2A	GREEN A2	GL	S2PRS-P1G2A, GREEN A2, GL	
H5550005007	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1G2AB	GREEN A2 B1	GL	S2PRS-P1G2AB, GREEN A2 B1, GL	
H5550005008	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1G2ABM	GREEN A2 B1	GL	S2PRS-P1G2ABM, GREEN A2 B1, GL	
H5550004948	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1G2AM	GREEN A2	GL	S2PRS-P1G2AM, GREEN A2, GL	
H5550004977	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1G2B	GREEN B2	GL	S2PRS-P1G2B, GREEN B2, GL	
H5550004978	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1G2BM	GREEN B2	GL	S2PRS-P1G2BM, GREEN B2, GL	
H5550004957	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1G3A	GREEN A3	GL	S2PRS-P1G3A, GREEN A3, GL	
H5550004958	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1G3AM	GREEN A3	GL	S2PRS-P1G3AM, GREEN A3, GL	
H5550004987	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1G3B	GREEN B3	GL	S2PRS-P1G3B, GREEN B3, GL	
H5550004988	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1G3BM	GREEN B3	GL	S2PRS-P1G3BM, GREEN B3, GL	
H5550005017	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1GA2B	GREEN A1 B2	GL	S2PRS-P1GA2B, GREEN A1 B2, GL	
H5550005018	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1GA2BM	GREEN A1 B2	GL	S2PRS-P1GA2BM, GREEN A1 B2, GL	
H5550004997	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1GAB	GREEN A1 B1	GL	S2PRS-P1GAB, GREEN A1 B1, GL	
H5550004998	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1GABM	GREEN A1 B1	GL	S2PRS-P1GABM, GREEN A1 B1, GL	
H5550004935	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1GAM	GREEN A1	GL	S2PRS-P1GAM, GREEN A1, GL	Квадратный кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Зеленый, Нормально открытый, Модульный тип
H5550004968	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1GBM	GREEN B1	GL	S2PRS-P1GBM, GREEN B1, GL	
H5550004951	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1K2A	BLACK A2	GL	S2PRS-P1K2A, BLACK A2, GL	
H5550005011	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1K2AB	BLACK A2 B1	GL	S2PRS-P1K2AB, BLACK A2 B1, GL	
H5550005012	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1K2ABM	BLACK A2 B1	GL	S2PRS-P1K2ABM, BLACK A2 B1, GL	
H5550004952	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1K2AM	BLACK A2	GL	S2PRS-P1K2AM, BLACK A2, GL	
H5550004981	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1K2B	BLACK B2	GL	S2PRS-P1K2B, BLACK B2, GL	
H5550004982	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1K2BM	BLACK B2	GL	S2PRS-P1K2BM, BLACK B2, GL	
H5550004961	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1K3A	BLACK A3	GL	S2PRS-P1K3A, BLACK A3, GL	

H5550004962	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1K3AM	BLACK A3	GL	S2PRS-P1K3AM, BLACK A3, GL	
H5550004991	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1K3B	BLACK B3	GL	S2PRS-P1K3B, BLACK B3, GL	
H5550004992	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1K3BM	BLACK B3	GL	S2PRS-P1K3BM, BLACK B3, GL	
H5550005021	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1KA2B	BLACK A1 B2	GL	S2PRS-P1KA2B, BLACK A1 B2, GL	
H5550005022	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1KA2BM	BLACK A1 B2	GL	S2PRS-P1KA2BM, BLACK A1 B2, GL	
H5550005001	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1KAB	BLACK A1 B1	GL	S2PRS-P1KAB, BLACK A1 B1, GL	
H5550005002	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1KABM	BLACK A1 B1	GL	S2PRS-P1KABM, BLACK A1 B1, GL	
H5550004941	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1KAM	BLACK A1	GL	S2PRS-P1KAM, BLACK A1, GL	Квадратный кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Чёрный, Нормально открытый, Модульный тип
H5550004971	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1KB	BLACK B1	GL	S2PRS-P1KB, BLACK B1, GL	
H5550004972	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1KBM	BLACK B1	GL	S2PRS-P1KBM, BLACK B1, GL	
H5550004949	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1Y2A	YELLOW A2	GL	S2PRS-P1Y2A, YELLOW A2, GL	
H5550005009	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1Y2AB	YELLOW A2 B1	GL	S2PRS-P1Y2AB, YELLOW A2 B1, GL	
H5550005010	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1Y2ABM	YELLOW A2 B1	GL	S2PRS-P1Y2ABM, YELLOW A2 B1, GL	
H5550004950	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1Y2AM	YELLOW A2	GL	S2PRS-P1Y2AM, YELLOW A2, GL	
H5550004979	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1Y2B	YELLOW B2	GL	S2PRS-P1Y2B, YELLOW B2, GL	
H5550004980	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1Y2BM	YELLOW B2	GL	S2PRS-P1Y2BM, YELLOW B2, GL	
H5550004959	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1Y3A	Y3LLOW A3	GL	S2PRS-P1Y3A, Y3LLOW A3, GL	
H5550004960	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1Y3AM	Y3LLOW A3	GL	S2PRS-P1Y3AM, Y3LLOW A3, GL	
H5550004989	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1Y3B	YELLOW B3	GL	S2PRS-P1Y3B, YELLOW B3, GL	
H5550004990	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1Y3BM	YELLOW B3	GL	S2PRS-P1Y3BM, YELLOW B3, GL	
H5550004937	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1YA	YELLOW A1	GL	S2PRS-P1YA, YELLOW A1, GL	
H5550005019	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1YA2B	YELLOW A1 B2	GL	S2PRS-P1YA2B, YELLOW A1 B2, GL	
H5550005020	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1YA2BM	YELLOW A1 B2	GL	S2PRS-P1YA2BM, YELLOW A1 B2, GL	
H5550004999	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1YAB	YELLOW A1 B1	GL	S2PRS-P1YAB, YELLOW A1 B1, GL	
H5550005000	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1YABM	YELLOW A1 B1	GL	S2PRS-P1YABM, YELLOW A1 B1, GL	
H5550004938	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1YAM	YELLOW A1	GL	S2PRS-P1YAM, YELLOW A1, GL	Квадратный кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Желтый, Нормально открытый, Модульный тип
H5550004970	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1YBM	YELLOW B1	GL	S2PRS-P1YBM, YELLOW B1, GL	

H5550005045	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3B2AD	BLUE A2 LED(DC)	GL	S2PRS-P3B2AD, BLUE A2 LED(DC), GL	
H5550005046	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3B2ADM	BLUE A2 LED(DC)	GL	S2PRS-P3B2ADM, BLUE A2 LED(DC), GL	
H5550005065	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3B2AL	BLUE A2 LED(AC)	GL	S2PRS-P3B2AL, BLUE A2 LED(AC), GL	
H5550005066	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3B2ALM	BLUE A2 LED(AC)	GL	S2PRS-P3B2ALM, BLUE A2 LED(AC), GL	
H5550005085	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3B2BD	BLUE B2 LED(DC)	GL	S2PRS-P3B2BD, BLUE B2 LED(DC), GL	
H5550005086	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3B2BDM	BLUE B2 LED(DC)	GL	S2PRS-P3B2BDM, BLUE B2 LED(DC), GL	
H5550005105	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3B2BL	BLUE B2 LED(AC)	GL	S2PRS-P3B2BL, BLUE B2 LED(AC), GL	
H5550005106	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3B2BLM	BLUE B2 LED(AC)	GL	S2PRS-P3B2BLM, BLUE B2 LED(AC), GL	
H5550005115	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BABD	BLUE AB LED(DC)	GL	S2PRS-P3BABD, BLUE AB LED(DC), GL	
H5550005116	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BABDM	BLUE AB LED(DC)	GL	S2PRS-P3BABDM, BLUE AB LED(DC), GL	
H5550005125	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BABL	BLUE AB LED(AC)	GL	S2PRS-P3BABL, BLUE AB LED(AC), GL	
H5550005126	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BABLM	BLUE AB LED(AC)	GL	S2PRS-P3BABLM, BLUE AB LED(AC), GL	
H5550005028	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BADM	BLUE A1 LED(DC)	GL	S2PRS-P3BADM, BLUE A1 LED(DC), GL	
H5550005056	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BALM	BLUE A1 LED(AC)	GL	S2PRS-P3BALM, BLUE A1 LED(AC), GL	Квадратный кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Синий, Нормально открытый, многоуровневый, СИД 100-220В~
H5550005075	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BBD	BLUE B1 LED(DC)	GL	S2PRS-P3BBD, BLUE B1 LED(DC), GL	
H5550005076	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BBDM	BLUE B1 LED(DC)	GL	S2PRS-P3BBDM, BLUE B1 LED(DC), GL	
H5550005095	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BBL	BLUE B1 LED(AC)	GL	S2PRS-P3BBL, BLUE B1 LED(AC), GL	
H5550005096	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BBLM	BLUE B1 LED(AC)	GL	S2PRS-P3BBLM, BLUE B1 LED(AC), GL	
H5550005243	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BL		GL	S2PRS-P3BL, , GL	
H5550005255	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BL2AD	BLUE A2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3BL2AD, BLUE A2 LED(DC) LEFT/RIGHT, GL	
H5550005256	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BL2ADM	BLUE A2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3BL2ADM, BLUE A2 LED(DC) LEFT/RIGHT, GL	
H5550005305	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BL2AL	BLUE A2 LED(AC) LEFT/RIGHT	GL	S2PRS-P3BL2AL, BLUE A2 LED(AC) LEFT/RIGHT, GL	
H5550005306	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BL2ALM	BLUE A2 LED(AC) LEFT/RIGHT	GL	S2PRS-P3BL2ALM, BLUE A2 LED(AC) LEFT/RIGHT, GL	
H5550005275	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BL2BD	BLUE B2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3BL2BD, BLUE B2 LED(DC) LEFT/RIGHT, GL	
H5550005276	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BL2BDM	BLUE B2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3BL2BDM, BLUE B2 LED(DC) LEFT/RIGHT, GL	
H5550005325	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BL2BL	BLUE B2 LED(AC) LEFT/RIGHT	GL	S2PRS-P3BL2BL, BLUE B2 LED(AC) LEFT/RIGHT, GL	
H5550005326	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BL2BLM	BLUE B2 LED(AC) LEFT/RIGHT	GL	S2PRS-P3BL2BLM, BLUE B2 LED(AC) LEFT/RIGHT, GL	

H5550005285	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BLABD	BLUE A1 B1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3BLABD, BLUE A1 B1 LED(DC) LEFT/RIGHT, GL
H5550005286	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BLABDM	BLUE A1 B1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3BLABDM, BLUE A1 B1 LED(DC) LEFT/RIGHT, GL
H5550005335	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BLABL	BLUE A1 B1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3BLABL, BLUE A1 B1 LED(AC) LEFT/RIGHT, GL
H5550005336	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BLABL M	BLUE A1 B1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3BLABL M, BLUE A1 B1 LED(AC) LEFT/RIGHT, GL
H5550005241	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BLAD	BLUE A1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3BLAD, BLUE A1 LED(DC) LEFT/RIGHT, GL
H5550005242	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BLADM	BLUE A1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3BLADM, BLUE A1 LED(DC) LEFT/RIGHT, GL
H5550005295	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BLAL	BLUE A1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3BLAL, BLUE A1 LED(AC) LEFT/RIGHT, GL
H5550005296	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BLAL M	BLUE A1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3BLAL M, BLUE A1 LED(AC) LEFT/RIGHT, GL
H5550005265	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BLBD	BLUE B1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3BLBD, BLUE B1 LED(DC) LEFT/RIGHT, GL
H5550005266	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BLBDM	BLUE B1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3BLBDM, BLUE B1 LED(DC) LEFT/RIGHT, GL
H5550005315	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BLBL	BLUE B1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3BLBL, BLUE B1 LED(AC) LEFT/RIGHT, GL
H5550005316	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BLBL M	BLUE B1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3BLBL M, BLUE B1 LED(AC) LEFT/RIGHT, GL
H5550005188	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BU	BLUE	GL	S2PRS-P3BU, BLUE, GL
H5550005145	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BU2AD	BLUE A2 LED(DC) UP/DOWN	GL	S2PRS-P3BU2AD, BLUE A2 LED(DC) UP/DOWN, GL
H5550005146	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BU2ADM	BLUE A2 LED(DC) UP/DOWN	GL	S2PRS-P3BU2ADM, BLUE A2 LED(DC) UP/DOWN, GL
H5550005200	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BU2AL	BLUE A2 LED(AC) UP/DOWN	GL	S2PRS-P3BU2AL, BLUE A2 LED(AC) UP/DOWN, GL
H5550005201	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BU2AL M	BLUE A2 LED(AC) UP/DOWN	GL	S2PRS-P3BU2AL M, BLUE A2 LED(AC) UP/DOWN, GL
H5550005165	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BU2BD	BLUE B2 LED(DC) UP/DOWN	GL	S2PRS-P3BU2BD, BLUE B2 LED(DC) UP/DOWN, GL
H5550005166	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BU2BDM	BLUE B2 LED(DC) UP/DOWN	GL	S2PRS-P3BU2BDM, BLUE B2 LED(DC) UP/DOWN, GL
H5550005220	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BU2BL	BLUE B2 LED(AC) UP/DOWN	GL	S2PRS-P3BU2BL, BLUE B2 LED(AC) UP/DOWN, GL
H5550005221	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BU2BL M	BLUE B2 LED(AC) UP/DOWN	GL	S2PRS-P3BU2BL M, BLUE B2 LED(AC) UP/DOWN, GL
H5550005175	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BUABD	BLUE A1 B1 LED(DC) UP/DOWN	GL	S2PRS-P3BUABD, BLUE A1 B1 LED(DC) UP/DOWN, GL
H5550005176	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BUABDM	BLUE A1 B1 LED(DC) UP/DOWN	GL	S2PRS-P3BUABDM, BLUE A1 B1 LED(DC) UP/DOWN, GL
H5550005230	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BUABL	BLUE A1 B1 LED(AC) UP/DOWN	GL	S2PRS-P3BUABL, BLUE A1 B1 LED(AC) UP/DOWN, GL
H5550005231	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BUABL M	BLUE A1 B1 LED(AC) UP/DOWN	GL	S2PRS-P3BUABL M, BLUE A1 B1 LED(AC) UP/DOWN, GL
H5550005135	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BUAD	BLUE A1 LED(DC) UP/DOWN	GL	S2PRS-P3BUAD, BLUE A1 LED(DC) UP/DOWN, GL
H5550005136	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BUADM	BLUE A1 LED(DC) UP/DOWN	GL	S2PRS-P3BUADM, BLUE A1 LED(DC) UP/DOWN, GL
H5550005186	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BUAL	BLUE A1 LED(AC) UP/DOWN	GL	S2PRS-P3BUAL, BLUE A1 LED(AC) UP/DOWN, GL

H5550005187	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BUALM	BLUE A1 LED(AC) UP/DOWN	GL	S2PRS-P3BUALM, BLUE A1 LED(AC) UP/DOWN, GL	Квадратный кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Синий, Нормально открытый, Модульный тип, СИД 100-220В-, Стрелка вверх/вниз
H5550005155	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BUBD	BLUE B1 LED(DC) UP/DOWN	GL	S2PRS-P3BUBD, BLUE B1 LED(DC) UP/DOWN, GL	
H5550005156	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BUBDM	BLUE B1 LED(DC) UP/DOWN	GL	S2PRS-P3BUBDM, BLUE B1 LED(DC) UP/DOWN, GL	
H5550005210	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BUBL	BLUE B1 LED(AC) UP/DOWN	GL	S2PRS-P3BUBL, BLUE B1 LED(AC) UP/DOWN, GL	
H5550005211	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BUBLM	BLUE B1 LED(AC) UP/DOWN	GL	S2PRS-P3BUBLM, BLUE B1 LED(AC) UP/DOWN, GL	
H5550005047	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3G2AD	GREEN A2 LED(DC)	GL	S2PRS-P3G2AD, GREEN A2 LED(DC), GL	
H5550005048	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3G2ADM	GREEN A2 LED(DC)	GL	S2PRS-P3G2ADM, GREEN A2 LED(DC), GL	
H5550005067	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3G2AL	GREEN A2 LED(AC)	GL	S2PRS-P3G2AL, GREEN A2 LED(AC), GL	
H5550005068	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3G2ALM	GREEN A2 LED(AC)	GL	S2PRS-P3G2ALM, GREEN A2 LED(AC), GL	
H5550005087	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3G2BD	GREEN B2 LED(DC)	GL	S2PRS-P3G2BD, GREEN B2 LED(DC), GL	
H5550005088	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3G2BDM	GREEN B2 LED(DC)	GL	S2PRS-P3G2BDM, GREEN B2 LED(DC), GL	
H5550005107	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3G2BL	GREEN B2 LED(AC)	GL	S2PRS-P3G2BL, GREEN B2 LED(AC), GL	
H5550005108	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3G2BLM	GREEN B2 LED(AC)	GL	S2PRS-P3G2BLM, GREEN B2 LED(AC), GL	
H5550005117	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GABD	GREEN AB LED(DC)	GL	S2PRS-P3GABD, GREEN AB LED(DC), GL	
H5550005118	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GABDM	GREEN AB LED(DC)	GL	S2PRS-P3GABDM, GREEN AB LED(DC), GL	
H5550005128	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GABLM	GREEN AB LED(AC)	GL	S2PRS-P3GABLM, GREEN AB LED(AC), GL	
H5550005032	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GADM	GREEN A1 LED(DC)	GL	S2PRS-P3GADM, GREEN A1 LED(DC), GL	
H5550005058	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GALM	GREEN A1 LED(AC)	GL	S2PRS-P3GALM, GREEN A1 LED(AC), GL	Квадратный кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Зеленый, Нормально открытый, Модульный тип, СИД 100-220В-
H5550005078	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GBDM	GREEN B1 LED(DC)	GL	S2PRS-P3GBDM, GREEN B1 LED(DC), GL	
H5550005098	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GBLM	GREEN B1 LED(AC)	GL	S2PRS-P3GBLM, GREEN B1 LED(AC), GL	
H5550005246	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GL		GL	S2PRS-P3GL, , GL	
H5550005257	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GL2AD	GREEN A2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3GL2AD, GREEN A2 LED(DC) LEFT/RIGHT, GL	
H5550005258	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GL2ADM	GREEN A2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3GL2ADM, GREEN A2 LED(DC) LEFT/RIGHT, GL	
H5550005307	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GL2AL	GREEN A2 LED(AC) LEFT/RIGHT	GL	S2PRS-P3GL2AL, GREEN A2 LED(AC) LEFT/RIGHT, GL	
H5550005308	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GL2ALM	GREEN A2 LED(AC) LEFT/RIGHT	GL	S2PRS-P3GL2ALM, GREEN A2 LED(AC) LEFT/RIGHT, GL	
H5550005277	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GL2BD	GREEN B2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3GL2BD, GREEN B2 LED(DC) LEFT/RIGHT, GL	
H5550005278	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GL2BDM	GREEN B2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3GL2BDM, GREEN B2 LED(DC) LEFT/RIGHT, GL	

H5550005327	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GL2BL	GREEN B2 LED(AC) LEFT/RIGHT	GL	S2PRS-P3GL2BL, GREEN B2 LED(AC) LEFT/RIGHT, GL	
H5550005328	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GL2BLM	GREEN B2 LED(AC) LEFT/RIGHT	GL	S2PRS-P3GL2BLM, GREEN B2 LED(AC) LEFT/RIGHT, GL	
H5550005287	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GLABD	GREEN A1 B1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3GLABD, GREEN A1 B1 LED(DC) LEFT/RIGHT, GL	
H5550005288	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GLABDM	GREEN A1 B1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3GLABDM, GREEN A1 B1 LED(DC) LEFT/RIGHT, GL	
H5550005337	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GLABL	GREEN A1 B1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3GLABL, GREEN A1 B1 LED(AC) LEFT/RIGHT, GL	
H5550005338	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GLABLM	GREEN A1 B1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3GLABLM, GREEN A1 B1 LED(AC) LEFT/RIGHT, GL	
H5550005245	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GLADM	GREEN A1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3GLADM, GREEN A1 LED(DC) LEFT/RIGHT, GL	
H5550005298	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GLALM	GREEN A1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3GLALM, GREEN A1 LED(AC) LEFT/RIGHT, GL	
H5550005268	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GLBDM	GREEN B1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3GLBDM, GREEN B1 LED(DC) LEFT/RIGHT, GL	
H5550005318	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GLBLM	GREEN B1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3GLBLM, GREEN B1 LED(AC) LEFT/RIGHT, GL	
H5550005191	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GU	GREEN	GL	S2PRS-P3GU, GREEN, GL	
H5550005147	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GU2AD	GREEN A2 LED(DC) UP/DOWN	GL	S2PRS-P3GU2AD, GREEN A2 LED(DC) UP/DOWN, GL	
H5550005148	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GU2ADM	GREEN A2 LED(DC) UP/DOWN	GL	S2PRS-P3GU2ADM, GREEN A2 LED(DC) UP/DOWN, GL	
H5550005202	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GU2AL	GREEN A2 LED(AC) UP/DOWN	GL	S2PRS-P3GU2AL, GREEN A2 LED(AC) UP/DOWN, GL	
H5550005203	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GU2ALM	GREEN A2 LED(AC) UP/DOWN	GL	S2PRS-P3GU2ALM, GREEN A2 LED(AC) UP/DOWN, GL	
H5550005167	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GU2BD	GREEN B2 LED(DC) UP/DOWN	GL	S2PRS-P3GU2BD, GREEN B2 LED(DC) UP/DOWN, GL	
H5550005168	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GU2BDM	GREEN B2 LED(DC) UP/DOWN	GL	S2PRS-P3GU2BDM, GREEN B2 LED(DC) UP/DOWN, GL	
H5550005222	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GU2BL	GREEN B2 LED(AC) UP/DOWN	GL	S2PRS-P3GU2BL, GREEN B2 LED(AC) UP/DOWN, GL	
H5550005223	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GU2BLM	GREEN B2 LED(AC) UP/DOWN	GL	S2PRS-P3GU2BLM, GREEN B2 LED(AC) UP/DOWN, GL	
H5550005177	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GUABD	GREEN A1 B1 LED(DC) UP/DOWN	GL	S2PRS-P3GUABD, GREEN A1 B1 LED(DC) UP/DOWN, GL	
H5550005178	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GUABDM	GREEN A1 B1 LED(DC) UP/DOWN	GL	S2PRS-P3GUABDM, GREEN A1 B1 LED(DC) UP/DOWN, GL	
H5550005232	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GUABL	GREEN A1 B1 LED(AC) UP/DOWN	GL	S2PRS-P3GUABL, GREEN A1 B1 LED(AC) UP/DOWN, GL	
H5550005233	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GUABLM	GREEN A1 B1 LED(AC) UP/DOWN	GL	S2PRS-P3GUABLM, GREEN A1 B1 LED(AC) UP/DOWN, GL	
H5550005137	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GUAD	GREEN A1 LED(DC) UP/DOWN	GL	S2PRS-P3GUAD, GREEN A1 LED(DC) UP/DOWN, GL	
H5550005138	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GUADM	GREEN A1 LED(DC) UP/DOWN	GL	S2PRS-P3GUADM, GREEN A1 LED(DC) UP/DOWN, GL	
H5550005189	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GUAL	GREEN A1 LED(AC) UP/DOWN	GL	S2PRS-P3GUAL, GREEN A1 LED(AC) UP/DOWN, GL	
H5550005190	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GUALM	GREEN A1 LED(AC) UP/DOWN	GL	S2PRS-P3GUALM, GREEN A1 LED(AC) UP/DOWN, GL	Квадратный кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Зеленый, Нормально открытый, Модульный тип, СИД 100-220В~, Стрелка вверх/вниз

H5550005157	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GUBD	GREEN B1 LED(DC) UP/DOWN	GL	S2PRS-P3GUBD, GREEN B1 LED(DC) UP/DOWN, GL	
H5550005158	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GUBDM	GREEN B1 LED(DC) UP/DOWN	GL	S2PRS-P3GUBDM, GREEN B1 LED(DC) UP/DOWN, GL	
H5550005212	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GUBL	GREEN B1 LED(AC) UP/DOWN	GL	S2PRS-P3GUBL, GREEN B1 LED(AC) UP/DOWN, GL	
H5550005213	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GUBLM	GREEN B1 LED(AC) UP/DOWN	GL	S2PRS-P3GUBLM, GREEN B1 LED(AC) UP/DOWN, GL	
H5550005240	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RL	RED	GL	S2PRS-P3RL, RED, GL	
H5550005264	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RLDBM	RED B1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3RLDBM, RED B1 LED(DC) LEFT/RIGHT, GL	
H5550005041	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3W	WHITE	GL	S2PRS-P3W, WHITE, GL	
H5550005051	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3W2AD	WHITE A2 LED(DC)	GL	S2PRS-P3W2AD, WHITE A2 LED(DC), GL	
H5550005052	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3W2ADM	WHITE A2 LED(DC)	GL	S2PRS-P3W2ADM, WHITE A2 LED(DC), GL	
H5550005071	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3W2AL	WHITE A2 LED(AC)	GL	S2PRS-P3W2AL, WHITE A2 LED(AC), GL	
H5550005072	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3W2ALM	WHITE A2 LED(AC)	GL	S2PRS-P3W2ALM, WHITE A2 LED(AC), GL	
H5550005091	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3W2BD	WHITE B2 LED(DC)	GL	S2PRS-P3W2BD, WHITE B2 LED(DC), GL	
H5550005092	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3W2BDM	WHITE B2 LED(DC)	GL	S2PRS-P3W2BDM, WHITE B2 LED(DC), GL	
H5550005111	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3W2BL	WHITE B2 LED(AC)	GL	S2PRS-P3W2BL, WHITE B2 LED(AC), GL	
H5550005112	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3W2BLM	WHITE B2 LED(AC)	GL	S2PRS-P3W2BLM, WHITE B2 LED(AC), GL	
H5550005121	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WABD	WHITE AB LED(DC)	GL	S2PRS-P3WABD, WHITE AB LED(DC), GL	
H5550005122	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WABDM	WHITE AB LED(DC)	GL	S2PRS-P3WABDM, WHITE AB LED(DC), GL	
H5550005131	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WABL	WHITE AB LED(AC)	GL	S2PRS-P3WABL, WHITE AB LED(AC), GL	
H5550005132	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WABLM	WHITE AB LED(AC)	GL	S2PRS-P3WABLM, WHITE AB LED(AC), GL	
H5550005040	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WADM	WHITE A1 LED(DC)	GL	S2PRS-P3WADM, WHITE A1 LED(DC), GL	
H5550005061	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WAL	WHITE A1 LED(AC)	GL	S2PRS-P3WAL, WHITE A1 LED(AC), GL	
H5550005062	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WALM	WHITE A1 LED(AC)	GL	S2PRS-P3WALM, WHITE A1 LED(AC), GL	Квадратный кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Белый, Нормально открытый, Модульный тип, СИД 100-220В-
H5550005081	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WBD	WHITE B1 LED(DC)	GL	S2PRS-P3WBD, WHITE B1 LED(DC), GL	
H5550005082	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WBDM	WHITE B1 LED(DC)	GL	S2PRS-P3WBDM, WHITE B1 LED(DC), GL	
H5550005101	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WBL	WHITE B1 LED(AC)	GL	S2PRS-P3WBL, WHITE B1 LED(AC), GL	
H5550005102	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WBLM	WHITE B1 LED(AC)	GL	S2PRS-P3WBLM, WHITE B1 LED(AC), GL	
H5550005252	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WL		GL	S2PRS-P3WL, , GL	

H5550005261	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WL2AD	WHITE A2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3WL2AD, WHITE A2 LED(DC) LEFT/RIGHT, GL
H5550005262	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WL2ADM	WHITE A2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3WL2ADM, WHITE A2 LED(DC) LEFT/RIGHT, GL
H5550005311	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WL2AL	WHITE A2 LED(AC) LEFT/RIGHT	GL	S2PRS-P3WL2AL, WHITE A2 LED(AC) LEFT/RIGHT, GL
H5550005312	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WL2ALM	WHITE A2 LED(AC) LEFT/RIGHT	GL	S2PRS-P3WL2ALM, WHITE A2 LED(AC) LEFT/RIGHT, GL
H5550005281	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WL2BD	WHITE B2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3WL2BD, WHITE B2 LED(DC) LEFT/RIGHT, GL
H5550005282	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WL2BDM	WHITE B2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3WL2BDM, WHITE B2 LED(DC) LEFT/RIGHT, GL
H5550005331	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WL2BL	WHITE B2 LED(AC) LEFT/RIGHT	GL	S2PRS-P3WL2BL, WHITE B2 LED(AC) LEFT/RIGHT, GL
H5550005332	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WL2BLM	WHITE B2 LED(AC) LEFT/RIGHT	GL	S2PRS-P3WL2BLM, WHITE B2 LED(AC) LEFT/RIGHT, GL
H5550005291	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WLABD	WHITE A1 B1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3WLABD, WHITE A1 B1 LED(DC) LEFT/RIGHT, GL
H5550005292	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WLABDM	WHITE A1 B1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3WLABDM, WHITE A1 B1 LED(DC) LEFT/RIGHT, GL
H5550005341	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WLABL	WHITE A1 B1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3WLABL, WHITE A1 B1 LED(AC) LEFT/RIGHT, GL
H5550005342	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WLABLM	WHITE A1 B1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3WLABLM, WHITE A1 B1 LED(AC) LEFT/RIGHT, GL
H5550005250	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WLAD	WHITE A1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3WLAD, WHITE A1 LED(DC) LEFT/RIGHT, GL
H5550005251	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WLADM	WHITE A1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3WLADM, WHITE A1 LED(DC) LEFT/RIGHT, GL
H5550005301	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WLAL	WHITE A1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3WLAL, WHITE A1 LED(AC) LEFT/RIGHT, GL
H5550005302	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WLALM	WHITE A1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3WLALM, WHITE A1 LED(AC) LEFT/RIGHT, GL
H5550005271	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WLBD	WHITE B1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3WLBD, WHITE B1 LED(DC) LEFT/RIGHT, GL
H5550005272	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WLBDM	WHITE B1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3WLBDM, WHITE B1 LED(DC) LEFT/RIGHT, GL
H5550005321	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WLBL	WHITE B1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3WLBL, WHITE B1 LED(AC) LEFT/RIGHT, GL
H5550005322	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WLBLM	WHITE B1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3WLBLM, WHITE B1 LED(AC) LEFT/RIGHT, GL
H5550005197	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WU	WHITE	GL	S2PRS-P3WU, WHITE, GL
H5550005151	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WU2AD	WHITE A2 LED(DC) UP/DOWN	GL	S2PRS-P3WU2AD, WHITE A2 LED(DC) UP/DOWN, GL
H5550005152	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WU2ADM	WHITE A2 LED(DC) UP/DOWN	GL	S2PRS-P3WU2ADM, WHITE A2 LED(DC) UP/DOWN, GL
H5550005206	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WU2AL	WHITE A2 LED(AC) UP/DOWN	GL	S2PRS-P3WU2AL, WHITE A2 LED(AC) UP/DOWN, GL
H5550005207	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WU2ALM	WHITE A2 LED(AC) UP/DOWN	GL	S2PRS-P3WU2ALM, WHITE A2 LED(AC) UP/DOWN, GL
H5550005171	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WU2BD	WHITE B2 LED(DC) UP/DOWN	GL	S2PRS-P3WU2BD, WHITE B2 LED(DC) UP/DOWN, GL
H5550005172	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WU2BDM	WHITE B2 LED(DC) UP/DOWN	GL	S2PRS-P3WU2BDM, WHITE B2 LED(DC) UP/DOWN, GL
H5550005226	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WU2BL	WHITE B2 LED(AC) UP/DOWN	GL	S2PRS-P3WU2BL, WHITE B2 LED(AC) UP/DOWN, GL

H5550005227	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WU2BLM	WHITE B2 LED(AC) UP/DOWN	GL	S2PRS-P3WU2BLM, WHITE B2 LED(AC) UP/DOWN, GL	
H5550005181	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WUABD	WHITE A1 B1 LED(DC) UP/DOWN	GL	S2PRS-P3WUABD, WHITE A1 B1 LED(DC) UP/DOWN, GL	
H5550005182	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WUABDM	WHITE A1 B1 LED(DC) UP/DOWN	GL	S2PRS-P3WUABDM, WHITE A1 B1 LED(DC) UP/DOWN, GL	
H5550005236	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WUABL	WHITE A1 B1 LED(AC) UP/DOWN	GL	S2PRS-P3WUABL, WHITE A1 B1 LED(AC) UP/DOWN, GL	
H5550005237	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WUABLM	WHITE A1 B1 LED(AC) UP/DOWN	GL	S2PRS-P3WUABLM, WHITE A1 B1 LED(AC) UP/DOWN, GL	
H5550005142	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WUADM	WHITE A1 LED(DC) UP/DOWN	GL	S2PRS-P3WUADM, WHITE A1 LED(DC) UP/DOWN, GL	
H5550005195	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WUAL	WHITE A1 LED(AC) UP/DOWN	GL	S2PRS-P3WUAL, WHITE A1 LED(AC) UP/DOWN, GL	
H5550005196	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WUALM	WHITE A1 LED(AC) UP/DOWN	GL	S2PRS-P3WUALM, WHITE A1 LED(AC) UP/DOWN, GL	Квадратный кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Белый, Нормально открытый, Модульный тип, СИД 100-220В-, Стрелка вверх/вниз
H5550005161	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WUBD	WHITE B1 LED(DC) UP/DOWN	GL	S2PRS-P3WUBD, WHITE B1 LED(DC) UP/DOWN, GL	
H5550005162	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WUBDM	WHITE B1 LED(DC) UP/DOWN	GL	S2PRS-P3WUBDM, WHITE B1 LED(DC) UP/DOWN, GL	
H5550005216	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WUBL	WHITE B1 LED(AC) UP/DOWN	GL	S2PRS-P3WUBL, WHITE B1 LED(AC) UP/DOWN, GL	
H5550005217	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WUBLM	WHITE B1 LED(AC) UP/DOWN	GL	S2PRS-P3WUBLM, WHITE B1 LED(AC) UP/DOWN, GL	
H5550005049	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3Y2AD	YELLOW A2 LED(DC)	GL	S2PRS-P3Y2AD, YELLOW A2 LED(DC), GL	
H5550005050	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3Y2ADM	YELLOW A2 LED(DC)	GL	S2PRS-P3Y2ADM, YELLOW A2 LED(DC), GL	
H5550005069	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3Y2AL	YELLOW A2 LED(AC)	GL	S2PRS-P3Y2AL, YELLOW A2 LED(AC), GL	
H5550005070	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3Y2ALM	YELLOW A2 LED(AC)	GL	S2PRS-P3Y2ALM, YELLOW A2 LED(AC), GL	
H5550005089	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3Y2BD	YELLOW B2 LED(DC)	GL	S2PRS-P3Y2BD, YELLOW B2 LED(DC), GL	
H5550005090	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3Y2BDM	YELLOW B2 LED(DC)	GL	S2PRS-P3Y2BDM, YELLOW B2 LED(DC), GL	
H5550005109	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3Y2BL	YELLOW B2 LED(AC)	GL	S2PRS-P3Y2BL, YELLOW B2 LED(AC), GL	
H5550005110	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3Y2BLM	YELLOW B2 LED(AC)	GL	S2PRS-P3Y2BLM, YELLOW B2 LED(AC), GL	
H5550005119	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YABD	YELLOW AB LED(DC)	GL	S2PRS-P3YABD, YELLOW AB LED(DC), GL	
H5550005120	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YABDM	YELLOW AB LED(DC)	GL	S2PRS-P3YABDM, YELLOW AB LED(DC), GL	
H5550005129	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YABL	YELLOW AB LED(AC)	GL	S2PRS-P3YABL, YELLOW AB LED(AC), GL	
H5550005130	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YABLM	YELLOW AB LED(AC)	GL	S2PRS-P3YABLM, YELLOW AB LED(AC), GL	
H5550005035	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YAD	YELLOW A1 LED(DC)	GL	S2PRS-P3YAD, YELLOW A1 LED(DC), GL	
H5550005036	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YADM	YELLOW A1 LED(DC)	GL	S2PRS-P3YADM, YELLOW A1 LED(DC), GL	
H5550005059	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YAL	YELLOW A1 LED(AC)	GL	S2PRS-P3YAL, YELLOW A1 LED(AC), GL	

H5550005060	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YALM	YELLOW A1 LED(AC)	GL	S2PRS-P3YALM, YELLOW A1 LED(AC), GL	Квадратный кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Желтый, Нормально открытый, Модульный тип, СИД 100-220В-
H5550005080	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YBDM	YELLOW B1 LED(DC)	GL	S2PRS-P3YBDM, YELLOW B1 LED(DC), GL	
H5550005100	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YBLM	YELLOW B1 LED(AC)	GL	S2PRS-P3YBLM, YELLOW B1 LED(AC), GL	
H5550005249	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YL		GL	S2PRS-P3YL, , GL	
H5550005259	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YL2AD	YELLOW A2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3YL2AD, YELLOW A2 LED(DC) LEFT/RIGHT, GL	
H5550005260	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YL2ADM	YELLOW A2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3YL2ADM, YELLOW A2 LED(DC) LEFT/RIGHT, GL	
H5550005309	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YL2AL	YELLOW A2 LED(AC) LEFT/RIGHT	GL	S2PRS-P3YL2AL, YELLOW A2 LED(AC) LEFT/RIGHT, GL	
H5550005310	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YL2ALM	YELLOW A2 LED(AC) LEFT/RIGHT	GL	S2PRS-P3YL2ALM, YELLOW A2 LED(AC) LEFT/RIGHT, GL	
H5550005279	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YL2BD	YELLOW B2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3YL2BD, YELLOW B2 LED(DC) LEFT/RIGHT, GL	
H5550005280	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YL2BDM	YELLOW B2 LED(DC) LEFT/RIGHT	GL	S2PRS-P3YL2BDM, YELLOW B2 LED(DC) LEFT/RIGHT, GL	
H5550005329	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YL2BL	YELLOW B2 LED(AC) LEFT/RIGHT	GL	S2PRS-P3YL2BL, YELLOW B2 LED(AC) LEFT/RIGHT, GL	
H5550005289	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YLABD	YELLOW A1 B1 LED(DC)LEFT/RIGHT	GL	S2PRS-P3YLABD, YELLOW A1 B1 LED(DC)LEFT/RIGHT, GL	
H5550005290	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YLABDM	YELLOW A1 B1 LED(DC)LEFT/RIGHT	GL	S2PRS-P3YLABDM, YELLOW A1 B1 LED(DC)LEFT/RIGHT, GL	
H5550005339	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YLABL	YELLOW A1 B1 LED(AC)LEFT/RIGHT	GL	S2PRS-P3YLABL, YELLOW A1 B1 LED(AC)LEFT/RIGHT, GL	
H5550005340	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YLABLM	YELLOW A1 B1 LED(AC)LEFT/RIGHT	GL	S2PRS-P3YLABLM, YELLOW A1 B1 LED(AC)LEFT/RIGHT, GL	
H5550005247	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YLAD	YELLOW A1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3YLAD, YELLOW A1 LED(DC) LEFT/RIGHT, GL	
H5550005248	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YLADM	YELLOW A1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3YLADM, YELLOW A1 LED(DC) LEFT/RIGHT, GL	
H5550005299	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YLA	YELLOW A1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3YLA, YELLOW A1 LED(AC) LEFT/RIGHT, GL	
H5550005300	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YALM	YELLOW A1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3YALM, YELLOW A1 LED(AC) LEFT/RIGHT, GL	
H5550005269	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YLB	YELLOW B1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3YLB, YELLOW B1 LED(DC) LEFT/RIGHT, GL	
H5550005270	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YLBDM	YELLOW B1 LED(DC) LEFT/RIGHT	GL	S2PRS-P3YLBDM, YELLOW B1 LED(DC) LEFT/RIGHT, GL	
H5550005319	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YLBL	YELLOW B1 LED(AC) LEFT/RIGHT	GL	S2PRS-P3YLBL, YELLOW B1 LED(AC) LEFT/RIGHT, GL	
H5550005194	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YU	YELLOW	GL	S2PRS-P3YU, YELLOW, GL	
H5550005149	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YU2AD	YELLOW A2 LED(DC) UP/DOWN	GL	S2PRS-P3YU2AD, YELLOW A2 LED(DC) UP/DOWN, GL	
H5550005150	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YU2ADM	YELLOW A2 LED(DC) UP/DOWN	GL	S2PRS-P3YU2ADM, YELLOW A2 LED(DC) UP/DOWN, GL	
H5550005204	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YU2AL	YELLOW A2 LED(AC) UP/DOWN	GL	S2PRS-P3YU2AL, YELLOW A2 LED(AC) UP/DOWN, GL	
H5550005205	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YU2ALM	YELLOW A2 LED(AC) UP/DOWN	GL	S2PRS-P3YU2ALM, YELLOW A2 LED(AC) UP/DOWN, GL	

H5550005169	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YU2BD	YELLOW B2 LED(DC) UP/DOWN	GL	S2PRS-P3YU2BD, YELLOW B2 LED(DC) UP/DOWN, GL	
H5550005170	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YU2BDM	YELLOW B2 LED(DC) UP/DOWN	GL	S2PRS-P3YU2BDM, YELLOW B2 LED(DC) UP/DOWN, GL	
H5550005224	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YU2BL	YELLOW B2 LED(AC) UP/DOWN	GL	S2PRS-P3YU2BL, YELLOW B2 LED(AC) UP/DOWN, GL	
H5550005225	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YU2BLM	YELLOW B2 LED(AC) UP/DOWN	GL	S2PRS-P3YU2BLM, YELLOW B2 LED(AC) UP/DOWN, GL	
H5550005179	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YUABD	YELLOW A1 B1 LED(DC) UP/DOWN	GL	S2PRS-P3YUABD, YELLOW A1 B1 LED(DC) UP/DOWN, GL	
H5550005180	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YUABDM	YELLOW A1 B1 LED(DC) UP/DOWN	GL	S2PRS-P3YUABDM, YELLOW A1 B1 LED(DC) UP/DOWN, GL	
H5550005234	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YUABL	YELLOW A1 B1 LED(AC) UP/DOWN	GL	S2PRS-P3YUABL, YELLOW A1 B1 LED(AC) UP/DOWN, GL	
H5550005235	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YUABLM	YELLOW A1 B1 LED(AC) UP/DOWN	GL	S2PRS-P3YUABLM, YELLOW A1 B1 LED(AC) UP/DOWN, GL	
H5550005139	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YUAD	YELLOW A1 LED(DC) UP/DOWN	GL	S2PRS-P3YUAD, YELLOW A1 LED(DC) UP/DOWN, GL	
H5550005140	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YUADM	YELLOW A1 LED(DC) UP/DOWN	GL	S2PRS-P3YUADM, YELLOW A1 LED(DC) UP/DOWN, GL	
H5550005192	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YUAL	YELLOW A1 LED(AC) UP/DOWN	GL	S2PRS-P3YUAL, YELLOW A1 LED(AC) UP/DOWN, GL	
H5550005193	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YUALM	YELLOW A1 LED(AC) UP/DOWN	GL	S2PRS-P3YUALM, YELLOW A1 LED(AC) UP/DOWN, GL	Квадратный кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Желтый, Нормально открытый, Модульный тип, СИД 100-220В~, Стрелка вверх/вниз
H5550005159	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YUBD	YELLOW B1 LED(DC) UP/DOWN	GL	S2PRS-P3YUBD, YELLOW B1 LED(DC) UP/DOWN, GL	
H5550005160	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YUBDM	YELLOW B1 LED(DC) UP/DOWN	GL	S2PRS-P3YUBDM, YELLOW B1 LED(DC) UP/DOWN, GL	
H5550005214	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YUBL	YELLOW B1 LED(AC) UP/DOWN	GL	S2PRS-P3YUBL, YELLOW B1 LED(AC) UP/DOWN, GL	
H5550005215	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YUBLM	YELLOW B1 LED(AC) UP/DOWN	GL	S2PRS-P3YUBLM, YELLOW B1 LED(AC) UP/DOWN, GL	
H5550005030	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRSU SERIES	S2PRSU-P3B	BLUE(NO PRINTING)	GL	S2PRSU-P3B, BLUE(NO PRINTING), GL	
H5550005042	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRSU SERIES	S2PRSU-P3W	WHITE(NO PRINTING)	GL	S2PRSU-P3W, WHITE(NO PRINTING), GL	
H5550005038	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRSU SERIES	S2PRSU-P3Y	YELLOW(NO PRINTING)	GL	S2PRSU-P3Y, YELLOW(NO PRINTING), GL	
H5550010342	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRU SERIES	S2PRU-E3B	BLUE	GL	S2PRU-E3B, BLUE, GL	
H5550010343	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRU SERIES	S2PRU-E3G	GREEN	GL	S2PRU-E3G, GREEN, GL	
H5550010345	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRU SERIES	S2PRU-E3W	WHITE	GL	S2PRU-E3W, WHITE, GL	
H5550010344	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRU SERIES	S2PRU-E3Y	YELLOW	GL	S2PRU-E3Y, YELLOW, GL	
H5550006868	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P1W2A	WHITE	GL	S2TR-P1W2A, WHITE, GL	
H5550006876	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P1W2AM	WHITE	GL	S2TR-P1W2AM, WHITE, GL	
H5550006869	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P1W2B	WHITE	GL	S2TR-P1W2B, WHITE, GL	Двойной кнопочный выключатель 22/25, Белый, 2 нормально закрытых, Без подсветки, С самовозвратом, 110В~/10А, 220В~/5А

H5550006877	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P1W2BM	WHITE	GL	S2TR-P1W2BM, WHITE, GL	
H5550006865	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P1WAB	WHITE	GL	S2TR-P1WAB, WHITE, GL	Двойной кнопочный выключатель 22/25, Белый, 1 нормально открытый, 1 нормально закрытый, Без подсветки, С самовозвратом, 110В~/10А, 220В~/5А
H5550006878	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P3W2ADM	WHITE	GL	S2TR-P3W2ADM, WHITE, GL	
H5550006863	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P3W2AL	WHITE	GL	S2TR-P3W2AL, WHITE, GL	
H5550006880	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P3W2ALM	WHITE	GL	S2TR-P3W2ALM, WHITE, GL	
H5550006862	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P3W2BD	WHITE	GL	S2TR-P3W2BD, WHITE, GL	
H5550006879	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P3W2BDM	WHITE	GL	S2TR-P3W2BDM, WHITE, GL	
H5550006864	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P3W2BL	WHITE	GL	S2TR-P3W2BL, WHITE, GL	
H5550006881	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P3W2BLM	WHITE	GL	S2TR-P3W2BLM, WHITE, GL	
H5550010696	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1W2AM	WHITE A2	GL	S2SR-S1W2AM, WHITE A2, GL	
H5550010697	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1W2B	WHITE B2	GL	S2SR-S1W2B, WHITE B2, GL	
H5550010698	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1W2BM	WHITE B2	GL	S2SR-S1W2BM, WHITE B2, GL	
H5550010699	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1WA	WHITE A	GL	S2SR-S1WA, WHITE A, GL	
H5550010700	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1WAB	WHITE AB	GL	S2SR-S1WAB, WHITE AB, GL	
H5550010701	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1WABM	WHITE AB	GL	S2SR-S1WABM, WHITE AB, GL	
H5550010703	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1WB	WHITE B	GL	S2SR-S1WB, WHITE B, GL	
H5550010704	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1WBM	WHITE B	GL	S2SR-S1WBM, WHITE B, GL	
H5550010705	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2R	RED (HEAD)	GL	S2SR-S2R, RED (HEAD), GL	
H5550010715	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2W	WHITE (HEAD)	GL	S2SR-S2W, WHITE (HEAD), GL	

H5550010716	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2W2A	WHITE A2	GL	S2SR-S2W2A, WHITE A2, GL	
H5550010717	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2W2AM	WHITE A2	GL	S2SR-S2W2AM, WHITE A2, GL	
H5550010718	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2W2B	WHITE B2	GL	S2SR-S2W2B, WHITE B2, GL	
H5550010719	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2W2BM	WHITE B2	GL	S2SR-S2W2BM, WHITE B2, GL	
H5550010720	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2WAB	WHITE AB	GL	S2SR-S2WAB, WHITE AB, GL	
H5550010721	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2WABM	WHITE AB	GL	S2SR-S2WABM, WHITE AB, GL	
H5550010722	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2WAM	WHITE A	GL	S2SR-S2WAM, WHITE A, GL	
H5550010723	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2WB	WHITE B	GL	S2SR-S2WB, WHITE B, GL	
H5550010724	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2WBM	WHITE B	GL	S2SR-S2WBM, WHITE B, GL	
H5550005448	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3W2AM	WHITE A2	GL	S2SR-S3W2AM, WHITE A2, GL	
H5550005452	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3W2BM	WHITE B2	GL	S2SR-S3W2BM, WHITE B2, GL	
H5550005454	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3WABM	WHITE A1 B1	GL	S2SR-S3WABM, WHITE A1 B1, GL	
H5550005450	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3WBM	WHITE B1	GL	S2SR-S3WBM, WHITE B1, GL	
H5550005464	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4W2AM	WHITE A2	GL	S2SR-S4W2AM, WHITE A2, GL	
H5550005404	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4W2B	WHITE B2	GL	S2SR-S4W2B, WHITE B2, GL	Селекторный переключатель, 22/25, 2-позиционный, С фиксацией, С длинной рукояткой, Белый, 1 нормально закрытых, 110В~/10А, 220В~/5А
H5550005468	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4W2BM	WHITE B2	GL	S2SR-S4W2BM, WHITE B2, GL	
H5550005406	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4WAB	WHITE A1 B1	GL	S2SR-S4WAB, WHITE A1 B1, GL	Селекторный переключатель, 22/25, 2-позиционный, С фиксацией, С длинной рукояткой, Белый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550010725	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5KR	RED (HEAD)	GL	S2SR-S5KR, RED (HEAD), GL	
H5550010732	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5KW	WHITE (HEAD)	GL	S2SR-S5KW, WHITE (HEAD), GL	

H5550010733	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5KW2A	WHITE A2	GL	S2SR-S5KW2A, WHITE A2, GL	
H5550010734	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5KW2AM	WHITE A2	GL	S2SR-S5KW2AM, WHITE A2, GL	
H5550010735	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5KW2B	WHITE B2	GL	S2SR-S5KW2B, WHITE B2, GL	
H5550010736	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5KW2BM	WHITE B2	GL	S2SR-S5KW2BM, WHITE B2, GL	
H5550010737	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5KWAB	WHITE AB	GL	S2SR-S5KWAB, WHITE AB, GL	
H5550010738	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5KWABM	WHITE AB	GL	S2SR-S5KWABM, WHITE AB, GL	
H5550005432	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5W2AM	WHITE	GL	S2SR-S5W2AM, WHITE, GL	
H5550005383	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5W2B	WHITE B2	GL	S2SR-S5W2B, WHITE B2, GL	Селекторный переключатель, 22/25, 3-позиционный, С самовозвратом, С короткой рукояткой, Белый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550005456	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5W2BM	WHITE B2	GL	S2SR-S5W2BM, WHITE B2, GL	
H5550005458	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5WABM	WHITE A1 B1	GL	S2SR-S5WABM, WHITE A1 B1, GL	
H5550010739	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6KR	RED (HEAD)	GL	S2SR-S6KR, RED (HEAD), GL	
H5550010746	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6KW	WHITE (HEAD)	GL	S2SR-S6KW, WHITE (HEAD), GL	
H5550010747	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6KW2A	WHITE A2	GL	S2SR-S6KW2A, WHITE A2, GL	
H5550010748	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6KW2AM	WHITE A2	GL	S2SR-S6KW2AM, WHITE A2, GL	
H5550010749	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6KW2B	WHITE B2	GL	S2SR-S6KW2B, WHITE B2, GL	
H5550010750	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6KW2BM	WHITE B2	GL	S2SR-S6KW2BM, WHITE B2, GL	

H5550010751	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6KWAB	WHITE AB	GL	S2SR-S6KWAB, WHITE AB, GL	
H5550010752	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6KWABM	WHITE AB	GL	S2SR-S6KWABM, WHITE AB, GL	
H5550005473	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6R2BM	RED B2	GL	S2SR-S6R2BM, RED B2, GL	
H5550005410	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6W2B	WHITE B2	GL	S2SR-S6W2B, WHITE B2, GL	Селекторный переключатель, 22/25, 3-позиционный, С самовозвратом, С длинной рукояткой, Белый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550005472	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6W2BM	WHITE B2	GL	S2SR-S6W2BM, WHITE B2, GL	
H5550005413	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6WAB	WHITE A1 B1	GL	S2SR-S6WAB, WHITE A1 B1, GL	Селекторный переключатель, 22/25, 3-позиционный, С самовозвратом, С длинной рукояткой, Белый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550005474	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6WABM	WHITE A1 B1	GL	S2SR-S6WABM, WHITE A1 B1, GL	
H5550010753	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7KR	RED (HEAD)	GL	S2SR-S7KR, RED (HEAD), GL	
H5550010760	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7KW	WHITE (HEAD)	GL	S2SR-S7KW, WHITE (HEAD), GL	
H5550010761	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7KW2A	WHITE A2	GL	S2SR-S7KW2A, WHITE A2, GL	
H5550010762	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7KW2AM	WHITE A2	GL	S2SR-S7KW2AM, WHITE A2, GL	
H5550010763	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7KW2B	WHITE B2	GL	S2SR-S7KW2B, WHITE B2, GL	
H5550010764	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7KW2BM	WHITE B2	GL	S2SR-S7KW2BM, WHITE B2, GL	
H5550010765	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7KWAB	WHITE AB	GL	S2SR-S7KWAB, WHITE AB, GL	
H5550010766	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7KWABM	WHITE AB	GL	S2SR-S7KWABM, WHITE AB, GL	

H5550005390	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7W2B	WHITE B2	GL	S2SR-S7W2B, WHITE B2, GL	Селекторный переключатель, 22/25, 3-позиционный, С фиксацией, С короткой рукояткой, Белый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550005460	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7W2BM	WHITE B2	GL	S2SR-S7W2BM, WHITE B2, GL	
H5550010767	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8KR	RED (HEAD)	GL	S2SR-S8KR, RED (HEAD), GL	
H5550010774	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8KW	WHITE (HEAD)	GL	S2SR-S8KW, WHITE (HEAD), GL	
H5550010775	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8KW2A	WHITE A2	GL	S2SR-S8KW2A, WHITE A2, GL	
H5550010776	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8KW2AM	WHITE A2	GL	S2SR-S8KW2AM, WHITE A2, GL	
H5550010777	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8KW2B	WHITE B2	GL	S2SR-S8KW2B, WHITE B2, GL	
H5550010778	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8KW2BM	WHITE B2	GL	S2SR-S8KW2BM, WHITE B2, GL	
H5550010779	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8KWAB	WHITE AB	GL	S2SR-S8KWAB, WHITE AB, GL	
H5550010780	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8KWABM	WHITE AB	GL	S2SR-S8KWABM, WHITE AB, GL	
H5550005446	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8W2AM	WHITE	GL	S2SR-S8W2AM, WHITE, GL	
H5550005417	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8W2B	WHITE B2	GL	S2SR-S8W2B, WHITE B2, GL	Селекторный переключатель, 22/25, 3-позиционный, С фиксацией, С длинной рукояткой, Белый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550005476	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8W2BM	WHITE B2	GL	S2SR-S8W2BM, WHITE B2, GL	
H5550005478	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8WABM	WHITE A1 B1	GL	S2SR-S8WABM, WHITE A1 B1, GL	
H5550010781	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SAKR	RED (HEAD)	GL	S2SR-SAKR, RED (HEAD), GL	
H5550010788	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SAKW	WHITE (HEAD)	GL	S2SR-SAKW, WHITE (HEAD), GL	

H5550010789	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SAKW2A	WHITE A2	GL	S2SR-SAKW2A, WHITE A2, GL
H5550010790	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SAKW2AM	WHITE A2	GL	S2SR-SAKW2AM, WHITE A2, GL
H5550010791	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SAKW2B	WHITE B2	GL	S2SR-SAKW2B, WHITE B2, GL
H5550010792	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SAKW2BM	WHITE B2	GL	S2SR-SAKW2BM, WHITE B2, GL
H5550010793	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SAKWAB	WHITE AB	GL	S2SR-SAKWAB, WHITE AB, GL
H5550010794	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SAKWABM	WHITE AB	GL	S2SR-SAKWABM, WHITE AB, GL
H5550010795	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SBKR	RED (HEAD)	GL	S2SR-SBKR, RED (HEAD), GL
H5550010802	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SBKW	WHITE (HEAD)	GL	S2SR-SBKW, WHITE (HEAD), GL
H5550010803	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SBKW2A	WHITE A2	GL	S2SR-SBKW2A, WHITE A2, GL
H5550010804	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SBKW2AM	WHITE A2	GL	S2SR-SBKW2AM, WHITE A2, GL
H5550010805	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SBKW2B	WHITE B2	GL	S2SR-SBKW2B, WHITE B2, GL
H5550010806	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SBKW2BM	WHITE B2	GL	S2SR-SBKW2BM, WHITE B2, GL
H5550010807	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SBKWAB	WHITE AB	GL	S2SR-SBKWAB, WHITE AB, GL
H5550010808	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SBKWABM	WHITE AB	GL	S2SR-SBKWABM, WHITE AB, GL

H5550010809	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SCKR	RED (HEAD)	GL	S2SR-SCKR, RED (HEAD), GL
H5550010816	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SCKW	WHITE (HEAD)	GL	S2SR-SCKW, WHITE (HEAD), GL
H5550010817	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SCKW2A	WHITE A2	GL	S2SR-SCKW2A, WHITE A2, GL
H5550010818	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SCKW2AM	WHITE A2	GL	S2SR-SCKW2AM, WHITE A2, GL
H5550010819	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SCKW2B	WHITE B2	GL	S2SR-SCKW2B, WHITE B2, GL
H5550010820	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SCKW2BM	WHITE B2	GL	S2SR-SCKW2BM, WHITE B2, GL
H5550010821	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SCKWAB	WHITE AB	GL	S2SR-SCKWAB, WHITE AB, GL
H5550010822	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SCKWABM	WHITE AB	GL	S2SR-SCKWABM, WHITE AB, GL
H5550010823	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SDKR	RED (HEAD)	GL	S2SR-SDKR, RED (HEAD), GL
H5550010830	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SDKW	WHITE (HEAD)	GL	S2SR-SDKW, WHITE (HEAD), GL
H5550010831	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SDKW2A	WHITE A2	GL	S2SR-SDKW2A, WHITE A2, GL
H5550010832	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SDKW2AM	WHITE A2	GL	S2SR-SDKW2AM, WHITE A2, GL
H5550010833	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SDKW2B	WHITE B2	GL	S2SR-SDKW2B, WHITE B2, GL
H5550010834	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SDKW2BM	WHITE B2	GL	S2SR-SDKW2BM, WHITE B2, GL
H5550010835	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SDKWAB	WHITE AB	GL	S2SR-SDKWAB, WHITE AB, GL
H5550010836	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SDKWABM	WHITE AB	GL	S2SR-SDKWABM, WHITE AB, GL
H5550005976	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AB2AD	BLUE A2 DC	GL	S2SRN-L1AB2AD, BLUE A2 DC, GL
H5550005977	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AB2ADM	BLUE A2 DC	GL	S2SRN-L1AB2ADM, BLUE A2 DC, GL
H5550006488	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AB2AL	BLUE A2 AC	GL	S2SRN-L1AB2AL, BLUE A2 AC, GL
H5550006489	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AB2ALM	BLUE A2 AC	GL	S2SRN-L1AB2ALM, BLUE A2 AC, GL
H5550006024	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AB2BD	BLUE B2 DC	GL	S2SRN-L1AB2BD, BLUE B2 DC, GL
H5550006025	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AB2BDM	BLUE B2 DC	GL	S2SRN-L1AB2BDM, BLUE B2 DC, GL

H5550006536	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AB2BL	BLUE B2 AC	GL	S2SRN-L1AB2BL, BLUE B2 AC, GL
H5550006537	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AB2BLM	BLUE B2 AC	GL	S2SRN-L1AB2BLM, BLUE B2 AC, GL
H5550006056	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ABABD	BLUE A1 B1 DC	GL	S2SRN-L1ABABD, BLUE A1 B1 DC, GL
H5550006057	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ABABDM	BLUE A1 B1 DC	GL	S2SRN-L1ABABDM, BLUE A1 B1 DC, GL
H5550006568	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ABABL	BLUE A1 B1 AC	GL	S2SRN-L1ABABL, BLUE A1 B1 AC, GL
H5550006569	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ABABLM	BLUE A1 B1 AC	GL	S2SRN-L1ABABLM, BLUE A1 B1 AC, GL
H5550005961	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ABADM	BLUE A1 DC	GL	S2SRN-L1ABADM, BLUE A1 DC, GL
H5550006472	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ABAL	BLUE A1 AC	GL	S2SRN-L1ABAL, BLUE A1 AC, GL
H5550006473	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ABALM	BLUE A1 AC	GL	S2SRN-L1ABALM, BLUE A1 AC, GL
H5550006008	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ABBD	BLUE B1 DC	GL	S2SRN-L1ABBD, BLUE B1 DC, GL
H5550006009	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ABBDM	BLUE B1 DC	GL	S2SRN-L1ABBDM, BLUE B1 DC, GL
H5550006520	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ABBL	BLUE B1 AC	GL	S2SRN-L1ABBL, BLUE B1 AC, GL
H5550006521	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ABBLM	BLUE B1 AC	GL	S2SRN-L1ABBLM, BLUE B1 AC, GL
H5550006104	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AG2AD	GREEN A2 DC	GL	S2SRN-L1AG2AD, GREEN A2 DC, GL

H5550006105	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AG2ADM	GREEN A2 DC	GL	S2SRN-L1AG2ADM, GREEN A2 DC, GL	
H5550006616	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AG2AL	GREEN A2 AC	GL	S2SRN-L1AG2AL, GREEN A2 AC, GL	
H5550006617	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AG2ALM	GREEN A2 AC	GL	S2SRN-L1AG2ALM, GREEN A2 AC, GL	
H5550006152	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AG2BD	GREEN B2 DC	GL	S2SRN-L1AG2BD, GREEN B2 DC, GL	
H5550006153	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AG2BDM	GREEN B2 DC	GL	S2SRN-L1AG2BDM, GREEN B2 DC, GL	
H5550006664	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AG2BL	GREEN B2 AC	GL	S2SRN-L1AG2BL, GREEN B2 AC, GL	
H5550006665	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AG2BLM	GREEN B2 AC	GL	S2SRN-L1AG2BLM, GREEN B2 AC, GL	
H5550006184	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AGABD	GREEN A1 B1 DC	GL	S2SRN-L1AGABD, GREEN A1 B1 DC, GL	
H5550006185	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AGABDM	GREEN A1 B1 DC	GL	S2SRN-L1AGABDM, GREEN A1 B1 DC, GL	
H5550006696	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AGABL	GREEN A1 B1 AC	GL	S2SRN-L1AGABL, GREEN A1 B1 AC, GL	
H5550006697	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AGABLM	GREEN A1 B1 AC	GL	S2SRN-L1AGABLM, GREEN A1 B1 AC, GL	
H5550006089	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AGADM	GREEN A1 DC	GL	S2SRN-L1AGADM, GREEN A1 DC, GL	
H5550006600	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AGAL	GREEN A1 AC	GL	S2SRN-L1AGAL, GREEN A1 AC, GL	
H5550006601	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AGALM	GREEN A1 AC	GL	S2SRN-L1AGALM, GREEN A1 AC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 2-позиционный, с самовозвратом, По центру 0, вправо 60, Зеленый, 1 нормально открытый, Модульный тип, СИД 110-220В~ 50/60Hz
H5550006136	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AGBD	GREEN B1 DC	GL	S2SRN-L1AGBD, GREEN B1 DC, GL	
H5550006137	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AGBDM	GREEN B1 DC	GL	S2SRN-L1AGBDM, GREEN B1 DC, GL	
H5550006648	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AGBL	GREEN B1 AC	GL	S2SRN-L1AGBL, GREEN B1 AC, GL	
H5550006649	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AGBLM	GREEN B1 AC	GL	S2SRN-L1AGBLM, GREEN B1 AC, GL	

H5550005848	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AR2AD	RED A2 DC	GL	S2SRN-L1AR2AD, RED A2 DC, GL	
H5550005849	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AR2ADM	RED A2 DC	GL	S2SRN-L1AR2ADM, RED A2 DC, GL	
H5550006360	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AR2AL	RED A2 AC	GL	S2SRN-L1AR2AL, RED A2 AC, GL	
H5550006361	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AR2ALM	RED A2 AC	GL	S2SRN-L1AR2ALM, RED A2 AC, GL	
H5550005896	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AR2BD	RED B2 DC	GL	S2SRN-L1AR2BD, RED B2 DC, GL	
H5550005897	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AR2BDM	RED B2 DC	GL	S2SRN-L1AR2BDM, RED B2 DC, GL	
H5550006408	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AR2BL	RED B2 AC	GL	S2SRN-L1AR2BL, RED B2 AC, GL	
H5550006409	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AR2BLM	RED B2 AC	GL	S2SRN-L1AR2BLM, RED B2 AC, GL	
H5550005928	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ARABD	RED A1 B1 DC	GL	S2SRN-L1ARABD, RED A1 B1 DC, GL	
H5550005929	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ARABDM	RED A1 B1 DC	GL	S2SRN-L1ARABDM, RED A1 B1 DC, GL	
H5550006440	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ARABL	RED A1 B1 AC	GL	S2SRN-L1ARABL, RED A1 B1 AC, GL	
H5550006441	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ARABLM	RED A1 B1 AC	GL	S2SRN-L1ARABLM, RED A1 B1 AC, GL	
H5550006344	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ARAL	RED A1 AC	GL	S2SRN-L1ARAL, RED A1 AC, GL	
H5550006345	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ARALM	RED A1 AC	GL	S2SRN-L1ARALM, RED A1 AC, GL	
H5550006392	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ARBL	RED B1 AC	GL	S2SRN-L1ARBL, RED B1 AC, GL	
H5550006393	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ARBLM	RED B1 AC	GL	S2SRN-L1ARBLM, RED B1 AC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 2-позиционный, с самовозвратом, По центру 0, вправо 60, Красный, 1 нормально закрытый, Модульный тип, СИД 110-220В~ 50/60Hz
H5550006232	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AY2AD	YELLOW A2 DC	GL	S2SRN-L1AY2AD, YELLOW A2 DC, GL	
H5550006233	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AY2ADM	YELLOW A2 DC	GL	S2SRN-L1AY2ADM, YELLOW A2 DC, GL	
H5550006744	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AY2AL	YELLOW A2 AC	GL	S2SRN-L1AY2AL, YELLOW A2 AC, GL	
H5550006745	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AY2ALM	YELLOW A2 AC	GL	S2SRN-L1AY2ALM, YELLOW A2 AC, GL	

H5550006280	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AY2BD	YELLOW B2 DC	GL	S2SRN-L1AY2BD, YELLOW B2 DC, GL	
H5550006281	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AY2BDM	YELLOW B2 DC	GL	S2SRN-L1AY2BDM, YELLOW B2 DC, GL	
H5550006792	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AY2BL	YELLOW B2 AC	GL	S2SRN-L1AY2BL, YELLOW B2 AC, GL	
H5550006793	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AY2BLM	YELLOW B2 AC	GL	S2SRN-L1AY2BLM, YELLOW B2 AC, GL	
H5550006312	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AYABD	YELLOW A1 B1 DC	GL	S2SRN-L1AYABD, YELLOW A1 B1 DC, GL	
H5550006313	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AYABDM	YELLOW A1 B1 DC	GL	S2SRN-L1AYABDM, YELLOW A1 B1 DC, GL	
H5550006824	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AYABL	YELLOW A1 B1 AC	GL	S2SRN-L1AYABL, YELLOW A1 B1 AC, GL	
H5550006825	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AYABLM	YELLOW A1 B1 AC	GL	S2SRN-L1AYABLM, YELLOW A1 B1 AC, GL	
H5550006216	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AYAD	YELLOW A1 DC	GL	S2SRN-L1AYAD, YELLOW A1 DC, GL	
H5550006217	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AYADM	YELLOW A1 DC	GL	S2SRN-L1AYADM, YELLOW A1 DC, GL	
H5550006728	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AYAL	YELLOW A1 AC	GL	S2SRN-L1AYAL, YELLOW A1 AC, GL	
H5550006729	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AYALM	YELLOW A1 AC	GL	S2SRN-L1AYALM, YELLOW A1 AC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 2-позиционный, с самовозвратом, По центру 0, вправо 60, Желтый, 1 нормально открытый, Модульный тип, СИД 110-220В- 50/60Hz
H5550006264	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AYBD	YELLOW B1 DC	GL	S2SRN-L1AYBD, YELLOW B1 DC, GL	
H5550006265	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AYBDM	YELLOW B1 DC	GL	S2SRN-L1AYBDM, YELLOW B1 DC, GL	
H5550006776	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AYBL	YELLOW B1 AC	GL	S2SRN-L1AYBL, YELLOW B1 AC, GL	

H555006777	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AYBLM	YELLOW B1 AC	GL	S2SRN-L1AYBLM, YELLOW B1 AC, GL
H5550011060	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1B	BLUE (HEAD)	GL	S2SRN-L1B, BLUE (HEAD), GL
H5550011061	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1B2AD	BLUE A2 LED(DC)	GL	S2SRN-L1B2AD, BLUE A2 LED(DC), GL
H5550011062	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1B2ADM	BLUE A2 LED(DC)	GL	S2SRN-L1B2ADM, BLUE A2 LED(DC), GL
H5550011063	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1B2AL	BLUE A2 LED(AC)	GL	S2SRN-L1B2AL, BLUE A2 LED(AC), GL
H5550011064	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1B2ALM	BLUE A2 LED(AC)	GL	S2SRN-L1B2ALM, BLUE A2 LED(AC), GL
H5550011065	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1B2BD	BLUE B2 LED(DC)	GL	S2SRN-L1B2BD, BLUE B2 LED(DC), GL
H5550011066	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1B2BDM	BLUE B2 LED(DC)	GL	S2SRN-L1B2BDM, BLUE B2 LED(DC), GL
H5550011067	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1B2BL	BLUE B2 LED(AC)	GL	S2SRN-L1B2BL, BLUE B2 LED(AC), GL
H5550011068	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1B2BLM	BLUE B2 LED(AC)	GL	S2SRN-L1B2BLM, BLUE B2 LED(AC), GL
H5550011069	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BABD	BLUE AB LED(DC)	GL	S2SRN-L1BABD, BLUE AB LED(DC), GL
H5550011070	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BABDM	BLUE AB LED(DC)	GL	S2SRN-L1BABDM, BLUE AB LED(DC), GL
H5550011071	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BABL	BLUE AB LED(AC)	GL	S2SRN-L1BABL, BLUE AB LED(AC), GL
H5550011072	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BABLM	BLUE AB LED(AC)	GL	S2SRN-L1BABLM, BLUE AB LED(AC), GL
H5550011073	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BAD	BLUE A LED(DC)	GL	S2SRN-L1BAD, BLUE A LED(DC), GL

H5550011074	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BADM	BLUE A LED(DC)	GL	S2SRN-L1BADM, BLUE A LED(DC), GL
H5550011075	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BAL	BLUE A LED(AC)	GL	S2SRN-L1BAL, BLUE A LED(AC), GL
H5550011076	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BALM	BLUE A LED(AC)	GL	S2SRN-L1BALM, BLUE A LED(AC), GL
H5550005978	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BB2AD	BLUE A2 DC	GL	S2SRN-L1BB2AD, BLUE A2 DC, GL
H5550005979	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BB2ADM	BLUE A2 DC	GL	S2SRN-L1BB2ADM, BLUE A2 DC, GL
H5550006490	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BB2AL	BLUE A2 AC	GL	S2SRN-L1BB2AL, BLUE A2 AC, GL
H5550006491	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BB2ALM	BLUE A2 AC	GL	S2SRN-L1BB2ALM, BLUE A2 AC, GL
H5550006026	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BB2BD	BLUE B2 DC	GL	S2SRN-L1BB2BD, BLUE B2 DC, GL
H5550006027	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BB2BDM	BLUE B2 DC	GL	S2SRN-L1BB2BDM, BLUE B2 DC, GL
H5550006538	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BB2BL	BLUE B2 AC	GL	S2SRN-L1BB2BL, BLUE B2 AC, GL
H5550006539	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BB2BLM	BLUE B2 AC	GL	S2SRN-L1BB2BLM, BLUE B2 AC, GL
H5550006058	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBABD	BLUE A1 B1 DC	GL	S2SRN-L1BBABD, BLUE A1 B1 DC, GL
H5550006059	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBABDM	BLUE A1 B1 DC	GL	S2SRN-L1BBABDM, BLUE A1 B1 DC, GL
H5550006570	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBABL	BLUE A1 B1 AC	GL	S2SRN-L1BBABL, BLUE A1 B1 AC, GL
H5550006571	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBABL M	BLUE A1 B1 AC	GL	S2SRN-L1BBABL M, BLUE A1 B1 AC, GL
H5550005962	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBAD	BLUE A1 DC	GL	S2SRN-L1BBAD, BLUE A1 DC, GL
H5550005963	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBADM	BLUE A1 DC	GL	S2SRN-L1BBADM, BLUE A1 DC, GL

H5550006474	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBAL	BLUE A1 AC	GL	S2SRN-L1BBAL, BLUE A1 AC, GL
H5550006475	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBALM	BLUE A1 AC	GL	S2SRN-L1BBALM, BLUE A1 AC, GL
H5550006010	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBBD	BLUE B1 DC	GL	S2SRN-L1BBBD, BLUE B1 DC, GL
H5550006011	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBBDM	BLUE B1 DC	GL	S2SRN-L1BBBDM, BLUE B1 DC, GL
H5550006522	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBBL	BLUE B1 AC	GL	S2SRN-L1BBBL, BLUE B1 AC, GL
H5550006523	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBBLM	BLUE B1 AC	GL	S2SRN-L1BBBLM, BLUE B1 AC, GL
H5550011077	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBBD	BLUE B LED(DC)	GL	S2SRN-L1BBBD, BLUE B LED(DC), GL
H5550011078	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBBDM	BLUE B LED(DC)	GL	S2SRN-L1BBBDM, BLUE B LED(DC), GL
H5550011079	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBL	BLUE B LED(AC)	GL	S2SRN-L1BBL, BLUE B LED(AC), GL
H5550011080	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BBBLM	BLUE B LED(AC)	GL	S2SRN-L1BBBLM, BLUE B LED(AC), GL
H5550006106	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BG2AD	GREEN A2 DC	GL	S2SRN-L1BG2AD, GREEN A2 DC, GL
H5550006107	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BG2ADM	GREEN A2 DC	GL	S2SRN-L1BG2ADM, GREEN A2 DC, GL
H5550006618	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BG2AL	GREEN A2 AC	GL	S2SRN-L1BG2AL, GREEN A2 AC, GL
H5550006619	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BG2ALM	GREEN A2 AC	GL	S2SRN-L1BG2ALM, GREEN A2 AC, GL
H5550006154	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BG2BD	GREEN B2 DC	GL	S2SRN-L1BG2BD, GREEN B2 DC, GL
H5550006155	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BG2BDM	GREEN B2 DC	GL	S2SRN-L1BG2BDM, GREEN B2 DC, GL
H5550006666	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BG2BL	GREEN B2 AC	GL	S2SRN-L1BG2BL, GREEN B2 AC, GL

H5550006667	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BG2BLM	GREEN B2 AC	GL	S2SRN-L1BG2BLM, GREEN B2 AC, GL
H5550006186	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BGABD	GREEN A1 B1 DC	GL	S2SRN-L1BGABD, GREEN A1 B1 DC, GL
H5550006187	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BGABDM	GREEN A1 B1 DC	GL	S2SRN-L1BGABDM, GREEN A1 B1 DC, GL
H5550006698	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BGABL	GREEN A1 B1 AC	GL	S2SRN-L1BGABL, GREEN A1 B1 AC, GL
H5550006699	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BGABLM	GREEN A1 B1 AC	GL	S2SRN-L1BGABLM, GREEN A1 B1 AC, GL
H5550006090	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BGAD	GREEN A1 DC	GL	S2SRN-L1BGAD, GREEN A1 DC, GL
H5550006091	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BGADM	GREEN A1 DC	GL	S2SRN-L1BGADM, GREEN A1 DC, GL
H5550006602	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BGAL	GREEN A1 AC	GL	S2SRN-L1BGAL, GREEN A1 AC, GL
H5550006603	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BGALM	GREEN A1 AC	GL	S2SRN-L1BGALM, GREEN A1 AC, GL
H5550006138	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BGBD	GREEN B1 DC	GL	S2SRN-L1BGBD, GREEN B1 DC, GL
H5550006139	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BGBDM	GREEN B1 DC	GL	S2SRN-L1BGBDM, GREEN B1 DC, GL
H5550006650	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BGBL	GREEN B1 AC	GL	S2SRN-L1BGBL, GREEN B1 AC, GL
H5550006651	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BGBLM	GREEN B1 AC	GL	S2SRN-L1BGBLM, GREEN B1 AC, GL
H5550005850	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BR2AD	RED A2 DC	GL	S2SRN-L1BR2AD, RED A2 DC, GL
H5550005851	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BR2ADM	RED A2 DC	GL	S2SRN-L1BR2ADM, RED A2 DC, GL

H5550006362	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BR2AL	RED A2 AC	GL	S2SRN-L1BR2AL, RED A2 AC, GL
H5550006363	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BR2ALM	RED A2 AC	GL	S2SRN-L1BR2ALM, RED A2 AC, GL
H5550005898	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BR2BD	RED B2 DC	GL	S2SRN-L1BR2BD, RED B2 DC, GL
H5550005899	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BR2BDM	RED B2 DC	GL	S2SRN-L1BR2BDM, RED B2 DC, GL
H5550006410	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BR2BL	RED B2 AC	GL	S2SRN-L1BR2BL, RED B2 AC, GL
H5550006411	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BR2BLM	RED B2 AC	GL	S2SRN-L1BR2BLM, RED B2 AC, GL
H5550005930	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BRABD	RED A1 B1 DC	GL	S2SRN-L1BRABD, RED A1 B1 DC, GL
H5550005931	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BRABDM	RED A1 B1 DC	GL	S2SRN-L1BRABDM, RED A1 B1 DC, GL
H5550006442	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BRABL	RED A1 B1 AC	GL	S2SRN-L1BRABL, RED A1 B1 AC, GL
H5550006443	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BRABLM	RED A1 B1 AC	GL	S2SRN-L1BRABLM, RED A1 B1 AC, GL
H5550006346	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BRAL	RED A1 AC	GL	S2SRN-L1BRAL, RED A1 AC, GL
H5550006347	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BRALM	RED A1 AC	GL	S2SRN-L1BRALM, RED A1 AC, GL
H5550006394	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BRBL	RED B1 AC	GL	S2SRN-L1BRBL, RED B1 AC, GL
H5550006395	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BRBLM	RED B1 AC	GL	S2SRN-L1BRBLM, RED B1 AC, GL
H5550006234	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BY2AD	YELLOW A2 DC	GL	S2SRN-L1BY2AD, YELLOW A2 DC, GL

H5550006235	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BY2ADM	YELLOW A2 DC	GL	S2SRN-L1BY2ADM, YELLOW A2 DC, GL
H5550006746	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BY2AL	YELLOW A2 AC	GL	S2SRN-L1BY2AL, YELLOW A2 AC, GL
H5550006747	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BY2ALM	YELLOW A2 AC	GL	S2SRN-L1BY2ALM, YELLOW A2 AC, GL
H5550006282	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BY2BD	YELLOW B2 DC	GL	S2SRN-L1BY2BD, YELLOW B2 DC, GL
H5550006283	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BY2BDM	YELLOW B2 DC	GL	S2SRN-L1BY2BDM, YELLOW B2 DC, GL
H5550006794	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BY2BL	YELLOW B2 AC	GL	S2SRN-L1BY2BL, YELLOW B2 AC, GL
H5550006795	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BY2BLM	YELLOW B2 AC	GL	S2SRN-L1BY2BLM, YELLOW B2 AC, GL
H5550006314	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BYABD	YELLOW A1 B1 DC	GL	S2SRN-L1BYABD, YELLOW A1 B1 DC, GL
H5550006315	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BYABDM	YELLOW A1 B1 DC	GL	S2SRN-L1BYABDM, YELLOW A1 B1 DC, GL
H5550006826	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BYABL	YELLOW A1 B1 AC	GL	S2SRN-L1BYABL, YELLOW A1 B1 AC, GL
H5550006827	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BYABLM	YELLOW A1 B1 AC	GL	S2SRN-L1BYABLM, YELLOW A1 B1 AC, GL
H5550006218	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BYAD	YELLOW A1 DC	GL	S2SRN-L1BYAD, YELLOW A1 DC, GL
H5550006219	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BYADM	YELLOW A1 DC	GL	S2SRN-L1BYADM, YELLOW A1 DC, GL
H5550006730	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BYAL	YELLOW A1 AC	GL	S2SRN-L1BYAL, YELLOW A1 AC, GL
H5550006731	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BYALM	YELLOW A1 AC	GL	S2SRN-L1BYALM, YELLOW A1 AC, GL

H5550006266	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BYBD	YELLOW B1 DC	GL	S2SRN-L1BYBD, YELLOW B1 DC, GL
H5550006267	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BYBDM	YELLOW B1 DC	GL	S2SRN-L1BYBDM, YELLOW B1 DC, GL
H5550006778	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BYBL	YELLOW B1 AC	GL	S2SRN-L1BYBL, YELLOW B1 AC, GL
H5550006779	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BYBLM	YELLOW B1 AC	GL	S2SRN-L1BYBLM, YELLOW B1 AC, GL
H5550011081	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1G	GREEN (HEAD)	GL	S2SRN-L1G, GREEN (HEAD), GL
H5550011082	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1G2AD	GREEN A2 LED(DC)	GL	S2SRN-L1G2AD, GREEN A2 LED(DC), GL
H5550011083	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1G2ADM	GREEN A2 LED(DC)	GL	S2SRN-L1G2ADM, GREEN A2 LED(DC), GL
H5550011084	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1G2AL	GREEN A2 LED(AC)	GL	S2SRN-L1G2AL, GREEN A2 LED(AC), GL
H5550011085	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1G2ALM	GREEN A2 LED(AC)	GL	S2SRN-L1G2ALM, GREEN A2 LED(AC), GL
H5550011086	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1G2BD	GREEN B2 LED(DC)	GL	S2SRN-L1G2BD, GREEN B2 LED(DC), GL
H5550011087	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1G2BDM	GREEN B2 LED(DC)	GL	S2SRN-L1G2BDM, GREEN B2 LED(DC), GL
H5550011088	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1G2BL	GREEN B2 LED(AC)	GL	S2SRN-L1G2BL, GREEN B2 LED(AC), GL
H5550011089	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1G2BLM	GREEN B2 LED(AC)	GL	S2SRN-L1G2BLM, GREEN B2 LED(AC), GL
H5550011090	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1GABD	GREEN AB LED(DC)	GL	S2SRN-L1GABD, GREEN AB LED(DC), GL
H5550011091	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1GABDM	GREEN AB LED(DC)	GL	S2SRN-L1GABDM, GREEN AB LED(DC), GL
H5550011092	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1GABL	GREEN AB LED(AC)	GL	S2SRN-L1GABL, GREEN AB LED(AC), GL
H5550011093	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1GABLM	GREEN AB LED(AC)	GL	S2SRN-L1GABLM, GREEN AB LED(AC), GL
H5550011094	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1GAD	GREEN A LED(DC)	GL	S2SRN-L1GAD, GREEN A LED(DC), GL
H5550011095	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1GADM	GREEN A LED(DC)	GL	S2SRN-L1GADM, GREEN A LED(DC), GL
H5550011096	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1GAL	GREEN A LED(AC)	GL	S2SRN-L1GAL, GREEN A LED(AC), GL

H5550011097	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1GALM	GREEN A LED(AC)	GL	S2SRN-L1GALM, GREEN A LED(AC), GL
H5550011098	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1GBD	GREEN B LED(DC)	GL	S2SRN-L1GBD, GREEN B LED(DC), GL
H5550011099	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1GBDM	GREEN B LED(DC)	GL	S2SRN-L1GBDM, GREEN B LED(DC), GL
H5550011100	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1GBL	GREEN B LED(AC)	GL	S2SRN-L1GBL, GREEN B LED(AC), GL
H5550011101	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1GBLM	GREEN B LED(AC)	GL	S2SRN-L1GBLM, GREEN B LED(AC), GL
H5550011102	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1R	RED (HEAD)	GL	S2SRN-L1R, RED (HEAD), GL
H5550011105	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1R2AL	RED A2 LED(AC)	GL	S2SRN-L1R2AL, RED A2 LED(AC), GL
H5550011106	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1R2ALM	RED A2 LED(AC)	GL	S2SRN-L1R2ALM, RED A2 LED(AC), GL
H5550011109	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1R2BL	RED B2 LED(AC)	GL	S2SRN-L1R2BL, RED B2 LED(AC), GL
H5550011110	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1R2BLM	RED B2 LED(AC)	GL	S2SRN-L1R2BLM, RED B2 LED(AC), GL
H5550011113	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1RABL	RED AB LED(AC)	GL	S2SRN-L1RABL, RED AB LED(AC), GL
H5550011114	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1RABLM	RED AB LED(AC)	GL	S2SRN-L1RABLM, RED AB LED(AC), GL
H5550011123	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1Y	YELLOW (HEAD)	GL	S2SRN-L1Y, YELLOW (HEAD), GL
H5550011124	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1Y2AD	YELLOW A2 LED(DC)	GL	S2SRN-L1Y2AD, YELLOW A2 LED(DC), GL
H5550011125	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1Y2ADM	YELLOW A2 LED(DC)	GL	S2SRN-L1Y2ADM, YELLOW A2 LED(DC), GL
H5550011126	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1Y2AL	YELLOW A2 LED(AC)	GL	S2SRN-L1Y2AL, YELLOW A2 LED(AC), GL
H5550011127	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1Y2ALM	YELLOW A2 LED(AC)	GL	S2SRN-L1Y2ALM, YELLOW A2 LED(AC), GL
H5550011128	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1Y2BD	YELLOW B2 LED(DC)	GL	S2SRN-L1Y2BD, YELLOW B2 LED(DC), GL
H5550011129	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1Y2BDM	YELLOW B2 LED(DC)	GL	S2SRN-L1Y2BDM, YELLOW B2 LED(DC), GL
H5550011130	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1Y2BL	YELLOW B2 LED(AC)	GL	S2SRN-L1Y2BL, YELLOW B2 LED(AC), GL
H5550011131	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1Y2BLM	YELLOW B2 LED(AC)	GL	S2SRN-L1Y2BLM, YELLOW B2 LED(AC), GL
H5550011132	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1YABD	YELLOW AB LED(DC)	GL	S2SRN-L1YABD, YELLOW AB LED(DC), GL
H5550011133	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1YABDM	YELLOW AB LED(DC)	GL	S2SRN-L1YABDM, YELLOW AB LED(DC), GL

H5550011134	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1YABL	YELLOW AB LED(AC)	GL	S2SRN-L1YABL, YELLOW AB LED(AC), GL
H5550011135	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1YABLM	YELLOW AB LED(AC)	GL	S2SRN-L1YABLM, YELLOW AB LED(AC), GL
H5550011136	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1YAD	YELLOW A LED(DC)	GL	S2SRN-L1YAD, YELLOW A LED(DC), GL
H5550011137	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1YADM	YELLOW A LED(DC)	GL	S2SRN-L1YADM, YELLOW A LED(DC), GL
H5550011138	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1YAL	YELLOW A LED(AC)	GL	S2SRN-L1YAL, YELLOW A LED(AC), GL
H5550011139	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1YALM	YELLOW A LED(AC)	GL	S2SRN-L1YALM, YELLOW A LED(AC), GL
H5550011140	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1YBD	YELLOW B LED(DC)	GL	S2SRN-L1YBD, YELLOW B LED(DC), GL
H5550011141	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1YBDM	YELLOW B LED(DC)	GL	S2SRN-L1YBDM, YELLOW B LED(DC), GL
H5550011142	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1YBL	YELLOW B LED(AC)	GL	S2SRN-L1YBL, YELLOW B LED(AC), GL
H5550011143	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1YBLM	YELLOW B LED(AC)	GL	S2SRN-L1YBLM, YELLOW B LED(AC), GL
H5550005632	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AB		GL	S2SRN-L2AB, , GL
H5550005980	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AB2AD	BLUE A2 DC	GL	S2SRN-L2AB2AD, BLUE A2 DC, GL
H5550005981	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AB2ADM	BLUE A2 DC	GL	S2SRN-L2AB2ADM, BLUE A2 DC, GL

H5550006492	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AB2AL	BLUE A2 AC	GL	S2SRN-L2AB2AL, BLUE A2 AC, GL
H5550006493	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AB2ALM	BLUE A2 AC	GL	S2SRN-L2AB2ALM, BLUE A2 AC, GL
H5550006028	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AB2BD	BLUE B2 DC	GL	S2SRN-L2AB2BD, BLUE B2 DC, GL
H5550006029	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AB2BDM	BLUE B2 DC	GL	S2SRN-L2AB2BDM, BLUE B2 DC, GL
H5550006540	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AB2BL	BLUE B2 AC	GL	S2SRN-L2AB2BL, BLUE B2 AC, GL
H5550006541	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AB2BLM	BLUE B2 AC	GL	S2SRN-L2AB2BLM, BLUE B2 AC, GL
H5550006060	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ABABD	BLUE A1 B1 DC	GL	S2SRN-L2ABABD, BLUE A1 B1 DC, GL
H5550006061	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ABABDM	BLUE A1 B1 DC	GL	S2SRN-L2ABABDM, BLUE A1 B1 DC, GL
H5550006572	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ABABL	BLUE A1 B1 AC	GL	S2SRN-L2ABABL, BLUE A1 B1 AC, GL
H5550006573	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ABABLM	BLUE A1 B1 AC	GL	S2SRN-L2ABABLM, BLUE A1 B1 AC, GL
H5550005964	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ABAD	BLUE A1 DC	GL	S2SRN-L2ABAD, BLUE A1 DC, GL
H5550005965	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ABADM	BLUE A1 DC	GL	S2SRN-L2ABADM, BLUE A1 DC, GL
H5550006476	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ABAL	BLUE A1 AC	GL	S2SRN-L2ABAL, BLUE A1 AC, GL
H5550006477	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ABALM	BLUE A1 AC	GL	S2SRN-L2ABALM, BLUE A1 AC, GL
H5550006012	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ABBD	BLUE B1 DC	GL	S2SRN-L2ABBD, BLUE B1 DC, GL
H5550006013	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ABBDM	BLUE B1 DC	GL	S2SRN-L2ABBDM, BLUE B1 DC, GL

H5550006524	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ABBL	BLUE B1 AC	GL	S2SRN-L2ABBL, BLUE B1 AC, GL
H5550006525	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ABBLM	BLUE B1 AC	GL	S2SRN-L2ABBLM, BLUE B1 AC, GL
H5550005680	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AG		GL	S2SRN-L2AG, , GL
H5550006108	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AG2AD	GREEN A2 DC	GL	S2SRN-L2AG2AD, GREEN A2 DC, GL
H5550006109	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AG2ADM	GREEN A2 DC	GL	S2SRN-L2AG2ADM, GREEN A2 DC, GL
H5550006620	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AG2AL	GREEN A2 AC	GL	S2SRN-L2AG2AL, GREEN A2 AC, GL
H5550006621	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AG2ALM	GREEN A2 AC	GL	S2SRN-L2AG2ALM, GREEN A2 AC, GL
H5550006156	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AG2BD	GREEN B2 DC	GL	S2SRN-L2AG2BD, GREEN B2 DC, GL
H5550006157	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AG2BDM	GREEN B2 DC	GL	S2SRN-L2AG2BDM, GREEN B2 DC, GL
H5550006668	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AG2BL	GREEN B2 AC	GL	S2SRN-L2AG2BL, GREEN B2 AC, GL
H5550006669	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AG2BLM	GREEN B2 AC	GL	S2SRN-L2AG2BLM, GREEN B2 AC, GL
H5550006188	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AGABD	GREEN A1 B1 DC	GL	S2SRN-L2AGABD, GREEN A1 B1 DC, GL
H5550006189	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AGABDM	GREEN A1 B1 DC	GL	S2SRN-L2AGABDM, GREEN A1 B1 DC, GL
H5550006700	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AGABL	GREEN A1 B1 AC	GL	S2SRN-L2AGABL, GREEN A1 B1 AC, GL

H5550006701	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AGABLM	GREEN A1 B1 AC	GL	S2SRN-L2AGABLM, GREEN A1 B1 AC, GL
H5550006092	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AGAD	GREEN A1 DC	GL	S2SRN-L2AGAD, GREEN A1 DC, GL
H5550006093	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AGADM	GREEN A1 DC	GL	S2SRN-L2AGADM, GREEN A1 DC, GL
H5550006604	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AGAL	GREEN A1 AC	GL	S2SRN-L2AGAL, GREEN A1 AC, GL
H5550006605	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AGALM	GREEN A1 AC	GL	S2SRN-L2AGALM, GREEN A1 AC, GL
H5550006140	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AGBD	GREEN B1 DC	GL	S2SRN-L2AGBD, GREEN B1 DC, GL
H5550006141	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AGBDM	GREEN B1 DC	GL	S2SRN-L2AGBDM, GREEN B1 DC, GL
H5550006652	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AGBL	GREEN B1 AC	GL	S2SRN-L2AGBL, GREEN B1 AC, GL
H5550006653	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AGBLM	GREEN B1 AC	GL	S2SRN-L2AGBLM, GREEN B1 AC, GL
H5550005852	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AR2AD	RED A2 DC	GL	S2SRN-L2AR2AD, RED A2 DC, GL
H5550005853	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AR2ADM	RED A2 DC	GL	S2SRN-L2AR2ADM, RED A2 DC, GL

H5550006364	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AR2AL	RED A2 AC	GL	S2SRN-L2AR2AL, RED A2 AC, GL
H5550006365	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AR2ALM	RED A2 AC	GL	S2SRN-L2AR2ALM, RED A2 AC, GL
H5550005900	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AR2BD	RED B2 DC	GL	S2SRN-L2AR2BD, RED B2 DC, GL
H5550005901	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AR2BDM	RED B2 DC	GL	S2SRN-L2AR2BDM, RED B2 DC, GL
H5550006412	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AR2BL	RED B2 AC	GL	S2SRN-L2AR2BL, RED B2 AC, GL
H5550006413	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AR2BLM	RED B2 AC	GL	S2SRN-L2AR2BLM, RED B2 AC, GL
H5550005932	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ARABD	RED A1 B1 DC	GL	S2SRN-L2ARABD, RED A1 B1 DC, GL
H5550005933	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ARABDM	RED A1 B1 DC	GL	S2SRN-L2ARABDM, RED A1 B1 DC, GL
H5550006444	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ARABL	RED A1 B1 AC	GL	S2SRN-L2ARABL, RED A1 B1 AC, GL
H5550006445	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ARABLM	RED A1 B1 AC	GL	S2SRN-L2ARABLM, RED A1 B1 AC, GL
H5550006348	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ARAL	RED A1 AC	GL	S2SRN-L2ARAL, RED A1 AC, GL
H5550006349	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ARALM	RED A1 AC	GL	S2SRN-L2ARALM, RED A1 AC, GL
H5550006396	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ARBL	RED B1 AC	GL	S2SRN-L2ARBL, RED B1 AC, GL
H5550006397	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ARBLM	RED B1 AC	GL	S2SRN-L2ARBLM, RED B1 AC, GL

H5550005728	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AY		GL	S2SRN-L2AY, , GL	
H5550006236	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AY2AD	YELLOW A2 DC	GL	S2SRN-L2AY2AD, YELLOW A2 DC, GL	
H5550006237	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AY2ADM	YELLOW A2 DC	GL	S2SRN-L2AY2ADM, YELLOW A2 DC, GL	
H5550006748	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AY2AL	YELLOW A2 AC	GL	S2SRN-L2AY2AL, YELLOW A2 AC, GL	
H5550006749	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AY2ALM	YELLOW A2 AC	GL	S2SRN-L2AY2ALM, YELLOW A2 AC, GL	
H5550006284	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AY2BD	YELLOW B2 DC	GL	S2SRN-L2AY2BD, YELLOW B2 DC, GL	
H5550006285	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AY2BDM	YELLOW B2 DC	GL	S2SRN-L2AY2BDM, YELLOW B2 DC, GL	
H5550006796	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AY2BL	YELLOW B2 AC	GL	S2SRN-L2AY2BL, YELLOW B2 AC, GL	
H5550006797	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AY2BLM	YELLOW B2 AC	GL	S2SRN-L2AY2BLM, YELLOW B2 AC, GL	
H5550006316	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AYABD	YELLOW A1 B1 DC	GL	S2SRN-L2AYABD, YELLOW A1 B1 DC, GL	
H5550006317	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AYABDM	YELLOW A1 B1 DC	GL	S2SRN-L2AYABDM, YELLOW A1 B1 DC, GL	
H5550006828	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AYABL	YELLOW A1 B1 AC	GL	S2SRN-L2AYABL, YELLOW A1 B1 AC, GL	
H5550006829	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AYABLM	YELLOW A1 B1 AC	GL	S2SRN-L2AYABLM, YELLOW A1 B1 AC, GL	
H5550006220	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AYAD	YELLOW A1 DC	GL	S2SRN-L2AYAD, YELLOW A1 DC, GL	
H5550006221	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AYADM	YELLOW A1 DC	GL	S2SRN-L2AYADM, YELLOW A1 DC, GL	

H5550006732	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AYAL	YELLOW A1 AC	GL	S2SRN-L2AYAL, YELLOW A1 AC, GL
H5550006733	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AYALM	YELLOW A1 AC	GL	S2SRN-L2AYALM, YELLOW A1 AC, GL
H5550006268	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AYBD	YELLOW B1 DC	GL	S2SRN-L2AYBD, YELLOW B1 DC, GL
H5550006269	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AYBDM	YELLOW B1 DC	GL	S2SRN-L2AYBDM, YELLOW B1 DC, GL
H5550006780	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AYBL	YELLOW B1 AC	GL	S2SRN-L2AYBL, YELLOW B1 AC, GL
H5550006781	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AYBLM	YELLOW B1 AC	GL	S2SRN-L2AYBLM, YELLOW B1 AC, GL
H5550011144	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2B	BLUE (HEAD)	GL	S2SRN-L2B, BLUE (HEAD), GL
H5550011145	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2B2AD	BLUE A2 LED(DC)	GL	S2SRN-L2B2AD, BLUE A2 LED(DC), GL
H5550011146	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2B2ADM	BLUE A2 LED(DC)	GL	S2SRN-L2B2ADM, BLUE A2 LED(DC), GL
H5550011147	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2B2AL	BLUE A2 LED(AC)	GL	S2SRN-L2B2AL, BLUE A2 LED(AC), GL
H5550011148	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2B2ALM	BLUE A2 LED(AC)	GL	S2SRN-L2B2ALM, BLUE A2 LED(AC), GL
H5550011149	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2B2BD	BLUE B2 LED(DC)	GL	S2SRN-L2B2BD, BLUE B2 LED(DC), GL
H5550011150	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2B2BDM	BLUE B2 LED(DC)	GL	S2SRN-L2B2BDM, BLUE B2 LED(DC), GL
H5550011151	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2B2BL	BLUE B2 LED(AC)	GL	S2SRN-L2B2BL, BLUE B2 LED(AC), GL

H5550011152	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2B2BLM	BLUE B2 LED(AC)	GL	S2SRN-L2B2BLM, BLUE B2 LED(AC), GL
H5550011153	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BABD	BLUE AB LED(DC)	GL	S2SRN-L2BABD, BLUE AB LED(DC), GL
H5550011154	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BABDM	BLUE AB LED(DC)	GL	S2SRN-L2BABDM, BLUE AB LED(DC), GL
H5550011155	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BABL	BLUE AB LED(AC)	GL	S2SRN-L2BABL, BLUE AB LED(AC), GL
H5550011156	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BABLM	BLUE AB LED(AC)	GL	S2SRN-L2BABLM, BLUE AB LED(AC), GL
H5550011157	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BAD	BLUE A LED(DC)	GL	S2SRN-L2BAD, BLUE A LED(DC), GL
H5550011158	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BADM	BLUE A LED(DC)	GL	S2SRN-L2BADM, BLUE A LED(DC), GL
H5550011159	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BAL	BLUE A LED(AC)	GL	S2SRN-L2BAL, BLUE A LED(AC), GL
H5550011160	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BALM	BLUE A LED(AC)	GL	S2SRN-L2BALM, BLUE A LED(AC), GL
H5550005635	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BB		GL	S2SRN-L2BB, , GL
H5550005982	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BB2AD	BLUE A2 DC	GL	S2SRN-L2BB2AD, BLUE A2 DC, GL
H5550005983	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BB2ADM	BLUE A2 DC	GL	S2SRN-L2BB2ADM, BLUE A2 DC, GL
H5550006494	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BB2AL	BLUE A2 AC	GL	S2SRN-L2BB2AL, BLUE A2 AC, GL
H5550006495	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BB2ALM	BLUE A2 AC	GL	S2SRN-L2BB2ALM, BLUE A2 AC, GL

H5550006030	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BB2BD	BLUE B2 DC	GL	S2SRN-L2BB2BD, BLUE B2 DC, GL
H5550006031	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BB2BDM	BLUE B2 DC	GL	S2SRN-L2BB2BDM, BLUE B2 DC, GL
H5550006542	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BB2BL	BLUE B2 AC	GL	S2SRN-L2BB2BL, BLUE B2 AC, GL
H5550006543	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BB2BLM	BLUE B2 AC	GL	S2SRN-L2BB2BLM, BLUE B2 AC, GL
H5550006062	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBABD	BLUE A1 B1 DC	GL	S2SRN-L2BBABD, BLUE A1 B1 DC, GL
H5550006063	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBABDM	BLUE A1 B1 DC	GL	S2SRN-L2BBABDM, BLUE A1 B1 DC, GL
H5550006574	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBABL	BLUE A1 B1 AC	GL	S2SRN-L2BBABL, BLUE A1 B1 AC, GL
H5550006575	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBABLM	BLUE A1 B1 AC	GL	S2SRN-L2BBABLM, BLUE A1 B1 AC, GL
H5550005966	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBAD	BLUE A1 DC	GL	S2SRN-L2BBAD, BLUE A1 DC, GL
H5550005967	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBADM	BLUE A1 DC	GL	S2SRN-L2BBADM, BLUE A1 DC, GL
H5550006478	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBAL	BLUE A1 AC	GL	S2SRN-L2BBAL, BLUE A1 AC, GL
H5550006479	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBALM	BLUE A1 AC	GL	S2SRN-L2BBALM, BLUE A1 AC, GL
H5550006014	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBBD	BLUE B1 DC	GL	S2SRN-L2BBBD, BLUE B1 DC, GL
H5550006015	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBBDM	BLUE B1 DC	GL	S2SRN-L2BBBDM, BLUE B1 DC, GL
H5550006526	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBBL	BLUE B1 AC	GL	S2SRN-L2BBBL, BLUE B1 AC, GL
H5550006527	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBBLM	BLUE B1 AC	GL	S2SRN-L2BBBLM, BLUE B1 AC, GL

H5550011161	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBD	BLUE B LED(DC)	GL	S2SRN-L2BBD, BLUE B LED(DC), GL
H5550011162	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBDM	BLUE B LED(DC)	GL	S2SRN-L2BBDM, BLUE B LED(DC), GL
H5550011163	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBL	BLUE B LED(AC)	GL	S2SRN-L2BBL, BLUE B LED(AC), GL
H5550011164	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BBLM	BLUE B LED(AC)	GL	S2SRN-L2BBLM, BLUE B LED(AC), GL
H5550005683	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BG		GL	S2SRN-L2BG, , GL
H5550006110	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BG2AD	GREEN A2 DC	GL	S2SRN-L2BG2AD, GREEN A2 DC, GL
H5550006111	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BG2ADM	GREEN A2 DC	GL	S2SRN-L2BG2ADM, GREEN A2 DC, GL
H5550006622	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BG2AL	GREEN A2 AC	GL	S2SRN-L2BG2AL, GREEN A2 AC, GL
H5550006623	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BG2ALM	GREEN A2 AC	GL	S2SRN-L2BG2ALM, GREEN A2 AC, GL
H5550006158	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BG2BD	GREEN B2 DC	GL	S2SRN-L2BG2BD, GREEN B2 DC, GL
H5550006159	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BG2BDM	GREEN B2 DC	GL	S2SRN-L2BG2BDM, GREEN B2 DC, GL
H5550006670	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BG2BL	GREEN B2 AC	GL	S2SRN-L2BG2BL, GREEN B2 AC, GL
H5550006671	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BG2BLM	GREEN B2 AC	GL	S2SRN-L2BG2BLM, GREEN B2 AC, GL
H5550006190	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BGABD	GREEN A1 B1 DC	GL	S2SRN-L2BGABD, GREEN A1 B1 DC, GL
H5550006191	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BGABDM	GREEN A1 B1 DC	GL	S2SRN-L2BGABDM, GREEN A1 B1 DC, GL
H5550006702	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BGABL	GREEN A1 B1 AC	GL	S2SRN-L2BGABL, GREEN A1 B1 AC, GL
H5550006703	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BGABLM	GREEN A1 B1 AC	GL	S2SRN-L2BGABLM, GREEN A1 B1 AC, GL
H5550006094	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BGAD	GREEN A1 DC	GL	S2SRN-L2BGAD, GREEN A1 DC, GL
H5550006095	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BGADM	GREEN A1 DC	GL	S2SRN-L2BGADM, GREEN A1 DC, GL

H5550006606	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BGAL	GREEN A1 AC	GL	S2SRN-L2BGAL, GREEN A1 AC, GL
H5550006607	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BGALM	GREEN A1 AC	GL	S2SRN-L2BGALM, GREEN A1 AC, GL
H5550006142	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BGBD	GREEN B1 DC	GL	S2SRN-L2BGBD, GREEN B1 DC, GL
H5550006143	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BGBDM	GREEN B1 DC	GL	S2SRN-L2BGBDM, GREEN B1 DC, GL
H5550006654	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BGBL	GREEN B1 AC	GL	S2SRN-L2BGBL, GREEN B1 AC, GL
H5550006655	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BGBLM	GREEN B1 AC	GL	S2SRN-L2BGBLM, GREEN B1 AC, GL
H5550005854	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BR2AD	RED A2 DC	GL	S2SRN-L2BR2AD, RED A2 DC, GL
H5550005855	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BR2ADM	RED A2 DC	GL	S2SRN-L2BR2ADM, RED A2 DC, GL
H5550006366	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BR2AL	RED A2 AC	GL	S2SRN-L2BR2AL, RED A2 AC, GL
H5550006367	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BR2ALM	RED A2 AC	GL	S2SRN-L2BR2ALM, RED A2 AC, GL
H5550005902	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BR2BD	RED B2 DC	GL	S2SRN-L2BR2BD, RED B2 DC, GL
H5550005903	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BR2BDM	RED B2 DC	GL	S2SRN-L2BR2BDM, RED B2 DC, GL
H5550006414	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BR2BL	RED B2 AC	GL	S2SRN-L2BR2BL, RED B2 AC, GL
H5550006415	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BR2BLM	RED B2 AC	GL	S2SRN-L2BR2BLM, RED B2 AC, GL
H5550005934	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BRABD	RED A1 B1 DC	GL	S2SRN-L2BRABD, RED A1 B1 DC, GL
H5550005935	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BRABDM	RED A1 B1 DC	GL	S2SRN-L2BRABDM, RED A1 B1 DC, GL
H5550006446	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BRABL	RED A1 B1 AC	GL	S2SRN-L2BRABL, RED A1 B1 AC, GL
H5550006447	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BRABLM	RED A1 B1 AC	GL	S2SRN-L2BRABLM, RED A1 B1 AC, GL
H5550006350	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BRAL	RED A1 AC	GL	S2SRN-L2BRAL, RED A1 AC, GL
H5550006351	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BRALM	RED A1 AC	GL	S2SRN-L2BRALM, RED A1 AC, GL

H5550006398	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BRBL	RED B1 AC	GL	S2SRN-L2BRBL, RED B1 AC, GL
H5550006399	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BRBLM	RED B1 AC	GL	S2SRN-L2BRBLM, RED B1 AC, GL
H5550005731	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BY		GL	S2SRN-L2BY, , GL
H5550006238	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BY2AD	YELLOW A2 DC	GL	S2SRN-L2BY2AD, YELLOW A2 DC, GL
H5550006239	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BY2ADM	YELLOW A2 DC	GL	S2SRN-L2BY2ADM, YELLOW A2 DC, GL
H5550006750	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BY2AL	YELLOW A2 AC	GL	S2SRN-L2BY2AL, YELLOW A2 AC, GL
H5550006751	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BY2ALM	YELLOW A2 AC	GL	S2SRN-L2BY2ALM, YELLOW A2 AC, GL
H5550006286	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BY2BD	YELLOW B2 DC	GL	S2SRN-L2BY2BD, YELLOW B2 DC, GL
H5550006287	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BY2BDM	YELLOW B2 DC	GL	S2SRN-L2BY2BDM, YELLOW B2 DC, GL
H5550006798	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BY2BL	YELLOW B2 AC	GL	S2SRN-L2BY2BL, YELLOW B2 AC, GL
H5550006799	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BY2BLM	YELLOW B2 AC	GL	S2SRN-L2BY2BLM, YELLOW B2 AC, GL
H5550006318	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BYABD	YELLOW A1 B1 DC	GL	S2SRN-L2BYABD, YELLOW A1 B1 DC, GL
H5550006319	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BYABDM	YELLOW A1 B1 DC	GL	S2SRN-L2BYABDM, YELLOW A1 B1 DC, GL
H5550006830	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BYABL	YELLOW A1 B1 AC	GL	S2SRN-L2BYABL, YELLOW A1 B1 AC, GL
H5550006831	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BYABLM	YELLOW A1 B1 AC	GL	S2SRN-L2BYABLM, YELLOW A1 B1 AC, GL

H5550006222	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BYAD	YELLOW A1 DC	GL	S2SRN-L2BYAD, YELLOW A1 DC, GL
H5550006223	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BYADM	YELLOW A1 DC	GL	S2SRN-L2BYADM, YELLOW A1 DC, GL
H5550006734	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BYAL	YELLOW A1 AC	GL	S2SRN-L2BYAL, YELLOW A1 AC, GL
H5550006735	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BYALM	YELLOW A1 AC	GL	S2SRN-L2BYALM, YELLOW A1 AC, GL
H5550006270	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BYBD	YELLOW B1 DC	GL	S2SRN-L2BYBD, YELLOW B1 DC, GL
H5550006271	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BYBDM	YELLOW B1 DC	GL	S2SRN-L2BYBDM, YELLOW B1 DC, GL
H5550006782	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BYBL	YELLOW B1 AC	GL	S2SRN-L2BYBL, YELLOW B1 AC, GL
H5550006783	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BYBLM	YELLOW B1 AC	GL	S2SRN-L2BYBLM, YELLOW B1 AC, GL
H5550011165	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2G	GREEN (HEAD)	GL	S2SRN-L2G, GREEN (HEAD), GL
H5550011166	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2G2AD	GREEN A2 LED(DC)	GL	S2SRN-L2G2AD, GREEN A2 LED(DC), GL
H5550011167	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2G2ADM	GREEN A2 LED(DC)	GL	S2SRN-L2G2ADM, GREEN A2 LED(DC), GL
H5550011168	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2G2AL	GREEN A2 LED(AC)	GL	S2SRN-L2G2AL, GREEN A2 LED(AC), GL
H5550011169	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2G2ALM	GREEN A2 LED(AC)	GL	S2SRN-L2G2ALM, GREEN A2 LED(AC), GL
H5550011170	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2G2BD	GREEN B2 LED(DC)	GL	S2SRN-L2G2BD, GREEN B2 LED(DC), GL

H5550011171	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2G2BDM	GREEN B2 LED(DC)	GL	S2SRN-L2G2BDM, GREEN B2 LED(DC), GL
H5550011172	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2G2BL	GREEN B2 LED(AC)	GL	S2SRN-L2G2BL, GREEN B2 LED(AC), GL
H5550011173	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2G2BLM	GREEN B2 LED(AC)	GL	S2SRN-L2G2BLM, GREEN B2 LED(AC), GL
H5550011174	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2GABD	GREEN AB LED(DC)	GL	S2SRN-L2GABD, GREEN AB LED(DC), GL
H5550011175	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2GABDM	GREEN AB LED(DC)	GL	S2SRN-L2GABDM, GREEN AB LED(DC), GL
H5550011176	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2GABL	GREEN AB LED(AC)	GL	S2SRN-L2GABL, GREEN AB LED(AC), GL
H5550011177	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2GABLM	GREEN AB LED(AC)	GL	S2SRN-L2GABLM, GREEN AB LED(AC), GL
H5550011178	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2GAD	GREEN A LED(DC)	GL	S2SRN-L2GAD, GREEN A LED(DC), GL
H5550011179	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2GADM	GREEN A LED(DC)	GL	S2SRN-L2GADM, GREEN A LED(DC), GL
H5550011180	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2GAL	GREEN A LED(AC)	GL	S2SRN-L2GAL, GREEN A LED(AC), GL
H5550011181	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2GALM	GREEN A LED(AC)	GL	S2SRN-L2GALM, GREEN A LED(AC), GL
H5550011182	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2GBD	GREEN B LED(DC)	GL	S2SRN-L2GBD, GREEN B LED(DC), GL
H5550011183	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2GBDM	GREEN B LED(DC)	GL	S2SRN-L2GBDM, GREEN B LED(DC), GL
H5550011184	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2GBL	GREEN B LED(AC)	GL	S2SRN-L2GBL, GREEN B LED(AC), GL
H5550011185	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2GBLM	GREEN B LED(AC)	GL	S2SRN-L2GBLM, GREEN B LED(AC), GL

H5550011186	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2R	RED (HEAD)	GL	S2SRN-L2R, RED (HEAD), GL
H5550011189	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2R2AL	RED A2 LED(AC)	GL	S2SRN-L2R2AL, RED A2 LED(AC), GL
H5550011190	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2R2ALM	RED A2 LED(AC)	GL	S2SRN-L2R2ALM, RED A2 LED(AC), GL
H5550011193	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2R2BL	RED B2 LED(AC)	GL	S2SRN-L2R2BL, RED B2 LED(AC), GL
H5550011194	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2R2BLM	RED B2 LED(AC)	GL	S2SRN-L2R2BLM, RED B2 LED(AC), GL
H5550011197	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2RABL	RED AB LED(AC)	GL	S2SRN-L2RABL, RED AB LED(AC), GL
H5550011198	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2RABLM	RED AB LED(AC)	GL	S2SRN-L2RABLM, RED AB LED(AC), GL
H5550011207	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2Y	YELLOW (HEAD)	GL	S2SRN-L2Y, YELLOW (HEAD), GL
H5550011208	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2Y2AD	YELLOW A2 LED(DC)	GL	S2SRN-L2Y2AD, YELLOW A2 LED(DC), GL
H5550011209	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2Y2ADM	YELLOW A2 LED(DC)	GL	S2SRN-L2Y2ADM, YELLOW A2 LED(DC), GL
H5550011210	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2Y2AL	YELLOW A2 LED(AC)	GL	S2SRN-L2Y2AL, YELLOW A2 LED(AC), GL
H5550011211	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2Y2ALM	YELLOW A2 LED(AC)	GL	S2SRN-L2Y2ALM, YELLOW A2 LED(AC), GL
H5550011212	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2Y2BD	YELLOW B2 LED(DC)	GL	S2SRN-L2Y2BD, YELLOW B2 LED(DC), GL
H5550011213	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2Y2BDM	YELLOW B2 LED(DC)	GL	S2SRN-L2Y2BDM, YELLOW B2 LED(DC), GL
H5550011214	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2Y2BL	YELLOW B2 LED(AC)	GL	S2SRN-L2Y2BL, YELLOW B2 LED(AC), GL

H5550011215	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2Y2BLM	YELLOW B2 LED(AC)	GL	S2SRN-L2Y2BLM, YELLOW B2 LED(AC), GL
H5550011216	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2YABD	YELLOW AB LED(DC)	GL	S2SRN-L2YABD, YELLOW AB LED(DC), GL
H5550011217	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2YABDM	YELLOW AB LED(DC)	GL	S2SRN-L2YABDM, YELLOW AB LED(DC), GL
H5550011218	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2YABL	YELLOW AB LED(AC)	GL	S2SRN-L2YABL, YELLOW AB LED(AC), GL
H5550011219	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2YABLM	YELLOW AB LED(AC)	GL	S2SRN-L2YABLM, YELLOW AB LED(AC), GL
H5550011220	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2YAD	YELLOW A LED(DC)	GL	S2SRN-L2YAD, YELLOW A LED(DC), GL
H5550011221	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2YADM	YELLOW A LED(DC)	GL	S2SRN-L2YADM, YELLOW A LED(DC), GL
H5550011222	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2YAL	YELLOW A LED(AC)	GL	S2SRN-L2YAL, YELLOW A LED(AC), GL
H5550011223	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2YALM	YELLOW A LED(AC)	GL	S2SRN-L2YALM, YELLOW A LED(AC), GL
H5550011224	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2YBD	YELLOW B LED(DC)	GL	S2SRN-L2YBD, YELLOW B LED(DC), GL
H5550011225	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2YBDM	YELLOW B LED(DC)	GL	S2SRN-L2YBDM, YELLOW B LED(DC), GL
H5550011226	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2YBL	YELLOW B LED(AC)	GL	S2SRN-L2YBL, YELLOW B LED(AC), GL
H5550011227	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2YBLM	YELLOW B LED(AC)	GL	S2SRN-L2YBLM, YELLOW B LED(AC), GL
H5550005984	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AB2AD	BLUE A2 DC	GL	S2SRN-L3AB2AD, BLUE A2 DC, GL
H5550005985	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AB2ADM	BLUE A2 DC	GL	S2SRN-L3AB2ADM, BLUE A2 DC, GL
H5550006496	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AB2AL	BLUE A2 AC	GL	S2SRN-L3AB2AL, BLUE A2 AC, GL

H5550006497	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AB2ALM	BLUE A2 AC	GL	S2SRN-L3AB2ALM, BLUE A2 AC, GL	
H5550006032	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AB2BD	BLUE B2 DC	GL	S2SRN-L3AB2BD, BLUE B2 DC, GL	
H5550006033	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AB2BDM	BLUE B2 DC	GL	S2SRN-L3AB2BDM, BLUE B2 DC, GL	
H5550006544	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AB2BL	BLUE B2 AC	GL	S2SRN-L3AB2BL, BLUE B2 AC, GL	
H5550006545	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AB2BLM	BLUE B2 AC	GL	S2SRN-L3AB2BLM, BLUE B2 AC, GL	
H5550006064	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ABABD	BLUE A1 B1 DC	GL	S2SRN-L3ABABD, BLUE A1 B1 DC, GL	
H5550006065	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ABABDM	BLUE A1 B1 DC	GL	S2SRN-L3ABABDM, BLUE A1 B1 DC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 2-позиционный, с фиксацией, По центру 0, вправо 90, Синий, 1 нормально открытый 1 многоуровневый, СИД 12-24В~50/60Hz 12-24 В=
H5550006576	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ABABL	BLUE A1 B1 AC	GL	S2SRN-L3ABABL, BLUE A1 B1 AC, GL	
H5550006577	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ABABLM	BLUE A1 B1 AC	GL	S2SRN-L3ABABLM, BLUE A1 B1 AC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 2-позиционный, с фиксацией, По центру 0, вправо 90, Синий, 1 нормально открытый 1 нормально закрытый, многоуровневый, СИД 110-220В~ 50/60Hz
H5550005968	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ABAD	BLUE A1 DC	GL	S2SRN-L3ABAD, BLUE A1 DC, GL	
H5550006480	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ABAL	BLUE A1 AC	GL	S2SRN-L3ABAL, BLUE A1 AC, GL	
H5550006016	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ABBDD	BLUE B1 DC	GL	S2SRN-L3ABBDD, BLUE B1 DC, GL	
H5550006017	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ABBDM	BLUE B1 DC	GL	S2SRN-L3ABBDM, BLUE B1 DC, GL	
H5550006528	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ABBL	BLUE B1 AC	GL	S2SRN-L3ABBL, BLUE B1 AC, GL	
H5550006529	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ABBLM	BLUE B1 AC	GL	S2SRN-L3ABBLM, BLUE B1 AC, GL	
H5550006112	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AG2AD	GREEN A2 DC	GL	S2SRN-L3AG2AD, GREEN A2 DC, GL	
H5550006113	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AG2ADM	GREEN A2 DC	GL	S2SRN-L3AG2ADM, GREEN A2 DC, GL	

H5550006624	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AG2AL	GREEN A2 AC	GL	S2SRN-L3AG2AL, GREEN A2 AC, GL	
H5550006625	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AG2ALM	GREEN A2 AC	GL	S2SRN-L3AG2ALM, GREEN A2 AC, GL	
H5550006160	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AG2BD	GREEN B2 DC	GL	S2SRN-L3AG2BD, GREEN B2 DC, GL	
H5550006161	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AG2BDM	GREEN B2 DC	GL	S2SRN-L3AG2BDM, GREEN B2 DC, GL	
H5550006672	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AG2BL	GREEN B2 AC	GL	S2SRN-L3AG2BL, GREEN B2 AC, GL	
H5550006673	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AG2BLM	GREEN B2 AC	GL	S2SRN-L3AG2BLM, GREEN B2 AC, GL	
H5550006192	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AGABD	GREEN A1 B1 DC	GL	S2SRN-L3AGABD, GREEN A1 B1 DC, GL	
H5550006193	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AGABDM	GREEN A1 B1 DC	GL	S2SRN-L3AGABDM, GREEN A1 B1 DC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 2-позиционный, с фиксацией, По центру 0, вправо 90, Зеленый, 1 нормально открытый 1 нормально закрытый 1 многоуровневый, СИД 12-24В~50/60Hz 12-24 В=
H5550006704	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AGABL	GREEN A1 B1 AC	GL	S2SRN-L3AGABL, GREEN A1 B1 AC, GL	
H5550006705	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AGABLM	GREEN A1 B1 AC	GL	S2SRN-L3AGABLM, GREEN A1 B1 AC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 2-позиционный, с фиксацией, По центру 0, вправо 90, Зеленый, 1 нормально открытый 1 нормально закрытый, многоуровневый, СИД 110-220В~50/60Hz
H5550006144	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AGBD	GREEN B1 DC	GL	S2SRN-L3AGBD, GREEN B1 DC, GL	
H5550006145	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AGBDM	GREEN B1 DC	GL	S2SRN-L3AGBDM, GREEN B1 DC, GL	
H5550006656	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AGBL	GREEN B1 AC	GL	S2SRN-L3AGBL, GREEN B1 AC, GL	
H5550006657	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AGBLM	GREEN B1 AC	GL	S2SRN-L3AGBLM, GREEN B1 AC, GL	
H5550005856	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AR2AD	RED A2 DC	GL	S2SRN-L3AR2AD, RED A2 DC, GL	

H5550005857	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AR2ADM	RED A2 DC	GL	S2SRN-L3AR2ADM, RED A2 DC, GL	
H5550005904	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AR2BD	RED B2 DC	GL	S2SRN-L3AR2BD, RED B2 DC, GL	
H5550005905	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AR2BDM	RED B2 DC	GL	S2SRN-L3AR2BDM, RED B2 DC, GL	
H5550005936	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ARABD	RED A1 B1 DC	GL	S2SRN-L3ARABD, RED A1 B1 DC, GL	
H5550005937	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ARABDM	RED A1 B1 DC	GL	S2SRN-L3ARABDM, RED A1 B1 DC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 2-позиционный, с фиксацией, По центру 0, вправо 90, Красный, 1 нормально открытый 1 нормально закрытый, многоуровневый, СИД 12-24В~50/60Hz 12-24 В=
H5550006240	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AY2AD	YELLOW A2 DC	GL	S2SRN-L3AY2AD, YELLOW A2 DC, GL	
H5550006241	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AY2ADM	YELLOW A2 DC	GL	S2SRN-L3AY2ADM, YELLOW A2 DC, GL	
H5550006752	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AY2AL	YELLOW A2 AC	GL	S2SRN-L3AY2AL, YELLOW A2 AC, GL	
H5550006753	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AY2ALM	YELLOW A2 AC	GL	S2SRN-L3AY2ALM, YELLOW A2 AC, GL	
H5550006288	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AY2BD	YELLOW B2 DC	GL	S2SRN-L3AY2BD, YELLOW B2 DC, GL	
H5550006289	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AY2BDM	YELLOW B2 DC	GL	S2SRN-L3AY2BDM, YELLOW B2 DC, GL	
H5550006800	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AY2BL	YELLOW B2 AC	GL	S2SRN-L3AY2BL, YELLOW B2 AC, GL	
H5550006801	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AY2BLM	YELLOW B2 AC	GL	S2SRN-L3AY2BLM, YELLOW B2 AC, GL	
H5550006320	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AYABD	YELLOW A1 B1 DC	GL	S2SRN-L3AYABD, YELLOW A1 B1 DC, GL	
H5550006321	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AYABDM	YELLOW A1 B1 DC	GL	S2SRN-L3AYABDM, YELLOW A1 B1 DC, GL	
H5550006832	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AYABL	YELLOW A1 B1 AC	GL	S2SRN-L3AYABL, YELLOW A1 B1 AC, GL	
H5550006833	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AYABLM	YELLOW A1 B1 AC	GL	S2SRN-L3AYABLM, YELLOW A1 B1 AC, GL	

H5550006736	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AYAL	YELLOW A1 AC	GL	S2SRN-L3AYAL, YELLOW A1 AC, GL
H5550006272	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AYBD	YELLOW B1 DC	GL	S2SRN-L3AYBD, YELLOW B1 DC, GL
H5550006273	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AYBDM	YELLOW B1 DC	GL	S2SRN-L3AYBDM, YELLOW B1 DC, GL
H5550006784	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AYBL	YELLOW B1 AC	GL	S2SRN-L3AYBL, YELLOW B1 AC, GL
H5550006785	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AYBLM	YELLOW B1 AC	GL	S2SRN-L3AYBLM, YELLOW B1 AC, GL
H5550005986	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BB2AD	BLUE A2 DC	GL	S2SRN-L3BB2AD, BLUE A2 DC, GL
H5550005987	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BB2ADM	BLUE A2 DC	GL	S2SRN-L3BB2ADM, BLUE A2 DC, GL
H5550006498	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BB2AL	BLUE A2 AC	GL	S2SRN-L3BB2AL, BLUE A2 AC, GL
H5550006499	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BB2ALM	BLUE A2 AC	GL	S2SRN-L3BB2ALM, BLUE A2 AC, GL
H5550006034	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BB2BD	BLUE B2 DC	GL	S2SRN-L3BB2BD, BLUE B2 DC, GL
H5550006035	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BB2BDM	BLUE B2 DC	GL	S2SRN-L3BB2BDM, BLUE B2 DC, GL
H5550006546	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BB2BL	BLUE B2 AC	GL	S2SRN-L3BB2BL, BLUE B2 AC, GL
H5550006547	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BB2BLM	BLUE B2 AC	GL	S2SRN-L3BB2BLM, BLUE B2 AC, GL
H5550006066	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BBABD	BLUE A1 B1 DC	GL	S2SRN-L3BBABD, BLUE A1 B1 DC, GL
H5550006067	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BBABDM	BLUE A1 B1 DC	GL	S2SRN-L3BBABDM, BLUE A1 B1 DC, GL
H5550006578	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BBABL	BLUE A1 B1 AC	GL	S2SRN-L3BBABL, BLUE A1 B1 AC, GL

H5550006579	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BBABLM	BLUE A1 B1 AC	GL	S2SRN-L3BBABLM, BLUE A1 B1 AC, GL	
H5550005970	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BBAD	BLUE A1 DC	GL	S2SRN-L3BBAD, BLUE A1 DC, GL	
H5550005971	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BBADM	BLUE A1 DC	GL	S2SRN-L3BBADM, BLUE A1 DC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 2-позиционный, с фиксацией, влево 45, вправо 45, Синий, 1 нормально открытый, многоуровневый, СИД 12-24В~50/60Hz 12-24 В=
H5550006482	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BBAL	BLUE A1 AC	GL	S2SRN-L3BBAL, BLUE A1 AC, GL	
H5550006483	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BBALM	BLUE A1 AC	GL	S2SRN-L3BBALM, BLUE A1 AC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 2-позиционный, с фиксацией, влево 45, вправо 45, Синий, 1 нормально открытый, многоуровневый, СИД 110-220В~ 50/60Hz
H5550006018	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BBBD	BLUE B1 DC	GL	S2SRN-L3BBBD, BLUE B1 DC, GL	
H5550006019	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BBBDM	BLUE B1 DC	GL	S2SRN-L3BBBDM, BLUE B1 DC, GL	
H5550006530	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BBBL	BLUE B1 AC	GL	S2SRN-L3BBBL, BLUE B1 AC, GL	
H5550006531	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BBBLM	BLUE B1 AC	GL	S2SRN-L3BBBLM, BLUE B1 AC, GL	
H5550006114	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BG2AD	GREEN A2 DC	GL	S2SRN-L3BG2AD, GREEN A2 DC, GL	
H5550006115	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BG2ADM	GREEN A2 DC	GL	S2SRN-L3BG2ADM, GREEN A2 DC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 2-позиционный, с фиксацией, влево 45, вправо 45, Зеленый, 2 нормально открытых, многоуровневый, СИД 12-24В~50/60Hz 12-24 В=
H5550006626	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BG2AL	GREEN A2 AC	GL	S2SRN-L3BG2AL, GREEN A2 AC, GL	
H5550006627	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BG2ALM	GREEN A2 AC	GL	S2SRN-L3BG2ALM, GREEN A2 AC, GL	
H5550006162	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BG2BD	GREEN B2 DC	GL	S2SRN-L3BG2BD, GREEN B2 DC, GL	
H5550006163	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BG2BDM	GREEN B2 DC	GL	S2SRN-L3BG2BDM, GREEN B2 DC, GL	

H5550006674	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BG2BL	GREEN B2 AC	GL	S2SRN-L3BG2BL, GREEN B2 AC, GL	
H5550006675	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BG2BLM	GREEN B2 AC	GL	S2SRN-L3BG2BLM, GREEN B2 AC, GL	
H5550006194	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BGABD	GREEN A1 B1 DC	GL	S2SRN-L3BGABD, GREEN A1 B1 DC, GL	
H5550006195	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BGABDM	GREEN A1 B1 DC	GL	S2SRN-L3BGABDM, GREEN A1 B1 DC, GL	
H5550006706	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BGABL	GREEN A1 B1 AC	GL	S2SRN-L3BGABL, GREEN A1 B1 AC, GL	
H5550006707	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BGABLM	GREEN A1 B1 AC	GL	S2SRN-L3BGABLM, GREEN A1 B1 AC, GL	
H5550006098	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BGAD	GREEN A1 DC	GL	S2SRN-L3BGAD, GREEN A1 DC, GL	
H5550006099	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BGADM	GREEN A1 DC	GL	S2SRN-L3BGADM, GREEN A1 DC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 2-позиционный, с фиксацией, влево 45, вправо 45, Зеленый, 1 нормально открытый, многоуровневый, СИД 12-24В~50/60Hz 12-24 В=
H5550006610	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BGAL	GREEN A1 AC	GL	S2SRN-L3BGAL, GREEN A1 AC, GL	
H5550006611	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BGALM	GREEN A1 AC	GL	S2SRN-L3BGALM, GREEN A1 AC, GL	
H5550006146	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BGBD	GREEN B1 DC	GL	S2SRN-L3BGBD, GREEN B1 DC, GL	
H5550006147	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BGBDM	GREEN B1 DC	GL	S2SRN-L3BGBDM, GREEN B1 DC, GL	
H5550006658	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BGBL	GREEN B1 AC	GL	S2SRN-L3BGBL, GREEN B1 AC, GL	

H5550006659	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BGBLM	GREEN B1 AC	GL	S2SRN-L3BGBLM, GREEN B1 AC, GL
H5550005858	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BR2AD	RED A2 DC	GL	S2SRN-L3BR2AD, RED A2 DC, GL
H5550005859	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BR2ADM	RED A2 DC	GL	S2SRN-L3BR2ADM, RED A2 DC, GL
H5550005906	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BR2BD	RED B2 DC	GL	S2SRN-L3BR2BD, RED B2 DC, GL
H5550005907	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BR2BDM	RED B2 DC	GL	S2SRN-L3BR2BDM, RED B2 DC, GL
H5550005938	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BRABD	RED A1 B1 DC	GL	S2SRN-L3BRABD, RED A1 B1 DC, GL
H5550005939	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BRABDM	RED A1 B1 DC	GL	S2SRN-L3BRABDM, RED A1 B1 DC, GL
H5550006242	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BY2AD	YELLOW A2 DC	GL	S2SRN-L3BY2AD, YELLOW A2 DC, GL
H5550006243	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BY2ADM	YELLOW A2 DC	GL	S2SRN-L3BY2ADM, YELLOW A2 DC, GL
H5550006754	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BY2AL	YELLOW A2 AC	GL	S2SRN-L3BY2AL, YELLOW A2 AC, GL

H5550006755	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BY2ALM	YELLOW A2 AC	GL	S2SRN-L3BY2ALM, YELLOW A2 AC, GL
H5550006290	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BY2BD	YELLOW B2 DC	GL	S2SRN-L3BY2BD, YELLOW B2 DC, GL
H5550006291	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BY2BDM	YELLOW B2 DC	GL	S2SRN-L3BY2BDM, YELLOW B2 DC, GL
H5550006802	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BY2BL	YELLOW B2 AC	GL	S2SRN-L3BY2BL, YELLOW B2 AC, GL
H5550006803	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BY2BLM	YELLOW B2 AC	GL	S2SRN-L3BY2BLM, YELLOW B2 AC, GL
H5550006322	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BYABD	YELLOW A1 B1 DC	GL	S2SRN-L3BYABD, YELLOW A1 B1 DC, GL
H5550006323	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BYABDM	YELLOW A1 B1 DC	GL	S2SRN-L3BYABDM, YELLOW A1 B1 DC, GL
H5550006834	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BYABL	YELLOW A1 B1 AC	GL	S2SRN-L3BYABL, YELLOW A1 B1 AC, GL
H5550006835	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BYABLM	YELLOW A1 B1 AC	GL	S2SRN-L3BYABLM, YELLOW A1 B1 AC, GL

H5550006226	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BYAD	YELLOW A1 DC	GL	S2SRN-L3BYAD, YELLOW A1 DC, GL	
H5550006227	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BYADM	YELLOW A1 DC	GL	S2SRN-L3BYADM, YELLOW A1 DC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 2-позиционный, с фиксацией, влево 45, вправо 45, Желтый, 1 нормально открытый, многоуровневый, СИД 12-24В-50/60Hz 12-24 В=
H5550006738	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BYAL	YELLOW A1 AC	GL	S2SRN-L3BYAL, YELLOW A1 AC, GL	
H5550006739	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BYALM	YELLOW A1 AC	GL	S2SRN-L3BYALM, YELLOW A1 AC, GL	
H5550006274	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BYBD	YELLOW B1 DC	GL	S2SRN-L3BYBD, YELLOW B1 DC, GL	
H5550006275	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BYBDM	YELLOW B1 DC	GL	S2SRN-L3BYBDM, YELLOW B1 DC, GL	
H5550006786	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BYBL	YELLOW B1 AC	GL	S2SRN-L3BYBL, YELLOW B1 AC, GL	
H5550006787	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BYBLM	YELLOW B1 AC	GL	S2SRN-L3BYBLM, YELLOW B1 AC, GL	
H5550005644	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AB		GL	S2SRN-L4AB, , GL	
H5550005988	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AB2AD	BLUE A2 DC	GL	S2SRN-L4AB2AD, BLUE A2 DC, GL	
H5550005989	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AB2ADM	BLUE A2 DC	GL	S2SRN-L4AB2ADM, BLUE A2 DC, GL	

H5550006500	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AB2AL	BLUE A2 AC	GL	S2SRN-L4AB2AL, BLUE A2 AC, GL
H5550006501	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AB2ALM	BLUE A2 AC	GL	S2SRN-L4AB2ALM, BLUE A2 AC, GL
H5550006036	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AB2BD	BLUE B2 DC	GL	S2SRN-L4AB2BD, BLUE B2 DC, GL
H5550006037	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AB2BDM	BLUE B2 DC	GL	S2SRN-L4AB2BDM, BLUE B2 DC, GL
H5550006548	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AB2BL	BLUE B2 AC	GL	S2SRN-L4AB2BL, BLUE B2 AC, GL
H5550006549	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AB2BLM	BLUE B2 AC	GL	S2SRN-L4AB2BLM, BLUE B2 AC, GL
H5550006068	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ABABD	BLUE A1 B1 DC	GL	S2SRN-L4ABABD, BLUE A1 B1 DC, GL
H5550006069	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ABABDM	BLUE A1 B1 DC	GL	S2SRN-L4ABABDM, BLUE A1 B1 DC, GL
H5550006580	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ABABL	BLUE A1 B1 AC	GL	S2SRN-L4ABABL, BLUE A1 B1 AC, GL
H5550006581	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ABABLM	BLUE A1 B1 AC	GL	S2SRN-L4ABABLM, BLUE A1 B1 AC, GL
H5550005972	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ABAD	BLUE A1 DC	GL	S2SRN-L4ABAD, BLUE A1 DC, GL

H5550005973	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ABADM	BLUE A1 DC	GL	S2SRN-L4ABADM, BLUE A1 DC, GL
H5550006484	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ABAL	BLUE A1 AC	GL	S2SRN-L4ABAL, BLUE A1 AC, GL
H5550006485	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ABALM	BLUE A1 AC	GL	S2SRN-L4ABALM, BLUE A1 AC, GL
H5550006020	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ABBD	BLUE B1 DC	GL	S2SRN-L4ABBD, BLUE B1 DC, GL
H5550006021	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ABBDM	BLUE B1 DC	GL	S2SRN-L4ABBDM, BLUE B1 DC, GL
H5550006532	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ABBL	BLUE B1 AC	GL	S2SRN-L4ABBL, BLUE B1 AC, GL
H5550006533	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ABBLM	BLUE B1 AC	GL	S2SRN-L4ABBLM, BLUE B1 AC, GL
H5550006116	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AG2AD	GREEN A2 DC	GL	S2SRN-L4AG2AD, GREEN A2 DC, GL
H5550006117	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AG2ADM	GREEN A2 DC	GL	S2SRN-L4AG2ADM, GREEN A2 DC, GL
H5550006629	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AG2ALM	GREEN A2 AC	GL	S2SRN-L4AG2ALM, GREEN A2 AC, GL

H5550006164	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AG2BD	GREEN B2 DC	GL	S2SRN-L4AG2BD, GREEN B2 DC, GL	
H5550006165	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AG2BDM	GREEN B2 DC	GL	S2SRN-L4AG2BDM, GREEN B2 DC, GL	
H5550006676	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AG2BL	GREEN B2 AC	GL	S2SRN-L4AG2BL, GREEN B2 AC, GL	
H5550006677	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AG2BLM	GREEN B2 AC	GL	S2SRN-L4AG2BLM, GREEN B2 AC, GL	
H5550006197	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AGABDM	GREEN A1 B1 DC	GL	S2SRN-L4AGABDM, GREEN A1 B1 DC, GL	
H5550006708	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AGABL	GREEN A1 B1 AC	GL	S2SRN-L4AGABL, GREEN A1 B1 AC, GL	
H5550006709	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AGABLM	GREEN A1 B1 AC	GL	S2SRN-L4AGABLM, GREEN A1 B1 AC, GL	
H5550006100	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AGAD	GREEN A1 DC	GL	S2SRN-L4AGAD, GREEN A1 DC, GL	
H5550006101	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AGADM	GREEN A1 DC	GL	S2SRN-L4AGADM, GREEN A1 DC, GL	Селекторный переключатель, с длинной ручкой, выступающего типа, С подсветкой, 22/25, 2-позиционный, без возврата, влево 90, вправо 90, зелёный, 1 нормально открытый, Модульный тип, СИД 110-220В~ 50/60Hz

H5550006612	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AGAL	GREEN A1 AC	GL	S2SRN-L4AGAL, GREEN A1 AC, GL
H5550006613	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AGALM	GREEN A1 AC	GL	S2SRN-L4AGALM, GREEN A1 AC, GL
H5550006148	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AGBD	GREEN B1 DC	GL	S2SRN-L4AGBD, GREEN B1 DC, GL
H5550006149	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AGBDM	GREEN B1 DC	GL	S2SRN-L4AGBDM, GREEN B1 DC, GL
H5550006660	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AGBL	GREEN B1 AC	GL	S2SRN-L4AGBL, GREEN B1 AC, GL
H5550006661	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AGBLM	GREEN B1 AC	GL	S2SRN-L4AGBLM, GREEN B1 AC, GL
H5550005860	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AR2AD	RED A2 DC	GL	S2SRN-L4AR2AD, RED A2 DC, GL
H5550005861	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AR2ADM	RED A2 DC	GL	S2SRN-L4AR2ADM, RED A2 DC, GL
H5550005908	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AR2BD	RED B2 DC	GL	S2SRN-L4AR2BD, RED B2 DC, GL
H5550005909	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AR2BDM	RED B2 DC	GL	S2SRN-L4AR2BDM, RED B2 DC, GL
H5550005940	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ARABD	RED A1 B1 DC	GL	S2SRN-L4ARABD, RED A1 B1 DC, GL
H5550005941	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ARABDM	RED A1 B1 DC	GL	S2SRN-L4ARABDM, RED A1 B1 DC, GL
H5550005740	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AY		GL	S2SRN-L4AY, , GL

H5550006244	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AY2AD	YELLOW A2 DC	GL	S2SRN-L4AY2AD, YELLOW A2 DC, GL
H5550006245	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AY2ADM	YELLOW A2 DC	GL	S2SRN-L4AY2ADM, YELLOW A2 DC, GL
H5550006756	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AY2AL	YELLOW A2 AC	GL	S2SRN-L4AY2AL, YELLOW A2 AC, GL
H5550006757	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AY2ALM	YELLOW A2 AC	GL	S2SRN-L4AY2ALM, YELLOW A2 AC, GL
H5550006292	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AY2BD	YELLOW B2 DC	GL	S2SRN-L4AY2BD, YELLOW B2 DC, GL
H5550006293	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AY2BDM	YELLOW B2 DC	GL	S2SRN-L4AY2BDM, YELLOW B2 DC, GL
H5550006804	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AY2BL	YELLOW B2 AC	GL	S2SRN-L4AY2BL, YELLOW B2 AC, GL
H5550006805	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AY2BLM	YELLOW B2 AC	GL	S2SRN-L4AY2BLM, YELLOW B2 AC, GL
H5550006324	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AYABD	YELLOW A1 B1 DC	GL	S2SRN-L4AYABD, YELLOW A1 B1 DC, GL
H5550006325	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AYABDM	YELLOW A1 B1 DC	GL	S2SRN-L4AYABDM, YELLOW A1 B1 DC, GL
H5550006836	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AYABL	YELLOW A1 B1 AC	GL	S2SRN-L4AYABL, YELLOW A1 B1 AC, GL
H5550006837	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AYABLM	YELLOW A1 B1 AC	GL	S2SRN-L4AYABLM, YELLOW A1 B1 AC, GL
H5550006228	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AYAD	YELLOW A1 DC	GL	S2SRN-L4AYAD, YELLOW A1 DC, GL
H5550006229	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AYADM	YELLOW A1 DC	GL	S2SRN-L4AYADM, YELLOW A1 DC, GL
H5550006740	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AYAL	YELLOW A1 AC	GL	S2SRN-L4AYAL, YELLOW A1 AC, GL
H5550006741	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AYALM	YELLOW A1 AC	GL	S2SRN-L4AYALM, YELLOW A1 AC, GL

H5550006276	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AYBD	YELLOW B1 DC	GL	S2SRN-L4AYBD, YELLOW B1 DC, GL
H5550006277	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AYBDM	YELLOW B1 DC	GL	S2SRN-L4AYBDM, YELLOW B1 DC, GL
H5550006788	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AYBL	YELLOW B1 AC	GL	S2SRN-L4AYBL, YELLOW B1 AC, GL
H5550006789	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AYBLM	YELLOW B1 AC	GL	S2SRN-L4AYBLM, YELLOW B1 AC, GL
H5550005647	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BB		GL	S2SRN-L4BB, , GL
H5550005990	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BB2AD	BLUE A2 DC	GL	S2SRN-L4BB2AD, BLUE A2 DC, GL
H5550005991	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BB2ADM	BLUE A2 DC	GL	S2SRN-L4BB2ADM, BLUE A2 DC, GL
H5550006502	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BB2AL	BLUE A2 AC	GL	S2SRN-L4BB2AL, BLUE A2 AC, GL
H5550006503	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BB2ALM	BLUE A2 AC	GL	S2SRN-L4BB2ALM, BLUE A2 AC, GL
H5550006038	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BB2BD	BLUE B2 DC	GL	S2SRN-L4BB2BD, BLUE B2 DC, GL
H5550006039	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BB2BDM	BLUE B2 DC	GL	S2SRN-L4BB2BDM, BLUE B2 DC, GL
H5550006550	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BB2BL	BLUE B2 AC	GL	S2SRN-L4BB2BL, BLUE B2 AC, GL
H5550006551	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BB2BLM	BLUE B2 AC	GL	S2SRN-L4BB2BLM, BLUE B2 AC, GL
H5550006070	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BBABD	BLUE A1 B1 DC	GL	S2SRN-L4BBABD, BLUE A1 B1 DC, GL
H5550006071	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BBABDM	BLUE A1 B1 DC	GL	S2SRN-L4BBABDM, BLUE A1 B1 DC, GL
H5550006582	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BBABL	BLUE A1 B1 AC	GL	S2SRN-L4BBABL, BLUE A1 B1 AC, GL

H5550006583	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BBABLM	BLUE A1 B1 AC	GL	S2SRN-L4BBABLM, BLUE A1 B1 AC, GL
H5550005974	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BBAD	BLUE A1 DC	GL	S2SRN-L4BBAD, BLUE A1 DC, GL
H5550005975	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BBADM	BLUE A1 DC	GL	S2SRN-L4BBADM, BLUE A1 DC, GL
H5550006486	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BBAL	BLUE A1 AC	GL	S2SRN-L4BBAL, BLUE A1 AC, GL
H5550006487	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BBALM	BLUE A1 AC	GL	S2SRN-L4BBALM, BLUE A1 AC, GL
H5550006022	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BBBD	BLUE B1 DC	GL	S2SRN-L4BBBD, BLUE B1 DC, GL
H5550006023	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BBBDM	BLUE B1 DC	GL	S2SRN-L4BBBDM, BLUE B1 DC, GL
H5550006534	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BBBL	BLUE B1 AC	GL	S2SRN-L4BBBL, BLUE B1 AC, GL
H5550006535	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BBBLM	BLUE B1 AC	GL	S2SRN-L4BBBLM, BLUE B1 AC, GL
H5550006118	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BG2AD	GREEN A2 DC	GL	S2SRN-L4BG2AD, GREEN A2 DC, GL
H5550006119	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BG2ADM	GREEN A2 DC	GL	S2SRN-L4BG2ADM, GREEN A2 DC, GL
H5550006630	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BG2AL	GREEN A2 AC	GL	S2SRN-L4BG2AL, GREEN A2 AC, GL
H5550006631	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BG2ALM	GREEN A2 AC	GL	S2SRN-L4BG2ALM, GREEN A2 AC, GL
H5550006166	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BG2BD	GREEN B2 DC	GL	S2SRN-L4BG2BD, GREEN B2 DC, GL

H5550006167	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BG2BDM	GREEN B2 DC	GL	S2SRN-L4BG2BDM, GREEN B2 DC, GL
H5550006678	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BG2BL	GREEN B2 AC	GL	S2SRN-L4BG2BL, GREEN B2 AC, GL
H5550006679	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BG2BLM	GREEN B2 AC	GL	S2SRN-L4BG2BLM, GREEN B2 AC, GL
H5550006198	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BGABD	GREEN A1 B1 DC	GL	S2SRN-L4BGABD, GREEN A1 B1 DC, GL
H5550006199	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BGABDM	GREEN A1 B1 DC	GL	S2SRN-L4BGABDM, GREEN A1 B1 DC, GL
H5550006710	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BGABL	GREEN A1 B1 AC	GL	S2SRN-L4BGABL, GREEN A1 B1 AC, GL
H5550006711	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BGABLM	GREEN A1 B1 AC	GL	S2SRN-L4BGABLM, GREEN A1 B1 AC, GL
H5550006103	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BGADM	GREEN A1 DC	GL	S2SRN-L4BGADM, GREEN A1 DC, GL
H5550006614	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BGAL	GREEN A1 AC	GL	S2SRN-L4BGAL, GREEN A1 AC, GL
H5550006615	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BGALM	GREEN A1 AC	GL	S2SRN-L4BGALM, GREEN A1 AC, GL
H5550006150	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BGBD	GREEN B1 DC	GL	S2SRN-L4BGBD, GREEN B1 DC, GL
H5550006151	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BGBDM	GREEN B1 DC	GL	S2SRN-L4BGBDM, GREEN B1 DC, GL
H5550006662	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BGBL	GREEN B1 AC	GL	S2SRN-L4BGBL, GREEN B1 AC, GL
H5550006663	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BGBLM	GREEN B1 AC	GL	S2SRN-L4BGBLM, GREEN B1 AC, GL
H5550005743	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BY		GL	S2SRN-L4BY, , GL
H5550006246	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BY2AD	YELLOW A2 DC	GL	S2SRN-L4BY2AD, YELLOW A2 DC, GL
H5550006247	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BY2ADM	YELLOW A2 DC	GL	S2SRN-L4BY2ADM, YELLOW A2 DC, GL
H5550006758	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BY2AL	YELLOW A2 AC	GL	S2SRN-L4BY2AL, YELLOW A2 AC, GL

H5550006759	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BY2ALM	YELLOW A2 AC	GL	S2SRN-L4BY2ALM, YELLOW A2 AC, GL
H5550006294	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BY2BD	YELLOW B2 DC	GL	S2SRN-L4BY2BD, YELLOW B2 DC, GL
H5550006295	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BY2BDM	YELLOW B2 DC	GL	S2SRN-L4BY2BDM, YELLOW B2 DC, GL
H5550006806	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BY2BL	YELLOW B2 AC	GL	S2SRN-L4BY2BL, YELLOW B2 AC, GL
H5550006807	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BY2BLM	YELLOW B2 AC	GL	S2SRN-L4BY2BLM, YELLOW B2 AC, GL
H5550006326	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BYABD	YELLOW A1 B1 DC	GL	S2SRN-L4BYABD, YELLOW A1 B1 DC, GL
H5550006327	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BYABDM	YELLOW A1 B1 DC	GL	S2SRN-L4BYABDM, YELLOW A1 B1 DC, GL
H5550006838	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BYABL	YELLOW A1 B1 AC	GL	S2SRN-L4BYABL, YELLOW A1 B1 AC, GL
H5550006839	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BYABLM	YELLOW A1 B1 AC	GL	S2SRN-L4BYABLM, YELLOW A1 B1 AC, GL
H5550006230	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BYAD	YELLOW A1 DC	GL	S2SRN-L4BYAD, YELLOW A1 DC, GL
H5550006231	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BYADM	YELLOW A1 DC	GL	S2SRN-L4BYADM, YELLOW A1 DC, GL
H5550006742	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BYAL	YELLOW A1 AC	GL	S2SRN-L4BYAL, YELLOW A1 AC, GL
H5550006743	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BYALM	YELLOW A1 AC	GL	S2SRN-L4BYALM, YELLOW A1 AC, GL
H5550006278	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BYBD	YELLOW B1 DC	GL	S2SRN-L4BYBD, YELLOW B1 DC, GL
H5550006279	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BYBDM	YELLOW B1 DC	GL	S2SRN-L4BYBDM, YELLOW B1 DC, GL
H5550006790	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BYBL	YELLOW B1 AC	GL	S2SRN-L4BYBL, YELLOW B1 AC, GL
H5550006791	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BYBLM	YELLOW B1 AC	GL	S2SRN-L4BYBLM, YELLOW B1 AC, GL

H5550005992	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5B2AD	BLUE A2 DC	GL	S2SRN-L5B2AD, BLUE A2 DC, GL	
H5550005993	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5B2ADM	BLUE A2 DC	GL	S2SRN-L5B2ADM, BLUE A2 DC, GL	
H5550006504	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5B2AL	BLUE A2 AC	GL	S2SRN-L5B2AL, BLUE A2 AC, GL	
H5550006505	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5B2ALM	BLUE A2 AC	GL	S2SRN-L5B2ALM, BLUE A2 AC, GL	
H5550006040	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5B2BD	BLUE B2 DC	GL	S2SRN-L5B2BD, BLUE B2 DC, GL	
H5550006041	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5B2BDM	BLUE B2 DC	GL	S2SRN-L5B2BDM, BLUE B2 DC, GL	
H5550006552	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5B2BL	BLUE B2 AC	GL	S2SRN-L5B2BL, BLUE B2 AC, GL	
H5550006553	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5B2BLM	BLUE B2 AC	GL	S2SRN-L5B2BLM, BLUE B2 AC, GL	
H5550006072	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5BABD	BLUE A1 B1 DC	GL	S2SRN-L5BABD, BLUE A1 B1 DC, GL	
H5550006073	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5BABDM	BLUE A1 B1 DC	GL	S2SRN-L5BABDM, BLUE A1 B1 DC, GL	
H5550006584	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5BABL	BLUE A1 B1 AC	GL	S2SRN-L5BABL, BLUE A1 B1 AC, GL	
H5550006585	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5BABLM	BLUE A1 B1 AC	GL	S2SRN-L5BABLM, BLUE A1 B1 AC, GL	
H5550006120	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5G2AD	GREEN A2 DC	GL	S2SRN-L5G2AD, GREEN A2 DC, GL	
H5550006121	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5G2ADM	GREEN A2 DC	GL	S2SRN-L5G2ADM, GREEN A2 DC, GL	
H5550006632	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5G2AL	GREEN A2 AC	GL	S2SRN-L5G2AL, GREEN A2 AC, GL	
H5550006633	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5G2ALM	GREEN A2 AC	GL	S2SRN-L5G2ALM, GREEN A2 AC, GL	Селекторный переключатель, с длинной ручкой, выступающего типа, С подсветкой, 22/25, 3-позиционный, с самовозвратом с двух сторон, влево 60, вправо 60, Зеленый, 2 нормально открытых, Модульный тип, СИД 110-220В~ 50/60Hz
H5550006168	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5G2BD	GREEN B2 DC	GL	S2SRN-L5G2BD, GREEN B2 DC, GL	

H5550006169	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5G2BDM	GREEN B2 DC	GL	S2SRN-L5G2BDM, GREEN B2 DC, GL
H5550006680	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5G2BL	GREEN B2 AC	GL	S2SRN-L5G2BL, GREEN B2 AC, GL
H5550006681	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5G2BLM	GREEN B2 AC	GL	S2SRN-L5G2BLM, GREEN B2 AC, GL
H5550006200	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5GABD	GREEN A1 B1 DC	GL	S2SRN-L5GABD, GREEN A1 B1 DC, GL
H5550006201	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5GABDM	GREEN A1 B1 DC	GL	S2SRN-L5GABDM, GREEN A1 B1 DC, GL
H5550006712	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5GABL	GREEN A1 B1 AC	GL	S2SRN-L5GABL, GREEN A1 B1 AC, GL
H5550006713	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5GABLM	GREEN A1 B1 AC	GL	S2SRN-L5GABLM, GREEN A1 B1 AC, GL
H5550011228	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KB	BLUE (HEAD)	GL	S2SRN-L5KB, BLUE (HEAD), GL
H5550011229	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KB2AD	BLUE A2 LED(DC)	GL	S2SRN-L5KB2AD, BLUE A2 LED(DC), GL
H5550011230	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KB2ADM	BLUE A2 LED(DC)	GL	S2SRN-L5KB2ADM, BLUE A2 LED(DC), GL
H5550011231	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KB2AL	BLUE A2 LED(AC)	GL	S2SRN-L5KB2AL, BLUE A2 LED(AC), GL
H5550011232	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KB2ALM	BLUE A2 LED(AC)	GL	S2SRN-L5KB2ALM, BLUE A2 LED(AC), GL
H5550011233	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KB2BD	BLUE B2 LED(DC)	GL	S2SRN-L5KB2BD, BLUE B2 LED(DC), GL
H5550011234	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KB2BDM	BLUE B2 LED(DC)	GL	S2SRN-L5KB2BDM, BLUE B2 LED(DC), GL
H5550011235	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KB2BL	BLUE B2 LED(AC)	GL	S2SRN-L5KB2BL, BLUE B2 LED(AC), GL
H5550011236	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KB2BLM	BLUE B2 LED(AC)	GL	S2SRN-L5KB2BLM, BLUE B2 LED(AC), GL
H5550011237	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KBABD	BLUE AB LED(DC)	GL	S2SRN-L5KBABD, BLUE AB LED(DC), GL
H5550011238	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KBABDM	BLUE AB LED(DC)	GL	S2SRN-L5KBABDM, BLUE AB LED(DC), GL

H5550011239	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KBABL	BLUE AB LED(AC)	GL	S2SRN-L5KBABL, BLUE AB LED(AC), GL
H5550011240	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KBABLM	BLUE AB LED(AC)	GL	S2SRN-L5KBABLM, BLUE AB LED(AC), GL
H5550011241	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KG	GREEN (HEAD)	GL	S2SRN-L5KG, GREEN (HEAD), GL
H5550011242	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KG2AD	GREEN A2 LED(DC)	GL	S2SRN-L5KG2AD, GREEN A2 LED(DC), GL
H5550011243	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KG2ADM	GREEN A2 LED(DC)	GL	S2SRN-L5KG2ADM, GREEN A2 LED(DC), GL
H5550011244	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KG2AL	GREEN A2 LED(AC)	GL	S2SRN-L5KG2AL, GREEN A2 LED(AC), GL
H5550011245	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KG2ALM	GREEN A2 LED(AC)	GL	S2SRN-L5KG2ALM, GREEN A2 LED(AC), GL
H5550011246	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KG2BD	GREEN B2 LED(DC)	GL	S2SRN-L5KG2BD, GREEN B2 LED(DC), GL
H5550011247	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KG2BDM	GREEN B2 LED(DC)	GL	S2SRN-L5KG2BDM, GREEN B2 LED(DC), GL
H5550011248	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KG2BL	GREEN B2 LED(AC)	GL	S2SRN-L5KG2BL, GREEN B2 LED(AC), GL
H5550011249	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KG2BLM	GREEN B2 LED(AC)	GL	S2SRN-L5KG2BLM, GREEN B2 LED(AC), GL
H5550011250	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KGABD	GREEN AB LED(DC)	GL	S2SRN-L5KGABD, GREEN AB LED(DC), GL
H5550011251	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KGABDM	GREEN AB LED(DC)	GL	S2SRN-L5KGABDM, GREEN AB LED(DC), GL
H5550011252	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KGABL	GREEN AB LED(AC)	GL	S2SRN-L5KGABL, GREEN AB LED(AC), GL
H5550011253	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KGABLM	GREEN AB LED(AC)	GL	S2SRN-L5KGABLM, GREEN AB LED(AC), GL
H5550011254	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KR	RED (HEAD)	GL	S2SRN-L5KR, RED (HEAD), GL
H5550011257	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KR2AL	RED A2 LED(AC)	GL	S2SRN-L5KR2AL, RED A2 LED(AC), GL
H5550011258	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KR2ALM	RED A2 LED(AC)	GL	S2SRN-L5KR2ALM, RED A2 LED(AC), GL

H5550011261	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KR2BL	RED B2 LED(AC)	GL	S2SRN-L5KR2BL, RED B2 LED(AC), GL
H5550011262	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KR2BLM	RED B2 LED(AC)	GL	S2SRN-L5KR2BLM, RED B2 LED(AC), GL
H5550011265	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KRABL	RED AB LED(AC)	GL	S2SRN-L5KRABL, RED AB LED(AC), GL
H5550011266	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KRABLM	RED AB LED(AC)	GL	S2SRN-L5KRABLM, RED AB LED(AC), GL
H5550011267	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KY	YELLOW (HEAD)	GL	S2SRN-L5KY, YELLOW (HEAD), GL
H5550011268	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KY2AD	YELLOW A2 LED(DC)	GL	S2SRN-L5KY2AD, YELLOW A2 LED(DC), GL
H5550011269	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KY2ADM	YELLOW A2 LED(DC)	GL	S2SRN-L5KY2ADM, YELLOW A2 LED(DC), GL
H5550011270	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KY2AL	YELLOW A2 LED(AC)	GL	S2SRN-L5KY2AL, YELLOW A2 LED(AC), GL
H5550011271	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KY2ALM	YELLOW A2 LED(AC)	GL	S2SRN-L5KY2ALM, YELLOW A2 LED(AC), GL
H5550011272	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KY2BD	YELLOW B2 LED(DC)	GL	S2SRN-L5KY2BD, YELLOW B2 LED(DC), GL
H5550011273	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KY2BDM	YELLOW B2 LED(DC)	GL	S2SRN-L5KY2BDM, YELLOW B2 LED(DC), GL
H5550011274	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KY2BL	YELLOW B2 LED(AC)	GL	S2SRN-L5KY2BL, YELLOW B2 LED(AC), GL
H5550011275	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KY2BLM	YELLOW B2 LED(AC)	GL	S2SRN-L5KY2BLM, YELLOW B2 LED(AC), GL
H5550011276	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KYABD	YELLOW AB LED(DC)	GL	S2SRN-L5KYABD, YELLOW AB LED(DC), GL
H5550011277	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KYABDM	YELLOW AB LED(DC)	GL	S2SRN-L5KYABDM, YELLOW AB LED(DC), GL
H5550011278	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KYABL	YELLOW AB LED(AC)	GL	S2SRN-L5KYABL, YELLOW AB LED(AC), GL

H5550011279	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KYABLM	YELLOW AB LED(AC)	GL	S2SRN-L5KYABLM, YELLOW AB LED(AC), GL	
H5550006248	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5Y2AD	YELLOW A2 DC	GL	S2SRN-L5Y2AD, YELLOW A2 DC, GL	
H5550006249	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5Y2ADM	YELLOW A2 DC	GL	S2SRN-L5Y2ADM, YELLOW A2 DC, GL	
H5550006760	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5Y2AL	YELLOW A2 AC	GL	S2SRN-L5Y2AL, YELLOW A2 AC, GL	
H5550006761	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5Y2ALM	YELLOW A2 AC	GL	S2SRN-L5Y2ALM, YELLOW A2 AC, GL	Селекторный переключатель, с длинной ручкой, выступающего типа, С подсветкой, 22/25, 3-позиционный, с самовозвратом с двух сторон, влево 60, вправо 60, Желтый. 2 нормально открытых, Модульный тип, СИД 110-220В~ 50/60Hz
H5550006296	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5Y2BD	YELLOW B2 DC	GL	S2SRN-L5Y2BD, YELLOW B2 DC, GL	
H5550006297	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5Y2BDM	YELLOW B2 DC	GL	S2SRN-L5Y2BDM, YELLOW B2 DC, GL	
H5550006808	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5Y2BL	YELLOW B2 AC	GL	S2SRN-L5Y2BL, YELLOW B2 AC, GL	
H5550006809	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5Y2BLM	YELLOW B2 AC	GL	S2SRN-L5Y2BLM, YELLOW B2 AC, GL	
H5550006328	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5YABD	YELLOW A1 B1 DC	GL	S2SRN-L5YABD, YELLOW A1 B1 DC, GL	
H5550006329	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5YABDM	YELLOW A1 B1 DC	GL	S2SRN-L5YABDM, YELLOW A1 B1 DC, GL	
H5550006840	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5YABL	YELLOW A1 B1 AC	GL	S2SRN-L5YABL, YELLOW A1 B1 AC, GL	
H5550006841	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5YABLM	YELLOW A1 B1 AC	GL	S2SRN-L5YABLM, YELLOW A1 B1 AC, GL	
H5550005653	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6B		GL	S2SRN-L6B, , GL	
H5550005994	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6B2AD	BLUE A2 DC	GL	S2SRN-L6B2AD, BLUE A2 DC, GL	

H5550005995	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6B2ADM	BLUE A2 DC	GL	S2SRN-L6B2ADM, BLUE A2 DC, GL
H5550006506	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6B2AL	BLUE A2 AC	GL	S2SRN-L6B2AL, BLUE A2 AC, GL
H5550006507	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6B2ALM	BLUE A2 AC	GL	S2SRN-L6B2ALM, BLUE A2 AC, GL
H5550006042	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6B2BD	BLUE B2 DC	GL	S2SRN-L6B2BD, BLUE B2 DC, GL
H5550006043	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6B2BDM	BLUE B2 DC	GL	S2SRN-L6B2BDM, BLUE B2 DC, GL
H5550006554	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6B2BL	BLUE B2 AC	GL	S2SRN-L6B2BL, BLUE B2 AC, GL
H5550006555	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6B2BLM	BLUE B2 AC	GL	S2SRN-L6B2BLM, BLUE B2 AC, GL
H5550006074	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6BABD	BLUE A1 B1 DC	GL	S2SRN-L6BABD, BLUE A1 B1 DC, GL
H5550006075	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6BABDM	BLUE A1 B1 DC	GL	S2SRN-L6BABDM, BLUE A1 B1 DC, GL
H5550006586	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6BABL	BLUE A1 B1 AC	GL	S2SRN-L6BABL, BLUE A1 B1 AC, GL
H5550006587	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6BABLM	BLUE A1 B1 AC	GL	S2SRN-L6BABLM, BLUE A1 B1 AC, GL
H5550006122	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6G2AD	GREEN A2 DC	GL	S2SRN-L6G2AD, GREEN A2 DC, GL
H5550006634	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6G2AL	GREEN A2 AC	GL	S2SRN-L6G2AL, GREEN A2 AC, GL
H5550006170	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6G2BD	GREEN B2 DC	GL	S2SRN-L6G2BD, GREEN B2 DC, GL
H5550006171	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6G2BDM	GREEN B2 DC	GL	S2SRN-L6G2BDM, GREEN B2 DC, GL

H5550006682	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6G2BL	GREEN B2 AC	GL	S2SRN-L6G2BL, GREEN B2 AC, GL
H5550006683	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6G2BLM	GREEN B2 AC	GL	S2SRN-L6G2BLM, GREEN B2 AC, GL
H5550006202	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6GABD	GREEN A1 B1 DC	GL	S2SRN-L6GABD, GREEN A1 B1 DC, GL
H5550006203	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6GABDM	GREEN A1 B1 DC	GL	S2SRN-L6GABDM, GREEN A1 B1 DC, GL
H5550006714	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6GABL	GREEN A1 B1 AC	GL	S2SRN-L6GABL, GREEN A1 B1 AC, GL
H5550006715	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6GABLM	GREEN A1 B1 AC	GL	S2SRN-L6GABLM, GREEN A1 B1 AC, GL
H5550011280	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KB	BLUE (HEAD)	GL	S2SRN-L6KB, BLUE (HEAD), GL
H5550011281	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KB2AD	BLUE A2 LED(DC)	GL	S2SRN-L6KB2AD, BLUE A2 LED(DC), GL
H5550011282	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KB2ADM	BLUE A2 LED(DC)	GL	S2SRN-L6KB2ADM, BLUE A2 LED(DC), GL
H5550011283	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KB2AL	BLUE A2 LED(AC)	GL	S2SRN-L6KB2AL, BLUE A2 LED(AC), GL
H5550011284	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KB2ALM	BLUE A2 LED(AC)	GL	S2SRN-L6KB2ALM, BLUE A2 LED(AC), GL
H5550011285	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KB2BD	BLUE B2 LED(DC)	GL	S2SRN-L6KB2BD, BLUE B2 LED(DC), GL
H5550011286	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KB2BDM	BLUE B2 LED(DC)	GL	S2SRN-L6KB2BDM, BLUE B2 LED(DC), GL
H5550011287	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KB2BL	BLUE B2 LED(AC)	GL	S2SRN-L6KB2BL, BLUE B2 LED(AC), GL
H5550011288	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KB2BLM	BLUE B2 LED(AC)	GL	S2SRN-L6KB2BLM, BLUE B2 LED(AC), GL

H5550011289	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KBABD	BLUE AB LED(DC)	GL	S2SRN-L6KBABD, BLUE AB LED(DC), GL
H5550011290	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KBABDM	BLUE AB LED(DC)	GL	S2SRN-L6KBABDM, BLUE AB LED(DC), GL
H5550011291	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KBABL	BLUE AB LED(AC)	GL	S2SRN-L6KBABL, BLUE AB LED(AC), GL
H5550011292	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KBABLM	BLUE AB LED(AC)	GL	S2SRN-L6KBABLM, BLUE AB LED(AC), GL
H5550011293	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KG	GREEN (HEAD)	GL	S2SRN-L6KG, GREEN (HEAD), GL
H5550011294	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KG2AD	GREEN A2 LED(DC)	GL	S2SRN-L6KG2AD, GREEN A2 LED(DC), GL
H5550011295	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KG2ADM	GREEN A2 LED(DC)	GL	S2SRN-L6KG2ADM, GREEN A2 LED(DC), GL
H5550011296	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KG2AL	GREEN A2 LED(AC)	GL	S2SRN-L6KG2AL, GREEN A2 LED(AC), GL
H5550011297	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KG2ALM	GREEN A2 LED(AC)	GL	S2SRN-L6KG2ALM, GREEN A2 LED(AC), GL
H5550011298	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KG2BD	GREEN B2 LED(DC)	GL	S2SRN-L6KG2BD, GREEN B2 LED(DC), GL
H5550011299	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KG2BDM	GREEN B2 LED(DC)	GL	S2SRN-L6KG2BDM, GREEN B2 LED(DC), GL
H5550011300	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KG2BL	GREEN B2 LED(AC)	GL	S2SRN-L6KG2BL, GREEN B2 LED(AC), GL
H5550011301	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KG2BLM	GREEN B2 LED(AC)	GL	S2SRN-L6KG2BLM, GREEN B2 LED(AC), GL
H5550011302	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KGABD	GREEN AB LED(DC)	GL	S2SRN-L6KGABD, GREEN AB LED(DC), GL
H5550011303	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KGABDM	GREEN AB LED(DC)	GL	S2SRN-L6KGABDM, GREEN AB LED(DC), GL
H5550011304	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KGABL	GREEN AB LED(AC)	GL	S2SRN-L6KGABL, GREEN AB LED(AC), GL

H5550011305	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KGABLM	GREEN AB LED(AC)	GL	S2SRN-L6KGABLM, GREEN AB LED(AC), GL
H5550011306	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KR	RED (HEAD)	GL	S2SRN-L6KR, RED (HEAD), GL
H5550011309	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KR2AL	RED A2 LED(AC)	GL	S2SRN-L6KR2AL, RED A2 LED(AC), GL
H5550011310	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KR2ALM	RED A2 LED(AC)	GL	S2SRN-L6KR2ALM, RED A2 LED(AC), GL
H5550011313	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KR2BL	RED B2 LED(AC)	GL	S2SRN-L6KR2BL, RED B2 LED(AC), GL
H5550011314	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KR2BLM	RED B2 LED(AC)	GL	S2SRN-L6KR2BLM, RED B2 LED(AC), GL
H5550011317	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KRABL	RED AB LED(AC)	GL	S2SRN-L6KRABL, RED AB LED(AC), GL
H5550011318	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KRABLM	RED AB LED(AC)	GL	S2SRN-L6KRABLM, RED AB LED(AC), GL
H5550011319	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KY	YELLOW (HEAD)	GL	S2SRN-L6KY, YELLOW (HEAD), GL
H5550011320	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KY2AD	YELLOW A2 LED(DC)	GL	S2SRN-L6KY2AD, YELLOW A2 LED(DC), GL
H5550011321	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KY2ADM	YELLOW A2 LED(DC)	GL	S2SRN-L6KY2ADM, YELLOW A2 LED(DC), GL
H5550011322	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KY2AL	YELLOW A2 LED(AC)	GL	S2SRN-L6KY2AL, YELLOW A2 LED(AC), GL
H5550011323	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KY2ALM	YELLOW A2 LED(AC)	GL	S2SRN-L6KY2ALM, YELLOW A2 LED(AC), GL
H5550011324	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KY2BD	YELLOW B2 LED(DC)	GL	S2SRN-L6KY2BD, YELLOW B2 LED(DC), GL
H5550011325	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KY2BDM	YELLOW B2 LED(DC)	GL	S2SRN-L6KY2BDM, YELLOW B2 LED(DC), GL
H5550011326	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KY2BL	YELLOW B2 LED(AC)	GL	S2SRN-L6KY2BL, YELLOW B2 LED(AC), GL
H5550011327	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KY2BLM	YELLOW B2 LED(AC)	GL	S2SRN-L6KY2BLM, YELLOW B2 LED(AC), GL

H5550011328	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KYABD	YELLOW AB LED(DC)	GL	S2SRN-L6KYABD, YELLOW AB LED(DC), GL
H5550011329	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KYABDM	YELLOW AB LED(DC)	GL	S2SRN-L6KYABDM, YELLOW AB LED(DC), GL
H5550011330	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KYABL	YELLOW AB LED(AC)	GL	S2SRN-L6KYABL, YELLOW AB LED(AC), GL
H5550011331	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KYABLM	YELLOW AB LED(AC)	GL	S2SRN-L6KYABLM, YELLOW AB LED(AC), GL
H5550005749	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6Y		GL	S2SRN-L6Y, , GL
H5550006250	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6Y2AD	YELLOW A2 DC	GL	S2SRN-L6Y2AD, YELLOW A2 DC, GL
H5550006251	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6Y2ADM	YELLOW A2 DC	GL	S2SRN-L6Y2ADM, YELLOW A2 DC, GL
H5550006762	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6Y2AL	YELLOW A2 AC	GL	S2SRN-L6Y2AL, YELLOW A2 AC, GL
H5550006763	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6Y2ALM	YELLOW A2 AC	GL	S2SRN-L6Y2ALM, YELLOW A2 AC, GL
H5550006298	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6Y2BD	YELLOW B2 DC	GL	S2SRN-L6Y2BD, YELLOW B2 DC, GL
H5550006299	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6Y2BDM	YELLOW B2 DC	GL	S2SRN-L6Y2BDM, YELLOW B2 DC, GL
H5550006810	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6Y2BL	YELLOW B2 AC	GL	S2SRN-L6Y2BL, YELLOW B2 AC, GL
H5550006811	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6Y2BLM	YELLOW B2 AC	GL	S2SRN-L6Y2BLM, YELLOW B2 AC, GL
H5550006330	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6YABD	YELLOW A1 B1 DC	GL	S2SRN-L6YABD, YELLOW A1 B1 DC, GL
H5550006331	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6YABDM	YELLOW A1 B1 DC	GL	S2SRN-L6YABDM, YELLOW A1 B1 DC, GL
H5550006842	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6YABL	YELLOW A1 B1 AC	GL	S2SRN-L6YABL, YELLOW A1 B1 AC, GL

H5550006843	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6YABLM	YELLOW A1 B1 AC	GL	S2SRN-L6YABLM, YELLOW A1 B1 AC, GL
H5550005996	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7B2AD	BLUE A2 DC	GL	S2SRN-L7B2AD, BLUE A2 DC, GL
H5550006508	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7B2AL	BLUE A2 AC	GL	S2SRN-L7B2AL, BLUE A2 AC, GL
H5550006044	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7B2BD	BLUE B2 DC	GL	S2SRN-L7B2BD, BLUE B2 DC, GL
H5550006045	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7B2BDM	BLUE B2 DC	GL	S2SRN-L7B2BDM, BLUE B2 DC, GL
H5550006556	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7B2BL	BLUE B2 AC	GL	S2SRN-L7B2BL, BLUE B2 AC, GL
H5550006557	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7B2BLM	BLUE B2 AC	GL	S2SRN-L7B2BLM, BLUE B2 AC, GL
H5550006076	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7BABD	BLUE A1 B1 DC	GL	S2SRN-L7BABD, BLUE A1 B1 DC, GL
H5550006077	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7BABDM	BLUE A1 B1 DC	GL	S2SRN-L7BABDM, BLUE A1 B1 DC, GL
H5550006588	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7BABL	BLUE A1 B1 AC	GL	S2SRN-L7BABL, BLUE A1 B1 AC, GL
H5550006589	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7BABLM	BLUE A1 B1 AC	GL	S2SRN-L7BABLM, BLUE A1 B1 AC, GL
H5550006124	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7G2AD	GREEN A2 DC	GL	S2SRN-L7G2AD, GREEN A2 DC, GL
H5550006172	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7G2BD	GREEN B2 DC	GL	S2SRN-L7G2BD, GREEN B2 DC, GL
H5550006173	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7G2BDM	GREEN B2 DC	GL	S2SRN-L7G2BDM, GREEN B2 DC, GL
H5550006684	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7G2BL	GREEN B2 AC	GL	S2SRN-L7G2BL, GREEN B2 AC, GL
H5550006685	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7G2BLM	GREEN B2 AC	GL	S2SRN-L7G2BLM, GREEN B2 AC, GL
H5550006204	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7GABD	GREEN A1 B1 DC	GL	S2SRN-L7GABD, GREEN A1 B1 DC, GL

H5550006205	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7GABDM	GREEN A1 B1 DC	GL	S2SRN-L7GABDM, GREEN A1 B1 DC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 3-позиционный, с фиксацией, влево 90, вправо 90, Зеленый, 1 нормально открытый 1 нормально закрытый, многоуровневый, СИД 12-24В~50/60Hz 12-24 В=
H5550006716	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7GABL	GREEN A1 B1 AC	GL	S2SRN-L7GABL, GREEN A1 B1 AC, GL	
H5550006717	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7GABLM	GREEN A1 B1 AC	GL	S2SRN-L7GABLM, GREEN A1 B1 AC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 3-позиционный, с фиксацией, влево 90, вправо 90, Зеленый, 1 нормально открытый 1 нормально закрытый, многоуровневый, СИД 110-220В~50/60Hz
H5550011332	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KB	BLUE (HEAD)	GL	S2SRN-L7KB, BLUE (HEAD), GL	
H5550011333	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KB2AD	BLUE A2 LED(DC)	GL	S2SRN-L7KB2AD, BLUE A2 LED(DC), GL	
H5550011334	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KB2ADM	BLUE A2 LED(DC)	GL	S2SRN-L7KB2ADM, BLUE A2 LED(DC), GL	
H5550011335	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KB2AL	BLUE A2 LED(AC)	GL	S2SRN-L7KB2AL, BLUE A2 LED(AC), GL	
H5550011336	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KB2ALM	BLUE A2 LED(AC)	GL	S2SRN-L7KB2ALM, BLUE A2 LED(AC), GL	
H5550011337	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KB2BD	BLUE B2 LED(DC)	GL	S2SRN-L7KB2BD, BLUE B2 LED(DC), GL	
H5550011338	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KB2BDM	BLUE B2 LED(DC)	GL	S2SRN-L7KB2BDM, BLUE B2 LED(DC), GL	
H5550011339	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KB2BL	BLUE B2 LED(AC)	GL	S2SRN-L7KB2BL, BLUE B2 LED(AC), GL	
H5550011340	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KB2BLM	BLUE B2 LED(AC)	GL	S2SRN-L7KB2BLM, BLUE B2 LED(AC), GL	
H5550011341	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KBABD	BLUE AB LED(DC)	GL	S2SRN-L7KBABD, BLUE AB LED(DC), GL	
H5550011342	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KBABDM	BLUE AB LED(DC)	GL	S2SRN-L7KBABDM, BLUE AB LED(DC), GL	
H5550011343	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KBABL	BLUE AB LED(AC)	GL	S2SRN-L7KBABL, BLUE AB LED(AC), GL	
H5550011344	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KBABLM	BLUE AB LED(AC)	GL	S2SRN-L7KBABLM, BLUE AB LED(AC), GL	

H5550011345	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KG	GREEN (HEAD)	GL	S2SRN-L7KG, GREEN (HEAD), GL
H5550011346	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KG2AD	GREEN A2 LED(DC)	GL	S2SRN-L7KG2AD, GREEN A2 LED(DC), GL
H5550011347	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KG2ADM	GREEN A2 LED(DC)	GL	S2SRN-L7KG2ADM, GREEN A2 LED(DC), GL
H5550011348	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KG2AL	GREEN A2 LED(AC)	GL	S2SRN-L7KG2AL, GREEN A2 LED(AC), GL
H5550011349	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KG2ALM	GREEN A2 LED(AC)	GL	S2SRN-L7KG2ALM, GREEN A2 LED(AC), GL
H5550011350	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KG2BD	GREEN B2 LED(DC)	GL	S2SRN-L7KG2BD, GREEN B2 LED(DC), GL
H5550011351	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KG2BDM	GREEN B2 LED(DC)	GL	S2SRN-L7KG2BDM, GREEN B2 LED(DC), GL
H5550011352	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KG2BL	GREEN B2 LED(AC)	GL	S2SRN-L7KG2BL, GREEN B2 LED(AC), GL
H5550011353	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KG2BLM	GREEN B2 LED(AC)	GL	S2SRN-L7KG2BLM, GREEN B2 LED(AC), GL
H5550011354	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KGABD	GREEN AB LED(DC)	GL	S2SRN-L7KGABD, GREEN AB LED(DC), GL
H5550011355	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KGABDM	GREEN AB LED(DC)	GL	S2SRN-L7KGABDM, GREEN AB LED(DC), GL
H5550011356	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KGABL	GREEN AB LED(AC)	GL	S2SRN-L7KGABL, GREEN AB LED(AC), GL
H5550011357	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KGABLM	GREEN AB LED(AC)	GL	S2SRN-L7KGABLM, GREEN AB LED(AC), GL
H5550011358	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KR	RED (HEAD)	GL	S2SRN-L7KR, RED (HEAD), GL
H5550011365	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KR2BL	RED B2 LED(AC)	GL	S2SRN-L7KR2BL, RED B2 LED(AC), GL
H5550011366	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KR2BLM	RED B2 LED(AC)	GL	S2SRN-L7KR2BLM, RED B2 LED(AC), GL
H5550011369	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KRABL	RED AB LED(AC)	GL	S2SRN-L7KRABL, RED AB LED(AC), GL
H5550011370	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KRABLM	RED AB LED(AC)	GL	S2SRN-L7KRABLM, RED AB LED(AC), GL

H5550011371	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KY	YELLOW (HEAD)	GL	S2SRN-L7KY, YELLOW (HEAD), GL
H5550011372	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KY2AD	YELLOW A2 LED(DC)	GL	S2SRN-L7KY2AD, YELLOW A2 LED(DC), GL
H5550011373	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KY2ADM	YELLOW A2 LED(DC)	GL	S2SRN-L7KY2ADM, YELLOW A2 LED(DC), GL
H5550011374	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KY2AL	YELLOW A2 LED(AC)	GL	S2SRN-L7KY2AL, YELLOW A2 LED(AC), GL
H5550011375	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KY2ALM	YELLOW A2 LED(AC)	GL	S2SRN-L7KY2ALM, YELLOW A2 LED(AC), GL
H5550011376	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KY2BD	YELLOW B2 LED(DC)	GL	S2SRN-L7KY2BD, YELLOW B2 LED(DC), GL
H5550011377	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KY2BDM	YELLOW B2 LED(DC)	GL	S2SRN-L7KY2BDM, YELLOW B2 LED(DC), GL
H5550011378	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KY2BL	YELLOW B2 LED(AC)	GL	S2SRN-L7KY2BL, YELLOW B2 LED(AC), GL
H5550011379	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KY2BLM	YELLOW B2 LED(AC)	GL	S2SRN-L7KY2BLM, YELLOW B2 LED(AC), GL
H5550011380	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KYABD	YELLOW AB LED(DC)	GL	S2SRN-L7KYABD, YELLOW AB LED(DC), GL
H5550011381	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KYABDM	YELLOW AB LED(DC)	GL	S2SRN-L7KYABDM, YELLOW AB LED(DC), GL
H5550011382	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KYABL	YELLOW AB LED(AC)	GL	S2SRN-L7KYABL, YELLOW AB LED(AC), GL
H5550011383	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KYABL M	YELLOW AB LED(AC)	GL	S2SRN-L7KYABL M, YELLOW AB LED(AC), GL
H5550006252	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7Y2AD	YELLOW A2 DC	GL	S2SRN-L7Y2AD, YELLOW A2 DC, GL
H5550006764	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7Y2AL	YELLOW A2 AC	GL	S2SRN-L7Y2AL, YELLOW A2 AC, GL
H5550006300	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7Y2BD	YELLOW B2 DC	GL	S2SRN-L7Y2BD, YELLOW B2 DC, GL
H5550006301	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7Y2BDM	YELLOW B2 DC	GL	S2SRN-L7Y2BDM, YELLOW B2 DC, GL

H5550006812	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7Y2BL	YELLOW B2 AC	GL	S2SRN-L7Y2BL, YELLOW B2 AC, GL
H5550006813	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7Y2BLM	YELLOW B2 AC	GL	S2SRN-L7Y2BLM, YELLOW B2 AC, GL
H5550006332	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7YABD	YELLOW A1 B1 DC	GL	S2SRN-L7YABD, YELLOW A1 B1 DC, GL
H5550006333	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7YABDM	YELLOW A1 B1 DC	GL	S2SRN-L7YABDM, YELLOW A1 B1 DC, GL
H5550006844	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7YABL	YELLOW A1 B1 AC	GL	S2SRN-L7YABL, YELLOW A1 B1 AC, GL
H5550006845	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7YABLM	YELLOW A1 B1 AC	GL	S2SRN-L7YABLM, YELLOW A1 B1 AC, GL
H5550005659	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8B		GL	S2SRN-L8B, , GL
H5550005998	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8B2AD	BLUE A2 DC	GL	S2SRN-L8B2AD, BLUE A2 DC, GL
H5550005999	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8B2ADM	BLUE A2 DC	GL	S2SRN-L8B2ADM, BLUE A2 DC, GL
H5550006510	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8B2AL	BLUE A2 AC	GL	S2SRN-L8B2AL, BLUE A2 AC, GL
H5550006511	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8B2ALM	BLUE A2 AC	GL	S2SRN-L8B2ALM, BLUE A2 AC, GL
H5550006046	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8B2BD	BLUE B2 DC	GL	S2SRN-L8B2BD, BLUE B2 DC, GL
H5550006047	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8B2BDM	BLUE B2 DC	GL	S2SRN-L8B2BDM, BLUE B2 DC, GL
H5550006558	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8B2BL	BLUE B2 AC	GL	S2SRN-L8B2BL, BLUE B2 AC, GL
H5550006559	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8B2BLM	BLUE B2 AC	GL	S2SRN-L8B2BLM, BLUE B2 AC, GL
H5550006078	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8BABD	BLUE A1 B1 DC	GL	S2SRN-L8BABD, BLUE A1 B1 DC, GL

H5550006079	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8BABDM	BLUE A1 B1 DC	GL	S2SRN-L8BABDM, BLUE A1 B1 DC, GL
H5550006590	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8BABL	BLUE A1 B1 AC	GL	S2SRN-L8BABL, BLUE A1 B1 AC, GL
H5550006591	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8BABLM	BLUE A1 B1 AC	GL	S2SRN-L8BABLM, BLUE A1 B1 AC, GL
H5550006127	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8G2ADM	GREEN A2 DC	GL	S2SRN-L8G2ADM, GREEN A2 DC, GL
H5550006639	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8G2ALM	GREEN A2 AC	GL	S2SRN-L8G2ALM, GREEN A2 AC, GL
H5550006174	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8G2BD	GREEN B2 DC	GL	S2SRN-L8G2BD, GREEN B2 DC, GL
H5550006175	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8G2BDM	GREEN B2 DC	GL	S2SRN-L8G2BDM, GREEN B2 DC, GL
H5550006686	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8G2BL	GREEN B2 AC	GL	S2SRN-L8G2BL, GREEN B2 AC, GL
H5550006687	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8G2BLM	GREEN B2 AC	GL	S2SRN-L8G2BLM, GREEN B2 AC, GL
H5550006206	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8GABD	GREEN A1 B1 DC	GL	S2SRN-L8GABD, GREEN A1 B1 DC, GL
H5550006207	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8GABDM	GREEN A1 B1 DC	GL	S2SRN-L8GABDM, GREEN A1 B1 DC, GL
H5550006718	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8GABL	GREEN A1 B1 AC	GL	S2SRN-L8GABL, GREEN A1 B1 AC, GL
H5550006719	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8GABLM	GREEN A1 B1 AC	GL	S2SRN-L8GABLM, GREEN A1 B1 AC, GL
H5550011384	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KB	BLUE (HEAD)	GL	S2SRN-L8KB, BLUE (HEAD), GL
H5550011385	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KB2AD	BLUE A2 LED(DC)	GL	S2SRN-L8KB2AD, BLUE A2 LED(DC), GL
H5550011386	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KB2ADM	BLUE A2 LED(DC)	GL	S2SRN-L8KB2ADM, BLUE A2 LED(DC), GL
H5550011387	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KB2AL	BLUE A2 LED(AC)	GL	S2SRN-L8KB2AL, BLUE A2 LED(AC), GL

H5550011388	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KB2ALM	BLUE A2 LED(AC)	GL	S2SRN-L8KB2ALM, BLUE A2 LED(AC), GL
H5550011389	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KB2BD	BLUE B2 LED(DC)	GL	S2SRN-L8KB2BD, BLUE B2 LED(DC), GL
H5550011390	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KB2BDM	BLUE B2 LED(DC)	GL	S2SRN-L8KB2BDM, BLUE B2 LED(DC), GL
H5550011391	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KB2BL	BLUE B2 LED(AC)	GL	S2SRN-L8KB2BL, BLUE B2 LED(AC), GL
H5550011392	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KB2BLM	BLUE B2 LED(AC)	GL	S2SRN-L8KB2BLM, BLUE B2 LED(AC), GL
H5550011393	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KBABD	BLUE AB LED(DC)	GL	S2SRN-L8KBABD, BLUE AB LED(DC), GL
H5550011394	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KBABDM	BLUE AB LED(DC)	GL	S2SRN-L8KBABDM, BLUE AB LED(DC), GL
H5550011395	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KBABL	BLUE AB LED(AC)	GL	S2SRN-L8KBABL, BLUE AB LED(AC), GL
H5550011396	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KBABLM	BLUE AB LED(AC)	GL	S2SRN-L8KBABLM, BLUE AB LED(AC), GL
H5550011397	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KG	GREEN (HEAD)	GL	S2SRN-L8KG, GREEN (HEAD), GL
H5550011398	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KG2AD	GREEN A2 LED(DC)	GL	S2SRN-L8KG2AD, GREEN A2 LED(DC), GL
H5550011399	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KG2ADM	GREEN A2 LED(DC)	GL	S2SRN-L8KG2ADM, GREEN A2 LED(DC), GL
H5550011400	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KG2AL	GREEN A2 LED(AC)	GL	S2SRN-L8KG2AL, GREEN A2 LED(AC), GL
H5550011401	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KG2ALM	GREEN A2 LED(AC)	GL	S2SRN-L8KG2ALM, GREEN A2 LED(AC), GL
H5550011402	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KG2BD	GREEN B2 LED(DC)	GL	S2SRN-L8KG2BD, GREEN B2 LED(DC), GL
H5550011403	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KG2BDM	GREEN B2 LED(DC)	GL	S2SRN-L8KG2BDM, GREEN B2 LED(DC), GL
H5550011404	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KG2BL	GREEN B2 LED(AC)	GL	S2SRN-L8KG2BL, GREEN B2 LED(AC), GL
H5550011405	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KG2BLM	GREEN B2 LED(AC)	GL	S2SRN-L8KG2BLM, GREEN B2 LED(AC), GL
H5550011406	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KGABD	GREEN AB LED(DC)	GL	S2SRN-L8KGABD, GREEN AB LED(DC), GL

H5550011407	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KGABDM	GREEN AB LED(DC)	GL	S2SRN-L8KGABDM, GREEN AB LED(DC), GL
H5550011408	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KGABL	GREEN AB LED(AC)	GL	S2SRN-L8KGABL, GREEN AB LED(AC), GL
H5550011409	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KGABLM	GREEN AB LED(AC)	GL	S2SRN-L8KGABLM, GREEN AB LED(AC), GL
H5550011410	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KR	RED (HEAD)	GL	S2SRN-L8KR, RED (HEAD), GL
H5550011417	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KR2BL	RED B2 LED(AC)	GL	S2SRN-L8KR2BL, RED B2 LED(AC), GL
H5550011418	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KR2BLM	RED B2 LED(AC)	GL	S2SRN-L8KR2BLM, RED B2 LED(AC), GL
H5550011421	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KRABL	RED AB LED(AC)	GL	S2SRN-L8KRABL, RED AB LED(AC), GL
H5550011422	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KRABLM	RED AB LED(AC)	GL	S2SRN-L8KRABLM, RED AB LED(AC), GL
H5550011423	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KY	YELLOW (HEAD)	GL	S2SRN-L8KY, YELLOW (HEAD), GL
H5550011424	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KY2AD	YELLOW A2 LED(DC)	GL	S2SRN-L8KY2AD, YELLOW A2 LED(DC), GL
H5550011425	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KY2ADM	YELLOW A2 LED(DC)	GL	S2SRN-L8KY2ADM, YELLOW A2 LED(DC), GL
H5550011426	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KY2AL	YELLOW A2 LED(AC)	GL	S2SRN-L8KY2AL, YELLOW A2 LED(AC), GL
H5550011427	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KY2ALM	YELLOW A2 LED(AC)	GL	S2SRN-L8KY2ALM, YELLOW A2 LED(AC), GL
H5550011428	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KY2BD	YELLOW B2 LED(DC)	GL	S2SRN-L8KY2BD, YELLOW B2 LED(DC), GL
H5550011429	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KY2BDM	YELLOW B2 LED(DC)	GL	S2SRN-L8KY2BDM, YELLOW B2 LED(DC), GL
H5550011430	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KY2BL	YELLOW B2 LED(AC)	GL	S2SRN-L8KY2BL, YELLOW B2 LED(AC), GL

H5550011431	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KY2BLM	YELLOW B2 LED(AC)	GL	S2SRN-L8KY2BLM, YELLOW B2 LED(AC), GL
H5550011432	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KYABD	YELLOW AB LED(DC)	GL	S2SRN-L8KYABD, YELLOW AB LED(DC), GL
H5550011433	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KYABDM	YELLOW AB LED(DC)	GL	S2SRN-L8KYABDM, YELLOW AB LED(DC), GL
H5550011434	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KYABL	YELLOW AB LED(AC)	GL	S2SRN-L8KYABL, YELLOW AB LED(AC), GL
H5550011435	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KYABLM	YELLOW AB LED(AC)	GL	S2SRN-L8KYABLM, YELLOW AB LED(AC), GL
H5550005755	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8Y		GL	S2SRN-L8Y, , GL
H5550006254	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8Y2AD	YELLOW A2 DC	GL	S2SRN-L8Y2AD, YELLOW A2 DC, GL
H5550006255	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8Y2ADM	YELLOW A2 DC	GL	S2SRN-L8Y2ADM, YELLOW A2 DC, GL
H5550006766	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8Y2AL	YELLOW A2 AC	GL	S2SRN-L8Y2AL, YELLOW A2 AC, GL
H5550006767	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8Y2ALM	YELLOW A2 AC	GL	S2SRN-L8Y2ALM, YELLOW A2 AC, GL
H5550006302	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8Y2BD	YELLOW B2 DC	GL	S2SRN-L8Y2BD, YELLOW B2 DC, GL
H5550006303	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8Y2BDM	YELLOW B2 DC	GL	S2SRN-L8Y2BDM, YELLOW B2 DC, GL
H5550006814	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8Y2BL	YELLOW B2 AC	GL	S2SRN-L8Y2BL, YELLOW B2 AC, GL
H5550006815	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8Y2BLM	YELLOW B2 AC	GL	S2SRN-L8Y2BLM, YELLOW B2 AC, GL
H5550006334	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8YABD	YELLOW A1 B1 DC	GL	S2SRN-L8YABD, YELLOW A1 B1 DC, GL
H5550006335	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8YABDM	YELLOW A1 B1 DC	GL	S2SRN-L8YABDM, YELLOW A1 B1 DC, GL
H5550006846	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8YABL	YELLOW A1 B1 AC	GL	S2SRN-L8YABL, YELLOW A1 B1 AC, GL
H5550006847	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8YABLM	YELLOW A1 B1 AC	GL	S2SRN-L8YABLM, YELLOW A1 B1 AC, GL

H5550005662	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAB		GL	S2SRN-LAB, , GL
H5550006000	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAB2AD	BLUE A2 DC	GL	S2SRN-LAB2AD, BLUE A2 DC, GL
H5550006001	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAB2ADM	BLUE A2 DC	GL	S2SRN-LAB2ADM, BLUE A2 DC, GL
H5550006512	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAB2AL	BLUE A2 AC	GL	S2SRN-LAB2AL, BLUE A2 AC, GL
H5550006513	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAB2ALM	BLUE A2 AC	GL	S2SRN-LAB2ALM, BLUE A2 AC, GL
H5550006048	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAB2BD	BLUE B2 DC	GL	S2SRN-LAB2BD, BLUE B2 DC, GL
H5550006049	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAB2BDM	BLUE B2 DC	GL	S2SRN-LAB2BDM, BLUE B2 DC, GL
H5550006560	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAB2BL	BLUE B2 AC	GL	S2SRN-LAB2BL, BLUE B2 AC, GL
H5550006561	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAB2BLM	BLUE B2 AC	GL	S2SRN-LAB2BLM, BLUE B2 AC, GL
H5550006080	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LABABD	BLUE A1 B1 DC	GL	S2SRN-LABABD, BLUE A1 B1 DC, GL
H5550006081	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LABABDM	BLUE A1 B1 DC	GL	S2SRN-LABABDM, BLUE A1 B1 DC, GL
H5550006592	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LABABL	BLUE A1 B1 AC	GL	S2SRN-LABABL, BLUE A1 B1 AC, GL
H5550006593	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LABABLM	BLUE A1 B1 AC	GL	S2SRN-LABABLM, BLUE A1 B1 AC, GL
H5550005710	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAG		GL	S2SRN-LAG, , GL
H5550006128	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAG2AD	GREEN A2 DC	GL	S2SRN-LAG2AD, GREEN A2 DC, GL
H5550006129	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAG2ADM	GREEN A2 DC	GL	S2SRN-LAG2ADM, GREEN A2 DC, GL
H5550006640	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAG2AL	GREEN A2 AC	GL	S2SRN-LAG2AL, GREEN A2 AC, GL

H5550006641	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAG2ALM	GREEN A2 AC	GL	S2SRN-LAG2ALM, GREEN A2 AC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 3-позиционный, с фиксацией, влево 90, вправо 90, Зеленый, 1 нормально открытый 1 нормально закрытый, многоуровневый, СИД 110-220В~ 50/60Hz
H5550006176	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAG2BD	GREEN B2 DC	GL	S2SRN-LAG2BD, GREEN B2 DC, GL	
H5550006177	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAG2BDM	GREEN B2 DC	GL	S2SRN-LAG2BDM, GREEN B2 DC, GL	
H5550006688	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAG2BL	GREEN B2 AC	GL	S2SRN-LAG2BL, GREEN B2 AC, GL	
H5550006689	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAG2BLM	GREEN B2 AC	GL	S2SRN-LAG2BLM, GREEN B2 AC, GL	
H5550006208	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAGABD	GREEN A1 B1 DC	GL	S2SRN-LAGABD, GREEN A1 B1 DC, GL	
H5550006209	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAGABDM	GREEN A1 B1 DC	GL	S2SRN-LAGABDM, GREEN A1 B1 DC, GL	
H5550006720	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAGABL	GREEN A1 B1 AC	GL	S2SRN-LAGABL, GREEN A1 B1 AC, GL	
H5550006721	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAGABLM	GREEN A1 B1 AC	GL	S2SRN-LAGABLM, GREEN A1 B1 AC, GL	
H5550011436	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKB	BLUE (HEAD)	GL	S2SRN-LAKB, BLUE (HEAD), GL	
H5550011437	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKB2AD	BLUE A2 LED(DC)	GL	S2SRN-LAKB2AD, BLUE A2 LED(DC), GL	
H5550011438	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKB2ADM	BLUE A2 LED(DC)	GL	S2SRN-LAKB2ADM, BLUE A2 LED(DC), GL	
H5550011439	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKB2AL	BLUE A2 LED(AC)	GL	S2SRN-LAKB2AL, BLUE A2 LED(AC), GL	
H5550011440	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKB2ALM	BLUE A2 LED(AC)	GL	S2SRN-LAKB2ALM, BLUE A2 LED(AC), GL	
H5550011441	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKB2BD	BLUE B2 LED(DC)	GL	S2SRN-LAKB2BD, BLUE B2 LED(DC), GL	
H5550011442	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKB2BDM	BLUE B2 LED(DC)	GL	S2SRN-LAKB2BDM, BLUE B2 LED(DC), GL	

H5550011443	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKB2BL	BLUE B2 LED(AC)	GL	S2SRN-LAKB2BL, BLUE B2 LED(AC), GL
H5550011444	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKB2BLM	BLUE B2 LED(AC)	GL	S2SRN-LAKB2BLM, BLUE B2 LED(AC), GL
H5550011445	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKB2BD	BLUE AB LED(DC)	GL	S2SRN-LAKB2BD, BLUE AB LED(DC), GL
H5550011446	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKB2BDM	BLUE AB LED(DC)	GL	S2SRN-LAKB2BDM, BLUE AB LED(DC), GL
H5550011447	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKB2BL	BLUE AB LED(AC)	GL	S2SRN-LAKB2BL, BLUE AB LED(AC), GL
H5550011448	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKB2BLM	BLUE AB LED(AC)	GL	S2SRN-LAKB2BLM, BLUE AB LED(AC), GL
H5550011449	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKG	GREEN (HEAD)	GL	S2SRN-LAKG, GREEN (HEAD), GL
H5550011450	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKG2AD	GREEN A2 LED(DC)	GL	S2SRN-LAKG2AD, GREEN A2 LED(DC), GL
H5550011451	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKG2ADM	GREEN A2 LED(DC)	GL	S2SRN-LAKG2ADM, GREEN A2 LED(DC), GL
H5550011452	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKG2AL	GREEN A2 LED(AC)	GL	S2SRN-LAKG2AL, GREEN A2 LED(AC), GL
H5550011453	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKG2ALM	GREEN A2 LED(AC)	GL	S2SRN-LAKG2ALM, GREEN A2 LED(AC), GL
H5550011454	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKG2BD	GREEN B2 LED(DC)	GL	S2SRN-LAKG2BD, GREEN B2 LED(DC), GL
H5550011455	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKG2BDM	GREEN B2 LED(DC)	GL	S2SRN-LAKG2BDM, GREEN B2 LED(DC), GL
H5550011456	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKG2BL	GREEN B2 LED(AC)	GL	S2SRN-LAKG2BL, GREEN B2 LED(AC), GL
H5550011457	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKG2BLM	GREEN B2 LED(AC)	GL	S2SRN-LAKG2BLM, GREEN B2 LED(AC), GL
H5550011458	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKG2BD	GREEN AB LED(DC)	GL	S2SRN-LAKG2BD, GREEN AB LED(DC), GL
H5550011459	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKG2BDM	GREEN AB LED(DC)	GL	S2SRN-LAKG2BDM, GREEN AB LED(DC), GL
H5550011460	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKG2BL	GREEN AB LED(AC)	GL	S2SRN-LAKG2BL, GREEN AB LED(AC), GL

H5550011461	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKGABLM	GREEN AB LED(AC)	GL	S2SRN-LAKGABLM, GREEN AB LED(AC), GL
H5550011462	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKR	RED (HEAD)	GL	S2SRN-LAKR, RED (HEAD), GL
H5550011469	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKR2BL	RED B2 LED(AC)	GL	S2SRN-LAKR2BL, RED B2 LED(AC), GL
H5550011470	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKR2BLM	RED B2 LED(AC)	GL	S2SRN-LAKR2BLM, RED B2 LED(AC), GL
H5550011473	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKRABL	RED AB LED(AC)	GL	S2SRN-LAKRABL, RED AB LED(AC), GL
H5550011474	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKRABLM	RED AB LED(AC)	GL	S2SRN-LAKRABLM, RED AB LED(AC), GL
H5550011475	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKY	YELLOW (HEAD)	GL	S2SRN-LAKY, YELLOW (HEAD), GL
H5550011476	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKY2AD	YELLOW A2 LED(DC)	GL	S2SRN-LAKY2AD, YELLOW A2 LED(DC), GL
H5550011477	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKY2ADM	YELLOW A2 LED(DC)	GL	S2SRN-LAKY2ADM, YELLOW A2 LED(DC), GL
H5550011478	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKY2AL	YELLOW A2 LED(AC)	GL	S2SRN-LAKY2AL, YELLOW A2 LED(AC), GL
H5550011479	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKY2ALM	YELLOW A2 LED(AC)	GL	S2SRN-LAKY2ALM, YELLOW A2 LED(AC), GL
H5550011480	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKY2BD	YELLOW B2 LED(DC)	GL	S2SRN-LAKY2BD, YELLOW B2 LED(DC), GL
H5550011481	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKY2BDM	YELLOW B2 LED(DC)	GL	S2SRN-LAKY2BDM, YELLOW B2 LED(DC), GL
H5550011482	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKY2BL	YELLOW B2 LED(AC)	GL	S2SRN-LAKY2BL, YELLOW B2 LED(AC), GL
H5550011483	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKY2BLM	YELLOW B2 LED(AC)	GL	S2SRN-LAKY2BLM, YELLOW B2 LED(AC), GL
H5550011484	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKYABD	YELLOW AB LED(DC)	GL	S2SRN-LAKYABD, YELLOW AB LED(DC), GL
H5550011485	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKYABDM	YELLOW AB LED(DC)	GL	S2SRN-LAKYABDM, YELLOW AB LED(DC), GL

H5550011486	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKYABL	YELLOW AB LED(AC)	GL	S2SRN-LAKYABL, YELLOW AB LED(AC), GL
H5550011487	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKYABLM	YELLOW AB LED(AC)	GL	S2SRN-LAKYABLM, YELLOW AB LED(AC), GL
H5550005758	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAY		GL	S2SRN-LAY, , GL
H5550006256	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAY2AD	YELLOW A2 DC	GL	S2SRN-LAY2AD, YELLOW A2 DC, GL
H5550006257	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAY2ADM	YELLOW A2 DC	GL	S2SRN-LAY2ADM, YELLOW A2 DC, GL
H5550006768	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAY2AL	YELLOW A2 AC	GL	S2SRN-LAY2AL, YELLOW A2 AC, GL
H5550006769	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAY2ALM	YELLOW A2 AC	GL	S2SRN-LAY2ALM, YELLOW A2 AC, GL
H5550006304	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAY2BD	YELLOW B2 DC	GL	S2SRN-LAY2BD, YELLOW B2 DC, GL
H5550006305	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAY2BDM	YELLOW B2 DC	GL	S2SRN-LAY2BDM, YELLOW B2 DC, GL
H5550006816	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAY2BL	YELLOW B2 AC	GL	S2SRN-LAY2BL, YELLOW B2 AC, GL
H5550006817	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAY2BLM	YELLOW B2 AC	GL	S2SRN-LAY2BLM, YELLOW B2 AC, GL
H5550006336	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAYABD	YELLOW A1 B1 DC	GL	S2SRN-LAYABD, YELLOW A1 B1 DC, GL
H5550006337	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAYABDM	YELLOW A1 B1 DC	GL	S2SRN-LAYABDM, YELLOW A1 B1 DC, GL
H5550006848	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAYABL	YELLOW A1 B1 AC	GL	S2SRN-LAYABL, YELLOW A1 B1 AC, GL
H5550006849	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAYABLM	YELLOW A1 B1 AC	GL	S2SRN-LAYABLM, YELLOW A1 B1 AC, GL
H5550005665	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBB		GL	S2SRN-LBB, , GL
H5550006002	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBB2AD	BLUE A2 DC	GL	S2SRN-LBB2AD, BLUE A2 DC, GL
H5550006003	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBB2ADM	BLUE A2 DC	GL	S2SRN-LBB2ADM, BLUE A2 DC, GL

H5550006514	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBB2AL	BLUE A2 AC	GL	S2SRN-LBB2AL, BLUE A2 AC, GL
H5550006515	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBB2ALM	BLUE A2 AC	GL	S2SRN-LBB2ALM, BLUE A2 AC, GL
H5550006050	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBB2BD	BLUE B2 DC	GL	S2SRN-LBB2BD, BLUE B2 DC, GL
H5550006051	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBB2BDM	BLUE B2 DC	GL	S2SRN-LBB2BDM, BLUE B2 DC, GL
H5550006562	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBB2BL	BLUE B2 AC	GL	S2SRN-LBB2BL, BLUE B2 AC, GL
H5550006563	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBB2BLM	BLUE B2 AC	GL	S2SRN-LBB2BLM, BLUE B2 AC, GL
H5550006082	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBBABD	BLUE A1 B1 DC	GL	S2SRN-LBBABD, BLUE A1 B1 DC, GL
H5550006083	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBBABDM	BLUE A1 B1 DC	GL	S2SRN-LBBABDM, BLUE A1 B1 DC, GL
H5550006594	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBBABL	BLUE A1 B1 AC	GL	S2SRN-LBBABL, BLUE A1 B1 AC, GL
H5550006595	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBBABLM	BLUE A1 B1 AC	GL	S2SRN-LBBABLM, BLUE A1 B1 AC, GL
H5550005713	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBG		GL	S2SRN-LBG, , GL
H5550006130	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBG2AD	GREEN A2 DC	GL	S2SRN-LBG2AD, GREEN A2 DC, GL
H5550006131	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBG2ADM	GREEN A2 DC	GL	S2SRN-LBG2ADM, GREEN A2 DC, GL
H5550006642	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBG2AL	GREEN A2 AC	GL	S2SRN-LBG2AL, GREEN A2 AC, GL
H5550006643	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBG2ALM	GREEN A2 AC	GL	S2SRN-LBG2ALM, GREEN A2 AC, GL
H5550006178	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBG2BD	GREEN B2 DC	GL	S2SRN-LBG2BD, GREEN B2 DC, GL
H5550006179	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBG2BDM	GREEN B2 DC	GL	S2SRN-LBG2BDM, GREEN B2 DC, GL

H5550006690	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBG2BL	GREEN B2 AC	GL	S2SRN-LBG2BL, GREEN B2 AC, GL
H5550006691	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBG2BLM	GREEN B2 AC	GL	S2SRN-LBG2BLM, GREEN B2 AC, GL
H5550006210	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBGABD	GREEN A1 B1 DC	GL	S2SRN-LBGABD, GREEN A1 B1 DC, GL
H5550006211	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBGABDM	GREEN A1 B1 DC	GL	S2SRN-LBGABDM, GREEN A1 B1 DC, GL
H5550006722	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBGABL	GREEN A1 B1 AC	GL	S2SRN-LBGABL, GREEN A1 B1 AC, GL
H5550006723	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBGABLM	GREEN A1 B1 AC	GL	S2SRN-LBGABLM, GREEN A1 B1 AC, GL
H5550011488	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKB	BLUE (HEAD)	GL	S2SRN-LBKB, BLUE (HEAD), GL
H5550011489	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKB2AD	BLUE A2 LED(DC)	GL	S2SRN-LBKB2AD, BLUE A2 LED(DC), GL
H5550011490	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKB2ADM	BLUE A2 LED(DC)	GL	S2SRN-LBKB2ADM, BLUE A2 LED(DC), GL
H5550011491	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKB2AL	BLUE A2 LED(AC)	GL	S2SRN-LBKB2AL, BLUE A2 LED(AC), GL
H5550011492	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKB2ALM	BLUE A2 LED(AC)	GL	S2SRN-LBKB2ALM, BLUE A2 LED(AC), GL
H5550011493	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKB2BD	BLUE B2 LED(DC)	GL	S2SRN-LBKB2BD, BLUE B2 LED(DC), GL
H5550011494	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKB2BDM	BLUE B2 LED(DC)	GL	S2SRN-LBKB2BDM, BLUE B2 LED(DC), GL
H5550011495	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKB2BL	BLUE B2 LED(AC)	GL	S2SRN-LBKB2BL, BLUE B2 LED(AC), GL
H5550011496	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKB2BLM	BLUE B2 LED(AC)	GL	S2SRN-LBKB2BLM, BLUE B2 LED(AC), GL
H5550011497	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKBABD	BLUE AB LED(DC)	GL	S2SRN-LBKBABD, BLUE AB LED(DC), GL
H5550011498	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKBABDM	BLUE AB LED(DC)	GL	S2SRN-LBKBABDM, BLUE AB LED(DC), GL
H5550011499	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKBABL	BLUE AB LED(AC)	GL	S2SRN-LBKBABL, BLUE AB LED(AC), GL

H5550011500	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKBABLM	BLUE AB LED(AC)	GL	S2SRN-LBKBABLM, BLUE AB LED(AC), GL
H5550011501	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKG	GREEN (HEAD)	GL	S2SRN-LBKG, GREEN (HEAD), GL
H5550011502	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKG2AD	GREEN A2 LED(DC)	GL	S2SRN-LBKG2AD, GREEN A2 LED(DC), GL
H5550011503	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKG2ADM	GREEN A2 LED(DC)	GL	S2SRN-LBKG2ADM, GREEN A2 LED(DC), GL
H5550011504	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKG2AL	GREEN A2 LED(AC)	GL	S2SRN-LBKG2AL, GREEN A2 LED(AC), GL
H5550011505	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKG2ALM	GREEN A2 LED(AC)	GL	S2SRN-LBKG2ALM, GREEN A2 LED(AC), GL
H5550011506	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKG2BD	GREEN B2 LED(DC)	GL	S2SRN-LBKG2BD, GREEN B2 LED(DC), GL
H5550011507	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKG2BDM	GREEN B2 LED(DC)	GL	S2SRN-LBKG2BDM, GREEN B2 LED(DC), GL
H5550011508	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKG2BL	GREEN B2 LED(AC)	GL	S2SRN-LBKG2BL, GREEN B2 LED(AC), GL
H5550011509	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKG2BLM	GREEN B2 LED(AC)	GL	S2SRN-LBKG2BLM, GREEN B2 LED(AC), GL
H5550011510	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKGABD	GREEN AB LED(DC)	GL	S2SRN-LBKGABD, GREEN AB LED(DC), GL
H5550011511	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKGABDM	GREEN AB LED(DC)	GL	S2SRN-LBKGABDM, GREEN AB LED(DC), GL
H5550011512	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKGABL	GREEN AB LED(AC)	GL	S2SRN-LBKGABL, GREEN AB LED(AC), GL
H5550011513	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKGABLM	GREEN AB LED(AC)	GL	S2SRN-LBKGABLM, GREEN AB LED(AC), GL
H5550011514	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKR	RED (HEAD)	GL	S2SRN-LBKR, RED (HEAD), GL
H5550011521	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKR2BL	RED B2 LED(AC)	GL	S2SRN-LBKR2BL, RED B2 LED(AC), GL
H5550011522	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKR2BLM	RED B2 LED(AC)	GL	S2SRN-LBKR2BLM, RED B2 LED(AC), GL

H5550011525	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKRABL	RED AB LED(AC)	GL	S2SRN-LBKRABL, RED AB LED(AC), GL
H5550011526	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKRABLM	RED AB LED(AC)	GL	S2SRN-LBKRABLM, RED AB LED(AC), GL
H5550011527	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKY	YELLOW (HEAD)	GL	S2SRN-LBKY, YELLOW (HEAD), GL
H5550011528	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKY2AD	YELLOW A2 LED(DC)	GL	S2SRN-LBKY2AD, YELLOW A2 LED(DC), GL
H5550011529	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKY2ADM	YELLOW A2 LED(DC)	GL	S2SRN-LBKY2ADM, YELLOW A2 LED(DC), GL
H5550011530	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKY2AL	YELLOW A2 LED(AC)	GL	S2SRN-LBKY2AL, YELLOW A2 LED(AC), GL
H5550011531	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKY2ALM	YELLOW A2 LED(AC)	GL	S2SRN-LBKY2ALM, YELLOW A2 LED(AC), GL
H5550011532	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKY2BD	YELLOW B2 LED(DC)	GL	S2SRN-LBKY2BD, YELLOW B2 LED(DC), GL
H5550011533	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKY2BDM	YELLOW B2 LED(DC)	GL	S2SRN-LBKY2BDM, YELLOW B2 LED(DC), GL
H5550011534	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKY2BL	YELLOW B2 LED(AC)	GL	S2SRN-LBKY2BL, YELLOW B2 LED(AC), GL
H5550011535	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKY2BLM	YELLOW B2 LED(AC)	GL	S2SRN-LBKY2BLM, YELLOW B2 LED(AC), GL
H5550011536	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKYABD	YELLOW AB LED(DC)	GL	S2SRN-LBKYABD, YELLOW AB LED(DC), GL
H5550011537	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKYABDM	YELLOW AB LED(DC)	GL	S2SRN-LBKYABDM, YELLOW AB LED(DC), GL
H5550011538	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKYABL	YELLOW AB LED(AC)	GL	S2SRN-LBKYABL, YELLOW AB LED(AC), GL
H5550011539	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKYABLM	YELLOW AB LED(AC)	GL	S2SRN-LBKYABLM, YELLOW AB LED(AC), GL
H5550005761	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBY		GL	S2SRN-LBY, , GL
H5550006258	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBY2AD	YELLOW A2 DC	GL	S2SRN-LBY2AD, YELLOW A2 DC, GL

H5550006259	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBY2ADM	YELLOW A2 DC	GL	S2SRN-LBY2ADM, YELLOW A2 DC, GL
H5550006770	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBY2AL	YELLOW A2 AC	GL	S2SRN-LBY2AL, YELLOW A2 AC, GL
H5550006771	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBY2ALM	YELLOW A2 AC	GL	S2SRN-LBY2ALM, YELLOW A2 AC, GL
H5550006306	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBY2BD	YELLOW B2 DC	GL	S2SRN-LBY2BD, YELLOW B2 DC, GL
H5550006307	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBY2BDM	YELLOW B2 DC	GL	S2SRN-LBY2BDM, YELLOW B2 DC, GL
H5550006818	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBY2BL	YELLOW B2 AC	GL	S2SRN-LBY2BL, YELLOW B2 AC, GL
H5550006819	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBY2BLM	YELLOW B2 AC	GL	S2SRN-LBY2BLM, YELLOW B2 AC, GL
H5550006338	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBYABD	YELLOW A1 B1 DC	GL	S2SRN-LBYABD, YELLOW A1 B1 DC, GL
H5550006339	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBYABDM	YELLOW A1 B1 DC	GL	S2SRN-LBYABDM, YELLOW A1 B1 DC, GL
H5550006850	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBYABL	YELLOW A1 B1 AC	GL	S2SRN-LBYABL, YELLOW A1 B1 AC, GL
H5550006851	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBYABLM	YELLOW A1 B1 AC	GL	S2SRN-LBYABLM, YELLOW A1 B1 AC, GL
H5550005668	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCB		GL	S2SRN-LCB, , GL
H5550006004	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCB2AD	BLUE A2 DC	GL	S2SRN-LCB2AD, BLUE A2 DC, GL
H5550006005	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCB2ADM	BLUE A2 DC	GL	S2SRN-LCB2ADM, BLUE A2 DC, GL
H5550006516	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCB2AL	BLUE A2 AC	GL	S2SRN-LCB2AL, BLUE A2 AC, GL
H5550006517	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCB2ALM	BLUE A2 AC	GL	S2SRN-LCB2ALM, BLUE A2 AC, GL
H5550006052	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCB2BD	BLUE B2 DC	GL	S2SRN-LCB2BD, BLUE B2 DC, GL

H5550006053	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCB2BDM	BLUE B2 DC	GL	S2SRN-LCB2BDM, BLUE B2 DC, GL	
H5550006564	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCB2BL	BLUE B2 AC	GL	S2SRN-LCB2BL, BLUE B2 AC, GL	
H5550006565	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCB2BLM	BLUE B2 AC	GL	S2SRN-LCB2BLM, BLUE B2 AC, GL	
H5550006084	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCBABD	BLUE A1 B1 DC	GL	S2SRN-LCBABD, BLUE A1 B1 DC, GL	
H5550006085	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCBABDM	BLUE A1 B1 DC	GL	S2SRN-LCBABDM, BLUE A1 B1 DC, GL	
H5550006596	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCBABL	BLUE A1 B1 AC	GL	S2SRN-LCBABL, BLUE A1 B1 AC, GL	
H5550006597	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCBABLM	BLUE A1 B1 AC	GL	S2SRN-LCBABLM, BLUE A1 B1 AC, GL	
H5550005716	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCG		GL	S2SRN-LCG, , GL	
H5550006132	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCG2AD	GREEN A2 DC	GL	S2SRN-LCG2AD, GREEN A2 DC, GL	
H5550006133	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCG2ADM	GREEN A2 DC	GL	S2SRN-LCG2ADM, GREEN A2 DC, GL	
H5550006644	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCG2AL	GREEN A2 AC	GL	S2SRN-LCG2AL, GREEN A2 AC, GL	
H5550006645	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCG2ALM	GREEN A2 AC	GL	S2SRN-LCG2ALM, GREEN A2 AC, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, С подсветкой, 22/25, 3-позиционный, с самовозвратом, влево 60, с фиксацией, вправо 90, Зеленый, 2 нормально открытых, Модульный тип, СИД 110-220В~ 50/60Hz
H5550006180	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCG2BD	GREEN B2 DC	GL	S2SRN-LCG2BD, GREEN B2 DC, GL	
H5550006181	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCG2BDM	GREEN B2 DC	GL	S2SRN-LCG2BDM, GREEN B2 DC, GL	
H5550006692	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCG2BL	GREEN B2 AC	GL	S2SRN-LCG2BL, GREEN B2 AC, GL	
H5550006693	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCG2BLM	GREEN B2 AC	GL	S2SRN-LCG2BLM, GREEN B2 AC, GL	
H5550006212	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCGABD	GREEN A1 B1 DC	GL	S2SRN-LCGABD, GREEN A1 B1 DC, GL	

H5550006213	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCGABDM	GREEN A1 B1 DC	GL	S2SRN-LCGABDM, GREEN A1 B1 DC, GL
H5550006724	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCGABL	GREEN A1 B1 AC	GL	S2SRN-LCGABL, GREEN A1 B1 AC, GL
H5550006725	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCGABLM	GREEN A1 B1 AC	GL	S2SRN-LCGABLM, GREEN A1 B1 AC, GL
H5550011540	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKB	BLUE (HEAD)	GL	S2SRN-LCKB, BLUE (HEAD), GL
H5550011541	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKB2AD	BLUE A2 LED(DC)	GL	S2SRN-LCKB2AD, BLUE A2 LED(DC), GL
H5550011542	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKB2ADM	BLUE A2 LED(DC)	GL	S2SRN-LCKB2ADM, BLUE A2 LED(DC), GL
H5550011543	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKB2AL	BLUE A2 LED(AC)	GL	S2SRN-LCKB2AL, BLUE A2 LED(AC), GL
H5550011544	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKB2ALM	BLUE A2 LED(AC)	GL	S2SRN-LCKB2ALM, BLUE A2 LED(AC), GL
H5550011545	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKB2BD	BLUE B2 LED(DC)	GL	S2SRN-LCKB2BD, BLUE B2 LED(DC), GL
H5550011546	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKB2BDM	BLUE B2 LED(DC)	GL	S2SRN-LCKB2BDM, BLUE B2 LED(DC), GL
H5550011547	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKB2BL	BLUE B2 LED(AC)	GL	S2SRN-LCKB2BL, BLUE B2 LED(AC), GL
H5550011548	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKB2BLM	BLUE B2 LED(AC)	GL	S2SRN-LCKB2BLM, BLUE B2 LED(AC), GL
H5550011549	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKBABD	BLUE AB LED(DC)	GL	S2SRN-LCKBABD, BLUE AB LED(DC), GL
H5550011550	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKBABDM	BLUE AB LED(DC)	GL	S2SRN-LCKBABDM, BLUE AB LED(DC), GL
H5550011551	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKBABL	BLUE AB LED(AC)	GL	S2SRN-LCKBABL, BLUE AB LED(AC), GL
H5550011552	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKBABLM	BLUE AB LED(AC)	GL	S2SRN-LCKBABLM, BLUE AB LED(AC), GL
H5550011553	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKG	GREEN (HEAD)	GL	S2SRN-LCKG, GREEN (HEAD), GL
H5550011554	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKG2AD	GREEN A2 LED(DC)	GL	S2SRN-LCKG2AD, GREEN A2 LED(DC), GL

H5550011555	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKG2ADM	GREEN A2 LED(DC)	GL	S2SRN-LCKG2ADM, GREEN A2 LED(DC), GL
H5550011556	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKG2AL	GREEN A2 LED(AC)	GL	S2SRN-LCKG2AL, GREEN A2 LED(AC), GL
H5550011557	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKG2ALM	GREEN A2 LED(AC)	GL	S2SRN-LCKG2ALM, GREEN A2 LED(AC), GL
H5550011558	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKG2BD	GREEN B2 LED(DC)	GL	S2SRN-LCKG2BD, GREEN B2 LED(DC), GL
H5550011559	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKG2BDM	GREEN B2 LED(DC)	GL	S2SRN-LCKG2BDM, GREEN B2 LED(DC), GL
H5550011560	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKG2BL	GREEN B2 LED(AC)	GL	S2SRN-LCKG2BL, GREEN B2 LED(AC), GL
H5550011561	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKG2BLM	GREEN B2 LED(AC)	GL	S2SRN-LCKG2BLM, GREEN B2 LED(AC), GL
H5550011562	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKGABD	GREEN AB LED(DC)	GL	S2SRN-LCKGABD, GREEN AB LED(DC), GL
H5550011563	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKGABDM	GREEN AB LED(DC)	GL	S2SRN-LCKGABDM, GREEN AB LED(DC), GL
H5550011564	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKGABL	GREEN AB LED(AC)	GL	S2SRN-LCKGABL, GREEN AB LED(AC), GL
H5550011565	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKGABLM	GREEN AB LED(AC)	GL	S2SRN-LCKGABLM, GREEN AB LED(AC), GL
H5550011566	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKR	RED (HEAD)	GL	S2SRN-LCKR, RED (HEAD), GL
H5550011573	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKR2BL	RED B2 LED(AC)	GL	S2SRN-LCKR2BL, RED B2 LED(AC), GL
H5550011574	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKR2BLM	RED B2 LED(AC)	GL	S2SRN-LCKR2BLM, RED B2 LED(AC), GL
H5550011577	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKRABL	RED AB LED(AC)	GL	S2SRN-LCKRABL, RED AB LED(AC), GL
H5550011578	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKRABLM	RED AB LED(AC)	GL	S2SRN-LCKRABLM, RED AB LED(AC), GL
H5550011579	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKY	YELLOW (HEAD)	GL	S2SRN-LCKY, YELLOW (HEAD), GL

H5550011580	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKY2AD	YELLOW A2 LED(DC)	GL	S2SRN-LCKY2AD, YELLOW A2 LED(DC), GL
H5550011581	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKY2ADM	YELLOW A2 LED(DC)	GL	S2SRN-LCKY2ADM, YELLOW A2 LED(DC), GL
H5550011582	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKY2AL	YELLOW A2 LED(AC)	GL	S2SRN-LCKY2AL, YELLOW A2 LED(AC), GL
H5550011583	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKY2ALM	YELLOW A2 LED(AC)	GL	S2SRN-LCKY2ALM, YELLOW A2 LED(AC), GL
H5550011584	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKY2BD	YELLOW B2 LED(DC)	GL	S2SRN-LCKY2BD, YELLOW B2 LED(DC), GL
H5550011585	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKY2BDM	YELLOW B2 LED(DC)	GL	S2SRN-LCKY2BDM, YELLOW B2 LED(DC), GL
H5550011586	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKY2BL	YELLOW B2 LED(AC)	GL	S2SRN-LCKY2BL, YELLOW B2 LED(AC), GL
H5550011587	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKY2BLM	YELLOW B2 LED(AC)	GL	S2SRN-LCKY2BLM, YELLOW B2 LED(AC), GL
H5550011588	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKYABD	YELLOW AB LED(DC)	GL	S2SRN-LCKYABD, YELLOW AB LED(DC), GL
H5550011589	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKYABDM	YELLOW AB LED(DC)	GL	S2SRN-LCKYABDM, YELLOW AB LED(DC), GL
H5550011590	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKYABL	YELLOW AB LED(AC)	GL	S2SRN-LCKYABL, YELLOW AB LED(AC), GL
H5550011591	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKYABLM	YELLOW AB LED(AC)	GL	S2SRN-LCKYABLM, YELLOW AB LED(AC), GL
H5550005764	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCY		GL	S2SRN-LCY, , GL
H5550006260	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCY2AD	YELLOW A2 DC	GL	S2SRN-LCY2AD, YELLOW A2 DC, GL
H5550006261	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCY2ADM	YELLOW A2 DC	GL	S2SRN-LCY2ADM, YELLOW A2 DC, GL
H5550006772	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCY2AL	YELLOW A2 AC	GL	S2SRN-LCY2AL, YELLOW A2 AC, GL

H5550006773	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCY2ALM	YELLOW A2 AC	GL	S2SRN-LCY2ALM, YELLOW A2 AC, GL
H5550006308	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCY2BD	YELLOW B2 DC	GL	S2SRN-LCY2BD, YELLOW B2 DC, GL
H5550006309	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCY2BDM	YELLOW B2 DC	GL	S2SRN-LCY2BDM, YELLOW B2 DC, GL
H5550006820	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCY2BL	YELLOW B2 AC	GL	S2SRN-LCY2BL, YELLOW B2 AC, GL
H5550006821	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCY2BLM	YELLOW B2 AC	GL	S2SRN-LCY2BLM, YELLOW B2 AC, GL
H5550006340	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCYABD	YELLOW A1 B1 DC	GL	S2SRN-LCYABD, YELLOW A1 B1 DC, GL
H5550006341	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCYABDM	YELLOW A1 B1 DC	GL	S2SRN-LCYABDM, YELLOW A1 B1 DC, GL
H5550006852	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCYABL	YELLOW A1 B1 AC	GL	S2SRN-LCYABL, YELLOW A1 B1 AC, GL
H5550006853	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCYABLM	YELLOW A1 B1 AC	GL	S2SRN-LCYABLM, YELLOW A1 B1 AC, GL
H5550005671	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDB		GL	S2SRN-LDB, , GL
H5550006006	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDB2AD	BLUE A2 DC	GL	S2SRN-LDB2AD, BLUE A2 DC, GL
H5550006007	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDB2ADM	BLUE A2 DC	GL	S2SRN-LDB2ADM, BLUE A2 DC, GL
H5550006518	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDB2AL	BLUE A2 AC	GL	S2SRN-LDB2AL, BLUE A2 AC, GL
H5550006519	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDB2ALM	BLUE A2 AC	GL	S2SRN-LDB2ALM, BLUE A2 AC, GL
H5550006054	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDB2BD	BLUE B2 DC	GL	S2SRN-LDB2BD, BLUE B2 DC, GL
H5550006055	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDB2BDM	BLUE B2 DC	GL	S2SRN-LDB2BDM, BLUE B2 DC, GL

H5550006566	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDB2BL	BLUE B2 AC	GL	S2SRN-LDB2BL, BLUE B2 AC, GL
H5550006567	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDB2BLM	BLUE B2 AC	GL	S2SRN-LDB2BLM, BLUE B2 AC, GL
H5550006086	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDBABD	BLUE A1 B1 DC	GL	S2SRN-LDBABD, BLUE A1 B1 DC, GL
H5550006087	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDBABDM	BLUE A1 B1 DC	GL	S2SRN-LDBABDM, BLUE A1 B1 DC, GL
H5550006598	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDBABL	BLUE A1 B1 AC	GL	S2SRN-LDBABL, BLUE A1 B1 AC, GL
H5550006599	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDBABL M	BLUE A1 B1 AC	GL	S2SRN-LDBABL M, BLUE A1 B1 AC, GL
H5550005719	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDG		GL	S2SRN-LDG, , GL
H5550006134	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDG2AD	GREEN A2 DC	GL	S2SRN-LDG2AD, GREEN A2 DC, GL
H5550006135	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDG2ADM	GREEN A2 DC	GL	S2SRN-LDG2ADM, GREEN A2 DC, GL
H5550006646	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDG2AL	GREEN A2 AC	GL	S2SRN-LDG2AL, GREEN A2 AC, GL
H5550006647	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDG2ALM	GREEN A2 AC	GL	S2SRN-LDG2ALM, GREEN A2 AC, GL
H5550006182	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDG2BD	GREEN B2 DC	GL	S2SRN-LDG2BD, GREEN B2 DC, GL
H5550006183	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDG2BDM	GREEN B2 DC	GL	S2SRN-LDG2BDM, GREEN B2 DC, GL
H5550006694	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDG2BL	GREEN B2 AC	GL	S2SRN-LDG2BL, GREEN B2 AC, GL
H5550006695	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDG2BLM	GREEN B2 AC	GL	S2SRN-LDG2BLM, GREEN B2 AC, GL
H5550006214	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDGABD	GREEN A1 B1 DC	GL	S2SRN-LDGABD, GREEN A1 B1 DC, GL
H5550006215	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDGABDM	GREEN A1 B1 DC	GL	S2SRN-LDGABDM, GREEN A1 B1 DC, GL
H5550006726	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDGABL	GREEN A1 B1 AC	GL	S2SRN-LDGABL, GREEN A1 B1 AC, GL

H5550006727	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDGABLM	GREEN A1 B1 AC	GL	S2SRN-LDGABLM, GREEN A1 B1 AC, GL
H5550011592	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKB	BLUE (HEAD)	GL	S2SRN-LDKB, BLUE (HEAD), GL
H5550011593	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKB2AD	BLUE A2 LED(DC)	GL	S2SRN-LDKB2AD, BLUE A2 LED(DC), GL
H5550011594	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKB2ADM	BLUE A2 LED(DC)	GL	S2SRN-LDKB2ADM, BLUE A2 LED(DC), GL
H5550011595	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKB2AL	BLUE A2 LED(AC)	GL	S2SRN-LDKB2AL, BLUE A2 LED(AC), GL
H5550011596	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKB2ALM	BLUE A2 LED(AC)	GL	S2SRN-LDKB2ALM, BLUE A2 LED(AC), GL
H5550011597	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKB2BD	BLUE B2 LED(DC)	GL	S2SRN-LDKB2BD, BLUE B2 LED(DC), GL
H5550011598	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKB2BDM	BLUE B2 LED(DC)	GL	S2SRN-LDKB2BDM, BLUE B2 LED(DC), GL
H5550011599	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKB2BL	BLUE B2 LED(AC)	GL	S2SRN-LDKB2BL, BLUE B2 LED(AC), GL
H5550011600	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKB2BLM	BLUE B2 LED(AC)	GL	S2SRN-LDKB2BLM, BLUE B2 LED(AC), GL
H5550011601	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKBABD	BLUE AB LED(DC)	GL	S2SRN-LDKBABD, BLUE AB LED(DC), GL
H5550011602	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKBABDM	BLUE AB LED(DC)	GL	S2SRN-LDKBABDM, BLUE AB LED(DC), GL
H5550011603	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKBABL	BLUE AB LED(AC)	GL	S2SRN-LDKBABL, BLUE AB LED(AC), GL
H5550011604	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKBABL M	BLUE AB LED(AC)	GL	S2SRN-LDKBABL M, BLUE AB LED(AC), GL
H5550011605	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKG	GREEN (HEAD)	GL	S2SRN-LDKG, GREEN (HEAD), GL
H5550011606	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKG2AD	GREEN A2 LED(DC)	GL	S2SRN-LDKG2AD, GREEN A2 LED(DC), GL
H5550011607	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKG2ADM	GREEN A2 LED(DC)	GL	S2SRN-LDKG2ADM, GREEN A2 LED(DC), GL
H5550011608	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKG2AL	GREEN A2 LED(AC)	GL	S2SRN-LDKG2AL, GREEN A2 LED(AC), GL
H5550011609	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKG2ALM	GREEN A2 LED(AC)	GL	S2SRN-LDKG2ALM, GREEN A2 LED(AC), GL

H5550011610	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKG2BD	GREEN B2 LED(DC)	GL	S2SRN-LDKG2BD, GREEN B2 LED(DC), GL
H5550011611	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKG2BDM	GREEN B2 LED(DC)	GL	S2SRN-LDKG2BDM, GREEN B2 LED(DC), GL
H5550011612	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKG2BL	GREEN B2 LED(AC)	GL	S2SRN-LDKG2BL, GREEN B2 LED(AC), GL
H5550011613	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKG2BLM	GREEN B2 LED(AC)	GL	S2SRN-LDKG2BLM, GREEN B2 LED(AC), GL
H5550011614	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKGABD	GREEN AB LED(DC)	GL	S2SRN-LDKGABD, GREEN AB LED(DC), GL
H5550011615	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKGABDM	GREEN AB LED(DC)	GL	S2SRN-LDKGABDM, GREEN AB LED(DC), GL
H5550011616	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKGABL	GREEN AB LED(AC)	GL	S2SRN-LDKGABL, GREEN AB LED(AC), GL
H5550011617	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKGABLM	GREEN AB LED(AC)	GL	S2SRN-LDKGABLM, GREEN AB LED(AC), GL
H5550011618	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKR	RED (HEAD)	GL	S2SRN-LDKR, RED (HEAD), GL
H5550011625	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKR2BL	RED B2 LED(AC)	GL	S2SRN-LDKR2BL, RED B2 LED(AC), GL
H5550011626	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKR2BLM	RED B2 LED(AC)	GL	S2SRN-LDKR2BLM, RED B2 LED(AC), GL
H5550011629	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKRABL	RED AB LED(AC)	GL	S2SRN-LDKRABL, RED AB LED(AC), GL
H5550011630	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKRABLM	RED AB LED(AC)	GL	S2SRN-LDKRABLM, RED AB LED(AC), GL
H5550011631	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKY	YELLOW (HEAD)	GL	S2SRN-LDKY, YELLOW (HEAD), GL
H5550011632	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKY2AD	YELLOW A2 LED(DC)	GL	S2SRN-LDKY2AD, YELLOW A2 LED(DC), GL
H5550011633	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKY2ADM	YELLOW A2 LED(DC)	GL	S2SRN-LDKY2ADM, YELLOW A2 LED(DC), GL
H5550011634	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKY2AL	YELLOW A2 LED(AC)	GL	S2SRN-LDKY2AL, YELLOW A2 LED(AC), GL

H5550011635	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKY2ALM	YELLOW A2 LED(AC)	GL	S2SRN-LDKY2ALM, YELLOW A2 LED(AC), GL
H5550011636	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKY2BD	YELLOW B2 LED(DC)	GL	S2SRN-LDKY2BD, YELLOW B2 LED(DC), GL
H5550011637	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKY2BDM	YELLOW B2 LED(DC)	GL	S2SRN-LDKY2BDM, YELLOW B2 LED(DC), GL
H5550011638	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKY2BL	YELLOW B2 LED(AC)	GL	S2SRN-LDKY2BL, YELLOW B2 LED(AC), GL
H5550011639	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKY2BLM	YELLOW B2 LED(AC)	GL	S2SRN-LDKY2BLM, YELLOW B2 LED(AC), GL
H5550011640	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKYABD	YELLOW AB LED(DC)	GL	S2SRN-LDKYABD, YELLOW AB LED(DC), GL
H5550011641	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKYABDM	YELLOW AB LED(DC)	GL	S2SRN-LDKYABDM, YELLOW AB LED(DC), GL
H5550011642	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKYABL	YELLOW AB LED(AC)	GL	S2SRN-LDKYABL, YELLOW AB LED(AC), GL
H5550011643	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKYABLM	YELLOW AB LED(AC)	GL	S2SRN-LDKYABLM, YELLOW AB LED(AC), GL
H5550005767	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDY		GL	S2SRN-LDY, , GL
H5550006262	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDY2AD	YELLOW A2 DC	GL	S2SRN-LDY2AD, YELLOW A2 DC, GL
H5550006263	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDY2ADM	YELLOW A2 DC	GL	S2SRN-LDY2ADM, YELLOW A2 DC, GL
H5550006774	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDY2AL	YELLOW A2 AC	GL	S2SRN-LDY2AL, YELLOW A2 AC, GL
H5550006775	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDY2ALM	YELLOW A2 AC	GL	S2SRN-LDY2ALM, YELLOW A2 AC, GL
H5550006310	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDY2BD	YELLOW B2 DC	GL	S2SRN-LDY2BD, YELLOW B2 DC, GL
H5550006311	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDY2BDM	YELLOW B2 DC	GL	S2SRN-LDY2BDM, YELLOW B2 DC, GL
H5550006822	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDY2BL	YELLOW B2 AC	GL	S2SRN-LDY2BL, YELLOW B2 AC, GL

H5550006823	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDY2BLM	YELLOW B2 AC	GL	S2SRN-LDY2BLM, YELLOW B2 AC, GL	
H5550006342	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDYABD	YELLOW A1 B1 DC	GL	S2SRN-LDYABD, YELLOW A1 B1 DC, GL	
H5550006343	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDYABDM	YELLOW A1 B1 DC	GL	S2SRN-LDYABDM, YELLOW A1 B1 DC, GL	
H5550006854	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDYABL	YELLOW A1 B1 AC	GL	S2SRN-LDYABL, YELLOW A1 B1 AC, GL	
H5550006855	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDYABLM	YELLOW A1 B1 AC	GL	S2SRN-LDYABLM, YELLOW A1 B1 AC, GL	
H5550005696	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AW2A	WHITE A2	GL	S2SRN-S1AW2A, WHITE A2, GL	
H5550005697	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AW2AM	WHITE A2	GL	S2SRN-S1AW2AM, WHITE A2, GL	
H5550005768	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AW2B	WHITE B2	GL	S2SRN-S1AW2B, WHITE B2, GL	
H5550005769	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AW2BM	WHITE B2	GL	S2SRN-S1AW2BM, WHITE B2, GL	
H5550005672	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AWA	WHITE A1	GL	S2SRN-S1AWA, WHITE A1, GL	
H5550005800	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AWAB	WHITE A1 B1	GL	S2SRN-S1AWAB, WHITE A1 B1, GL	
H5550005801	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AWABM	WHITE A1 B1	GL	S2SRN-S1AWABM, WHITE A1 B1, GL	
H5550005673	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AWAM	WHITE A1	GL	S2SRN-S1AWAM, WHITE A1, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, 22/25, 2-позиционный, с самовозвратом, вправо 60, Белый, 1 нормально открытый, Модульный тип, СИД 110-220В~ 50/60Hz
H5550005744	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AWB	WHITE B1	GL	S2SRN-S1AWB, WHITE B1, GL	
H5550005745	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AWBM	WHITE B1	GL	S2SRN-S1AWBM, WHITE B1, GL	
H5550005699	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BW2A	WHITE A2	GL	S2SRN-S1BW2A, WHITE A2, GL	
H5550005700	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BW2AM	WHITE A2	GL	S2SRN-S1BW2AM, WHITE A2, GL	

H5550005770	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BW2B	WHITE B2	GL	S2SRN-S1BW2B, WHITE B2, GL
H5550005771	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BW2BM	WHITE B2	GL	S2SRN-S1BW2BM, WHITE B2, GL
H5550005675	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BWA	WHITE A1	GL	S2SRN-S1BWA, WHITE A1, GL
H5550005802	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BWAB	WHITE A1 B1	GL	S2SRN-S1BWAB, WHITE A1 B1, GL
H5550005803	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BWABM	WHITE A1 B1	GL	S2SRN-S1BWABM, WHITE A1 B1, GL
H5550005676	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BWAM	WHITE A1	GL	S2SRN-S1BWAM, WHITE A1, GL
H5550005747	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BWB	WHITE B1	GL	S2SRN-S1BWB, WHITE B1, GL
H5550005748	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BWBm	WHITE B1	GL	S2SRN-S1BWBm, WHITE B1, GL
H5550011644	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1R	RED (HEAD)	GL	S2SRN-S1R, RED (HEAD), GL
H5550011655	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1W	WHITE (HEAD)	GL	S2SRN-S1W, WHITE (HEAD), GL
H5550011656	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1W2A	WHITE A2	GL	S2SRN-S1W2A, WHITE A2, GL
H5550011657	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1W2AM	WHITE A2	GL	S2SRN-S1W2AM, WHITE A2, GL
H5550011658	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1W2B	WHITE B2	GL	S2SRN-S1W2B, WHITE B2, GL
H5550011659	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1W2BM	WHITE B2	GL	S2SRN-S1W2BM, WHITE B2, GL
H5550011660	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1WA	WHITE A	GL	S2SRN-S1WA, WHITE A, GL
H5550011661	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1WAB	WHITE AB	GL	S2SRN-S1WAB, WHITE AB, GL
H5550011662	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1WABM	WHITE AB	GL	S2SRN-S1WABM, WHITE AB, GL
H5550011663	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1WAM	WHITE A	GL	S2SRN-S1WAM, WHITE A, GL

H5550011664	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1WB	WHITE B	GL	S2SRN-S1WB, WHITE B, GL
H5550011665	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1WBM	WHITE B	GL	S2SRN-S1WBM, WHITE B, GL
H5550005536	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AW		GL	S2SRN-S2AW, , GL
H5550005702	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AW2A	WHITE A2	GL	S2SRN-S2AW2A, WHITE A2, GL
H5550005703	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AW2AM	WHITE A2	GL	S2SRN-S2AW2AM, WHITE A2, GL
H5550005772	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AW2B	WHITE B2	GL	S2SRN-S2AW2B, WHITE B2, GL
H5550005773	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AW2BM	WHITE B2	GL	S2SRN-S2AW2BM, WHITE B2, GL
H5550005678	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AWA	WHITE A1	GL	S2SRN-S2AWA, WHITE A1, GL
H5550005804	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AWAB	WHITE A1 B1	GL	S2SRN-S2AWAB, WHITE A1 B1, GL
H5550005805	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AWABM	WHITE A1 B1	GL	S2SRN-S2AWABM, WHITE A1 B1, GL
H5550005679	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AWAM	WHITE A1	GL	S2SRN-S2AWAM, WHITE A1, GL
H5550005750	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AWB	WHITE B1	GL	S2SRN-S2AWB, WHITE B1, GL
H5550005751	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AWBM	WHITE B1	GL	S2SRN-S2AWBM, WHITE B1, GL
H5550005539	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BW		GL	S2SRN-S2BW, , GL

H5550005705	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BW2A	WHITE A2	GL	S2SRN-S2BW2A, WHITE A2, GL
H5550005706	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BW2AM	WHITE A2	GL	S2SRN-S2BW2AM, WHITE A2, GL
H5550005774	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BW2B	WHITE B2	GL	S2SRN-S2BW2B, WHITE B2, GL
H5550005775	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BW2BM	WHITE B2	GL	S2SRN-S2BW2BM, WHITE B2, GL
H5550005681	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BWA	WHITE A1	GL	S2SRN-S2BWA, WHITE A1, GL
H5550005806	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BWAB	WHITE A1 B1	GL	S2SRN-S2BWAB, WHITE A1 B1, GL
H5550005807	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BWABM	WHITE A1 B1	GL	S2SRN-S2BWABM, WHITE A1 B1, GL
H5550005682	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BWAM	WHITE A1	GL	S2SRN-S2BWAM, WHITE A1, GL
H5550005753	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BWB	WHITE B1	GL	S2SRN-S2BWB, WHITE B1, GL
H5550005754	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BWBM	WHITE B1	GL	S2SRN-S2BWBM, WHITE B1, GL
H5550011666	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2R	RED (HEAD)	GL	S2SRN-S2R, RED (HEAD), GL
H5550011677	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2W	WHITE (HEAD)	GL	S2SRN-S2W, WHITE (HEAD), GL

H5550011678	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2W2A	WHITE A2	GL	S2SRN-S2W2A, WHITE A2, GL
H5550011679	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2W2AM	WHITE A2	GL	S2SRN-S2W2AM, WHITE A2, GL
H5550011680	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2W2B	WHITE B2	GL	S2SRN-S2W2B, WHITE B2, GL
H5550011681	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2W2BM	WHITE B2	GL	S2SRN-S2W2BM, WHITE B2, GL
H5550011682	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2WA	WHITE A	GL	S2SRN-S2WA, WHITE A, GL
H5550011683	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2WAB	WHITE AB	GL	S2SRN-S2WAB, WHITE AB, GL
H5550011684	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2WABM	WHITE AB	GL	S2SRN-S2WABM, WHITE AB, GL
H5550011685	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2WAM	WHITE A	GL	S2SRN-S2WAM, WHITE A, GL
H5550011686	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2WB	WHITE B	GL	S2SRN-S2WB, WHITE B, GL
H5550011687	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2WBM	WHITE B	GL	S2SRN-S2WBM, WHITE B, GL
H5550005708	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AW2A	WHITE A2	GL	S2SRN-S3AW2A, WHITE A2, GL
H5550005709	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AW2AM	WHITE A2	GL	S2SRN-S3AW2AM, WHITE A2, GL
H5550005776	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AW2B	WHITE B2	GL	S2SRN-S3AW2B, WHITE B2, GL
H5550005777	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AW2BM	WHITE B2	GL	S2SRN-S3AW2BM, WHITE B2, GL
H5550005684	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AWA	WHITE A1	GL	S2SRN-S3AWA, WHITE A1, GL
H5550005808	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AWAB	WHITE A1 B1	GL	S2SRN-S3AWAB, WHITE A1 B1, GL
H5550005809	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AWABM	WHITE A1 B1	GL	S2SRN-S3AWABM, WHITE A1 B1, GL
H5550005756	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AWB	WHITE B1	GL	S2SRN-S3AWB, WHITE B1, GL
H5550005757	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AWBM	WHITE B1	GL	S2SRN-S3AWBM, WHITE B1, GL

H5550005545	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BW		GL	S2SRN-S3BW , GL	
H5550005712	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BW2AM	WHITE A2	GL	S2SRN-S3BW2AM, WHITE A2, GL	
H5550005778	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BW2B	WHITE B2	GL	S2SRN-S3BW2B, WHITE B2, GL	
H5550005779	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BW2BM	WHITE B2	GL	S2SRN-S3BW2BM, WHITE B2, GL	
H5550005687	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BWA	WHITE A1	GL	S2SRN-S3BWA, WHITE A1, GL	
H5550005810	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BWAB	WHITE A1 B1	GL	S2SRN-S3BWAB, WHITE A1 B1, GL	
H5550005811	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BWABM	WHITE A1 B1	GL	S2SRN-S3BWABM, WHITE A1 B1, GL	
H5550005688	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BWAM	WHITE A1	GL	S2SRN-S3BWAM, WHITE A1, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, 22/25, 2-позиционный, с фиксацией, влево 45, вправо 45, Белый, 1 нормально открытый, многоуровневый, 110В~/10А, 220В~/5А
H5550005759	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BWB	WHITE B1	GL	S2SRN-S3BWB, WHITE B1, GL	
H5550005760	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BWBM	WHITE B1	GL	S2SRN-S3BWBM, WHITE B1, GL	
H5550005548	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AW		GL	S2SRN-S4AW , GL	
H5550005714	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AW2A	WHITE A2	GL	S2SRN-S4AW2A, WHITE A2, GL	
H5550005715	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AW2AM	WHITE A2	GL	S2SRN-S4AW2AM, WHITE A2, GL	
H5550005780	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AW2B	WHITE B2	GL	S2SRN-S4AW2B, WHITE B2, GL	
H5550005781	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AW2BM	WHITE B2	GL	S2SRN-S4AW2BM, WHITE B2, GL	
H5550005690	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AWA	WHITE A1	GL	S2SRN-S4AWA, WHITE A1, GL	
H5550005812	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AWAB	WHITE A1 B1	GL	S2SRN-S4AWAB, WHITE A1 B1, GL	

H5550005813	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AWABM	WHITE A1 B1	GL	S2SRN-S4AWABM, WHITE A1 B1, GL
H5550005691	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AWAM	WHITE A1	GL	S2SRN-S4AWAM, WHITE A1, GL
H5550005762	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AWB	WHITE B1	GL	S2SRN-S4AWB, WHITE B1, GL
H5550005763	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AWBM	WHITE B1	GL	S2SRN-S4AWBM, WHITE B1, GL
H5550005717	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BW2A	WHITE A2	GL	S2SRN-S4BW2A, WHITE A2, GL
H5550005718	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BW2AM	WHITE A2	GL	S2SRN-S4BW2AM, WHITE A2, GL
H5550005782	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BW2B	WHITE B2	GL	S2SRN-S4BW2B, WHITE B2, GL
H5550005783	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BW2BM	WHITE B2	GL	S2SRN-S4BW2BM, WHITE B2, GL
H5550005693	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BWA	WHITE A1	GL	S2SRN-S4BWA, WHITE A1, GL
H5550005814	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BWAB	WHITE A1 B1	GL	S2SRN-S4BWAB, WHITE A1 B1, GL
H5550005815	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BWABM	WHITE A1 B1	GL	S2SRN-S4BWABM, WHITE A1 B1, GL
H5550005694	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BWAM	WHITE A1	GL	S2SRN-S4BWAM, WHITE A1, GL
H5550005765	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BWB	WHITE B1	GL	S2SRN-S4BWB, WHITE B1, GL
H5550005766	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BWB M	WHITE B1	GL	S2SRN-S4BWB M, WHITE B1, GL
H5550011688	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5KR	RED (HEAD)	GL	S2SRN-S5KR, RED (HEAD), GL
H5550011695	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5KW	WHITE (HEAD)	GL	S2SRN-S5KW, WHITE (HEAD), GL
H5550011696	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5KW2A	WHITE A2	GL	S2SRN-S5KW2A, WHITE A2, GL
H5550011697	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5KW2AM	WHITE A2	GL	S2SRN-S5KW2AM, WHITE A2, GL

H5550011698	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5KW2B	WHITE B2	GL	S2SRN-S5KW2B, WHITE B2, GL
H5550011699	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5KW2BM	WHITE B2	GL	S2SRN-S5KW2BM, WHITE B2, GL
H5550011700	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5KWAB	WHITE AB	GL	S2SRN-S5KWAB, WHITE AB, GL
H5550011701	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5KWABM	WHITE AB	GL	S2SRN-S5KWABM, WHITE AB, GL
H5550005554	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5W		GL	S2SRN-S5W, , GL
H5550005720	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5W2A	WHITE A2	GL	S2SRN-S5W2A, WHITE A2, GL
H5550005784	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5W2B	WHITE B2	GL	S2SRN-S5W2B, WHITE B2, GL
H5550005785	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5W2BM	WHITE B2	GL	S2SRN-S5W2BM, WHITE B2, GL
H5550005816	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5WAB	WHITE A1 B1	GL	S2SRN-S5WAB, WHITE A1 B1, GL
H5550005817	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5WABM	WHITE A1 B1	GL	S2SRN-S5WABM, WHITE A1 B1, GL
H5550011702	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6KR	RED (HEAD)	GL	S2SRN-S6KR, RED (HEAD), GL
H5550011709	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6KW	WHITE (HEAD)	GL	S2SRN-S6KW, WHITE (HEAD), GL
H5550011710	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6KW2A	WHITE A2	GL	S2SRN-S6KW2A, WHITE A2, GL
H5550011711	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6KW2AM	WHITE A2	GL	S2SRN-S6KW2AM, WHITE A2, GL
H5550011712	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6KW2B	WHITE B2	GL	S2SRN-S6KW2B, WHITE B2, GL
H5550011713	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6KW2BM	WHITE B2	GL	S2SRN-S6KW2BM, WHITE B2, GL
H5550011714	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6KWAB	WHITE AB	GL	S2SRN-S6KWAB, WHITE AB, GL
H5550011715	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6KWABM	WHITE AB	GL	S2SRN-S6KWABM, WHITE AB, GL
H5550005557	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6W		GL	S2SRN-S6W, , GL

H5550005723	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6W2A	WHITE A2	GL	S2SRN-S6W2A, WHITE A2, GL	
H5550005724	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6W2AM	WHITE A2	GL	S2SRN-S6W2AM, WHITE A2, GL	
H5550005786	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6W2B	WHITE B2	GL	S2SRN-S6W2B, WHITE B2, GL	
H5550005787	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6W2BM	WHITE B2	GL	S2SRN-S6W2BM, WHITE B2, GL	
H5550005818	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6WAB	WHITE A1 B1	GL	S2SRN-S6WAB, WHITE A1 B1, GL	
H5550005819	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6WABM	WHITE A1 B1	GL	S2SRN-S6WABM, WHITE A1 B1, GL	
H5550011716	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7KR	RED (HEAD)	GL	S2SRN-S7KR, RED (HEAD), GL	
H5550011723	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7KW	WHITE (HEAD)	GL	S2SRN-S7KW, WHITE (HEAD), GL	
H5550011724	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7KW2A	WHITE A2	GL	S2SRN-S7KW2A, WHITE A2, GL	
H5550011725	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7KW2AM	WHITE A2	GL	S2SRN-S7KW2AM, WHITE A2, GL	
H5550011726	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7KW2B	WHITE B2	GL	S2SRN-S7KW2B, WHITE B2, GL	
H5550011727	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7KW2BM	WHITE B2	GL	S2SRN-S7KW2BM, WHITE B2, GL	
H5550011728	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7KWAB	WHITE AB	GL	S2SRN-S7KWAB, WHITE AB, GL	
H5550011729	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7KWABM	WHITE AB	GL	S2SRN-S7KWABM, WHITE AB, GL	
H5550005727	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7W2AM	WHITE A2	GL	S2SRN-S7W2AM, WHITE A2, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, 22/25, 3-позиционный, с фиксацией, влево 90, вправо 90, Белый, 2 нормально открытых, Модульный тип, 110В~/10А, 220В~/5А
H5550005788	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7W2B	WHITE B2	GL	S2SRN-S7W2B, WHITE B2, GL	
H5550005789	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7W2BM	WHITE B2	GL	S2SRN-S7W2BM, WHITE B2, GL	
H5550005820	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7WAB	WHITE A1 B1	GL	S2SRN-S7WAB, WHITE A1 B1, GL	

H5550005821	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7WABM	WHITE A1 B1	GL	S2SRN-S7WABM, WHITE A1 B1, GL
H5550011730	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8KR	RED (HEAD)	GL	S2SRN-S8KR, RED (HEAD), GL
H5550011737	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8KW	WHITE (HEAD)	GL	S2SRN-S8KW, WHITE (HEAD), GL
H5550011738	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8KW2A	WHITE A2	GL	S2SRN-S8KW2A, WHITE A2, GL
H5550011739	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8KW2AM	WHITE A2	GL	S2SRN-S8KW2AM, WHITE A2, GL
H5550011740	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8KW2B	WHITE B2	GL	S2SRN-S8KW2B, WHITE B2, GL
H5550011741	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8KW2BM	WHITE B2	GL	S2SRN-S8KW2BM, WHITE B2, GL
H5550011742	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8KWAB	WHITE AB	GL	S2SRN-S8KWAB, WHITE AB, GL
H5550011743	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8KWABM	WHITE AB	GL	S2SRN-S8KWABM, WHITE AB, GL
H5550005563	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8W		GL	S2SRN-S8W, , GL
H5550005729	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8W2A	WHITE A2	GL	S2SRN-S8W2A, WHITE A2, GL
H5550005730	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8W2AM	WHITE A2	GL	S2SRN-S8W2AM, WHITE A2, GL
H5550005790	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8W2B	WHITE B2	GL	S2SRN-S8W2B, WHITE B2, GL
H5550005791	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8W2BM	WHITE B2	GL	S2SRN-S8W2BM, WHITE B2, GL
H5550005822	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8WAB	WHITE A1 B1	GL	S2SRN-S8WAB, WHITE A1 B1, GL
H5550005823	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8WABM	WHITE A1 B1	GL	S2SRN-S8WABM, WHITE A1 B1, GL
H5550011744	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAKR	RED (HEAD)	GL	S2SRN-SAKR, RED (HEAD), GL
H5550011751	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAKW	WHITE (HEAD)	GL	S2SRN-SAKW, WHITE (HEAD), GL
H5550011752	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAKW2A	WHITE A2	GL	S2SRN-SAKW2A, WHITE A2, GL

H5550011753	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAKW2AM	WHITE A2	GL	S2SRN-SAKW2AM, WHITE A2, GL	
H5550011754	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAKW2B	WHITE B2	GL	S2SRN-SAKW2B, WHITE B2, GL	
H5550011755	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAKW2BM	WHITE B2	GL	S2SRN-SAKW2BM, WHITE B2, GL	
H5550011756	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAKWAB	WHITE AB	GL	S2SRN-SAKWAB, WHITE AB, GL	
H5550011757	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAKWABM	WHITE AB	GL	S2SRN-SAKWABM, WHITE AB, GL	
H5550005732	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAW2A	WHITE A2	GL	S2SRN-SAW2A, WHITE A2, GL	
H5550005733	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAW2AM	WHITE A2	GL	S2SRN-SAW2AM, WHITE A2, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, 22/25, 3-позиционный, с фиксацией, влево 90, с самовозвратом, вправо 60, Белый, 2 нормально открытых, Модульный тип, 110В~/10А, 220В~/5А
H5550005792	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAW2B	WHITE B2	GL	S2SRN-SAW2B, WHITE B2, GL	
H5550005793	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAW2BM	WHITE B2	GL	S2SRN-SAW2BM, WHITE B2, GL	
H5550005824	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAWAB	WHITE A1 B1	GL	S2SRN-SAWAB, WHITE A1 B1, GL	
H5550005825	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAWABM	WHITE A1 B1	GL	S2SRN-SAWABM, WHITE A1 B1, GL	
H5550011758	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBKR	RED (HEAD)	GL	S2SRN-SBKR, RED (HEAD), GL	
H5550011765	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBKW	WHITE (HEAD)	GL	S2SRN-SBKW, WHITE (HEAD), GL	
H5550011766	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBKW2A	WHITE A2	GL	S2SRN-SBKW2A, WHITE A2, GL	
H5550011767	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBKW2AM	WHITE A2	GL	S2SRN-SBKW2AM, WHITE A2, GL	
H5550011768	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBKW2B	WHITE B2	GL	S2SRN-SBKW2B, WHITE B2, GL	
H5550011769	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBKW2BM	WHITE B2	GL	S2SRN-SBKW2BM, WHITE B2, GL	
H5550011770	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBKWAB	WHITE AB	GL	S2SRN-SBKWAB, WHITE AB, GL	

H5550011771	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBKWABM	WHITE AB	GL	S2SRN-SBKWABM, WHITE AB, GL	
H5550005569	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBW		GL	S2SRN-SBW, , GL	
H5550005735	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBW2A	WHITE A2	GL	S2SRN-SBW2A, WHITE A2, GL	
H5550005736	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBW2AM	WHITE A2	GL	S2SRN-SBW2AM, WHITE A2, GL	
H5550005794	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBW2B	WHITE B2	GL	S2SRN-SBW2B, WHITE B2, GL	
H5550005795	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBW2BM	WHITE B2	GL	S2SRN-SBW2BM, WHITE B2, GL	
H5550005826	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBWAB	WHITE A1 B1	GL	S2SRN-SBWAB, WHITE A1 B1, GL	
H5550005827	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBWABM	WHITE A1 B1	GL	S2SRN-SBWABM, WHITE A1 B1, GL	
H5550011772	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCKR	RED (HEAD)	GL	S2SRN-SCKR, RED (HEAD), GL	
H5550011779	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCKW	WHITE (HEAD)	GL	S2SRN-SCKW, WHITE (HEAD), GL	
H5550011780	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCKW2A	WHITE A2	GL	S2SRN-SCKW2A, WHITE A2, GL	
H5550011781	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCKW2AM	WHITE A2	GL	S2SRN-SCKW2AM, WHITE A2, GL	
H5550011782	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCKW2B	WHITE B2	GL	S2SRN-SCKW2B, WHITE B2, GL	
H5550011783	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCKW2BM	WHITE B2	GL	S2SRN-SCKW2BM, WHITE B2, GL	
H5550011784	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCKWAB	WHITE AB	GL	S2SRN-SCKWAB, WHITE AB, GL	
H5550011785	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCKWABM	WHITE AB	GL	S2SRN-SCKWABM, WHITE AB, GL	
H5550005738	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCW2A	WHITE A2	GL	S2SRN-SCW2A, WHITE A2, GL	
H5550005739	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCW2AM	WHITE A2	GL	S2SRN-SCW2AM, WHITE A2, GL	Селекторный переключатель, с короткой ручкой, выступающего типа, 22/25, 3-позиционный, с самовозвратом, влево 60, с фиксацией, вправо 90, Белый, 2 нормально открытых, Модульный тип, 110В~/10А, 220В~/5А

H5550005796	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCW2B	WHITE B2	GL	S2SRN-SCW2B, WHITE B2, GL
H5550005797	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCW2BM	WHITE B2	GL	S2SRN-SCW2BM, WHITE B2, GL
H5550005828	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCWAB	WHITE A1 B1	GL	S2SRN-SCWAB, WHITE A1 B1, GL
H5550005829	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCWABM	WHITE A1 B1	GL	S2SRN-SCWABM, WHITE A1 B1, GL
H5550011786	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDKR	RED (HEAD)	GL	S2SRN-SDKR, RED (HEAD), GL
H5550011793	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDKW	WHITE (HEAD)	GL	S2SRN-SDKW, WHITE (HEAD), GL
H5550011794	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDKW2A	WHITE A2	GL	S2SRN-SDKW2A, WHITE A2, GL
H5550011795	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDKW2AM	WHITE A2	GL	S2SRN-SDKW2AM, WHITE A2, GL
H5550011796	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDKW2B	WHITE B2	GL	S2SRN-SDKW2B, WHITE B2, GL
H5550011797	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDKW2BM	WHITE B2	GL	S2SRN-SDKW2BM, WHITE B2, GL
H5550011798	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDKWAB	WHITE AB	GL	S2SRN-SDKWAB, WHITE AB, GL
H5550011799	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDKWABM	WHITE AB	GL	S2SRN-SDKWABM, WHITE AB, GL
H5550005575	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDW		GL	S2SRN-SDW, , GL
H5550005741	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDW2A	WHITE A2	GL	S2SRN-SDW2A, WHITE A2, GL
H5550005742	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDW2AM	WHITE A2	GL	S2SRN-SDW2AM, WHITE A2, GL
H5550005798	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDW2B	WHITE B2	GL	S2SRN-SDW2B, WHITE B2, GL
H5550005799	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDW2BM	WHITE B2	GL	S2SRN-SDW2BM, WHITE B2, GL

H5550005830	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDWAB	WHITE A1 B1	GL	S2SRN-SDWAB, WHITE A1 B1, GL	
H5550005831	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDWABM	WHITE A1 B1	GL	S2SRN-SDWABM, WHITE A1 B1, GL	
A5550002092	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1R	RED		S2ER-E1R, RED,	Аварийный выключатель, позиция: Ø22/25, рабочее положение: блокировка нажатием, сброс поворотом, кнопка: D30 (с длинной головкой, без подсветки), красный
A5550002155	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1R2A	RED A2		S2ER-E1R2A, RED A2,	
A5550002167	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1R2AB	RED A2 B1		S2ER-E1R2AB, RED A2 B1,	
A5550002168	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1R2ABM	RED A2 B1		S2ER-E1R2ABM, RED A2 B1,	
A5550002156	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1R2AM	RED A2		S2ER-E1R2AM, RED A2,	
A5550002161	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1R2B	RED B2		S2ER-E1R2B, RED B2,	
A5550002162	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1R2BM	RED B2		S2ER-E1R2BM, RED B2,	
A5550002157	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1R3A	RED A3		S2ER-E1R3A, RED A3,	
A5550002158	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1R3AM	RED A3		S2ER-E1R3AM, RED A3,	
A5550002163	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1R3B	RED B3		S2ER-E1R3B, RED B3,	
A5550002164	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1R3BM	RED B3		S2ER-E1R3BM, RED B3,	
A5550002153	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1RA	RED A1		S2ER-E1RA, RED A1,	
A5550002169	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1RA2B	RED A1 B2		S2ER-E1RA2B, RED A1 B2,	
A5550002170	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1RA2BM	RED A1 B2		S2ER-E1RA2BM, RED A1 B2,	
A5550002165	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1RAB	RED A1 B1		S2ER-E1RAB, RED A1 B1,	
A5550002166	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1RABM	RED A1 B1		S2ER-E1RABM, RED A1 B1,	
A5550002154	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1RAM	RED A1		S2ER-E1RAM, RED A1,	

A5550002159	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1RB	RED B1		S2ER-E1RB, RED B1,	Аварийные выключатели 22/25, Красный, Размер головки 30(L), 1 нормально закрытый, 110В~/10А, 220В~/5А
A5550002160	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E1RBM	RED B1		S2ER-E1RBM, RED B1,	
A5550002093	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2R	RED		S2ER-E2R, RED,	Аварийный выключатель, позиция:Ø22/25,рабочее положение: блокировка нажатием, сброс поворотом, кнопка: D30 (с короткой кнопкой, без подсветки), красный
A5550002173	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2R2A	RED A2		S2ER-E2R2A, RED A2,	
A5550002185	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2R2AB	RED A2 B1		S2ER-E2R2AB, RED A2 B1,	
A5550002186	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2R2ABM	RED A2 B1		S2ER-E2R2ABM, RED A2 B1,	
A5550002174	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2R2AM	RED A2		S2ER-E2R2AM, RED A2,	
A5550002179	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2R2B	RED B2		S2ER-E2R2B, RED B2,	
A5550002180	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2R2BM	RED B2		S2ER-E2R2BM, RED B2,	
A5550002175	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2R3A	RED A3		S2ER-E2R3A, RED A3,	
A5550002176	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2R3AM	RED A3		S2ER-E2R3AM, RED A3,	
A5550002181	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2R3B	RED B3		S2ER-E2R3B, RED B3,	
A5550002182	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2R3BM	RED B3		S2ER-E2R3BM, RED B3,	
A5550002171	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2RA	RED A1		S2ER-E2RA, RED A1,	
A5550002187	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2RA2B	RED A1 B2		S2ER-E2RA2B, RED A1 B2,	
A5550002188	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2RA2BM	RED A1 B2		S2ER-E2RA2BM, RED A1 B2,	
A5550002183	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2RAB	RED A1 B1		S2ER-E2RAB, RED A1 B1,	
A5550002184	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2RABM	RED A1 B1		S2ER-E2RABM, RED A1 B1,	

A5550002172	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2RAM	RED A1		S2ER-E2RAM, RED A1,	
A5550002177	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2RB	RED B1		S2ER-E2RB, RED B1,	Аварийные выключатели 22/25, Красный, Размер головки 30(S), 1 нормально закрытый, 110В~/10А, 220В~/5А
A5550002178	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E2RBM	RED B1		S2ER-E2RBM, RED B1,	
A5550002096	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3R	RED		S2ER-E3R, RED,	Аварийный выключатель, позиция:Ø22/25, рабочее положение: блокировка нажатием, сброс поворотом, кнопка: D40 (с короткой головкой, без подсветки), красный
A5550002107	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3R2A	RED A2		S2ER-E3R2A, RED A2,	
A5550002117	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3R2AB	RED A2 B1		S2ER-E3R2AB, RED A2 B1,	
A5550002118	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3R2ABM	RED A2 B1		S2ER-E3R2ABM, RED A2 B1,	
A5550002108	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3R2AM	RED A2		S2ER-E3R2AM, RED A2,	
A5550002111	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3R2B	RED B2		S2ER-E3R2B, RED B2,	Аварийные выключатели 22/25, Красный, Размер головки 40, 2 нормально закрытых, 110В~/10А, 220В~/5А
A5550002112	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3R2BM	RED B2		S2ER-E3R2BM, RED B2,	
A5550002109	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3R3A	RED A3		S2ER-E3R3A, RED A3,	
A5550002110	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3R3AM	RED A3		S2ER-E3R3AM, RED A3,	
A5550002113	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3R3B	RED B3		S2ER-E3R3B, RED B3,	
A5550002114	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3R3BM	RED B3		S2ER-E3R3BM, RED B3,	
A5550002105	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3RA	RED A1		S2ER-E3RA, RED A1,	
A5550002119	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3RA2B	RED A1 B2		S2ER-E3RA2B, RED A1 B2,	
A5550002120	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3RA2BM	RED A1 B2		S2ER-E3RA2BM, RED A1 B2,	
A5550002115	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3RAB	RED A1 B1		S2ER-E3RAB, RED A1 B1,	Аварийный выключатель, позиция:Ø22/25, рабочее положение: блокировка нажатием, сброс поворотом, кнопка: D40 (с короткой головкой, без подсветки), красный, блок контактов: контакт А:1, контакт В:1

A5550002116	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3RABM	RED A1 B1		S2ER-E3RABM, RED A1 B1,	
A5550002106	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3RAM	RED A1		S2ER-E3RAM, RED A1,	
A5550002094	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3RB	RED		S2ER-E3RB, RED,	Аварийные выключатели 22/25, Красный, Размер головки 40, 1 нормально закрытый, 110В~/10А, 220В~/5А
A5550002095	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E3RBM	RED		S2ER-E3RBM, RED,	Аварийные выключатели 22/25, Красный, Размер головки 40, 1 нормально закрытый, 110В~/10А, 220В~/5А, модульный тип
A5550002102	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4R	RED		S2ER-E4R, RED,	Аварийный выключатель, позиция:Ø22/25, рабочее положение: блокировка нажатием, сброс поворотом, кнопка: D40 (с короткой головкой, с подсветкой), красный
A5550002123	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4R2AD	RED A2 LED(DC)		S2ER-E4R2AD, RED A2 LED(DC),	
A5550002124	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4R2ADM	RED A2 LED(DC)		S2ER-E4R2ADM, RED A2 LED(DC),	
A5550002131	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4R2AL	RED A2 LED(AC)		S2ER-E4R2AL, RED A2 LED(AC),	
A5550002132	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4R2ALM	RED A2 LED(AC)		S2ER-E4R2ALM, RED A2 LED(AC),	
A5550002125	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4R2BD	RED B2 LED(DC)		S2ER-E4R2BD, RED B2 LED(DC),	
A5550002126	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4R2BDM	RED B2 LED(DC)		S2ER-E4R2BDM, RED B2 LED(DC),	
A5550002133	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4R2BL	RED B2 LED(AC)		S2ER-E4R2BL, RED B2 LED(AC),	
A5550002134	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4R2BLM	RED B2 LED(AC)		S2ER-E4R2BLM, RED B2 LED(AC),	
A5550002127	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4RABD	RED A1 B1 LED(DC)		S2ER-E4RABD, RED A1 B1 LED(DC),	Аварийный выключатель, позиция:Ø22/25, рабочее положение: блокировка нажатием, сброс поворотом, кнопка: D40 (с короткой головкой, с подсветкой), красный, блок контактов: Контакт А:1, Контакт В:1, 12-30 В~/В~
A5550002128	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4RABDM	RED A1 B1 LED(DC)		S2ER-E4RABDM, RED A1 B1 LED(DC),	Аварийные выключатели 22/25мм, Красный, Размер головки 40мм(короткая), модульный, 1 нормально закрытый, 1 нормально открытый, коммутация до 110В~/10А, 220В~/5А, СИД 12-24В~/~

A5550002135	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4RABL	RED A1 B1 LED(AC)		S2ER-E4RABL, RED A1 B1 LED(AC),	
A5550002136	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4RABLM	RED A1 B1 LED(AC)		S2ER-E4RABLM, RED A1 B1 LED(AC),	
A5550002121	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4RAD	RED A1 LED(DC)		S2ER-E4RAD, RED A1 LED(DC),	
A5550002122	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4RADM	RED A1 LED(DC)		S2ER-E4RADM, RED A1 LED(DC),	
A5550002129	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4RAL	RED A1 LED(AC)		S2ER-E4RAL, RED A1 LED(AC),	
A5550002130	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4RALM	RED A1 LED(AC)		S2ER-E4RALM, RED A1 LED(AC),	
A5550002100	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4RBD	RED B1 LED(DC)		S2ER-E4RBD, RED B1 LED(DC),	Аварийные выключатели с подсветкой 22/25, Красный, Размер головки 40, 1 нормально закрытый, СИД 12-30 В=В~
A5550002101	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4RBDM	RED B1 LED(DC)		S2ER-E4RBDM, RED B1 LED(DC),	
A5550002103	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4RBL	RED B1 LED(AC)		S2ER-E4RBL, RED B1 LED(AC),	
A5550002104	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E4RBLM	RED B1 LED(AC)		S2ER-E4RBLM, RED B1 LED(AC),	
A5550002099	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5R	RED		S2ER-E5R, RED,	Аварийный выключатель, позиция:Ø22/25,рабочее положение: блокировка нажатием, сброс поворотом, кнопка: D60 (с короткой головкой, без подсветки), красный
A5550002139	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5R2A	RED A2		S2ER-E5R2A, RED A2,	
A5550002149	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5R2AB	RED A2 B1		S2ER-E5R2AB, RED A2 B1,	
A5550002150	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5R2ABM	RED A2 B1		S2ER-E5R2ABM, RED A2 B1,	
A5550002140	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5R2AM	RED A2		S2ER-E5R2AM, RED A2,	
A5550002143	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5R2B	RED B2		S2ER-E5R2B, RED B2,	
A5550002144	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5R2BM	RED B2		S2ER-E5R2BM, RED B2,	
A5550002141	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5R3A	RED A3		S2ER-E5R3A, RED A3,	
A5550002142	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5R3AM	RED A3		S2ER-E5R3AM, RED A3,	

A5550002145	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5R3B	RED B3		S2ER-E5R3B, RED B3,	
A5550002146	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5R3BM	RED B3		S2ER-E5R3BM, RED B3,	
A5550002137	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5RA	RED A1		S2ER-E5RA, RED A1,	
A5550002151	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5RA2B	RED A1 B2		S2ER-E5RA2B, RED A1 B2,	
A5550002152	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5RA2BM	RED A1 B2		S2ER-E5RA2BM, RED A1 B2,	
A5550002147	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5RAB	RED A1 B1		S2ER-E5RAB, RED A1 B1,	
A5550002148	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5RABM	RED A1 B1		S2ER-E5RABM, RED A1 B1,	
A5550002138	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5RAM	RED A1		S2ER-E5RAM, RED A1,	
A5550002097	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5RB	RED B1		S2ER-E5RB, RED B1,	Аварийные выключатели 22/25, Красный, Размер головки 60, 1 нормально закрытый, 110В~/10А, 220В~/5А
A5550002098	CONTROL SWITCH	EMERGENCY SWITCH	S2ER SERIES	S2ER-E5RBM	RED B1		S2ER-E5RBM, RED B1,	Аварийные выключатели 22/25, Красный, Размер головки 60, 1 нормально закрытый, 110В~/10А, 220В~/5А, модульный тип
A5550009115	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1EK			S2KR-1EK, ,	Селекторные переключатели, круглые, позиция: Ø22/25, рабочее положение: 2-х позиционный самовозврат, положение извлечения ключа: центр, черный
A5550009116	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1EK2A	2(0-R)/C/A2		S2KR-1EK2A, 2(0-R)/C/A2,	
A5550009117	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1EK2AM	2(0-R)/C/A2		S2KR-1EK2AM, 2(0-R)/C/A2,	
A5550009120	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1EK2B	2(0-R)/C/B2		S2KR-1EK2B, 2(0-R)/C/B2,	
A5550009121	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1EK2BM	2(0-R)/C/B2		S2KR-1EK2BM, 2(0-R)/C/B2,	
A5550009113	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1EKA	2(0-R)/C/A1		S2KR-1EKA, 2(0-R)/C/A1,	
A5550009122	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1EKAB	2(O-R)/C/A1B1		S2KR-1EKAB, 2(O-R)/C/A1B1,	
A5550009123	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1EKABM	2(O-R)/C/A1B1		S2KR-1EKABM, 2(O-R)/C/A1B1,	
A5550009114	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1EKAM	2(0-R)/C/A1		S2KR-1EKAM, 2(0-R)/C/A1,	
A5550009118	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1EKB	2(0-R)/C/B1		S2KR-1EKB, 2(0-R)/C/B1,	

A5550009119	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-1EKBM	2(0-R)/C/B1		S2KR-1EKBM, 2(0-R)/C/B1,	
A5550009126	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DK	2(0-S)/R		S2KR-2DK, 2(0-S)/R,	
A5550009127	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DK2A	2(0-S)/R/A2		S2KR-2DK2A, 2(0-S)/R/A2,	
A5550009128	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DK2AM	2(0-S)/R/A2		S2KR-2DK2AM, 2(0-S)/R/A2,	
A5550009131	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DK2B	2(0-S)/R/B2		S2KR-2DK2B, 2(0-S)/R/B2,	
A5550009132	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DK2BM	2(0-S)/R/B2		S2KR-2DK2BM, 2(0-S)/R/B2,	
A5550009124	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DKA	2(0-S)/R/A1		S2KR-2DKA, 2(0-S)/R/A1,	
A5550009133	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DKAB	2(0-S)/R/A1B1		S2KR-2DKAB, 2(0-S)/R/A1B1,	
A5550009134	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DKABM	2(0-S)/R/A1B1		S2KR-2DKABM, 2(0-S)/R/A1B1,	
A5550009125	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DKAM	2(0-S)/R/A1		S2KR-2DKAM, 2(0-S)/R/A1,	
A5550009129	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DKB	2(0-S)/R/B1		S2KR-2DKB, 2(0-S)/R/B1,	
A5550009130	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2DKBM	2(0-S)/R/B1		S2KR-2DKBM, 2(0-S)/R/B1,	
A5550009339	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2EK			S2KR-2EK, ,	Селекторные переключатели, круглые, позиция: Ø22/25, рабочее положение: 2-х позиционный без возврата, положение извлечения ключа: центр, чёрный
A5550009137	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2EK2A	2(0-S)/C/A2		S2KR-2EK2A, 2(0-S)/C/A2,	
A5550009138	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2EK2AM	2(0-S)/C/A2		S2KR-2EK2AM, 2(0-S)/C/A2,	
A5550009141	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2EK2B	2(0-S)/C/B2		S2KR-2EK2B, 2(0-S)/C/B2,	
A5550009142	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2EK2BM	2(0-S)/C/B2		S2KR-2EK2BM, 2(0-S)/C/B2,	
A5550009135	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2EKA	2(0-S)/C/A1		S2KR-2EKA, 2(0-S)/C/A1,	
A5550009143	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2EKAB	2(0-S)/C/A1B1		S2KR-2EKAB, 2(0-S)/C/A1B1,	Селекторный переключатель с ключом выступающего типа, 22/25, 2 положения с фиксацией, Снятие ключа в центральной позиции, Чёрный, 1 Нормально открытый, 1 Нормально закрытый, Одноуровневый, 110В~/10А, 220В~/5А
A5550009144	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2EKABM	2(0-S)/C/A1B1		S2KR-2EKABM, 2(0-S)/C/A1B1,	Селекторный переключатель с ключом выступающего типа, 22/25, 2 положения с фиксацией, Снятие ключа в центральной позиции, Чёрный,

								1 Нормально открытый, 1 Нормально закрытый, Многоуровневый, 110В~/10А, 220В~/5А
A5550009136	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2EKAM	2(0-S)/C/A1		S2KR-2EKAM, 2(0-S)/C/A1,	
A5550009139	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2EKB	2(0-S)/C/B1		S2KR-2EKB, 2(0-S)/C/B1,	
A5550009140	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2EKBM	2(0-S)/C/B1		S2KR-2EKBM, 2(0-S)/C/B1,	
A5550009147	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FK			S2KR-2FK, ,	Селекторные переключатели, круглые, позиция: Ø22/25, рабочее положение: 2-х позиционный без возврата, положение извлечения ключа: центр + прав., черный
A5550009148	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FK2A	2(0-S)/C+R/A2		S2KR-2FK2A, 2(0-S)/C+R/A2,	
A5550009149	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FK2AM	2(0-S)/C+R/A2		S2KR-2FK2AM, 2(0-S)/C+R/A2,	
A5550009152	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FK2B	2(0-S)/C+R/B2		S2KR-2FK2B, 2(0-S)/C+R/B2,	
A5550009153	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FK2BM	2(0-S)/C+R/B2		S2KR-2FK2BM, 2(0-S)/C+R/B2,	
A5550009145	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FKA	2(0-S)/C+R/A1		S2KR-2FKA, 2(0-S)/C+R/A1,	
A5550009154	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FKAB	2(0-S)/C+R/A1B1		S2KR-2FKAB, 2(0-S)/C+R/A1B1,	Селекторный переключатель с ключем выступающего типа, 22/25, 2 положения с фиксацией, Снятие ключа в центральной и правой позиции, Чёрный, 1 Нормально открытый, 1 Нормально закрытый, Одноуровневый, 110В~/10А, 220В~/5А
A5550009155	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FKABM	2(0-S)/C+R/A1B1		S2KR-2FKABM, 2(0-S)/C+R/A1B1,	
A5550009146	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FKAM	2(0-S)/C+R/A1		S2KR-2FKAM, 2(0-S)/C+R/A1,	
A5550009150	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FKB	2(0-S)/C+R/B1		S2KR-2FKB, 2(0-S)/C+R/B1,	
A5550009151	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-2FKBM	2(0-S)/C+R/B1		S2KR-2FKBM, 2(0-S)/C+R/B1,	
A5550009158	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-3EK			S2KR-3EK, ,	Селекторные переключатели, круглые, позиция: Ø22/25, рабочее положение: 3-х позиционный, пружинный самовозврат из 2 положений, положение извлечения ключа: центр, черный
A5550009157	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-3EK2AM	3(R-0-R)/C/A2		S2KR-3EK2AM, 3(R-0-R)/C/A2,	
A5550009165	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4BK			S2KR-4BK, ,	
A5550009163	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4BK2A	3(S-0-S)/L+R/A2		S2KR-4BK2A, 3(S-0-S)/L+R/A2,	
A5550009164	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4BK2AM	3(S-0-S)/L+R/A2		S2KR-4BK2AM, 3(S-0-S)/L+R/A2,	

A5550009166	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4BK2B	3(S-0-S)/L+R/B2		S2KR-4BK2B, 3(S-0-S)/L+R/B2,	
A5550009167	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4BK2BM	3(S-0-S)/L+R/B2		S2KR-4BK2BM, 3(S-0-S)/L+R/B2,	
A5550009168	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4BKAB	3(S-0-S)/L+R/A1B1		S2KR-4BKAB, 3(S-0-S)/L+R/A1B1,	
A5550009169	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4BKABM	3(S-0-S)/L+R/A1B1		S2KR-4BKABM, 3(S-0-S)/L+R/A1B1,	
A5550001384	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4CK			S2KR-4CK, ,	Селекторные переключатели, круглые, позиция: Ø22/25, рабочее положение: 3-х позиционный, без возврата, положение извлечения ключа: лев.+центр+прав., черный
A5550009170	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4CK2A	3(S-0-S)/L+C+R/A2		S2KR-4CK2A, 3(S-0-S)/L+C+R/A2,	
A5550009171	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4CK2AM	3(S-0-S)/L+C+R/A2		S2KR-4CK2AM, 3(S-0-S)/L+C+R/A2,	
A5550009172	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4CK2B	3(S-0-S)/L+C+R/B2		S2KR-4CK2B, 3(S-0-S)/L+C+R/B2,	
A5550009173	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4CK2BM	3(S-0-S)/L+C+R/B2		S2KR-4CK2BM, 3(S-0-S)/L+C+R/B2,	
A5550009174	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4CKAB	3(S-0-S)/L+C+R/A1B1		S2KR-4CKAB, 3(S-0-S)/L+C+R/A1B1,	
A5550009175	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4CKABM	3(S-0-S)/L+C+R/A1B1		S2KR-4CKABM, 3(S-0-S)/L+C+R/A1B1,	
A5550009176	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4EK			S2KR-4EK, ,	
A5550009177	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4EK2A	3(S-0-S)/C/A2		S2KR-4EK2A, 3(S-0-S)/C/A2,	
A5550009178	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4EK2AM	3(S-0-S)/C/A2		S2KR-4EK2AM, 3(S-0-S)/C/A2,	
A5550009180	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4EK2B	3(S-0-S)/C/B2		S2KR-4EK2B, 3(S-0-S)/C/B2,	
A5550009181	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4EK2BM	3(S-0-S)/C/B2		S2KR-4EK2BM, 3(S-0-S)/C/B2,	
A5550009182	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4EKAB	3(S-0-S)/C/A1B1		S2KR-4EKAB, 3(S-0-S)/C/A1B1,	
A5550009183	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-4EKABM	3(S-0-S)/C/A1B1		S2KR-4EKABM, 3(S-0-S)/C/A1B1,	
A5550009186	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5AK			S2KR-5AK, ,	
A5550009184	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5AK2A	3(S-0-R)/L/A2		S2KR-5AK2A, 3(S-0-R)/L/A2,	

A5550009185	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5AK2AM	3(S-0-R)/L/A2		S2KR-5AK2AM, 3(S-0-R)/L/A2,
A5550009187	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5AK2B	3(S-0-R)/L/B2		S2KR-5AK2B, 3(S-0-R)/L/B2,
A5550009188	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5AK2BM	3(S-0-R)/L/B2		S2KR-5AK2BM, 3(S-0-R)/L/B2,
A5550009189	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5AKAB	3(S-0-R)/L/A1B1		S2KR-5AKAB, 3(S-0-R)/L/A1B1,
A5550009190	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5AKABM	3(S-0-R)/L/A1B1		S2KR-5AKABM, 3(S-0-R)/L/A1B1,
A5550009179	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5EK			S2KR-5EK, ,
A5550009191	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5EK2A	3(S-0-R)/C/A2		S2KR-5EK2A, 3(S-0-R)/C/A2,
A5550009192	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5EK2AM	3(S-0-R)/C/A2		S2KR-5EK2AM, 3(S-0-R)/C/A2,
A5550009193	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5EK2B	3(S-0-R)/C/B2		S2KR-5EK2B, 3(S-0-R)/C/B2,
A5550009194	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5EK2BM	3(S-0-R)/C/B2		S2KR-5EK2BM, 3(S-0-R)/C/B2,
A5550009195	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5EKAB	3(S-0-R)/C/A1B1		S2KR-5EKAB, 3(S-0-R)/C/A1B1,
A5550009196	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5EKABM	3(S-0-R)/C/A1B1		S2KR-5EKABM, 3(S-0-R)/C/A1B1,
A5550009199	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5GK			S2KR-5GK, ,
A5550009197	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5GK2A	3(S-0-R)/L+C/A2		S2KR-5GK2A, 3(S-0-R)/L+C/A2,
A5550009198	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5GK2AM	3(S-0-R)/L+C/A2		S2KR-5GK2AM, 3(S-0-R)/L+C/A2,
A5550009200	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5GK2B	3(S-0-R)/L+C/B2		S2KR-5GK2B, 3(S-0-R)/L+C/B2,
A5550009201	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5GK2BM	3(S-0-R)/L+C/B2		S2KR-5GK2BM, 3(S-0-R)/L+C/B2,
A5550009202	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5GKAB	3(S-0-R)/L+C/A1B1		S2KR-5GKAB, 3(S-0-R)/L+C/A1B1,
A5550009203	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-5GKABM	3(S-0-R)/L+C/A1B1		S2KR-5GKABM, 3(S-0-R)/L+C/A1B1,
A5550009206	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6DK			S2KR-6DK, ,
A5550009204	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6DK2A	3(R-0-S)/R/A2		S2KR-6DK2A, 3(R-0-S)/R/A2,

A5550009205	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6DK2AM	3(R-0-S)/R/A2		S2KR-6DK2AM, 3(R-0-S)/R/A2,	
A5550009207	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6DK2B	3(R-0-S)/R/B2		S2KR-6DK2B, 3(R-0-S)/R/B2,	
A5550009208	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6DK2BM	3(R-0-S)/R/B2		S2KR-6DK2BM, 3(R-0-S)/R/B2,	
A5550009209	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6DKAB	3(R-0-S)/R/A1B1		S2KR-6DKAB, 3(R-0-S)/R/A1B1,	
A5550009210	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6DKABM	3(R-0-S)/R/A1B1		S2KR-6DKABM, 3(R-0-S)/R/A1B1,	
A5550009213	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6EK			S2KR-6EK, ,	
A5550009211	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6EK2A	3(R-0-S)/C/A2		S2KR-6EK2A, 3(R-0-S)/C/A2,	
A5550009212	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6EK2AM	3(R-0-S)/C/A2		S2KR-6EK2AM, 3(R-0-S)/C/A2,	
A5550009214	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6EK2B	3(R-0-S)/C/B2		S2KR-6EK2B, 3(R-0-S)/C/B2,	
A5550009215	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6EK2BM	3(R-0-S)/C/B2		S2KR-6EK2BM, 3(R-0-S)/C/B2,	
A5550009216	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6EKAB	3(R-0-S)/C/A1B1		S2KR-6EKAB, 3(R-0-S)/C/A1B1,	
A5550009217	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6EKABM	3(R-0-S)/C/A1B1		S2KR-6EKABM, 3(R-0-S)/C/A1B1,	
A5550009220	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6FK			S2KR-6FK, ,	
A5550009218	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6FK2A	3(R-0-S)/C+R/A2		S2KR-6FK2A, 3(R-0-S)/C+R/A2,	
A5550009219	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6FK2AM	3(R-0-S)/C+R/A2		S2KR-6FK2AM, 3(R-0-S)/C+R/A2,	
A5550009221	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6FK2B	3(R-0-S)/C+R/B2		S2KR-6FK2B, 3(R-0-S)/C+R/B2,	
A5550009222	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6FK2BM	3(R-0-S)/C+R/B2		S2KR-6FK2BM, 3(R-0-S)/C+R/B2,	
A5550009223	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6FKAB	3(R-0-S)/C+R/A1B1		S2KR-6FKAB, 3(R-0-S)/C+R/A1B1,	
A5550009224	CONTROL SWITCH	KEY SELECTOR SWITCH	S2KR SERIES	S2KR-6FKABM	3(R-0-S)/C+R/A1B1		S2KR-6FKABM, 3(R-0-S)/C+R/A1B1,	
A5550009616	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1B	BLUE		L2RR-L1B, BLUE,	Сигнальная лампа, полусферическая (выступающая), Ø22/25, голубой
A5550009619	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1G	GREEN		L2RR-L1G, GREEN,	Сигнальная лампа, полусферическая (выступающая), Ø22/25, зеленый

A5550009617	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1GD	GREEN		L2RR-L1GD, GREEN,	
A5550009664	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1GL	GREEN		L2RR-L1GL, GREEN,	
A5550009613	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1R	RED		L2RR-L1R, RED,	Сигнальная лампа, полусферическая (выступающая), Ø22/25, красный
A5550009611	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1RD	RED		L2RR-L1RD, RED,	Сигнальная лампа 22/25, Красный, сферическая головка, СИД 12-30 В=В~
A5550009612	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1RDM	RED		L2RR-L1RDM, RED,	
A5550009660	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1RL	RED		L2RR-L1RL, RED,	
A5550009661	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1RLM	RED		L2RR-L1RLM, RED,	
A5550009625	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1W	WHITE		L2RR-L1W, WHITE,	Сигнальная лампа, полусферическая (выступающая), Ø22/25, белый
A5550009623	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1WD	WHITE		L2RR-L1WD, WHITE,	
A5550009668	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1WL	WHITE		L2RR-L1WL, WHITE,	
A5550009622	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1Y	YELLOW		L2RR-L1Y, YELLOW,	Сигнальная лампа, полусферическая (выступающая), Ø22/25, желтый
A5550009620	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1YD	YELLOW		L2RR-L1YD, YELLOW,	
A5550009666	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L1YL	YELLOW		L2RR-L1YL, YELLOW,	
A5550009631	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2B	BLUE		L2RR-L2B, BLUE,	Сигнальная лампа, конусообразная (выступающая), Ø22/25, голубой
A5550009634	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2G	GREEN		L2RR-L2G, GREEN,	Сигнальная лампа, конусообразная (выступающая), Ø22/25, зеленый
A5550009632	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2GD	GREEN		L2RR-L2GD, GREEN,	
A5550009674	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2GL	GREEN		L2RR-L2GL, GREEN,	
A5550009628	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2R	RED		L2RR-L2R, RED,	Сигнальная лампа, конусообразная (выступающая), Ø22/25, красный
A5550009626	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2RD	RED		L2RR-L2RD, RED,	
A5550009627	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2RDM	RED		L2RR-L2RDM, RED,	

A5550009670	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2RL	RED		L2RR-L2RL, RED,	
A5550009671	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2RLM	RED		L2RR-L2RLM, RED,	
A5550009640	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2W	WHITE		L2RR-L2W, WHITE,	
A5550009678	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2WL	WHITE		L2RR-L2WL, WHITE,	
A5550009637	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2Y	YELLOW		L2RR-L2Y, YELLOW,	Сигнальная лампа, конусообразная (выступающая), Ø22/25, желтый
A5550009676	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L2YL	YELLOW		L2RR-L2YL, YELLOW,	
A5550009646	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3B	BLUE		L2RR-L3B, BLUE,	Сигнальная лампа, плоская, круглая, выступающая, Ø22/25, голубой
A5550009644	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3BD	BLUE		L2RR-L3BD, BLUE,	
A5550009682	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3BL	BLUE		L2RR-L3BL, BLUE,	
A5550009650	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3G	GREEN		L2RR-L3G, GREEN,	Сигнальная лампа, плоская, круглая, выступающая, Ø22/25, зеленый
A5550009649	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3GD	GREEN		L2RR-L3GD, GREEN,	Сигнальная лампа, плоская, круглая, выступающая, Ø22/25, зеленый
A5550009685	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3GL	GREEN		L2RR-L3GL, GREEN,	Сигнальная лампа, плоская, круглая, выступающая, Ø22/25, зеленый
A5550009715	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3R	RED		L2RR-L3R, RED,	
A5550009642	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3RD	RED		L2RR-L3RD, RED,	Сигнальная лампа Ø22/25, Красный, Плоская круглая выступающая головка, СИД 12-30 В=В~
A5550009641	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3RDM	RED		L2RR-L3RDM, RED,	
A5550009681	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3RL	RED		L2RR-L3RL, RED,	Сигнальная лампа 22/25, Красный, Плоская круглая головка, СИД 100-220В~
A5550009680	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3RLM	RED		L2RR-L3RLM, RED,	
A5550009658	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3W	WHITE		L2RR-L3W, WHITE,	Сигнальная лампа Ø22/25, Белый, Плоская круглая головка, СИД 12-30 В=В~
A5550009656	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3WD	WHITE		L2RR-L3WD, WHITE,	Сигнальная лампа 22/25, Белый, Плоская головка, СИД 12-30 В=В~
A5550009688	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3WL	WHITE		L2RR-L3WL, WHITE,	

A5550009654	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3Y	YELLOW		L2RR-L3Y, YELLOW,	Сигнальная лампа, плоская круглая выступающая, Ø22/25, Желтый
A5550009652	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3YD	YELLOW		L2RR-L3YD, YELLOW,	Сигнальная лампа 22/25, Желтый, Плоская головка, СИД 12-30 В~/В~
A5550009686	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L3YL	YELLOW		L2RR-L3YL, YELLOW,	
A5550009695	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4B	BLUE		L2RR-L4B, BLUE,	
A5550009693	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4BD	BLUE LED(DC)		L2RR-L4BD, BLUE LED(DC),	
A5550009707	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4BL	BLUE LED(AC)		L2RR-L4BL, BLUE LED(AC),	
A5550009698	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4G	GREEN		L2RR-L4G, GREEN,	
A5550009696	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4GD	GREEN LED(DC)		L2RR-L4GD, GREEN LED(DC),	
A5550009709	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4GL	GREEN LED(AC)		L2RR-L4GL, GREEN LED(AC),	
A5550009692	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4R	RED		L2RR-L4R, RED,	
A5550009690	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4RD	RED LED(DC)		L2RR-L4RD, RED LED(DC),	
A5550009691	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4RDM	RED LED(DC)		L2RR-L4RDM, RED LED(DC),	
A5550009705	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4RL	RED LED(AC)		L2RR-L4RL, RED LED(AC),	
A5550009706	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4RLM	RED LED(AC)		L2RR-L4RLM, RED LED(AC),	
A5550009704	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4W	WHITE		L2RR-L4W, WHITE,	
A5550009702	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4WD	WHITE LED(DC)		L2RR-L4WD, WHITE LED(DC),	
A5550009713	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4WL	WHITE LED(AC)		L2RR-L4WL, WHITE LED(AC),	
A5550009701	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4Y	YELLOW		L2RR-L4Y, YELLOW,	
A5550009699	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4YD	YELLOW LED(DC)		L2RR-L4YD, YELLOW LED(DC),	
A5550009711	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RR-L4YL	YELLOW LED(AC)		L2RR-L4YL, YELLOW LED(AC),	
A5550010487	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RRU-L3GD	GREEN		L2RRU-L3GD, GREEN,	

A5550010490	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RRU-L3GL	GREEN		L2RRU-L3GL, GREEN,	
A5550009643	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RRU-L3R	RED(NO PRINTING)		L2RRU-L3R, RED(NO PRINTING),	
A5550010486	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RRU-L3RD	RED		L2RRU-L3RD, RED,	
A5550010489	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RRU-L3RL	RED		L2RRU-L3RL, RED,	
A5550010488	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RRU-L3WD	WHITE		L2RRU-L3WD, WHITE,	
A5550000454	CONTROL SWITCH	PILOT LAMP	L2RR SERIES	L2RRU-L4R	RED		L2RRU-L4R, RED,	
A5550002056	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1G	GREEN		S2BR-P1G, GREEN,	Пусковой кнопочный выключатель, позиция:Ø22/25, выступающая, зеленый
A5550002054	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1GA	GREEN A1		S2BR-P1GA, GREEN A1,	
A5550002086	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1GAB	GREEN A1 B1		S2BR-P1GAB, GREEN A1 B1,	
A5550002080	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1GB	GREEN B1		S2BR-P1GB, GREEN B1,	
A5550002059	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1R	RED		S2BR-P1R, RED,	Пусковой кнопочный выключатель, позиция:Ø22/25, выступающая, красный
A5550002060	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1R2A	RED A2		S2BR-P1R2A, RED A2,	
A5550002072	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1R2AB	RED A2 B1		S2BR-P1R2AB, RED A2 B1,	
A5550002073	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1R2ABM	RED A2 B1		S2BR-P1R2ABM, RED A2 B1,	
A5550002061	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1R2AM	RED A2		S2BR-P1R2AM, RED A2,	
A5550002066	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1R2B	RED B2		S2BR-P1R2B, RED B2,	
A5550002067	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1R2BM	RED B2		S2BR-P1R2BM, RED B2,	
A5550002062	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1R3A	RED A3		S2BR-P1R3A, RED A3,	
A5550002063	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1R3AM	RED A3		S2BR-P1R3AM, RED A3,	
A5550002068	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1R3B	RED B3		S2BR-P1R3B, RED B3,	
A5550002069	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1R3BM	RED B3		S2BR-P1R3BM, RED B3,	

A5550002057	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1RA	RED A1		S2BR-P1RA, RED A1,
A5550002074	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1RA2B	RED A1 B2		S2BR-P1RA2B, RED A1 B2,
A5550002075	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1RA2BM	RED A1 B2		S2BR-P1RA2BM, RED A1 B2,
A5550002070	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1RAB	RED A1 B1		S2BR-P1RAB, RED A1 B1,
A5550002071	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1RABM	RED A1 B1		S2BR-P1RABM, RED A1 B1,
A5550002058	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1RAM	RED A1		S2BR-P1RAM, RED A1,
A5550002064	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1RB	RED B1		S2BR-P1RB, RED B1,
A5550002065	CONTROL SWITCH	PUSH BUTTON SWITCH	S2BR SERIES	S2BR-P1RBM	RED B1		S2BR-P1RBM, RED B1,
A5550001603	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1B	BLUE		S2PR-E1B, BLUE,
A5550001601	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1BA	BLUE A1		S2PR-E1BA, BLUE A1,
A5550001634	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1BB	BLUE B1		S2PR-E1BB, BLUE B1,
A5550001606	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1G	GREEN		S2PR-E1G, GREEN,
A5550001676	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1G2AB	GREEN A2 B1		S2PR-E1G2AB, GREEN A2 B1,
A5550001604	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1GA	GREEN A1		S2PR-E1GA, GREEN A1,
A5550001636	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1GB	GREEN B1		S2PR-E1GB, GREEN B1,
A5550001612	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1K	BLACK		S2PR-E1K, BLACK,
A5550001610	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1KA	BLACK A1		S2PR-E1KA, BLACK A1,
A5550001640	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1KB	BLACK B1		S2PR-E1KB, BLACK B1,
A5550001600	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1R	RED		S2PR-E1R, RED,
A5550001613	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1R2A	RED A2		S2PR-E1R2A, RED A2,
A5550001672	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1R2AB	RED A2 B1		S2PR-E1R2AB, RED A2 B1,
A5550001673	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1R2ABM	RED A2 B1		S2PR-E1R2ABM, RED A2 B1,
A5550001614	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1R2AM	RED A2		S2PR-E1R2AM, RED A2,

A5550001642	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1R2B	RED B2		S2PR-E1R2B, RED B2,	
A5550001643	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1R2BM	RED B2		S2PR-E1R2BM, RED B2,	
A5550001622	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1R3A	RED A3		S2PR-E1R3A, RED A3,	
A5550001623	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1R3AM	RED A3		S2PR-E1R3AM, RED A3,	
A5550001652	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1R3B	RED B3		S2PR-E1R3B, RED B3,	
A5550001653	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1R3BM	RED B3		S2PR-E1R3BM, RED B3,	
A5550001598	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1RA	RED A1		S2PR-E1RA, RED A1,	
A5550001682	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1RA2B	RED A1 B2		S2PR-E1RA2B, RED A1 B2,	
A5550001683	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1RA2BM	RED A1 B2		S2PR-E1RA2BM, RED A1 B2,	
A5550001662	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1RAB	RED A1 B1		S2PR-E1RAB, RED A1 B1,	
A5550001663	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1RABM	RED A1 B1		S2PR-E1RABM, RED A1 B1,	
A5550001599	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1RAM	RED A1		S2PR-E1RAM, RED A1,	
A5550001632	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1RB	RED B1		S2PR-E1RB, RED B1,	
A5550001633	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1RBM	RED B1		S2PR-E1RBM, RED B1,	
A5550001609	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1Y	YELLOW		S2PR-E1Y, YELLOW,	
A5550001607	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1YA	YELLOW A1		S2PR-E1YA, YELLOW A1,	
A5550001638	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E1YB	YELLOW B1		S2PR-E1YB, YELLOW B1,	
A5550001697	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3B	BLUE		S2PR-E3B, BLUE,	
A5550001700	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3G	GREEN		S2PR-E3G, GREEN,	Кнопочный переключатель, 22/25 мм, выступающий с подсветкой, Зелёный
A5550001698	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3GAD	GREEN A1 LED(DC)		S2PR-E3GAD, GREEN A1 LED(DC),	
A5550001721	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3GAL	GREEN A1 LED(AC)		S2PR-E3GAL, GREEN A1 LED(AC),	
A5550001741	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3GBD	GREEN B1 LED(DC)		S2PR-E3GBD, GREEN B1 LED(DC),	

A5550001761	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3GBL	GREEN B1 LED(AC)		S2PR-E3GBL, GREEN B1 LED(AC),	
A5550001694	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3R	RED		S2PR-E3R, RED,	Кнопочный переключатель, 22/25 мм, выступающий с подсветкой, Красный
A5550001707	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3R2AD	RED A2 LED(DC)		S2PR-E3R2AD, RED A2 LED(DC),	
A5550001708	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3R2ADM	RED A2 LED(DC)		S2PR-E3R2ADM, RED A2 LED(DC),	
A5550001727	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3R2AL	RED A2 LED(AC)		S2PR-E3R2AL, RED A2 LED(AC),	
A5550001728	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3R2ALM	RED A2 LED(AC)		S2PR-E3R2ALM, RED A2 LED(AC),	
A5550001747	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3R2BD	RED B2 LED(DC)		S2PR-E3R2BD, RED B2 LED(DC),	
A5550001748	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3R2BDM	RED B2 LED(DC)		S2PR-E3R2BDM, RED B2 LED(DC),	
A5550001767	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3R2BL	RED B2 LED(AC)		S2PR-E3R2BL, RED B2 LED(AC),	
A5550001768	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3R2BLM	RED B2 LED(AC)		S2PR-E3R2BLM, RED B2 LED(AC),	
A5550001777	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3RABD	RED A1 B1 LED(DC)		S2PR-E3RABD, RED A1 B1 LED(DC),	
A5550001778	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3RABDM	RED A1 B1 LED(DC)		S2PR-E3RABDM, RED A1 B1 LED(DC),	
A5550001787	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3RABL	RED A1 B1 LED(AC)		S2PR-E3RABL, RED A1 B1 LED(AC),	
A5550001788	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3RABLM	RED A1 B1 LED(AC)		S2PR-E3RABLM, RED A1 B1 LED(AC),	
A5550001692	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3RAD	RED A1 LED(DC)		S2PR-E3RAD, RED A1 LED(DC),	
A5550001693	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3RADM	RED A1 LED(DC)		S2PR-E3RADM, RED A1 LED(DC),	
A5550001717	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3RAL	RED A1 LED(AC)		S2PR-E3RAL, RED A1 LED(AC),	
A5550001718	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3RALM	RED A1 LED(AC)		S2PR-E3RALM, RED A1 LED(AC),	
A5550001737	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3RBD	RED B1 LED(DC)		S2PR-E3RBD, RED B1 LED(DC),	
A5550001738	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3RBDM	RED B1 LED(DC)		S2PR-E3RBDM, RED B1 LED(DC),	
A5550001757	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3RBL	RED B1 LED(AC)		S2PR-E3RBL, RED B1 LED(AC),	
A5550001758	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3RBLM	RED B1 LED(AC)		S2PR-E3RBLM, RED B1 LED(AC),	
A5550001706	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3W	WHITE		S2PR-E3W, WHITE,	
A5550001703	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-E3Y	YELLOW		S2PR-E3Y, YELLOW,	

A5550001390	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1B	BLUE		S2PR-P1B, BLUE,	Кнопочный переключатель, 22/25 мм, выступающий, Синий
A5550001490	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1B2AB	BLUE A2 B1		S2PR-P1B2AB, BLUE A2 B1,	
A5550001388	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1BA	BLUE		S2PR-P1BA, BLUE,	
A5550001480	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1BAB	BLUE A1 B1		S2PR-P1BAB, BLUE A1 B1,	
A5550001389	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1BAM	BLUE		S2PR-P1BAM, BLUE,	
A5550001590	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1BB	BLUE B1		S2PR-P1BB, BLUE B1,	
A5550001393	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1G	GREEN		S2PR-P1G, GREEN,	Кнопочный переключатель, 22/25 мм, выступающий, Зелённый
A5550001492	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1G2AB	GREEN A2 B1		S2PR-P1G2AB, GREEN A2 B1,	
A5550001391	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1GA	GREEN		S2PR-P1GA, GREEN,	Кнопочный переключатель, 22/25 мм, выступающий, Зелённый
A5550001482	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1GAB	GREEN A1 B1		S2PR-P1GAB, GREEN A1 B1,	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Зеленый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
A5550001392	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1GAM	GREEN		S2PR-P1GAM, GREEN,	
A5550001592	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1GB	GREEN B1		S2PR-P1GB, GREEN B1,	
A5550001593	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1GBM	GREEN B1		S2PR-P1GBM, GREEN B1,	
A5550001399	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1K	BLACK		S2PR-P1K, BLACK,	Кнопочный переключатель, 22/25 мм, выступающий, Чёрный
A5550001447	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1K2AM	BLACK A2		S2PR-P1K2AM, BLACK A2,	
A5550001397	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1KA	BLACK		S2PR-P1KA, BLACK,	Кнопочный переключатель, 22/25 мм, выступающий, Чёрный
A5550001486	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1KAB	BLACK A1 B1		S2PR-P1KAB, BLACK A1 B1,	
A5550001398	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1KAM	BLACK		S2PR-P1KAM, BLACK,	
A5550001596	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1KB	BLACK B1		S2PR-P1KB, BLACK B1,	
A5550001387	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1R	RED		S2PR-P1R, RED,	Кнопочный переключатель, 22/25 мм, выступающий, Красный
A5550001438	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1R2A	RED A2		S2PR-P1R2A, RED A2,	
A5550001488	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1R2AB	RED A2 B1		S2PR-P1R2AB, RED A2 B1,	

A5550001489	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1R2ABM	RED A2 B1		S2PR-P1R2ABM, RED A2 B1,	
A5550001439	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1R2AM	RED A2		S2PR-P1R2AM, RED A2,	
A5550001458	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1R2B	RED B2		S2PR-P1R2B, RED B2,	
A5550001459	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1R2BM	RED B2		S2PR-P1R2BM, RED B2,	
A5550001448	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1R3A	RED A3		S2PR-P1R3A, RED A3,	
A5550001449	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1R3AM	RED A3		S2PR-P1R3AM, RED A3,	
A5550001468	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1R3B	RED B3		S2PR-P1R3B, RED B3,	
A5550001469	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1R3BM	RED B3		S2PR-P1R3BM, RED B3,	
A5550001385	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1RA	RED		S2PR-P1RA, RED,	
A5550001498	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1RA2B	RED A1 B2		S2PR-P1RA2B, RED A1 B2,	
A5550001499	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1RA2BM	RED A1 B2		S2PR-P1RA2BM, RED A1 B2,	
A5550001478	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1RAB	RED A1 B1		S2PR-P1RAB, RED A1 B1,	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Красный, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
A5550001479	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1RABM	RED A1 B1		S2PR-P1RABM, RED A1 B1,	
A5550001386	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1RAM	RED		S2PR-P1RAM, RED,	
A5550001588	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1RB	RED B1		S2PR-P1RB, RED B1,	Кнопочный переключатель, 22/25 мм, выступающий, Красный
A5550001589	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1RBM	RED B1		S2PR-P1RBM, RED B1,	
A5550001396	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1Y	YELLOW		S2PR-P1Y, YELLOW,	Кнопочный переключатель, 22/25 мм, выступающий, Желтый
A5550001394	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1YA	YELLOW		S2PR-P1YA, YELLOW,	Кнопочный выключатель, без подсветки, выступающего типа, 22/25, Желтый, Нормально открытый, 110В~/10А, 220В~/5А
A5550001484	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1YAB	YELLOW A1 B1		S2PR-P1YAB, YELLOW A1 B1,	
A5550001395	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1YAM	YELLOW		S2PR-P1YAM, YELLOW,	
A5550001594	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P1YB	YELLOW B1		S2PR-P1YB, YELLOW B1,	
A5550001408	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3B	BLUE		S2PR-P3B, BLUE,	Кнопочный переключатель, 22/25 мм, выступающий с подсветкой, Синий

A5550001540	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3BABD	BLUE A1 B1 LED(DC)		S2PR-P3BABD, BLUE A1 B1 LED(DC),	
A5550001580	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3BABL	BLUE A1 B1 LED(AC)		S2PR-P3BABL, BLUE A1 B1 LED(AC),	
A5550001406	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3BAD	BLUE		S2PR-P3BAD, BLUE,	
A5550001407	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3BADM	BLUE		S2PR-P3BADM, BLUE,	
A5550001430	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3BAL	BLUE		S2PR-P3BAL, BLUE,	
A5550001431	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3BALM	BLUE		S2PR-P3BALM, BLUE,	
A5550001412	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3G	GREEN		S2PR-P3G, GREEN,	Кнопочный переключатель, 22/25 мм, выступающий с подсветкой, Зелёный
A5550001542	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3GABD	GREEN A1 B1 LED(DC)		S2PR-P3GABD, GREEN A1 B1 LED(DC),	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Зеленый, 1 нормально открытый, 1 нормально закрытый, СИД 12-30 В~/В~
A5550001583	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3GABL	GREEN A1 B1 LED(AC)		S2PR-P3GABL, GREEN A1 B1 LED(AC),	
A5550001582	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3GABLM	GREEN A1 B1 LED(AC)		S2PR-P3GABLM, GREEN A1 B1 LED(AC),	
A5550001415	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3GAD	GREEN		S2PR-P3GAD, GREEN,	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Зеленый, Нормально открытый, СИД 12-30 В~/В~
A5550001411	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3GADM	GREEN		S2PR-P3GADM, GREEN,	
A5550001432	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3GAL	GREEN		S2PR-P3GAL, GREEN,	Кнопочный переключатель, 22/25 мм, выступающий с подсветкой, Зелёный
A5550001433	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3GALM	GREEN		S2PR-P3GALM, GREEN,	
A5550001522	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3GBD	GREEN B1 LED(DC)		S2PR-P3GBD, GREEN B1 LED(DC),	
A5550001562	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3GBL	GREEN B1 LED(AC)		S2PR-P3GBL, GREEN B1 LED(AC),	
A5550001402	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3R	RED		S2PR-P3R, RED,	Кнопочный переключатель, 22/25 мм, выступающий с подсветкой, Красный
A5550001508	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3R2AD	RED A2 LED(DC)		S2PR-P3R2AD, RED A2 LED(DC),	

A5550001509	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3R2ADM	RED A2 LED(DC)		S2PR-P3R2ADM, RED A2 LED(DC),	
A5550001548	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3R2AL	RED A2 LED(AC)		S2PR-P3R2AL, RED A2 LED(AC),	
A5550001549	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3R2ALM	RED A2 LED(AC)		S2PR-P3R2ALM, RED A2 LED(AC),	
A5550001528	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3R2BD	RED B2 LED(DC)		S2PR-P3R2BD, RED B2 LED(DC),	
A5550001529	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3R2BDM	RED B2 LED(DC)		S2PR-P3R2BDM, RED B2 LED(DC),	
A5550001568	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3R2BL	RED B2 LED(AC)		S2PR-P3R2BL, RED B2 LED(AC),	
A5550001569	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3R2BLM	RED B2 LED(AC)		S2PR-P3R2BLM, RED B2 LED(AC),	
A5550001538	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3RABD	RED A1 B1 LED(DC)		S2PR-P3RABD, RED A1 B1 LED(DC),	
A5550001539	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3RABDM	RED A1 B1 LED(DC)		S2PR-P3RABDM, RED A1 B1 LED(DC),	
A5550001579	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3RABL	RED A1 B1 LED(AC)		S2PR-P3RABL, RED A1 B1 LED(AC),	
A5550001578	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3RABLM	RED A1 B1 LED(AC)		S2PR-P3RABLM, RED A1 B1 LED(AC),	
A5550001405	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3RAD	RED(NONE LED-DC)		S2PR-P3RAD, RED(NONE LED-DC),	
A5550001401	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3RAD	RED		S2PR-P3RAD, RED,	
A5550001400	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3RADM	RED		S2PR-P3RADM, RED,	

A5550001428	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3RAL	RED		S2PR-P3RAL, RED,	
A5550001429	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3RALM	RED		S2PR-P3RALM, RED,	
A5550001518	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3RBD	RED B1 LED(DC)		S2PR-P3RBD, RED B1 LED(DC),	
A5550001519	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3RBDM	RED B1 LED(DC)		S2PR-P3RBDM, RED B1 LED(DC),	
A5550001558	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3RBL	RED B1 LED(AC)		S2PR-P3RBL, RED B1 LED(AC),	Кнопочный переключатель, 22/25 мм, выступающий с подсветкой, Красный
A5550001559	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3RBLM	RED B1 LED(AC)		S2PR-P3RBLM, RED B1 LED(AC),	
A5550001425	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3W	WHITE		S2PR-P3W, WHITE,	Кнопочный переключатель, 22/25 мм, выступающий с подсветкой, Белый
A5550001556	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3W2AL	WHITE A2 LED(AC)		S2PR-P3W2AL, WHITE A2 LED(AC),	
A5550001546	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3WABD	WHITE A1 B1 LED(DC)		S2PR-P3WABD, WHITE A1 B1 LED(DC),	
A5550001422	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3WAD	WHITE		S2PR-P3WAD, WHITE,	Кнопочный выключатель, с подсветкой, выступающего типа, 22/25, Белый, Нормально открытый, СИД 12-30 В=В-
A5550001436	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3WAL	WHITE		S2PR-P3WAL, WHITE,	
A5550001437	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3WALM	WHITE		S2PR-P3WALM, WHITE,	
A5550001526	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3WBD	WHITE B1 LED(DC)		S2PR-P3WBD, WHITE B1 LED(DC),	
A5550001527	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3WBDM	WHITE B1 LED(DC)		S2PR-P3WBDM, WHITE B1 LED(DC),	

A5550001566	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3WBL	WHITE B1 LED(AC)		S2PR-P3WBL, WHITE B1 LED(AC),	
A5550001419	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3Y	YELLOW		S2PR-P3Y, YELLOW,	Кнопочный переключатель, 22/25 мм, выступающий с подсветкой, Жёлтый
A5550001544	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3YABD	YELLOW A1 B1 LED(DC)		S2PR-P3YABD, YELLOW A1 B1 LED(DC),	
A5550001584	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3YABL	YELLOW A1 B1 LED(AC)		S2PR-P3YABL, YELLOW A1 B1 LED(AC),	
A5550001417	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3YAD	YELLOW		S2PR-P3YAD, YELLOW,	
A5550001434	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3YAL	YELLOW		S2PR-P3YAL, YELLOW,	
A5550001435	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3YALM	YELLOW		S2PR-P3YALM, YELLOW,	
A5550001524	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3YBD	YELLOW B1 LED(DC)		S2PR-P3YBD, YELLOW B1 LED(DC),	
A5550001564	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PR SERIES	S2PR-P3YBL	YELLOW B1 LED(AC)		S2PR-P3YBL, YELLOW B1 LED(AC),	
A5550002765	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1B	BLUE		S2PRS-P1B, BLUE,	
A5550002763	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1BA	BLUE A1		S2PRS-P1BA, BLUE A1,	
A5550002768	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1G	GREEN		S2PRS-P1G, GREEN,	
A5550002766	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1GA	GREEN A1		S2PRS-P1GA, GREEN A1,	
A5550002798	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1GB	GREEN B1		S2PRS-P1GB, GREEN B1,	
A5550002774	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1K	BLACK		S2PRS-P1K, BLACK,	

A5550002772	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1KA	BLACK A1		S2PRS-P1KA, BLACK A1,	
A5550002762	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1R	RED		S2PRS-P1R, RED,	
A5550002775	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1R2A	RED A2		S2PRS-P1R2A, RED A2,	
A5550002834	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1R2AB	RED A2 B1		S2PRS-P1R2AB, RED A2 B1,	
A5550002835	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1R2ABM	RED A2 B1		S2PRS-P1R2ABM, RED A2 B1,	
A5550002776	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1R2AM	RED A2		S2PRS-P1R2AM, RED A2,	
A5550002804	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1R2B	RED B2		S2PRS-P1R2B, RED B2,	
A5550002805	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1R2BM	RED B2		S2PRS-P1R2BM, RED B2,	
A5550002785	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1R3A	RED A3		S2PRS-P1R3A, RED A3,	
A5550002786	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1R3AM	RED A3		S2PRS-P1R3AM, RED A3,	
A5550002814	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1R3B	RED B3		S2PRS-P1R3B, RED B3,	
A5550002815	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1R3BM	RED B3		S2PRS-P1R3BM, RED B3,	
A5550002760	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1RA	RED A1		S2PRS-P1RA, RED A1,	
A5550002844	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1RA2B	RED A1 B2		S2PRS-P1RA2B, RED A1 B2,	

A5550002845	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1RA2BM	RED A1 B2		S2PRS-P1RA2BM, RED A1 B2,	
A5550002824	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1RAB	RED A1 B1		S2PRS-P1RAB, RED A1 B1,	
A5550002825	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1RABM	RED A1 B1		S2PRS-P1RABM, RED A1 B1,	
A5550002761	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1RAM	RED A1		S2PRS-P1RAM, RED A1,	
A5550002794	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1RB	RED B1		S2PRS-P1RB, RED B1,	
A5550002795	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1RBM	RED B1		S2PRS-P1RBM, RED B1,	
A5550002771	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1Y	YELLOW		S2PRS-P1Y, YELLOW,	
A5550002800	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P1YB	YELLOW B1		S2PRS-P1YB, YELLOW B1,	
A5550002860	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3B	BLUE		S2PRS-P3B, BLUE,	
A5550002858	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BAD	BLUE A1 LED(DC)		S2PRS-P3BAD, BLUE A1 LED(DC),	
A5550002886	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3BAL	BLUE A1 LED(AC)		S2PRS-P3BAL, BLUE A1 LED(AC),	
A5550002864	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3G	GREEN		S2PRS-P3G, GREEN,	
A5550002958	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GABL	GREEN AB LED(AC)		S2PRS-P3GABL, GREEN AB LED(AC),	
A5550002862	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GAD	GREEN A1 LED(DC)		S2PRS-P3GAD, GREEN A1 LED(DC),	
A5550002888	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GAL	GREEN A1 LED(AC)		S2PRS-P3GAL, GREEN A1 LED(AC),	
A5550002908	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GBD	GREEN B1 LED(DC)		S2PRS-P3GBD, GREEN B1 LED(DC),	
A5550002928	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GBL	GREEN B1 LED(AC)		S2PRS-P3GBL, GREEN B1 LED(AC),	
A5550003075	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GLAD	GREEN A1 LED(DC)LEFT/RIGHT		S2PRS-P3GLAD, GREEN A1 LED(DC)LEFT/RIGHT,	
A5550003127	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GLAL	GREEN A1 LED(AC)LEFT/RIGHT		S2PRS-P3GLAL, GREEN A1 LED(AC)LEFT/RIGHT,	

A5550003097	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GLBD	GREEN B1 LED(DC)LEFT/RIGHT		S2PRS-P3GLBD, GREEN B1 LED(DC)LEFT/RIGHT,
A5550003147	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3GLBL	GREEN B1 LED(AC)LEFT/RIGHT		S2PRS-P3GLBL, GREEN B1 LED(AC)LEFT/RIGHT,
A5550002856	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3R	RED		S2PRS-P3R, RED,
A5550002874	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3R2AD	RED A2 LED(DC)		S2PRS-P3R2AD, RED A2 LED(DC),
A5550002875	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3R2ADM	RED A2 LED(DC)		S2PRS-P3R2ADM, RED A2 LED(DC),
A5550002894	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3R2AL	RED A2 LED(AC)		S2PRS-P3R2AL, RED A2 LED(AC),
A5550002895	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3R2ALM	RED A2 LED(AC)		S2PRS-P3R2ALM, RED A2 LED(AC),
A5550002914	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3R2BD	RED B2 LED(DC)		S2PRS-P3R2BD, RED B2 LED(DC),
A5550002915	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3R2BDM	RED B2 LED(DC)		S2PRS-P3R2BDM, RED B2 LED(DC),
A5550002934	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3R2BL	RED B2 LED(AC)		S2PRS-P3R2BL, RED B2 LED(AC),
A5550002935	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3R2BLM	RED B2 LED(AC)		S2PRS-P3R2BLM, RED B2 LED(AC),
A5550002944	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RABD	RED AB LED(DC)		S2PRS-P3RABD, RED AB LED(DC),
A5550002945	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RABDM	RED AB LED(DC)		S2PRS-P3RABDM, RED AB LED(DC),
A5550002954	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RABL	RED AB LED(AC)		S2PRS-P3RABL, RED AB LED(AC),
A5550002955	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RABLM	RED AB LED(AC)		S2PRS-P3RABLM, RED AB LED(AC),

A5550002854	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RAD	RED A1 LED(DC)		S2PRS-P3RAD, RED A1 LED(DC),
A5550002855	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RADM	RED A1 LED(DC)		S2PRS-P3RADM, RED A1 LED(DC),
A5550002884	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RAL	RED A1 LED(AC)		S2PRS-P3RAL, RED A1 LED(AC),
A5550002885	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RALM	RED A1 LED(AC)		S2PRS-P3RALM, RED A1 LED(AC),
A5550002904	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RBD	RED B1 LED(DC)		S2PRS-P3RBD, RED B1 LED(DC),
A5550002905	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RBDM	RED B1 LED(DC)		S2PRS-P3RBDM, RED B1 LED(DC),
A5550002924	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RBL	RED B1 LED(AC)		S2PRS-P3RBL, RED B1 LED(AC),
A5550002925	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RBLM	RED B1 LED(AC)		S2PRS-P3RBLM, RED B1 LED(AC),
A5550003084	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RL2AD	RED A2 LED(DC)LEFT/RIGHT		S2PRS-P3RL2AD, RED A2 LED(DC)LEFT/RIGHT,
A5550003085	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RL2ADM	RED A2 LED(DC)LEFT/RIGHT		S2PRS-P3RL2ADM, RED A2 LED(DC)LEFT/RIGHT,
A5550003133	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RL2AL	RED A2 LED(AC)LEFT/RIGHT		S2PRS-P3RL2AL, RED A2 LED(AC)LEFT/RIGHT,
A5550003134	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RL2ALM	RED A2 LED(AC)LEFT/RIGHT		S2PRS-P3RL2ALM, RED A2 LED(AC)LEFT/RIGHT,
A5550003103	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RL2BD	RED B2 LED(DC)LEFT/RIGHT		S2PRS-P3RL2BD, RED B2 LED(DC)LEFT/RIGHT,
A5550003104	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RL2BDM	RED B2 LED(DC)LEFT/RIGHT		S2PRS-P3RL2BDM, RED B2 LED(DC)LEFT/RIGHT,

A5550003153	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RL2BL	RED B2 LED(AC)LEFT/RIGHT	S2PRS-P3RL2BL, RED B2 LED(AC)LEFT/RIGHT,
A5550003154	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RL2BLM	RED B2 LED(AC)LEFT/RIGHT	S2PRS-P3RL2BLM, RED B2 LED(AC)LEFT/RIGHT,
A5550003113	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RLABD	RED A1 B1 LED(DC)LEFT/RIGHT	S2PRS-P3RLABD, RED A1 B1 LED(DC)LEFT/RIGHT,
A5550003114	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RLABDM	RED A1 B1 LED(DC)LEFT/RIGHT	S2PRS-P3RLABDM, RED A1 B1 LED(DC)LEFT/RIGHT,
A5550003163	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RLABL	RED A1 B1 LED(AC)LEFT/RIGHT	S2PRS-P3RLABL, RED A1 B1 LED(AC)LEFT/RIGHT,
A5550003164	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RLABLM	RED A1 B1 LED(AC)LEFT/RIGHT	S2PRS-P3RLABLM, RED A1 B1 LED(AC)LEFT/RIGHT,
A5550003069	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RLAD	RED A1 LED(DC)LEFT/RIGHT	S2PRS-P3RLAD, RED A1 LED(DC)LEFT/RIGHT,
A5550003070	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RLADM	RED A1 LED(DC)LEFT/RIGHT	S2PRS-P3RLADM, RED A1 LED(DC)LEFT/RIGHT,
A5550003123	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RLAL	RED A1 LED(AC)LEFT/RIGHT	S2PRS-P3RLAL, RED A1 LED(AC)LEFT/RIGHT,
A5550003124	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RLALM	RED A1 LED(AC)LEFT/RIGHT	S2PRS-P3RLALM, RED A1 LED(AC)LEFT/RIGHT,
A5550003093	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RLBD	RED B1 LED(DC)LEFT/RIGHT	S2PRS-P3RLBD, RED B1 LED(DC)LEFT/RIGHT,
A5550003094	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RLBDM	RED B1 LED(DC)LEFT/RIGHT	S2PRS-P3RLBDM, RED B1 LED(DC)LEFT/RIGHT,
A5550003143	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RLBL	RED B1 LED(AC)LEFT/RIGHT	S2PRS-P3RLBL, RED B1 LED(AC)LEFT/RIGHT,
A5550003144	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RLBLM	RED B1 LED(AC)LEFT/RIGHT	S2PRS-P3RLBLM, RED B1 LED(AC)LEFT/RIGHT,

A5550003016	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RU	RED		S2PRS-P3RU, RED,	
A5550002974	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RU2AD	RED A2 LED(DC)UP/DOWN		S2PRS-P3RU2AD, RED A2 LED(DC)UP/DOWN,	
A5550002975	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RU2ADM	RED A2 LED(DC)UP/DOWN		S2PRS-P3RU2ADM, RED A2 LED(DC)UP/DOWN,	
A5550003029	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RU2AL	RED A2 LED(AC)UP/DOWN		S2PRS-P3RU2AL, RED A2 LED(AC)UP/DOWN,	
A5550003030	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RU2ALM	RED A2 LED(AC)UP/DOWN		S2PRS-P3RU2ALM, RED A2 LED(AC)UP/DOWN,	
A5550002994	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RU2BD	RED B2 LED(DC)UP/DOWN		S2PRS-P3RU2BD, RED B2 LED(DC)UP/DOWN,	
A5550002995	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RU2BDM	RED B2 LED(DC)UP/DOWN		S2PRS-P3RU2BDM, RED B2 LED(DC)UP/DOWN,	
A5550003049	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RU2BL	RED B2 LED(AC)UP/DOWN		S2PRS-P3RU2BL, RED B2 LED(AC)UP/DOWN,	
A5550003050	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RU2BLM	RED B2 LED(AC)UP/DOWN		S2PRS-P3RU2BLM, RED B2 LED(AC)UP/DOWN,	
A5550003004	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RUABD	RED A1 B1 LED(DC)UP/DOWN		S2PRS-P3RUABD, RED A1 B1 LED(DC)UP/DOWN,	
A5550003005	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RUABDM	RED A1 B1 LED(DC)UP/DOWN		S2PRS-P3RUABDM, RED A1 B1 LED(DC)UP/DOWN,	
A5550003059	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RUABL	RED A1 B1 LED(AC)UP/DOWN		S2PRS-P3RUABL, RED A1 B1 LED(AC)UP/DOWN,	
A5550003060	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RUABLM	RED A1 B1 LED(AC)UP/DOWN		S2PRS-P3RUABLM, RED A1 B1 LED(AC)UP/DOWN,	
A5550002964	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RUAD	RED A1 LED(DC)UP/DOWN		S2PRS-P3RUAD, RED A1 LED(DC)UP/DOWN,	

A5550002965	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RUADM	RED A1 LED(DC)UP/DOWN		S2PRS-P3RUADM, RED A1 LED(DC)UP/DOWN,	
A5550003014	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RUAL	RED A1 LED(AC)UP/DOWN		S2PRS-P3RUAL, RED A1 LED(AC)UP/DOWN,	
A5550003015	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RUALM	RED A1 LED(AC)UP/DOWN		S2PRS-P3RUALM, RED A1 LED(AC)UP/DOWN,	
A5550002984	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RUBD	RED B1 LED(DC)UP/DOWN		S2PRS-P3RUBD, RED B1 LED(DC)UP/DOWN,	
A5550002985	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RUBDM	RED B1 LED(DC)UP/DOWN		S2PRS-P3RUBDM, RED B1 LED(DC)UP/DOWN,	
A5550003039	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RUBL	RED B1 LED(AC)UP/DOWN		S2PRS-P3RUBL, RED B1 LED(AC)UP/DOWN,	
A5550003040	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3RUBLM	RED B1 LED(AC)UP/DOWN		S2PRS-P3RUBLM, RED B1 LED(AC)UP/DOWN,	
A5550002870	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WAD	WHITE A1 LED(DC)		S2PRS-P3WAD, WHITE A1 LED(DC),	
A5550002972	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3WUAD	WHITE A1 LED(DC)UP/DOWN		S2PRS-P3WUAD, WHITE A1 LED(DC) UP/DOWN	Квадратный кнопочный выключатель, выступающий, с подсветкой, белый, стрелки (вверх/вниз), Ø22/25
A5550002868	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3Y	YELLOW		S2PRS-P3Y, YELLOW,	
A5550002910	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YBD	YELLOW B1 LED(DC)		S2PRS-P3YBD, YELLOW B1 LED(DC),	
A5550002930	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRS SERIES	S2PRS-P3YBL	YELLOW B1 LED(AC)		S2PRS-P3YBL, YELLOW B1 LED(AC),	
A5550002865	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRSU SERIES	S2PRSU-P3G	GREEN(NO PRINTING)		S2PRSU-P3G, GREEN(NO PRINTING),	Кнопочный переключатель, 22/25 мм, выступающий с подсветкой, Зелёный
A5550002857	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRSU SERIES	S2PRSU-P3R	RED(NO PRINTING)		S2PRSU-P3R, RED(NO PRINTING),	Кнопочный переключатель, 22/25 мм, выступающий с подсветкой, Красный

A5550001404	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRU SERIES	S2PRU-E3R	RED		S2PRU-E3R, RED,	
A5550001409	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRU SERIES	S2PRU-P3B	BLUE(NO PRINTING)		S2PRU-P3B, BLUE(NO PRINTING),	Кнопочный переключатель, 22/25 мм, выступающий с подсветкой, стрелки вверх/вниз, самовозврат, Синий
A5550012212	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRU SERIES	S2PRU-P3BAD	BLUE		S2PRU-P3BAD, BLUE,	
A5550001413	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRU SERIES	S2PRU-P3G	GREEN(NO PRINTING)		S2PRU-P3G, GREEN(NO PRINTING),	
A5550010478	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRU SERIES	S2PRU-P3GAD	GREEN		S2PRU-P3GAD, GREEN,	
A5550001403	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRU SERIES	S2PRU-P3R	RED(NO PRINTING)		S2PRU-P3R, RED(NO PRINTING),	
A5550010477	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRU SERIES	S2PRU-P3RAD	RED		S2PRU-P3RAD, RED,	
A5550001426	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRU SERIES	S2PRU-P3W	WHITE(NO PRINTING)		S2PRU-P3W, WHITE(NO PRINTING),	
A5550010479	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRU SERIES	S2PRU-P3WAD	WHITE		S2PRU-P3WAD, WHITE,	
A5550001420	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRU SERIES	S2PRU-P3Y	YELLOW(NO PRINTING)	GL	S2PRU-P3Y, YELLOW(NO PRINTING), GL	Кнопочный переключатель, 22/25 мм, выступающий с подсветкой, стрелки вверх/вниз, самовозврат, Желтый
A5550012213	CONTROL SWITCH	PUSH BUTTON SWITCH	S2PRU SERIES	S2PRU-P3YAD	YELLOW		S2PRU-P3YAD, YELLOW,	
A5550002041	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P1W	WHITE		S2TR-P1W, WHITE,	
A5550002040	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P1WABM	WHITE		S2TR-P1WABM, WHITE,	
A5550002036	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P3W	WHITE		S2TR-P3W, WHITE,	Двойной кнопочный выключатель 22/25 мм, Белый

A5550002046	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P3W2AD	WHITE		S2TR-P3W2AD, WHITE,	
A5550002035	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P3WABD	BLACK HEAD KNOB		S2TR-P3WABD, BLACK HEAD KNOB,	
A5550002033	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P3WABD	WHITE		S2TR-P3WABD, WHITE,	Двойной кнопочный выключатель 22/25 мм, Белый, 1 нормально открытый, 1 нормально закрытый, С подсветкой, С самовозвратом, СИД 12-30 В=/В~
A5550002034	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P3WABDM	WHITE		S2TR-P3WABDM, WHITE,	
A5550002037	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P3WABL	WHITE		S2TR-P3WABL, WHITE,	Двойной кнопочный выключатель 22/25 мм, Белый, 1 нормально открытый, 1 нормально закрытый, С подсветкой, С самовозвратом, СИД 100-220В~
A5550002038	CONTROL SWITCH	PUSH BUTTON SWITCH	S2TR SERIES	S2TR-P3WABLM	WHITE		S2TR-P3WABLM, WHITE,	
A5550009451	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1R	RED(HEAD)		S2SR-S1R, RED(HEAD),	
A5550001901	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1R2A	RED A2		S2SR-S1R2A, RED A2,	
A5550001902	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1R2AM	RED A2		S2SR-S1R2AM, RED A2,	
A5550001905	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1R2B	RED B2		S2SR-S1R2B, RED B2,	
A5550001906	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1R2BM	RED B2		S2SR-S1R2BM, RED B2,	
A5550001899	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1RA	RED A		S2SR-S1RA, RED A,	
A5550001907	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1RAB	RED AB		S2SR-S1RAB, RED AB,	
A5550001908	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1RABM	RED AB		S2SR-S1RABM, RED AB,	
A5550001900	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1RAM	RED A		S2SR-S1RAM, RED A,	
A5550001903	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1RB	RED B		S2SR-S1RB, RED B,	
A5550001904	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1RBM	RED B		S2SR-S1RBM, RED B,	
A5550009452	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1W	WHITE(HEAD)		S2SR-S1W, WHITE(HEAD),	Селекторный переключатель, 22/25 мм, 2-х позиционный, с самовозвратом, С длинной рукояткой, Белый
A5550001911	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1W2A	WHITE A2		S2SR-S1W2A, WHITE A2,	
A5550001910	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S1WAM	WHITE A		S2SR-S1WAM, WHITE A,	
A5550001920	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2R2A	RED A2		S2SR-S2R2A, RED A2,	
A5550001921	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2R2AM	RED A2		S2SR-S2R2AM, RED A2,	

A5550001924	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2R2B	RED B2		S2SR-S2R2B, RED B2,	
A5550001925	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2R2BM	RED B2		S2SR-S2R2BM, RED B2,	
A5550001815	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2RA	RED		S2SR-S2RA, RED,	
A5550001926	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2RAB	RED AB		S2SR-S2RAB, RED AB,	
A5550001927	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2RABM	RED AB		S2SR-S2RABM, RED AB,	
A5550001919	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2RAM	RED A		S2SR-S2RAM, RED A,	
A5550001922	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2RB	RED B		S2SR-S2RB, RED B,	
A5550001923	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S2RBM	RED B		S2SR-S2RBM, RED B,	
A5550001799	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3R	RED		S2SR-S3R, RED,	Селекторный переключатель, 22/25 мм, 2-позиционный, С фиксацией, С короткой рукояткой, Красный
A5550001837	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3R2A	RED A2		S2SR-S3R2A, RED A2,	
A5550001838	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3R2AM	RED A2		S2SR-S3R2AM, RED A2,	
A5550001845	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3R2B	RED B2		S2SR-S3R2B, RED B2,	
A5550001846	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3R2BM	RED B2		S2SR-S3R2BM, RED B2,	
A5550001797	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3RA	RED		S2SR-S3RA, RED,	
A5550001849	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3RAB	RED A1 B1		S2SR-S3RAB, RED A1 B1,	
A5550001850	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3RABM	RED A1 B1		S2SR-S3RABM, RED A1 B1,	
A5550001798	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3RAM	RED		S2SR-S3RAM, RED,	
A5550001841	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3RB	RED B1		S2SR-S3RB, RED B1,	
A5550001842	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3RBM	RED B1		S2SR-S3RBM, RED B1,	
A5550001808	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3W	WHITE		S2SR-S3W, WHITE,	Селекторный переключатель, 22/25 мм, 2-позиционный, С фиксацией, С короткой рукояткой, Белый
A5550001835	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3W2A	WHITE A2		S2SR-S3W2A, WHITE A2,	
A5550001843	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3W2B	WHITE B2		S2SR-S3W2B, WHITE B2,	
A5550001806	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3WA	WHITE		S2SR-S3WA, WHITE,	Селекторный переключатель, 22/25, 2-позиционный, С фиксацией, С короткой рукояткой, Белый, 1 нормально открытый, 110В~/10А, 220В~/5А
A5550001847	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3WAB	WHITE A1 B1		S2SR-S3WAB, WHITE A1 B1,	
A5550001807	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3WAM	WHITE		S2SR-S3WAM, WHITE,	
A5550001839	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S3WB	WHITE B1		S2SR-S3WB, WHITE B1,	
A5550001818	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4R	RED		S2SR-S4R, RED,	Селекторный переключатель, 22/25 мм, 2-позиционный, С фиксацией, С длинной рукояткой, Красный
A5550001869	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4R2A	RED A2		S2SR-S4R2A, RED A2,	

A5550001870	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4R2AM	RED A2		S2SR-S4R2AM, RED A2,	
A5550001877	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4R2B	RED B2		S2SR-S4R2B, RED B2,	
A5550001878	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4R2BM	RED B2		S2SR-S4R2BM, RED B2,	
A5550001816	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4RA	RED		S2SR-S4RA, RED,	
A5550001881	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4RAB	RED A1 B1		S2SR-S4RAB, RED A1 B1,	
A5550001882	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4RABM	RED A1 B1		S2SR-S4RABM, RED A1 B1,	
A5550001817	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4RAM	RED		S2SR-S4RAM, RED,	
A5550001873	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4RB	RED B1		S2SR-S4RB, RED B1,	
A5550001874	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4RBM	RED B1		S2SR-S4RBM, RED B1,	
A5550001828	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4W	WHITE		S2SR-S4W, WHITE,	Селекторный переключатель, 22/25 мм, 2-позиционный, С фиксацией, С длинной рукояткой, Белый
A5550001867	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4W2A	WHITE A2		S2SR-S4W2A, WHITE A2,	
A5550001826	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4WA	WHITE		S2SR-S4WA, WHITE,	Селекторный переключатель, 22/25 мм, 2-позиционный, С фиксацией, С длинной рукояткой, Белый, 1 нормально открытый, 110В~/10А, 220В~/5А
A5550001880	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4WABM	WHITE A1 B1		S2SR-S4WABM, WHITE A1 B1,	
A5550001827	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4WAM	WHITE		S2SR-S4WAM, WHITE,	
A5550001871	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4WB	WHITE B1		S2SR-S4WB, WHITE B1,	
A5550001872	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S4WBM	WHITE B1		S2SR-S4WBM, WHITE B1,	
A5550001937	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5KR2A	RED A2		S2SR-S5KR2A, RED A2,	
A5550001938	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5KR2AM	RED A2		S2SR-S5KR2AM, RED A2,	
A5550001939	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5KR2B	RED B2		S2SR-S5KR2B, RED B2,	
A5550001940	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5KR2BM	RED B2		S2SR-S5KR2BM, RED B2,	
A5550001941	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5KRAB	RED AB		S2SR-S5KRAB, RED AB,	
A5550001942	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5KRABM	RED AB		S2SR-S5KRABM, RED AB,	
A5550001802	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5R	RED		S2SR-S5R, RED,	Селекторный переключатель, 22/25 мм, 3-позиционный, С самовозвратом, С короткой рукояткой, Красный
A5550001800	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5R2A	RED		S2SR-S5R2A, RED,	
A5550001801	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5R2AM	RED		S2SR-S5R2AM, RED,	
A5550001853	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5R2B	RED B2		S2SR-S5R2B, RED B2,	
A5550001854	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5R2BM	RED B2		S2SR-S5R2BM, RED B2,	
A5550001857	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5RAB	RED A1 B1		S2SR-S5RAB, RED A1 B1,	

A5550001858	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5RABM	RED A1 B1		S2SR-S5RABM, RED A1 B1,	
A5550001811	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5W	WHITE		S2SR-S5W, WHITE,	Селекторный переключатель, 22/25 мм, 3-позиционный, С самовозвратом, С короткой рукояткой, Белый
A5550001809	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5W2A	WHITE		S2SR-S5W2A, WHITE,	
A5550001855	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S5WAB	WHITE A1 B1		S2SR-S5WAB, WHITE A1 B1,	
A5550001949	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6KR2A	RED A2		S2SR-S6KR2A, RED A2,	
A5550001950	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6KR2AM	RED A2		S2SR-S6KR2AM, RED A2,	
A5550001951	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6KR2B	RED B2		S2SR-S6KR2B, RED B2,	
A5550001952	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6KR2BM	RED B2		S2SR-S6KR2BM, RED B2,	
A5550001953	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6KRAB	RED AB		S2SR-S6KRAB, RED AB,	
A5550001954	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6KRABM	RED AB		S2SR-S6KRABM, RED AB,	
A5550001821	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6R	RED		S2SR-S6R, RED,	Селекторный переключатель, 22/25 мм, 3-позиционный, С самовозвратом, С длинной рукояткой, Красный
A5550001819	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6R2A	RED		S2SR-S6R2A, RED,	
A5550001820	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6R2AM	RED		S2SR-S6R2AM, RED,	
A5550001885	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6R2B	RED B2		S2SR-S6R2B, RED B2,	
A5550001889	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6RAB	RED A1 B1		S2SR-S6RAB, RED A1 B1,	
A5550001890	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6RABM	RED A1 B1		S2SR-S6RABM, RED A1 B1,	
A5550001831	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6W	WHITE		S2SR-S6W, WHITE,	Селекторный переключатель, 22/25 мм, 3-позиционный, С самовозвратом, С длинной рукояткой, Белый
A5550001829	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6W2A	WHITE		S2SR-S6W2A, WHITE,	
A5550001830	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S6W2AM	WHITE		S2SR-S6W2AM, WHITE,	
A5550001961	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7KR2A	RED A2		S2SR-S7KR2A, RED A2,	
A5550001962	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7KR2AM	RED A2		S2SR-S7KR2AM, RED A2,	
A5550001963	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7KR2B	RED B2		S2SR-S7KR2B, RED B2,	
A5550001964	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7KR2BM	RED B2		S2SR-S7KR2BM, RED B2,	
A5550001965	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7KRAB	RED AB		S2SR-S7KRAB, RED AB,	
A5550001966	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7KRABM	RED AB		S2SR-S7KRABM, RED AB,	
A5550001805	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7R	RED		S2SR-S7R, RED,	Селекторный переключатель, 22/25 мм, 3-позиционный, С фиксацией, С короткой рукояткой, Красный
A5550001803	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7R2A	RED		S2SR-S7R2A, RED,	
A5550001804	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7R2AM	RED		S2SR-S7R2AM, RED,	

A5550001861	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7R2B	RED B2		S2SR-S7R2B, RED B2,	
A5550001862	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7R2BM	RED B2		S2SR-S7R2BM, RED B2,	
A5550001865	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7RAB	RED A1 B1		S2SR-S7RAB, RED A1 B1,	
A5550001866	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7RABM	RED A1 B1		S2SR-S7RABM, RED A1 B1,	
A5550001814	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7W	WHITE		S2SR-S7W, WHITE,	Селекторный переключатель, 22/25 мм, 3-позиционный, С фиксацией, С короткой рукояткой, Белый
A5550001812	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7W2A	WHITE		S2SR-S7W2A, WHITE,	Селекторный переключатель, 22/25 мм, 3-позиционный, С фиксацией, С короткой рукояткой, Белый, 2 нормально открытых 110В~/10А, 220В~/5А
A5550001813	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7W2AM	WHITE		S2SR-S7W2AM, WHITE,	
A5550001863	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7WAB	WHITE A1 B1		S2SR-S7WAB, WHITE A1 B1,	
A5550001864	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S7WABM	WHITE A1 B1		S2SR-S7WABM, WHITE A1 B1,	
A5550001973	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8KR2A	RED A2		S2SR-S8KR2A, RED A2,	
A5550001974	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8KR2AM	RED A2		S2SR-S8KR2AM, RED A2,	
A5550001975	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8KR2B	RED B2		S2SR-S8KR2B, RED B2,	
A5550001976	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8KR2BM	RED B2		S2SR-S8KR2BM, RED B2,	
A5550001977	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8KRAB	RED AB		S2SR-S8KRAB, RED AB,	
A5550001978	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8KRABM	RED AB		S2SR-S8KRABM, RED AB,	
A5550001824	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8R	RED		S2SR-S8R, RED,	Селекторный переключатель, 22/25 мм, 3-позиционный, С фиксацией, С длинной рукояткой, Красный
A5550001822	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8R2A	RED		S2SR-S8R2A, RED,	
A5550001823	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8R2AM	RED		S2SR-S8R2AM, RED,	
A5550001893	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8R2B	RED B2		S2SR-S8R2B, RED B2,	
A5550001894	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8R2BM	RED B2		S2SR-S8R2BM, RED B2,	
A5550001897	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8RAB	RED A1 B1		S2SR-S8RAB, RED A1 B1,	
A5550001898	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8RABM	RED A1 B1		S2SR-S8RABM, RED A1 B1,	
A5550001834	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8W	WHITE		S2SR-S8W, WHITE,	Селекторный переключатель, 22/25 мм, 3-позиционный, С фиксацией, С длинной рукояткой, Белый
A5550001832	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8W2A	WHITE		S2SR-S8W2A, WHITE,	Селекторный переключатель, 22/25 мм, 3-позиционный, С фиксацией, С длинной рукояткой, Белый, 2 нормально открытых 110В~/10А, 220В~/5А
A5550001895	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-S8WAB	WHITE A1 B1		S2SR-S8WAB, WHITE A1 B1,	
A5550001985	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SAKR2A	RED A2		S2SR-SAKR2A, RED A2,	
A5550001986	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SAKR2AM	RED A2		S2SR-SAKR2AM, RED A2,	

A5550001987	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SAKR2B	RED B2		S2SR-SAKR2B, RED B2,
A5550001988	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SAKR2BM	RED B2		S2SR-SAKR2BM, RED B2,
A5550001989	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SAKRAB	RED AB		S2SR-SAKRAB, RED AB,
A5550001990	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SAKRABM	RED AB		S2SR-SAKRABM, RED AB,
A5550001997	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SBKR2A	RED A2		S2SR-SBKR2A, RED A2,
A5550001998	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SBKR2AM	RED A2		S2SR-SBKR2AM, RED A2,
A5550001999	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SBKR2B	RED B2		S2SR-SBKR2B, RED B2,
A5550002000	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SBKR2BM	RED B2		S2SR-SBKR2BM, RED B2,
A5550002001	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SBKRAB	RED AB		S2SR-SBKRAB, RED AB,
A5550002002	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SBKRABM	RED AB		S2SR-SBKRABM, RED AB,
A5550002009	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SCKR2A	RED A2		S2SR-SCKR2A, RED A2,
A5550002010	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SCKR2AM	RED A2		S2SR-SCKR2AM, RED A2,
A5550002011	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SCKR2B	RED B2		S2SR-SCKR2B, RED B2,
A5550002012	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SCKR2BM	RED B2		S2SR-SCKR2BM, RED B2,
A5550002013	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SCKRAB	RED AB		S2SR-SCKRAB, RED AB,
A5550002014	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SCKRABM	RED AB		S2SR-SCKRABM, RED AB,
A5550002021	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SDKR2A	RED A2		S2SR-SDKR2A, RED A2,
A5550002022	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SDKR2AM	RED A2		S2SR-SDKR2AM, RED A2,
A5550002023	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SDKR2B	RED B2		S2SR-SDKR2B, RED B2,
A5550002024	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SDKR2BM	RED B2		S2SR-SDKR2BM, RED B2,
A5550002025	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SDKRAB	RED AB		S2SR-SDKRAB, RED AB,
A5550002026	CONTROL SWITCH	SELECTOR SWITCH	S2SR SERIES	S2SR-SDKRABM	RED AB		S2SR-SDKRABM, RED AB,
A5550003735	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AB			S2SRN-L1AB, ,
A5550004069	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ABAD	BLUE A1 DC		S2SRN-L1ABAD, BLUE A1 DC,
A5550003783	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AG			S2SRN-L1AG, ,
A5550004197	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AGAD	GREEN A1 DC		S2SRN-L1AGAD, GREEN A1 DC,
A5550003687	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AR			S2SRN-L1AR, ,

A5550003941	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ARAD	RED A1 DC		S2SRN-L1ARAD, RED A1 DC,	
A5550003942	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ARADM	RED A1 DC		S2SRN-L1ARADM, RED A1 DC,	
A5550003989	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ARBD	RED B1 DC		S2SRN-L1ARBD, RED B1 DC,	
A5550003990	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1ARBDM	RED B1 DC		S2SRN-L1ARBDM, RED B1 DC,	
A5550003831	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1AY			S2SRN-L1AY, ,	
A5550003738	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BB			S2SRN-L1BB, ,	Селекторный переключатель, 22/25 мм, 2-х позиционный, с самовозвратом, С выступающей длинной ручкой "акула", Синий
A5550003786	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BG			S2SRN-L1BG, ,	Селекторный переключатель, 22/25 мм, 2-х позиционный, с самовозвратом, С выступающей длинной ручкой "акула", Зелёный
A5550003690	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BR			S2SRN-L1BR, ,	Селекторный переключатель, 22/25 мм, 2-х позиционный, с самовозвратом, С выступающей длинной ручкой "акула", Красный
A5550003943	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BRAD	RED A1 DC		S2SRN-L1BRAD, RED A1 DC,	
A5550003944	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BRADM	RED A1 DC		S2SRN-L1BRADM, RED A1 DC,	
A5550003991	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BRBD	RED B1 DC		S2SRN-L1BRBD, RED B1 DC,	
A5550003992	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BRBDM	RED B1 DC		S2SRN-L1BRBDM, RED B1 DC,	
A5550003834	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1BY			S2SRN-L1BY, ,	Селекторный переключатель, 22/25 мм, 2-х позиционный, с самовозвратом, С выступающей длинной ручкой "акула", Жёлтый
A5550005105	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1R2AD	RED A2 LED(DC)		S2SRN-L1R2AD, RED A2 LED(DC),	
A5550005106	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1R2ADM	RED A2 LED(DC)		S2SRN-L1R2ADM, RED A2 LED(DC),	
A5550005113	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1R2BD	RED B2 LED(DC)		S2SRN-L1R2BD, RED B2 LED(DC),	
A5550005114	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1R2BDM	RED B2 LED(DC)		S2SRN-L1R2BDM, RED B2 LED(DC),	
A5550005117	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1RABD	RED AB LED(DC)		S2SRN-L1RABD, RED AB LED(DC),	
A5550005118	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1RABDM	RED AB LED(DC)		S2SRN-L1RABDM, RED AB LED(DC),	
A5550005101	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1RAD	RED A LED(DC)		S2SRN-L1RAD, RED A LED(DC),	
A5550005102	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1RADM	RED A LED(DC)		S2SRN-L1RADM, RED A LED(DC),	
A5550005103	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1RAL	RED A LED(AC)		S2SRN-L1RAL, RED A LED(AC),	
A5550005104	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1RALM	RED A LED(AC)		S2SRN-L1RALM, RED A LED(AC),	
A5550005109	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1RBD	RED B LED(DC)		S2SRN-L1RBD, RED B LED(DC),	
A5550005110	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1RBDM	RED B LED(DC)		S2SRN-L1RBDM, RED B LED(DC),	
A5550005111	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1RBL	RED B LED(AC)		S2SRN-L1RBL, RED B LED(AC),	
A5550005112	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L1RBLM	RED B LED(AC)		S2SRN-L1RBLM, RED B LED(AC),	

A5550003693	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2AR			S2SRN-L2AR, ,	
A5550003945	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ARAD	RED A1 DC		S2SRN-L2ARAD, RED A1 DC,	
A5550003946	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ARADM	RED A1 DC		S2SRN-L2ARADM, RED A1 DC,	
A5550003993	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ARBD	RED B1 DC		S2SRN-L2ARBD, RED B1 DC,	
A5550003994	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2ARBDM	RED B1 DC		S2SRN-L2ARBDM, RED B1 DC,	
A5550003696	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BR			S2SRN-L2BR, ,	
A5550003947	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BRAD	RED A1 DC		S2SRN-L2BRAD, RED A1 DC,	
A5550003948	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BRADM	RED A1 DC		S2SRN-L2BRADM, RED A1 DC,	
A5550003995	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BRBD	RED B1 DC		S2SRN-L2BRBD, RED B1 DC,	
A5550003996	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2BRBDM	RED B1 DC		S2SRN-L2BRBDM, RED B1 DC,	
A5550005185	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2R2AD	RED A2 LED(DC)		S2SRN-L2R2AD, RED A2 LED(DC),	
A5550005186	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2R2ADM	RED A2 LED(DC)		S2SRN-L2R2ADM, RED A2 LED(DC),	
A5550005193	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2R2BD	RED B2 LED(DC)		S2SRN-L2R2BD, RED B2 LED(DC),	
A5550005194	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2R2BDM	RED B2 LED(DC)		S2SRN-L2R2BDM, RED B2 LED(DC),	
A5550005197	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2RABD	RED AB LED(DC)		S2SRN-L2RABD, RED AB LED(DC),	
A5550005198	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2RABDM	RED AB LED(DC)		S2SRN-L2RABDM, RED AB LED(DC),	
A5550005181	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2RAD	RED A LED(DC)		S2SRN-L2RAD, RED A LED(DC),	
A5550005182	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2RADM	RED A LED(DC)		S2SRN-L2RADM, RED A LED(DC),	
A5550005183	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2RAL	RED A LED(AC)		S2SRN-L2RAL, RED A LED(AC),	
A5550005184	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2RALM	RED A LED(AC)		S2SRN-L2RALM, RED A LED(AC),	
A5550005189	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2RBD	RED B LED(DC)		S2SRN-L2RBD, RED B LED(DC),	
A5550005190	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2RBDM	RED B LED(DC)		S2SRN-L2RBDM, RED B LED(DC),	
A5550005191	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2RBL	RED B LED(AC)		S2SRN-L2RBL, RED B LED(AC),	
A5550005192	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L2RBLM	RED B LED(AC)		S2SRN-L2RBLM, RED B LED(AC),	
A5550003747	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AB			S2SRN-L3AB, ,	
A5550004078	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ABADM	BLUE A1 DC		S2SRN-L3ABADM, BLUE A1 DC,	
A5550004590	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ABALM	BLUE A1 AC		S2SRN-L3ABALM, BLUE A1 AC,	
A5550003795	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AG			S2SRN-L3AG, ,	

A5550004205	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AGAD	GREEN A1 DC	GL	S2SRN-L3AGAD, GREEN A1 DC,	Селекторный переключатель выступающего типа с короткой ручкой shark (с подсветкой), 22 мм, 2-позиционный, без возврата, зеленый, СИД 12-24В=, 1 Нормально открытый, коммутация до 110В~/10А, 250В~/5А
A5550004206	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AGADM	GREEN A1 DC		S2SRN-L3AGADM, GREEN A1 DC,	
A5550004717	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AGAL	GREEN A1 AC		S2SRN-L3AGAL, GREEN A1 AC,	
A5550004718	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AGALM	GREEN A1 AC		S2SRN-L3AGALM, GREEN A1 AC,	
A5550003699	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AR			S2SRN-L3AR, ,	
A5550004477	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AR2AL	RED A2 AC		S2SRN-L3AR2AL, RED A2 AC,	
A5550004478	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AR2ALM	RED A2 AC		S2SRN-L3AR2ALM, RED A2 AC,	
A5550004525	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AR2BL	RED B2 AC		S2SRN-L3AR2BL, RED B2 AC,	
A5550004526	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AR2BLM	RED B2 AC		S2SRN-L3AR2BLM, RED B2 AC,	
A5550004557	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ARABL	RED A1 B1 AC		S2SRN-L3ARABL, RED A1 B1 AC,	
A5550004558	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ARABLM	RED A1 B1 AC		S2SRN-L3ARABLM, RED A1 B1 AC,	
A5550003949	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ARAD	RED A1 DC GL		S2SRN-L3ARAD, RED A1 DC,	Селекторный переключатель выступающего типа с короткой ручкой shark (с подсветкой), 22 мм, 2-позиционный, без возврата, красный, СИД 12-24В=, 1 Нормально открытый, коммутация до 110В~/10А, 250В~/5А
A5550003950	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ARADM	RED A1 DC		S2SRN-L3ARADM, RED A1 DC,	
A5550004461	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ARAL	RED A1 AC		S2SRN-L3ARAL, RED A1 AC,	
A5550004462	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ARALM	RED A1 AC		S2SRN-L3ARALM, RED A1 AC,	
A5550003997	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ARBD	RED B1 DC		S2SRN-L3ARBD, RED B1 DC,	
A5550003998	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ARBDM	RED B1 DC		S2SRN-L3ARBDM, RED B1 DC,	
A5550004509	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ARBL	RED B1 AC		S2SRN-L3ARBL, RED B1 AC,	
A5550004510	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3ARBLM	RED B1 AC		S2SRN-L3ARBLM, RED B1 AC,	
A5550003843	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AY			S2SRN-L3AY, ,	
A5550004333	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AYAD	YELLOW A1 DC		S2SRN-L3AYAD, YELLOW A1 DC,	Селекторный переключатель выступающего типа с короткой ручкой shark (с подсветкой), 2-позиционный, без возврата, желтый 12-24 В=
A5550004334	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AYADM	YELLOW A1 DC		S2SRN-L3AYADM, YELLOW A1 DC,	Селекторный переключатель, 22/25 мм, 2-х позиционный, фиксируемый, С короткой ручкой "акула", модульный, 1 нормально открытый контакт 250 В~/6А, СИД 12-24 В=~/, Жёлтый
A5550004846	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3AYALM	YELLOW A1 AC		S2SRN-L3AYALM, YELLOW A1 AC,	
A5550003750	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BB			S2SRN-L3BB, ,	Селекторный переключатель, 22/25 мм, 2-х позиционный, фиксируемый, С выступающей длинной ручкой "акула", Синий
A5550003798	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BG			S2SRN-L3BG, ,	Селекторный переключатель, 22/25 мм, 2-х позиционный, фиксируемый, С выступающей длинной ручкой "акула",

								Зеленный
A5550003702	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BR			S2SRN-L3BR, ,	
A5550004479	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BR2AL	RED A2 AC		S2SRN-L3BR2AL, RED A2 AC,	
A5550004480	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BR2ALM	RED A2 AC		S2SRN-L3BR2ALM, RED A2 AC,	
A5550004527	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BR2BL	RED B2 AC		S2SRN-L3BR2BL, RED B2 AC,	
A5550004528	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BR2BLM	RED B2 AC		S2SRN-L3BR2BLM, RED B2 AC,	
A5550004559	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BRABL	RED A1 B1 AC		S2SRN-L3BRABL, RED A1 B1 AC,	
A5550004560	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BRABLM	RED A1 B1 AC		S2SRN-L3BRABLM, RED A1 B1 AC,	
A5550003951	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BRAD	RED A1 DC		S2SRN-L3BRAD, RED A1 DC,	
A5550003952	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BRADM	RED A1 DC		S2SRN-L3BRADM, RED A1 DC,	
A5550004463	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BRAL	RED A1 AC		S2SRN-L3BRAL, RED A1 AC,	
A5550004464	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BRALM	RED A1 AC		S2SRN-L3BRALM, RED A1 AC,	
A5550003999	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BRBD	RED B1 DC		S2SRN-L3BRBD, RED B1 DC,	
A5550004000	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BRBDM	RED B1 DC		S2SRN-L3BRBDM, RED B1 DC,	
A5550004511	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BRBL	RED B1 AC		S2SRN-L3BRBL, RED B1 AC,	
A5550004512	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BRBLM	RED B1 AC		S2SRN-L3BRBLM, RED B1 AC,	
A5550003846	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L3BY			S2SRN-L3BY, ,	Селекторный переключатель, 22/25 мм, 2-х позиционный, фиксируемый, С выступающей длинной ручкой "акула", желтый
A5550003801	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AG			S2SRN-L4AG, ,	Селекторный переключатель, 22/25 мм, 2-х позиционный, без возврата, С выступающей длинной ручкой "акула", Зеленный
A5550004737	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AG2AL	GREEN A2 AC		S2SRN-L4AG2AL, GREEN A2 AC,	
A5550004305	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AGABD	GREEN A1 B1 DC		S2SRN-L4AGABD, GREEN A1 B1 DC,	
A5550003705	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AR			S2SRN-L4AR, ,	
A5550004481	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AR2AL	RED A2 AC		S2SRN-L4AR2AL, RED A2 AC,	
A5550004482	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AR2ALM	RED A2 AC		S2SRN-L4AR2ALM, RED A2 AC,	
A5550004529	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AR2BL	RED B2 AC		S2SRN-L4AR2BL, RED B2 AC,	
A5550004530	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4AR2BLM	RED B2 AC		S2SRN-L4AR2BLM, RED B2 AC,	
A5550004561	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ARABL	RED A1 B1 AC		S2SRN-L4ARABL, RED A1 B1 AC,	
A5550004562	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ARABLM	RED A1 B1 AC		S2SRN-L4ARABLM, RED A1 B1 AC,	
A5550003953	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ARAD	RED A1 DC		S2SRN-L4ARAD, RED A1 DC,	

A5550003954	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ARADM	RED A1 DC		S2SRN-L4ARADM, RED A1 DC,	
A5550004465	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ARAL	RED A1 AC		S2SRN-L4ARAL, RED A1 AC,	
A5550004466	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ARALM	RED A1 AC		S2SRN-L4ARALM, RED A1 AC,	
A5550004001	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ARBD	RED B1 DC		S2SRN-L4ARBD, RED B1 DC,	
A5550004002	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ARBDM	RED B1 DC		S2SRN-L4ARBDM, RED B1 DC,	
A5550004513	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ARBL	RED B1 AC		S2SRN-L4ARBL, RED B1 AC,	
A5550004514	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4ARBLM	RED B1 AC		S2SRN-L4ARBLM, RED B1 AC,	
A5550003804	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BG			S2SRN-L4BG, ,	Селекторный переключатель, 22/25 мм, 2-х позиционный, фиксируемый, С выступающей длинной ручкой "акула", Зеленный
A5550004211	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BGAD	GREEN A1 DC		S2SRN-L4BGAD, GREEN A1 DC,	
A5550003708	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BR			S2SRN-L4BR, ,	
A5550003971	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BR2AD	RED A2 DC		S2SRN-L4BR2AD, RED A2 DC,	
A5550003972	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BR2ADM	RED A2 DC		S2SRN-L4BR2ADM, RED A2 DC,	
A5550004483	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BR2AL	RED A2 AC		S2SRN-L4BR2AL, RED A2 AC,	
A5550004484	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BR2ALM	RED A2 AC		S2SRN-L4BR2ALM, RED A2 AC,	
A5550004019	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BR2BD	RED B2 DC		S2SRN-L4BR2BD, RED B2 DC,	
A5550004020	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BR2BDM	RED B2 DC		S2SRN-L4BR2BDM, RED B2 DC,	
A5550004531	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BR2BL	RED B2 AC		S2SRN-L4BR2BL, RED B2 AC,	
A5550004532	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BR2BLM	RED B2 AC		S2SRN-L4BR2BLM, RED B2 AC,	
A5550004051	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BRABD	RED A1 B1 DC		S2SRN-L4BRABD, RED A1 B1 DC,	
A5550004052	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BRABDM	RED A1 B1 DC		S2SRN-L4BRABDM, RED A1 B1 DC,	
A5550004563	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BRABL	RED A1 B1 AC		S2SRN-L4BRABL, RED A1 B1 AC,	
A5550004564	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BRABLM	RED A1 B1 AC		S2SRN-L4BRABLM, RED A1 B1 AC,	
A5550003955	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BRAD	RED A1 DC		S2SRN-L4BRAD, RED A1 DC,	
A5550003956	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BRADM	RED A1 DC		S2SRN-L4BRADM, RED A1 DC,	
A5550004467	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BRAL	RED A1 AC		S2SRN-L4BRAL, RED A1 AC,	
A5550004468	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BRALM	RED A1 AC		S2SRN-L4BRALM, RED A1 AC,	
A5550004003	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BRBD	RED B1 DC		S2SRN-L4BRBD, RED B1 DC,	
A5550004004	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BRBDM	RED B1 DC		S2SRN-L4BRBDM, RED B1 DC,	

A5550004515	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BRBL	RED B1 AC		S2SRN-L4BRBL, RED B1 AC,	
A5550004516	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L4BRBLM	RED B1 AC		S2SRN-L4BRBLM, RED B1 AC,	
A5550003759	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5B			S2SRN-L5B, ,	Селекторный переключатель, 22/25 мм, 3-х позиционный, пружинный самовозврат из 2 положений, С длинной ручкой "акула", Синий
A5550003807	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5G			S2SRN-L5G, ,	Селекторный переключатель, 22/25 мм, 3-х позиционный, пружинный самовозврат из 2 положений, С длинной ручкой "акула", Зелённый
A5550005261	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KR2AD	RED A2 LED(DC)		S2SRN-L5KR2AD, RED A2 LED(DC),	
A5550005262	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KR2ADM	RED A2 LED(DC)		S2SRN-L5KR2ADM, RED A2 LED(DC),	
A5550005265	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KR2BD	RED B2 LED(DC)		S2SRN-L5KR2BD, RED B2 LED(DC),	
A5550005266	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KR2BDM	RED B2 LED(DC)		S2SRN-L5KR2BDM, RED B2 LED(DC),	
A5550005269	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KRABD	RED AB LED(DC)		S2SRN-L5KRABD, RED AB LED(DC),	
A5550005270	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5KRABDM	RED AB LED(DC)		S2SRN-L5KRABDM, RED AB LED(DC),	
A5550003711	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5R			S2SRN-L5R, ,	Селекторный переключатель, 22/25 мм, 3-х позиционный, пружинный самовозврат из 2 положений, С длинной ручкой "акула", Красный
A5550003973	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5R2AD	RED A2 DC		S2SRN-L5R2AD, RED A2 DC,	
A5550003974	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5R2ADM	RED A2 DC		S2SRN-L5R2ADM, RED A2 DC,	Селекторный переключатель 22/25, переключатель выступающего типа с короткой ручкой shark (с подсветкой), 3 позиционный пружинный самовозврат из 2 положений, контакты модульного типа, красный, контакт А 2ЕА, 12-24 VAC 50-60 Гц, 12-24 VDC
A5550004485	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5R2AL	RED A2 AC		S2SRN-L5R2AL, RED A2 AC,	
A5550004486	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5R2ALM	RED A2 AC		S2SRN-L5R2ALM, RED A2 AC,	
A5550004021	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5R2BD	RED B2 DC		S2SRN-L5R2BD, RED B2 DC,	
A5550004022	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5R2BDM	RED B2 DC		S2SRN-L5R2BDM, RED B2 DC,	
A5550004533	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5R2BL	RED B2 AC		S2SRN-L5R2BL, RED B2 AC,	
A5550004534	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5R2BLM	RED B2 AC		S2SRN-L5R2BLM, RED B2 AC,	
A5550004053	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5RABD	RED A1 B1 DC		S2SRN-L5RABD, RED A1 B1 DC,	
A5550004054	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5RABDM	RED A1 B1 DC		S2SRN-L5RABDM, RED A1 B1 DC,	
A5550004565	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5RABL	RED A1 B1 AC		S2SRN-L5RABL, RED A1 B1 AC,	
A5550004566	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5RABLM	RED A1 B1 AC		S2SRN-L5RABLM, RED A1 B1 AC,	
A5550003855	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L5Y			S2SRN-L5Y, ,	Селекторный переключатель, 22/25 мм, 3-х позиционный, пружинный самовозврат из 2 положений, С длинной ручкой "акула", Жёлтый
A5550003810	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6G			S2SRN-L6G, ,	Селекторный переключатель, 22/25 мм, 3-х позиционный, пружинный самовозврат из 2 положений, С длинной ручкой "акула", Зелённый

A5550004232	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6G2ADM	GREEN A2 DC		S2SRN-L6G2ADM, GREEN A2 DC,	
A5550004744	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6G2ALM	GREEN A2 AC		S2SRN-L6G2ALM, GREEN A2 AC,	
A5550005309	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KR2AD	RED A2 LED(DC)		S2SRN-L6KR2AD, RED A2 LED(DC),	
A5550005310	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KR2ADM	RED A2 LED(DC)		S2SRN-L6KR2ADM, RED A2 LED(DC),	
A5550005313	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KR2BD	RED B2 LED(DC)		S2SRN-L6KR2BD, RED B2 LED(DC),	
A5550005314	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KR2BDM	RED B2 LED(DC)		S2SRN-L6KR2BDM, RED B2 LED(DC),	
A5550005317	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KRABD	RED AB LED(DC)		S2SRN-L6KRABD, RED AB LED(DC),	
A5550005318	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6KRABDM	RED AB LED(DC)		S2SRN-L6KRABDM, RED AB LED(DC),	
A5550003714	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6R			S2SRN-L6R, ,	
A5550003975	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6R2AD	RED A2 DC		S2SRN-L6R2AD, RED A2 DC,	
A5550003976	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6R2ADM	RED A2 DC		S2SRN-L6R2ADM, RED A2 DC,	
A5550004487	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6R2AL	RED A2 AC		S2SRN-L6R2AL, RED A2 AC,	
A5550004488	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6R2ALM	RED A2 AC		S2SRN-L6R2ALM, RED A2 AC,	
A5550004023	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6R2BD	RED B2 DC		S2SRN-L6R2BD, RED B2 DC,	
A5550004024	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6R2BDM	RED B2 DC		S2SRN-L6R2BDM, RED B2 DC,	
A5550004535	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6R2BL	RED B2 AC		S2SRN-L6R2BL, RED B2 AC,	
A5550004536	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6R2BLM	RED B2 AC		S2SRN-L6R2BLM, RED B2 AC,	
A5550004055	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6RABD	RED A1 B1 DC		S2SRN-L6RABD, RED A1 B1 DC,	
A5550004056	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6RABDM	RED A1 B1 DC		S2SRN-L6RABDM, RED A1 B1 DC,	
A5550004567	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6RABL	RED A1 B1 AC		S2SRN-L6RABL, RED A1 B1 AC,	
A5550004568	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L6RABLM	RED A1 B1 AC		S2SRN-L6RABLM, RED A1 B1 AC,	
A5550003765	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7B			S2SRN-L7B, ,	
A5550004106	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7B2ADM	BLUE A2 DC		S2SRN-L7B2ADM, BLUE A2 DC,	
A5550004618	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7B2ALM	BLUE A2 AC		S2SRN-L7B2ALM, BLUE A2 AC,	
A5550003813	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7G			S2SRN-L7G, ,	Селекторный переключатель, 22/25 мм, 3-х позиционный, без возврата, С длинной ручкой "акула", Зеленный
A5550004234	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7G2ADM	GREEN A2 DC		S2SRN-L7G2ADM, GREEN A2 DC,	
A5550004745	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7G2AL	GREEN A2 AC		S2SRN-L7G2AL, GREEN A2 AC,	
A5550004746	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7G2ALM	GREEN A2 AC		S2SRN-L7G2ALM, GREEN A2 AC,	

A5550005357	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KR2AD	RED A2 LED(DC)		S2SRN-L7KR2AD, RED A2 LED(DC),	
A5550005358	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KR2ADM	RED A2 LED(DC)		S2SRN-L7KR2ADM, RED A2 LED(DC),	
A5550005359	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KR2AL	RED A2 LED(AC)		S2SRN-L7KR2AL, RED A2 LED(AC),	
A5550005360	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KR2ALM	RED A2 LED(AC)		S2SRN-L7KR2ALM, RED A2 LED(AC),	
A5550005361	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KR2BD	RED B2 LED(DC)		S2SRN-L7KR2BD, RED B2 LED(DC),	
A5550005362	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KR2BDM	RED B2 LED(DC)		S2SRN-L7KR2BDM, RED B2 LED(DC),	
A5550005365	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KRABD	RED AB LED(DC)		S2SRN-L7KRABD, RED AB LED(DC),	
A5550005366	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7KRABDM	RED AB LED(DC)		S2SRN-L7KRABDM, RED AB LED(DC),	
A5550003717	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7R			S2SRN-L7R, ,	Селекторный переключатель, 22/25 мм, 3-х позиционный, без возврата, С короткой ручкой "акула", Красный
A5550003977	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7R2AD	RED A2 DC		S2SRN-L7R2AD, RED A2 DC,	
A5550003978	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7R2ADM	RED A2 DC		S2SRN-L7R2ADM, RED A2 DC,	
A5550004489	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7R2AL	RED A2 AC		S2SRN-L7R2AL, RED A2 AC,	
A5550004490	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7R2ALM	RED A2 AC		S2SRN-L7R2ALM, RED A2 AC,	
A5550004025	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7R2BD	RED B2 DC		S2SRN-L7R2BD, RED B2 DC,	
A5550004026	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7R2BDM	RED B2 DC		S2SRN-L7R2BDM, RED B2 DC,	
A5550004537	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7R2BL	RED B2 AC		S2SRN-L7R2BL, RED B2 AC,	
A5550004538	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7R2BLM	RED B2 AC		S2SRN-L7R2BLM, RED B2 AC,	
A5550004057	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7RABD	RED A1 B1 DC		S2SRN-L7RABD, RED A1 B1 DC,	
A5550004058	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7RABDM	RED A1 B1 DC		S2SRN-L7RABDM, RED A1 B1 DC,	
A5550004569	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7RABL	RED A1 B1 AC		S2SRN-L7RABL, RED A1 B1 AC,	
A5550004570	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7RABLM	RED A1 B1 AC		S2SRN-L7RABLM, RED A1 B1 AC,	
A5550003861	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7Y			S2SRN-L7Y, ,	Селекторный переключатель, 22/25 мм, 3-х позиционный, без возврата, С короткой ручкой "акула", Жёлтый
A5550004362	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7Y2ADM	YELLOW A2 DC		S2SRN-L7Y2ADM, YELLOW A2 DC,	
A5550004874	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L7Y2ALM	YELLOW A2 AC		S2SRN-L7Y2ALM, YELLOW A2 AC,	
A5550003816	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8G			S2SRN-L8G, ,	Селекторный переключатель, 22/25 мм, 3-х позиционный, без возврата, С длинной ручкой "акула", Зеленный
A5550004235	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8G2AD	GREEN A2 DC		S2SRN-L8G2AD, GREEN A2 DC,	
A5550004747	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8G2AL	GREEN A2 AC		S2SRN-L8G2AL, GREEN A2 AC,	
A5550005405	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KR2AD	RED A2 LED(DC)		S2SRN-L8KR2AD, RED A2 LED(DC),	

A5550005406	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KR2ADM	RED A2 LED(DC)		S2SRN-L8KR2ADM, RED A2 LED(DC),
A5550005407	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KR2AL	RED A2 LED(AC)		S2SRN-L8KR2AL, RED A2 LED(AC),
A5550005408	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KR2ALM	RED A2 LED(AC)		S2SRN-L8KR2ALM, RED A2 LED(AC),
A5550005409	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KR2BD	RED B2 LED(DC)		S2SRN-L8KR2BD, RED B2 LED(DC),
A5550005410	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KR2BDM	RED B2 LED(DC)		S2SRN-L8KR2BDM, RED B2 LED(DC),
A5550005413	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KRABD	RED AB LED(DC)		S2SRN-L8KRABD, RED AB LED(DC),
A5550005414	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8KRABDM	RED AB LED(DC)		S2SRN-L8KRABDM, RED AB LED(DC),
A5550003720	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8R			S2SRN-L8R, ,
A5550003979	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8R2AD	RED A2 DC		S2SRN-L8R2AD, RED A2 DC,
A5550003980	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8R2ADM	RED A2 DC		S2SRN-L8R2ADM, RED A2 DC,
A5550004491	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8R2AL	RED A2 AC		S2SRN-L8R2AL, RED A2 AC,
A5550004492	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8R2ALM	RED A2 AC		S2SRN-L8R2ALM, RED A2 AC,
A5550004027	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8R2BD	RED B2 DC		S2SRN-L8R2BD, RED B2 DC,
A5550004028	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8R2BDM	RED B2 DC		S2SRN-L8R2BDM, RED B2 DC,
A5550004539	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8R2BL	RED B2 AC		S2SRN-L8R2BL, RED B2 AC,
A5550004540	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8R2BLM	RED B2 AC		S2SRN-L8R2BLM, RED B2 AC,
A5550004059	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8RABD	RED A1 B1 DC		S2SRN-L8RABD, RED A1 B1 DC,
A5550004060	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8RABDM	RED A1 B1 DC		S2SRN-L8RABDM, RED A1 B1 DC,
A5550004571	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8RABL	RED A1 B1 AC		S2SRN-L8RABL, RED A1 B1 AC,
A5550004572	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-L8RABLM	RED A1 B1 AC		S2SRN-L8RABLM, RED A1 B1 AC,
A5550005453	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKR2AD	RED A2 LED(DC)		S2SRN-LAKR2AD, RED A2 LED(DC),
A5550005454	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKR2ADM	RED A2 LED(DC)		S2SRN-LAKR2ADM, RED A2 LED(DC),
A5550005455	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKR2AL	RED A2 LED(AC)		S2SRN-LAKR2AL, RED A2 LED(AC),
A5550005456	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKR2ALM	RED A2 LED(AC)		S2SRN-LAKR2ALM, RED A2 LED(AC),
A5550005457	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKR2BD	RED B2 LED(DC)		S2SRN-LAKR2BD, RED B2 LED(DC),

A5550005458	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKR2BDM	RED B2 LED(DC)		S2SRN-LAKR2BDM, RED B2 LED(DC),
A5550005461	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKRABD	RED AB LED(DC)		S2SRN-LAKRABD, RED AB LED(DC),
A5550005462	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAKRABDM	RED AB LED(DC)		S2SRN-LAKRABDM, RED AB LED(DC),
A5550003723	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAR			S2SRN-LAR, ,
A5550003981	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAR2AD	RED A2 DC		S2SRN-LAR2AD, RED A2 DC,
A5550003982	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAR2ADM	RED A2 DC		S2SRN-LAR2ADM, RED A2 DC,
A5550004493	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAR2AL	RED A2 AC		S2SRN-LAR2AL, RED A2 AC,
A5550004494	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAR2ALM	RED A2 AC		S2SRN-LAR2ALM, RED A2 AC,
A5550004029	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAR2BD	RED B2 DC		S2SRN-LAR2BD, RED B2 DC,
A5550004030	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAR2BDM	RED B2 DC		S2SRN-LAR2BDM, RED B2 DC,
A5550004541	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAR2BL	RED B2 AC		S2SRN-LAR2BL, RED B2 AC,
A5550004542	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LAR2BLM	RED B2 AC		S2SRN-LAR2BLM, RED B2 AC,
A5550004061	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LARABD	RED A1 B1 DC		S2SRN-LARABD, RED A1 B1 DC,
A5550004062	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LARABDM	RED A1 B1 DC		S2SRN-LARABDM, RED A1 B1 DC,
A5550004573	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LARABL	RED A1 B1 AC		S2SRN-LARABL, RED A1 B1 AC,
A5550004574	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LARABLM	RED A1 B1 AC		S2SRN-LARABLM, RED A1 B1 AC,
A5550005501	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKR2AD	RED A2 LED(DC)		S2SRN-LBKR2AD, RED A2 LED(DC),
A5550005502	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKR2ADM	RED A2 LED(DC)		S2SRN-LBKR2ADM, RED A2 LED(DC),
A5550005503	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKR2AL	RED A2 LED(AC)		S2SRN-LBKR2AL, RED A2 LED(AC),
A5550005504	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKR2ALM	RED A2 LED(AC)		S2SRN-LBKR2ALM, RED A2 LED(AC),
A5550005505	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKR2BD	RED B2 LED(DC)		S2SRN-LBKR2BD, RED B2 LED(DC),
A5550005506	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKR2BDM	RED B2 LED(DC)		S2SRN-LBKR2BDM, RED B2 LED(DC),
A5550005509	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKRABD	RED AB LED(DC)		S2SRN-LBKRABD, RED AB LED(DC),
A5550005510	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBKRABDM	RED AB LED(DC)		S2SRN-LBKRABDM, RED AB LED(DC),
A5550003726	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBR			S2SRN-LBR, ,
A5550003983	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBR2AD	RED A2 DC		S2SRN-LBR2AD, RED A2 DC,

A5550003984	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBR2ADM	RED A2 DC		S2SRN-LBR2ADM, RED A2 DC,
A5550004495	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBR2AL	RED A2 AC		S2SRN-LBR2AL, RED A2 AC,
A5550004496	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBR2ALM	RED A2 AC		S2SRN-LBR2ALM, RED A2 AC,
A5550004031	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBR2BD	RED B2 DC		S2SRN-LBR2BD, RED B2 DC,
A5550004032	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBR2BDM	RED B2 DC		S2SRN-LBR2BDM, RED B2 DC,
A5550004543	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBR2BL	RED B2 AC		S2SRN-LBR2BL, RED B2 AC,
A5550004544	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBR2BLM	RED B2 AC		S2SRN-LBR2BLM, RED B2 AC,
A5550004063	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBRABD	RED A1 B1 DC		S2SRN-LBRABD, RED A1 B1 DC,
A5550004064	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBRABDM	RED A1 B1 DC		S2SRN-LBRABDM, RED A1 B1 DC,
A5550004575	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBRABL	RED A1 B1 AC		S2SRN-LBRABL, RED A1 B1 AC,
A5550004576	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LBRABLM	RED A1 B1 AC		S2SRN-LBRABLM, RED A1 B1 AC,
A5550005549	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKR2AD	RED A2 LED(DC)		S2SRN-LCKR2AD, RED A2 LED(DC),
A5550005550	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKR2ADM	RED A2 LED(DC)		S2SRN-LCKR2ADM, RED A2 LED(DC),
A5550005551	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKR2AL	RED A2 LED(AC)		S2SRN-LCKR2AL, RED A2 LED(AC),
A5550005552	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKR2ALM	RED A2 LED(AC)		S2SRN-LCKR2ALM, RED A2 LED(AC),
A5550005553	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKR2BD	RED B2 LED(DC)		S2SRN-LCKR2BD, RED B2 LED(DC),
A5550005554	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKR2BDM	RED B2 LED(DC)		S2SRN-LCKR2BDM, RED B2 LED(DC),
A5550005557	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKRABD	RED AB LED(DC)		S2SRN-LCKRABD, RED AB LED(DC),
A5550005558	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCKRABDM	RED AB LED(DC)		S2SRN-LCKRABDM, RED AB LED(DC),

A5550003729	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCR			S2SRN-LCR, ,	
A5550003985	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCR2AD	RED A2 DC		S2SRN-LCR2AD, RED A2 DC,	
A5550003986	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCR2ADM	RED A2 DC		S2SRN-LCR2ADM, RED A2 DC,	
A5550004497	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCR2AL	RED A2 AC		S2SRN-LCR2AL, RED A2 AC,	
A5550004498	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCR2ALM	RED A2 AC		S2SRN-LCR2ALM, RED A2 AC,	
A5550004033	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCR2BD	RED B2 DC		S2SRN-LCR2BD, RED B2 DC,	
A5550004034	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCR2BDM	RED B2 DC		S2SRN-LCR2BDM, RED B2 DC,	
A5550004545	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCR2BL	RED B2 AC		S2SRN-LCR2BL, RED B2 AC,	
A5550004546	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCR2BLM	RED B2 AC		S2SRN-LCR2BLM, RED B2 AC,	
A5550004065	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCRABD	RED A1 B1 DC		S2SRN-LCRABD, RED A1 B1 DC,	
A5550004066	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCRABDM	RED A1 B1 DC		S2SRN-LCRABDM, RED A1 B1 DC,	
A5550004577	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCRABL	RED A1 B1 AC		S2SRN-LCRABL, RED A1 B1 AC,	
A5550004578	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LCRABLM	RED A1 B1 AC		S2SRN-LCRABLM, RED A1 B1 AC,	
A5550005597	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKR2AD	RED A2 LED(DC)		S2SRN-LDKR2AD, RED A2 LED(DC),	
A5550005598	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKR2ADM	RED A2 LED(DC)		S2SRN-LDKR2ADM, RED A2 LED(DC),	

A5550005599	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKR2AL	RED A2 LED(AC)		S2SRN-LDKR2AL, RED A2 LED(AC),	
A5550005600	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKR2ALM	RED A2 LED(AC)		S2SRN-LDKR2ALM, RED A2 LED(AC),	
A5550005601	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKR2BD	RED B2 LED(DC)		S2SRN-LDKR2BD, RED B2 LED(DC),	
A5550005602	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKR2BDM	RED B2 LED(DC)		S2SRN-LDKR2BDM, RED B2 LED(DC),	
A5550005605	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKRABD	RED AB LED(DC)		S2SRN-LDKRABD, RED AB LED(DC),	
A5550005606	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDKRABDM	RED AB LED(DC)		S2SRN-LDKRABDM, RED AB LED(DC),	
A5550003732	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDR			S2SRN-LDR, ,	
A5550003987	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDR2AD	RED A2 DC		S2SRN-LDR2AD, RED A2 DC,	
A5550003988	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDR2ADM	RED A2 DC		S2SRN-LDR2ADM, RED A2 DC,	
A5550004499	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDR2AL	RED A2 AC		S2SRN-LDR2AL, RED A2 AC,	
A5550004500	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDR2ALM	RED A2 AC		S2SRN-LDR2ALM, RED A2 AC,	
A5550004035	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDR2BD	RED B2 DC		S2SRN-LDR2BD, RED B2 DC,	
A5550004036	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDR2BDM	RED B2 DC		S2SRN-LDR2BDM, RED B2 DC,	
A5550004547	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDR2BL	RED B2 AC		S2SRN-LDR2BL, RED B2 AC,	

A5550004548	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDR2BLM	RED B2 AC		S2SRN-LDR2BLM, RED B2 AC,
A5550004067	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDRABD	RED A1 B1 DC		S2SRN-LDRABD, RED A1 B1 DC,
A5550004068	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDRABDM	RED A1 B1 DC		S2SRN-LDRABDM, RED A1 B1 DC,
A5550004579	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDRABL	RED A1 B1 AC		S2SRN-LDRABL, RED A1 B1 AC,
A5550004580	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-LDRABLM	RED A1 B1 AC		S2SRN-LDRABLM, RED A1 B1 AC,
A5550003591	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AR			S2SRN-S1AR, ,
A5550003613	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AR2A	RED A2		S2SRN-S1AR2A, RED A2,
A5550003614	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AR2AM	RED A2		S2SRN-S1AR2AM, RED A2,
A5550003685	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AR2B	RED B2		S2SRN-S1AR2B, RED B2,
A5550003686	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AR2BM	RED B2		S2SRN-S1AR2BM, RED B2,
A5550003589	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1ARA	RED A1		S2SRN-S1ARA, RED A1,
A5550003733	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1ARAB	RED A1 B1		S2SRN-S1ARAB, RED A1 B1,
A5550003734	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1ARABM	RED A1 B1		S2SRN-S1ARABM, RED A1 B1,
A5550003590	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1ARAM	RED A1		S2SRN-S1ARAM, RED A1,
A5550003661	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1ARB	RED B1		S2SRN-S1ARB, RED B1,
A5550003662	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1ARBM	RED B1		S2SRN-S1ARBM, RED B1,
A5550003639	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1AW			S2SRN-S1AW, ,
A5550003594	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BR			S2SRN-S1BR, ,

A5550003616	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BR2A	RED A2		S2SRN-S1BR2A, RED A2,
A5550003617	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BR2AM	RED A2		S2SRN-S1BR2AM, RED A2,
A5550003688	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BR2B	RED B2		S2SRN-S1BR2B, RED B2,
A5550003689	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BR2BM	RED B2		S2SRN-S1BR2BM, RED B2,
A5550003592	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BRA	RED A1		S2SRN-S1BRA, RED A1,
A5550003736	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BRAB	RED A1 B1		S2SRN-S1BRAB, RED A1 B1,
A5550003737	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BRABM	RED A1 B1		S2SRN-S1BRABM, RED A1 B1,
A5550003593	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BRAM	RED A1		S2SRN-S1BRAM, RED A1,
A5550003664	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BRB	RED B1		S2SRN-S1BRB, RED B1,
A5550003665	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BRBM	RED B1		S2SRN-S1BRBM, RED B1,
A5550003642	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1BW			S2SRN-S1BW, ,
A5550004967	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1R2A	RED A2		S2SRN-S1R2A, RED A2,
A5550004968	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1R2AM	RED A2		S2SRN-S1R2AM, RED A2,
A5550004971	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1R2B	RED B2		S2SRN-S1R2B, RED B2,
A5550004972	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1R2BM	RED B2		S2SRN-S1R2BM, RED B2,
A5550004965	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1RA	RED A		S2SRN-S1RA, RED A,
A5550004973	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1RAB	RED AB		S2SRN-S1RAB, RED AB,
A5550004974	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1RABM	RED AB		S2SRN-S1RABM, RED AB,
A5550004966	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1RAM	RED A		S2SRN-S1RAM, RED A,
A5550004969	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1RB	RED B		S2SRN-S1RB, RED B,
A5550004970	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S1RBM	RED B		S2SRN-S1RBM, RED B,

A5550003597	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AR			S2SRN-S2AR, ,
A5550003619	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AR2A	RED A2		S2SRN-S2AR2A, RED A2,
A5550003620	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AR2AM	RED A2		S2SRN-S2AR2AM, RED A2,
A5550003691	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AR2B	RED B2		S2SRN-S2AR2B, RED B2,
A5550003692	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2AR2BM	RED B2		S2SRN-S2AR2BM, RED B2,
A5550003595	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2ARA	RED A1		S2SRN-S2ARA, RED A1,
A5550003739	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2ARAB	RED A1 B1		S2SRN-S2ARAB, RED A1 B1,
A5550003740	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2ARABM	RED A1 B1		S2SRN-S2ARABM, RED A1 B1,
A5550003596	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2ARAM	RED A1		S2SRN-S2ARAM, RED A1,
A5550003667	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2ARB	RED B1		S2SRN-S2ARB, RED B1,
A5550003668	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2ARBM	RED B1		S2SRN-S2ARBM, RED B1,
A5550003600	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BR			S2SRN-S2BR, ,
A5550003622	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BR2A	RED A2		S2SRN-S2BR2A, RED A2,
A5550003623	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BR2AM	RED A2		S2SRN-S2BR2AM, RED A2,
A5550003694	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BR2B	RED B2		S2SRN-S2BR2B, RED B2,
A5550003695	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BR2BM	RED B2		S2SRN-S2BR2BM, RED B2,
A5550003598	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BRA	RED A1		S2SRN-S2BRA, RED A1,
A5550003742	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BRAB	RED A1 B1		S2SRN-S2BRAB, RED A1 B1,
A5550003743	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BRABM	RED A1 B1		S2SRN-S2BRABM, RED A1 B1,
A5550003599	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BRAM	RED A1		S2SRN-S2BRAM, RED A1,
A5550003670	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BRB	RED B1		S2SRN-S2BRB, RED B1,
A5550003671	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2BRBM	RED B1		S2SRN-S2BRBM, RED B1,

A5550004987	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2R2A	RED A2		S2SRN-S2R2A, RED A2,
A5550004988	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2R2AM	RED A2		S2SRN-S2R2AM, RED A2,
A5550004991	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2R2B	RED B2		S2SRN-S2R2B, RED B2,
A5550004992	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2R2BM	RED B2		S2SRN-S2R2BM, RED B2,
A5550004985	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2RA	RED A		S2SRN-S2RA, RED A,
A5550004993	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2RAB	RED AB		S2SRN-S2RAB, RED AB,
A5550004994	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2RABM	RED AB		S2SRN-S2RABM, RED AB,
A5550004986	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2RAM	RED A		S2SRN-S2RAM, RED A,
A5550004989	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2RB	RED B		S2SRN-S2RB, RED B,
A5550004990	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S2RBM	RED B		S2SRN-S2RBM, RED B,
A5550003603	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AR			S2SRN-S3AR, ,
A5550003625	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AR2A	RED A2		S2SRN-S3AR2A, RED A2,
A5550003626	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AR2AM	RED A2		S2SRN-S3AR2AM, RED A2,
A5550003697	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AR2B	RED B2		S2SRN-S3AR2B, RED B2,
A5550003698	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AR2BM	RED B2		S2SRN-S3AR2BM, RED B2,
A5550003601	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3ARA	RED A1		S2SRN-S3ARA, RED A1,
A5550003745	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3ARAB	RED A1 B1		S2SRN-S3ARAB, RED A1 B1,
A5550003746	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3ARABM	RED A1 B1		S2SRN-S3ARABM, RED A1 B1,
A5550003602	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3ARAM	RED A1		S2SRN-S3ARAM, RED A1,
A5550003673	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3ARB	RED B1		S2SRN-S3ARB, RED B1,
A5550003674	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3ARBM	RED B1		S2SRN-S3ARBM, RED B1,
A5550003651	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AW			S2SRN-S3AW, ,
A5550003794	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3AWAM	WHITE A1		S2SRN-S3AWAM, WHITE A1,

A5550003606	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BR			S2SRN-S3BR, ,	
A5550003628	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BR2A	RED A2		S2SRN-S3BR2A, RED A2,	
A5550003629	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BR2AM	RED A2		S2SRN-S3BR2AM, RED A2,	
A5550003700	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BR2B	RED B2		S2SRN-S3BR2B, RED B2,	
A5550003701	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BR2BM	RED B2		S2SRN-S3BR2BM, RED B2,	
A5550003604	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BRA	RED A1		S2SRN-S3BRA, RED A1,	
A5550003748	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BRAB	RED A1 B1		S2SRN-S3BRAB, RED A1 B1,	
A5550003749	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BRABM	RED A1 B1		S2SRN-S3BRABM, RED A1 B1,	
A5550003605	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BRAM	RED A1		S2SRN-S3BRAM, RED A1,	
A5550003676	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BRB	RED B1		S2SRN-S3BRB, RED B1,	
A5550003677	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BRBM	RED B1		S2SRN-S3BRBM, RED B1,	
A5550003820	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S3BW2A	WHITE A2		S2SRN-S3BW2A, WHITE A2,	
A5550003609	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AR			S2SRN-S4AR, ,	
A5550003631	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AR2A	RED A2		S2SRN-S4AR2A, RED A2,	

A5550003632	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AR2AM	RED A2		S2SRN-S4AR2AM, RED A2,	
A5550003703	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AR2B	RED B2		S2SRN-S4AR2B, RED B2,	
A5550003704	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4AR2BM	RED B2		S2SRN-S4AR2BM, RED B2,	
A5550003607	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4ARA	RED A1		S2SRN-S4ARA, RED A1,	
A5550003751	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4ARAB	RED A1 B1		S2SRN-S4ARAB, RED A1 B1,	
A5550003752	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4ARABM	RED A1 B1		S2SRN-S4ARABM, RED A1 B1,	
A5550003608	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4ARAM	RED A1		S2SRN-S4ARAM, RED A1,	
A5550003679	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4ARB	RED B1		S2SRN-S4ARB, RED B1,	
A5550003680	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4ARBM	RED B1		S2SRN-S4ARBM, RED B1,	
A5550003612	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BR			S2SRN-S4BR, ,	
A5550003634	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BR2A	RED A2		S2SRN-S4BR2A, RED A2,	
A5550003635	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BR2AM	RED A2		S2SRN-S4BR2AM, RED A2,	
A5550003706	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BR2B	RED B2		S2SRN-S4BR2B, RED B2,	
A5550003707	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BR2BM	RED B2		S2SRN-S4BR2BM, RED B2,	
A5550003610	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BRA	RED A1		S2SRN-S4BRA, RED A1,	
A5550003754	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BRAB	RED A1 B1		S2SRN-S4BRAB, RED A1 B1,	
A5550003755	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BRABM	RED A1 B1		S2SRN-S4BRABM, RED A1 B1,	
A5550003611	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BRAM	RED A1		S2SRN-S4BRAM, RED A1,	
A5550003682	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BRB	RED B1		S2SRN-S4BRB, RED B1,	
A5550003683	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BRBM	RED B1		S2SRN-S4BRBM, RED B1,	
A5550003660	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S4BW			S2SRN-S4BW, ,	Селекторный переключатель, 22/25 мм, 2-х позиционный, фиксируемый, С длинной ручкой "акула", Белый
A5550005005	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5KR2A	RED A2		S2SRN-S5KR2A, RED A2,	

A5550005006	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5KR2AM	RED A2		S2SRN-S5KR2AM, RED A2,
A5550005007	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5KR2B	RED B2		S2SRN-S5KR2B, RED B2,
A5550005008	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5KR2BM	RED B2		S2SRN-S5KR2BM, RED B2,
A5550005009	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5KRAB	RED AB		S2SRN-S5KRAB, RED AB,
A5550005010	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5KRABM	RED AB		S2SRN-S5KRABM, RED AB,
A5550003615	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5R			S2SRN-S5R, ,
A5550003637	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5R2A	RED A2		S2SRN-S5R2A, RED A2,
A5550003638	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5R2AM	RED A2		S2SRN-S5R2AM, RED A2,
A5550003709	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5R2B	RED B2		S2SRN-S5R2B, RED B2,
A5550003710	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5R2BM	RED B2		S2SRN-S5R2BM, RED B2,
A5550003757	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5RAB	RED A1 B1		S2SRN-S5RAB, RED A1 B1,
A5550003758	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5RABM	RED A1 B1		S2SRN-S5RABM, RED A1 B1,
A5550003830	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S5W2AM	WHITE A2		S2SRN-S5W2AM, WHITE A2,
A5550005017	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6KR2A	RED A2		S2SRN-S6KR2A, RED A2,
A5550005018	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6KR2AM	RED A2		S2SRN-S6KR2AM, RED A2,
A5550005019	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6KR2B	RED B2		S2SRN-S6KR2B, RED B2,
A5550005020	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6KR2BM	RED B2		S2SRN-S6KR2BM, RED B2,
A5550005021	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6KRAB	RED AB		S2SRN-S6KRAB, RED AB,
A5550005022	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6KRABM	RED AB		S2SRN-S6KRABM, RED AB,
A5550003618	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6R			S2SRN-S6R, ,
A5550003640	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6R2A	RED A2		S2SRN-S6R2A, RED A2,
A5550003641	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6R2AM	RED A2		S2SRN-S6R2AM, RED A2,
A5550003712	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6R2B	RED B2		S2SRN-S6R2B, RED B2,
A5550003713	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6R2BM	RED B2		S2SRN-S6R2BM, RED B2,

A5550003760	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6RAB	RED A1 B1		S2SRN-S6RAB, RED A1 B1,
A5550003761	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S6RABM	RED A1 B1		S2SRN-S6RABM, RED A1 B1,
A5550005029	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7KR2A	RED A2		S2SRN-S7KR2A, RED A2,
A5550005030	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7KR2AM	RED A2		S2SRN-S7KR2AM, RED A2,
A5550005031	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7KR2B	RED B2		S2SRN-S7KR2B, RED B2,
A5550005032	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7KR2BM	RED B2		S2SRN-S7KR2BM, RED B2,
A5550005033	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7KRAB	RED AB		S2SRN-S7KRAB, RED AB,
A5550005034	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7KRABM	RED AB		S2SRN-S7KRABM, RED AB,
A5550003621	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7R			S2SRN-S7R, ,
A5550003643	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7R2A	RED A2		S2SRN-S7R2A, RED A2,
A5550003644	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7R2AM	RED A2		S2SRN-S7R2AM, RED A2,
A5550003715	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7R2B	RED B2		S2SRN-S7R2B, RED B2,
A5550003716	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7R2BM	RED B2		S2SRN-S7R2BM, RED B2,
A5550003763	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7RAB	RED A1 B1		S2SRN-S7RAB, RED A1 B1,
A5550003764	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7RABM	RED A1 B1		S2SRN-S7RABM, RED A1 B1,
A5550003669	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7W			S2SRN-S7W, ,
A5550003835	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S7W2A	WHITE A2		S2SRN-S7W2A, WHITE A2,
A5550005041	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8KR2A	RED A2		S2SRN-S8KR2A, RED A2,
A5550005042	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8KR2AM	RED A2		S2SRN-S8KR2AM, RED A2,
A5550005043	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8KR2B	RED B2		S2SRN-S8KR2B, RED B2,
A5550005044	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8KR2BM	RED B2		S2SRN-S8KR2BM, RED B2,
A5550005045	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8KRAB	RED AB		S2SRN-S8KRAB, RED AB,
A5550005046	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8KRABM	RED AB		S2SRN-S8KRABM, RED AB,
A5550003624	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8R			S2SRN-S8R, ,
A5550003646	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8R2A	RED A2		S2SRN-S8R2A, RED A2,
A5550003647	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8R2AM	RED A2		S2SRN-S8R2AM, RED A2,
A5550003718	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8R2B	RED B2		S2SRN-S8R2B, RED B2,
A5550003719	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8R2BM	RED B2		S2SRN-S8R2BM, RED B2,

A5550003766	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8RAB	RED A1 B1		S2SRN-S8RAB, RED A1 B1,
A5550003767	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-S8RABM	RED A1 B1		S2SRN-S8RABM, RED A1 B1,
A5550005053	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAKR2A	RED A2		S2SRN-SAKR2A, RED A2,
A5550005054	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAKR2AM	RED A2		S2SRN-SAKR2AM, RED A2,
A5550005055	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAKR2B	RED B2		S2SRN-SAKR2B, RED B2,
A5550005056	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAKR2BM	RED B2		S2SRN-SAKR2BM, RED B2,
A5550005057	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAKRAB	RED AB		S2SRN-SAKRAB, RED AB,
A5550005058	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAKRABM	RED AB		S2SRN-SAKRABM, RED AB,
A5550003627	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAR			S2SRN-SAR, ,
A5550003649	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAR2A	RED A2		S2SRN-SAR2A, RED A2,
A5550003650	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAR2AM	RED A2		S2SRN-SAR2AM, RED A2,
A5550003721	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAR2B	RED B2		S2SRN-SAR2B, RED B2,
A5550003722	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAR2BM	RED B2		S2SRN-SAR2BM, RED B2,
A5550003769	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SARAB	RED A1 B1		S2SRN-SARAB, RED A1 B1,
A5550003770	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SARABM	RED A1 B1		S2SRN-SARABM, RED A1 B1,
A5550003675	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SAW			S2SRN-SAW, ,
A5550005065	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBKR2A	RED A2		S2SRN-SBKR2A, RED A2,
A5550005066	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBKR2AM	RED A2		S2SRN-SBKR2AM, RED A2,
A5550005067	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBKR2B	RED B2		S2SRN-SBKR2B, RED B2,
A5550005068	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBKR2BM	RED B2		S2SRN-SBKR2BM, RED B2,
A5550005069	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBKCRAB	RED AB		S2SRN-SBKCRAB, RED AB,
A5550005070	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBKCRABM	RED AB		S2SRN-SBKCRABM, RED AB,
A5550003630	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBR			S2SRN-SBR, ,
A5550003652	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBR2A	RED A2		S2SRN-SBR2A, RED A2,
A5550003653	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBR2AM	RED A2		S2SRN-SBR2AM, RED A2,
A5550003724	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBR2B	RED B2		S2SRN-SBR2B, RED B2,
A5550003725	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBR2BM	RED B2		S2SRN-SBR2BM, RED B2,

A5550003772	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBRAB	RED A1 B1		S2SRN-SBRAB, RED A1 B1,	
A5550003773	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SBRABM	RED A1 B1		S2SRN-SBRABM, RED A1 B1,	
A5550005077	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCKR2A	RED A2		S2SRN-SCKR2A, RED A2,	
A5550005078	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCKR2AM	RED A2		S2SRN-SCKR2AM, RED A2,	
A5550005079	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCKR2B	RED B2		S2SRN-SCKR2B, RED B2,	
A5550005080	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCKR2BM	RED B2		S2SRN-SCKR2BM, RED B2,	
A5550005081	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCKRAB	RED AB		S2SRN-SCKRAB, RED AB,	
A5550005082	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCKRABM	RED AB		S2SRN-SCKRABM, RED AB,	
A5550003633	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCR			S2SRN-SCR, ,	
A5550003655	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCR2A	RED A2		S2SRN-SCR2A, RED A2,	
A5550003656	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCR2AM	RED A2		S2SRN-SCR2AM, RED A2,	
A5550003727	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCR2B	RED B2		S2SRN-SCR2B, RED B2,	
A5550003728	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCR2BM	RED B2		S2SRN-SCR2BM, RED B2,	
A5550003775	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCRAB	RED A1 B1		S2SRN-SCRAB, RED A1 B1,	
A5550003776	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCRABM	RED A1 B1		S2SRN-SCRABM, RED A1 B1,	
A5550003681	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SCW			S2SRN-SCW, ,	Селекторный переключатель, 22/25 мм, 3-х позиционный, с самовозвратом из левого положения, С короткой ручкой "акула", Белый
A5550005089	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDKR2A	RED A2		S2SRN-SDKR2A, RED A2,	
A5550005090	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDKR2AM	RED A2		S2SRN-SDKR2AM, RED A2,	
A5550005091	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDKR2B	RED B2		S2SRN-SDKR2B, RED B2,	
A5550005092	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDKR2BM	RED B2		S2SRN-SDKR2BM, RED B2,	
A5550005093	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDKRAB	RED AB		S2SRN-SDKRAB, RED AB,	
A5550005094	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDKRABM	RED AB		S2SRN-SDKRABM, RED AB,	
A5550003636	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDR			S2SRN-SDR, ,	
A5550003658	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDR2A	RED A2		S2SRN-SDR2A, RED A2,	
A5550003659	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDR2AM	RED A2		S2SRN-SDR2AM, RED A2,	
A5550003730	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDR2B	RED B2		S2SRN-SDR2B, RED B2,	
A5550003731	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDR2BM	RED B2		S2SRN-SDR2BM, RED B2,	
A5550003778	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDRAB	RED A1 B1		S2SRN-SDRAB, RED A1 B1,	

A5550003779	CONTROL SWITCH	SELECTOR SWITCH	S2SRN SERIES	S2SRN-SDRABM	RED A1 B1		S2SRN-SDRABM, RED A1 B1,
-------------	----------------	-----------------	--------------	--------------	-----------	--	--------------------------

30мм управляющие перелючатели

Артикул	Категория продукции 1 (Группа товаров)	Категория продукции 2 (Серия)	Категория продукции 3 (Подсерия)	Наименование модели	Спецификация (1)	Наименование модели + Спецификация	Описание товара
H5550009469	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2FS2B	2(0-S)/C+R/B2	S3KF-2FS2B, 2(0-S)/C+R/B2, GL	
H5550009470	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2FS2BM	2(0-S)/C+R/B2	S3KF-2FS2BM, 2(0-S)/C+R/B2, GL	
H5550009507	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5ASABM	3(S-0-R)/L/A1B1	S3KF-5ASABM, 3(S-0-R)/L/A1B1, GL	
H5550009713	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3BDM	BLUE LED(DC)	L3RF-L3BDM, BLUE LED(DC), GL	
H5550009726	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3BLM	BLUE LED(AC)	L3RF-L3BLM, BLUE LED(AC), GL	
H5550009716	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3GDM	GREEN LED(DC)	L3RF-L3GDM, GREEN LED(DC), GL	Сигнальная лампа 30, Зеленый, Плоская головка, СИД 12-30 В=В~
H5550009727	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3GLM	GREEN LED(AC)	L3RF-L3GLM, GREEN LED(AC), GL	
H5550009722	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3WDM	WHITE LED(DC)	L3RF-L3WDM, WHITE LED(DC), GL	
H5550009729	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3WLM	WHITE LED(AC)	L3RF-L3WLM, WHITE LED(AC), GL	
H5550009719	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3YDM	YELLOW LED(DC)	L3RF-L3YDM, YELLOW LED(DC), GL	Сигнальная лампа 30, Желтый, Плоская головка, СИД 12-30 В=В~
H5550009715	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RFU-L3B	BLUE(NO PRINTING)	L3RFU-L3B, BLUE(NO PRINTING), GL	
H5550009718	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RFU-L3G	GREEN(NO PRINTING)	L3RFU-L3G, GREEN(NO PRINTING), GL	
H5550009724	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RFU-L3W	WHITE(NO PRINTING)	L3RFU-L3W, WHITE(NO PRINTING), GL	
H5550009721	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RFU-L3Y	YELLOW(NO PRINTING)	L3RFU-L3Y, YELLOW(NO PRINTING), GL	
H5550007170	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1B2A	BLUE A2	S3PF-P1B2A, BLUE A2, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Синий, 2 нормально открытых, 110В~/10А, 220В~/5А
H5550007207	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1B2AB	BLUE A2 B1	S3PF-P1B2AB, BLUE A2 B1, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Синий, 2 нормально открытых, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007343	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1B2ABM	BLUE A2 B1	S3PF-P1B2ABM, BLUE A2 B1, GL	
H5550007313	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1B2AM	BLUE A2	S3PF-P1B2AM, BLUE A2, GL	

H5550007188	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1B2B	BLUE B2	S3PF-P1B2B, BLUE B2, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Синий, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007328	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1B2BM	BLUE B2	S3PF-P1B2BM, BLUE B2, GL	
H5550007175	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1B3A	BLUE A3	S3PF-P1B3A, BLUE A3, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Синий, 3 нормально открытых, 110В~/10А, 220В~/5А
H5550007318	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1B3AM	BLUE A3	S3PF-P1B3AM, BLUE A3, GL	
H5550007193	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1B3B	BLUE B3	S3PF-P1B3B, BLUE B3, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Синий, 3 нормально закрытых, 110В~/10А, 220В~/5А
H5550007333	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1B3BM	BLUE B3	S3PF-P1B3BM, BLUE B3, GL	
H5550007212	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1BA2B	BLUE A1 B2	S3PF-P1BA2B, BLUE A1 B2, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Синий, 1 нормально открытый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007348	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1BA2BM	BLUE A1 B2	S3PF-P1BA2BM, BLUE A1 B2, GL	
H5550007199	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1BAB	BLUE A1 B1	S3PF-P1BAB, BLUE A1 B1, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Синий, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007338	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1BABM	BLUE A1 B1	S3PF-P1BABM, BLUE A1 B1, GL	
H5550007294	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1BAM	BLUE A1	S3PF-P1BAM, BLUE A1, GL	
H5550002562	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1BB	BLUE B1	S3PF-P1BB, BLUE B1, GL	

H5550007323	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1BBM	BLUE B1	S3PF-P1BBM, BLUE B1, GL	
H5550007171	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1G2A	GREEN A2	S3PF-P1G2A, GREEN A2, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Зеленый, 2 нормально открытых, 110В~/10А, 220В~/5А
H5550007208	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1G2AB	GREEN A2 B1	S3PF-P1G2AB, GREEN A2 B1, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Зеленый, 2 нормально открытых, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007344	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1G2ABM	GREEN A2 B1	S3PF-P1G2ABM, GREEN A2 B1, GL	
H5550007314	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1G2AM	GREEN A2	S3PF-P1G2AM, GREEN A2, GL	
H5550007189	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1G2B	GREEN B2	S3PF-P1G2B, GREEN B2, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Зеленый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007329	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1G2BM	GREEN B2	S3PF-P1G2BM, GREEN B2, GL	
H5550007176	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1G3A	GREEN A3	S3PF-P1G3A, GREEN A3, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Зеленый, 3 нормально открытых, 110В~/10А, 220В~/5А
H5550007319	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1G3AM	GREEN A3	S3PF-P1G3AM, GREEN A3, GL	
H5550007194	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1G3B	GREEN B3	S3PF-P1G3B, GREEN B3, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Зеленый, 3 нормально закрытых, 110В~/10А, 220В~/5А
H5550007334	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1G3BM	GREEN B3	S3PF-P1G3BM, GREEN B3, GL	
H5550007213	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1GA2B	GREEN A1 B2	S3PF-P1GA2B, GREEN A1 B2, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Зеленый, 1 нормально открытый, 2 нормально закрытых,

							110В~/10А, 220В~/5А
H5550007349	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1GA2BM	GREEN A1 B2	S3PF-P1GA2BM, GREEN A1 B2, GL	
H5550007201	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1GAB	GREEN A1 B1	S3PF-P1GAB, GREEN A1 B1, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Зеленый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007339	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1GABM	GREEN A1 B1	S3PF-P1GABM, GREEN A1 B1, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Зеленый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007296	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1GAM	GREEN A1	S3PF-P1GAM, GREEN A1, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Зеленый, Нормально открытый, 110В~/10А, 220В~/5А, многоуровневый
H5550007182	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1GB	GREEN B1	S3PF-P1GB, GREEN B1, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Зеленый, Нормально закрытый, 110В~/10А, 220В~/5А
H5550007324	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1GBM	GREEN B1	S3PF-P1GBM, GREEN B1, GL	
H5550007173	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1K2A	BLACK A2	S3PF-P1K2A, BLACK A2, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Чёрный, 2 нормально открытых, 110В~/10А, 220В~/5А
H5550007210	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1K2AB	BLACK A2 B1	S3PF-P1K2AB, BLACK A2 B1, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Чёрный, 2 нормально открытых, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007346	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1K2ABM	BLACK A2 B1	S3PF-P1K2ABM, BLACK A2 B1, GL	

H5550007316	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1K2AM	BLACK A2	S3PF-P1K2AM, BLACK A2, GL	
H5550007191	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1K2B	BLACK B2	S3PF-P1K2B, BLACK B2, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Чёрный, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007331	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1K2BM	BLACK B2	S3PF-P1K2BM, BLACK B2, GL	
H5550007178	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1K3A	BLACK A3	S3PF-P1K3A, BLACK A3, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Чёрный, 3 нормально открытых, 110В~/10А, 220В~/5А
H5550007321	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1K3AM	BLACK A3	S3PF-P1K3AM, BLACK A3, GL	
H5550007196	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1K3B	BLACK B3	S3PF-P1K3B, BLACK B3, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Чёрный, 3 нормально закрытых, 110В~/10А, 220В~/5А
H5550007336	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1K3BM	BLACK B3	S3PF-P1K3BM, BLACK B3, GL	
H5550007215	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1KA2B	BLACK A1 B2	S3PF-P1KA2B, BLACK A1 B2, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Чёрный, 1 нормально открытый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007351	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1KA2BM	BLACK A1 B2	S3PF-P1KA2BM, BLACK A1 B2, GL	
H5550009816	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1KAB	BLACK A1 B1	S3PF-P1KAB, BLACK A1 B1, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Чёрный, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007341	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1KABM	BLACK A1 B1	S3PF-P1KABM, BLACK A1 B1, GL	

H5550007300	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1KAM	BLACK A1	S3PF-P1KAM, BLACK A1, GL	
H5550007186	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1KB	BLACK B1	S3PF-P1KB, BLACK B1, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Чёрный, Нормально закрытый, 110В~/10А, 220В~/5А
H5550007326	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1KBM	BLACK B1	S3PF-P1KBM, BLACK B1, GL	
H5550007172	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1Y2A	YELLOW A2	S3PF-P1Y2A, YELLOW A2, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Желтый, 2 нормально открытых, 110В~/10А, 220В~/5А
H5550007209	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1Y2AB	YELLOW A2 B1	S3PF-P1Y2AB, YELLOW A2 B1, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Желтый, 2 нормально открытых, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007345	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1Y2ABM	YELLOW A2 B1	S3PF-P1Y2ABM, YELLOW A2 B1, GL	
H5550007315	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1Y2AM	YELLOW A2	S3PF-P1Y2AM, YELLOW A2, GL	
H5550007190	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1Y2B	YELLOW B2	S3PF-P1Y2B, YELLOW B2, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Желтый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007330	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1Y2BM	YELLOW B2	S3PF-P1Y2BM, YELLOW B2, GL	
H5550007177	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1Y3A	YELLOW A3	S3PF-P1Y3A, YELLOW A3, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Желтый, 3 нормально открытых, 110В~/10А, 220В~/5А
H5550007320	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1Y3AM	YELLOW A3	S3PF-P1Y3AM, YELLOW A3, GL	
H5550007195	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1Y3B	YELLOW B3	S3PF-P1Y3B, YELLOW B3, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Желтый, 3 нормально закрытых, 110В~/10А, 220В~/5А
H5550007335	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1Y3BM	YELLOW B3	S3PF-P1Y3BM, YELLOW B3, GL	

H5550007214	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1YA2B	YELLOW A1 B2	S3PF-P1YA2B, YELLOW A1 B2, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Желтый, 1 нормально открытый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007350	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1YA2BM	YELLOW A1 B2	S3PF-P1YA2BM, YELLOW A1 B2, GL	
H5550007203	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1YAB	YELLOW A1 B1	S3PF-P1YAB, YELLOW A1 B1, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Желтый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007340	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1YABM	YELLOW A1 B1	S3PF-P1YABM, YELLOW A1 B1, GL	Кнопочный выключатель, без подсветки, утопленный, 30, Желтый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007298	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1YAM	YELLOW A1	S3PF-P1YAM, YELLOW A1, GL	
H5550007325	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1YBM	YELLOW B1	S3PF-P1YBM, YELLOW B1, GL	
H5550002597	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3B2AD	BLUE A2 LED(DC)	S3PF-P3B2AD, BLUE A2 LED(DC), GL	
H5550007358	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3B2ADM	BLUE A2 LED(DC)	S3PF-P3B2ADM, BLUE A2 LED(DC), GL	
H5550007266	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3B2AL	BLUE A2 LED(AC)	S3PF-P3B2AL, BLUE A2 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Синий, 2 нормально открытых, СИД 100-220В~
H5550007383	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3B2ALM	BLUE A2 LED(AC)	S3PF-P3B2ALM, BLUE A2 LED(AC), GL	
H5550007240	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3B2BD	BLUE B2 LED(DC)	S3PF-P3B2BD, BLUE B2 LED(DC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Синий, 2 нормально закрытых, СИД 12-30 В=В~
H5550007368	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3B2BDM	BLUE B2 LED(DC)	S3PF-P3B2BDM, BLUE B2 LED(DC), GL	
H5550007280	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3B2BL	BLUE B2 LED(AC)	S3PF-P3B2BL, BLUE B2 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Синий, 2 нормально закрытых, СИД 100-220В~

H5550007393	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3B2BLM	BLUE B2 LED(AC)	S3PF-P3B2BLM, BLUE B2 LED(AC), GL	
H5550007246	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3BABD	BLUE A1 B1 LED(DC)	S3PF-P3BABD, BLUE A1 B1 LED(DC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Синий, 1 нормально открытый, 1 нормально закрытый, СИД 12-30 В~/В~
H5550007373	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3BABDM	BLUE A1 B1 LED(DC)	S3PF-P3BABDM, BLUE A1 B1 LED(DC), GL	
H5550007398	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3BABLM	BLUE A1 B1 LED(AC)	S3PF-P3BABLM, BLUE A1 B1 LED(AC), GL	
H5550007353	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3BADM	BLUE A1 LED(DC)	S3PF-P3BADM, BLUE A1 LED(DC), GL	
H5550007378	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3BALM	BLUE A1 LED(AC)	S3PF-P3BALM, BLUE A1 LED(AC), GL	
H5550007363	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3BBDM	BLUE B1 LED(DC)	S3PF-P3BBDM, BLUE B1 LED(DC), GL	
H5550002627	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3BBL	BLUE B1 LED(AC)	S3PF-P3BBL, BLUE B1 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Синий, Нормально закрытый, СИД 100-220В~
H5550007388	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3BBLM	BLUE B1 LED(AC)	S3PF-P3BBLM, BLUE B1 LED(AC), GL	
H5550007359	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3G2ADM	GREEN A2 LED(DC)	S3PF-P3G2ADM, GREEN A2 LED(DC), GL	
H5550007267	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3G2AL	GREEN A2 LED(AC)	S3PF-P3G2AL, GREEN A2 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Зеленый, 2 нормально открытых, СИД 100-220В~
H5550007384	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3G2ALM	GREEN A2 LED(AC)	S3PF-P3G2ALM, GREEN A2 LED(AC), GL	
H5550007241	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3G2BD	GREEN B2 LED(DC)	S3PF-P3G2BD, GREEN B2 LED(DC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Зеленый, 2 нормально закрытых, СИД 12-30 В~/В~
H5550007369	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3G2BDM	GREEN B2 LED(DC)	S3PF-P3G2BDM, GREEN B2 LED(DC), GL	

H5550007281	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3G2BL	GREEN B2 LED(AC)	S3PF-P3G2BL, GREEN B2 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Зеленый, 2 нормально закрытых, СИД 100-220В~
H5550007394	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3G2BLM	GREEN B2 LED(AC)	S3PF-P3G2BLM, GREEN B2 LED(AC), GL	
H5550007374	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3GABDM	GREEN A1 B1 LED(DC)	S3PF-P3GABDM, GREEN A1 B1 LED(DC), GL	
H5550007288	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3GABL	GREEN A1 B1 LED(AC)	S3PF-P3GABL, GREEN A1 B1 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Зеленый, 1 нормально открытый, 1 нормально закрытый, СИД 100-220В~
H5550007399	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3GABLM	GREEN A1 B1 LED(AC)	S3PF-P3GABLM, GREEN A1 B1 LED(AC), GL	
H5550007354	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3GADM	GREEN A1 LED(DC)	S3PF-P3GADM, GREEN A1 LED(DC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Зеленый, Нормально открытый, СИД 12-30 В=В~
H5550007379	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3GALM	GREEN A1 LED(AC)	S3PF-P3GALM, GREEN A1 LED(AC), GL	
H5550007235	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3GBD	GREEN B1 LED(DC)	S3PF-P3GBD, GREEN B1 LED(DC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Зеленый, Нормально закрытый, СИД 12-30 В=В~
H5550007364	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3GBDM	GREEN B1 LED(DC)	S3PF-P3GBDM, GREEN B1 LED(DC), GL	
H5550007274	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3GBL	GREEN B1 LED(AC)	S3PF-P3GBL, GREEN B1 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Зеленый, Нормально закрытый, СИД 100-220В~
H5550007389	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3GBLM	GREEN B1 LED(AC)	S3PF-P3GBLM, GREEN B1 LED(AC), GL	

H5550007365	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3RYDM	YELLOW B1 LED(DC)	S3PF-P3RYDM, YELLOW B1 LED(DC),	
H5550007231	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3W2AD	WHITE A2 LED(DC)	S3PF-P3W2AD, WHITE A2 LED(DC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Белый, 2 нормально открытых, СИД 12-30 В=/В~
H5550007361	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3W2ADM	WHITE A2 LED(DC)	S3PF-P3W2ADM, WHITE A2 LED(DC), GL	
H5550007270	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3W2AL	WHITE A2 LED(AC)	S3PF-P3W2AL, WHITE A2 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Белый, 2 нормально открытых, СИД 100-220В~
H5550007386	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3W2ALM	WHITE A2 LED(AC)	S3PF-P3W2ALM, WHITE A2 LED(AC), GL	
H5550007243	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3W2BD	WHITE B2 LED(DC)	S3PF-P3W2BD, WHITE B2 LED(DC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Белый, 2 нормально закрытых, СИД 12-30 В=/В~
H5550007371	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3W2BDM	WHITE B2 LED(DC)	S3PF-P3W2BDM, WHITE B2 LED(DC), GL	
H5550007283	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3W2BL	WHITE B2 LED(AC)	S3PF-P3W2BL, WHITE B2 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Белый, 2 нормально закрытых, СИД 100-220В~
H5550007396	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3W2BLM	WHITE B2 LED(AC)	S3PF-P3W2BLM, WHITE B2 LED(AC), GL	
H5550007252	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3WABD	WHITE A1 B1 LED(DC)	S3PF-P3WABD, WHITE A1 B1 LED(DC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Белый, 1 нормально открытый, 1 нормально закрытый, СИД 12-30 В=/В~
H5550007376	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3WABDM	WHITE A1 B1 LED(DC)	S3PF-P3WABDM, WHITE A1 B1 LED(DC), GL	
H5550007291	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3WABL	WHITE A1 B1 LED(AC)	S3PF-P3WABL, WHITE A1 B1 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Белый, 1 нормально открытый, 1 нормально закрытый, СИД 100-220В~

H5550007401	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3WABLM	WHITE A1 B1 LED(AC)	S3PF-P3WABLM, WHITE A1 B1 LED(AC), GL	
H5550007356	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3WADM	WHITE A1 LED(DC)	S3PF-P3WADM, WHITE A1 LED(DC), GL	
H5550007262	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3WAL	WHITE A1 LED(AC)	S3PF-P3WAL, WHITE A1 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Белый, Нормально открытый, СИД 100-220В~
H5550007381	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3WALM	WHITE A1 LED(AC)	S3PF-P3WALM, WHITE A1 LED(AC), GL	
H5550002605	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3WBD	WHITE B1 LED(DC)	S3PF-P3WBD, WHITE B1 LED(DC), GL	
H5550007366	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3WBDM	WHITE B1 LED(DC)	S3PF-P3WBDM, WHITE B1 LED(DC), GL	
H5550002630	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3WBL	WHITE B1 LED(AC)	S3PF-P3WBL, WHITE B1 LED(AC), GL	
H5550007391	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3WBLM	WHITE B1 LED(AC)	S3PF-P3WBLM, WHITE B1 LED(AC), GL	
H5550007230	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3Y2AD	YELLOW A2 LED(DC)	S3PF-P3Y2AD, YELLOW A2 LED(DC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Желтый, 2 нормально открытых, СИД 12-30 В=В~
H5550007360	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3Y2ADM	YELLOW A2 LED(DC)	S3PF-P3Y2ADM, YELLOW A2 LED(DC), GL	
H5550007269	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3Y2AL	YELLOW A2 LED(AC)	S3PF-P3Y2AL, YELLOW A2 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Желтый, 2 нормально открытых, СИД 100-220В~
H5550007385	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3Y2ALM	YELLOW A2 LED(AC)	S3PF-P3Y2ALM, YELLOW A2 LED(AC), GL	
H5550007242	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3Y2BD	YELLOW B2 LED(DC)	S3PF-P3Y2BD, YELLOW B2 LED(DC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Желтый, 2 нормально закрытых, СИД 12-30 В=В~

H5550007370	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3Y2BDM	YELLOW B2 LED(DC)	S3PF-P3Y2BDM, YELLOW B2 LED(DC), GL	
H5550007282	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3Y2BL	YELLOW B2 LED(AC)	S3PF-P3Y2BL, YELLOW B2 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Желтый, 2 нормально закрытых, СИД 100-220В~
H5550007395	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3Y2BLM	YELLOW B2 LED(AC)	S3PF-P3Y2BLM, YELLOW B2 LED(AC), GL	
H5550007250	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3YABD	YELLOW A1 B1 LED(DC)	S3PF-P3YABD, YELLOW A1 B1 LED(DC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Желтый, 1 нормально открытый, 1 нормально закрытый, СИД 12-30 В=В~
H5550007375	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3YABDM	YELLOW A1 B1 LED(DC)	S3PF-P3YABDM, YELLOW A1 B1 LED(DC), GL	
H5550007290	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3YABL	YELLOW A1 B1 LED(AC)	S3PF-P3YABL, YELLOW A1 B1 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Желтый, 1 нормально открытый, 1 нормально закрытый, СИД 100-220В~
H5550007400	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3YABLM	YELLOW A1 B1 LED(AC)	S3PF-P3YABLM, YELLOW A1 B1 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Желтый, 1 нормально открытый, 1 нормально закрытый, СИД 100-220В~, многоуровневый
H5550007355	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3YADM	YELLOW A1 LED(DC)	S3PF-P3YADM, YELLOW A1 LED(DC), GL	
H5550007260	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3YAL	YELLOW A1 LED(AC)	S3PF-P3YAL, YELLOW A1 LED(AC), GL	Кнопочный выключатель, с подсветкой, утопленный, 30, Желтый, Нормально открытый, СИД 100-220В~
H5550007380	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3YALM	YELLOW A1 LED(AC)	S3PF-P3YALM, YELLOW A1 LED(AC), GL	

H5550007390	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3YBLM	YELLOW B1 LED(AC)	S3PF-P3YBLM, YELLOW B1 LED(AC), GL	
H5550007062	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1B2A	BLUE A2	S3PR-P1B2A, BLUE A2, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Синий, 2 нормально открытых, 110В~/10А, 220В~/5А
H5550007100	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1B2AB	BLUE A2 B1	S3PR-P1B2AB, BLUE A2 B1, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Синий, 2 нормально открытых, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007150	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1B2ABM	BLUE A2 B1	S3PR-P1B2ABM, BLUE A2 B1, GL	
H5550007120	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1B2AM	BLUE A2	S3PR-P1B2AM, BLUE A2, GL	
H5550007080	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1B2B	BLUE B2	S3PR-P1B2B, BLUE B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Синий, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007135	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1B2BM	BLUE B2	S3PR-P1B2BM, BLUE B2, GL	
H5550007069	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1B3A	BLUE A3	S3PR-P1B3A, BLUE A3, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Синий, 3 нормально открытых, 110В~/10А, 220В~/5А
H5550007125	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1B3AM	BLUE A3	S3PR-P1B3AM, BLUE A3, GL	
H5550007085	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1B3B	BLUE B3	S3PR-P1B3B, BLUE B3, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Синий, 3 нормально закрытых, 110В~/10А, 220В~/5А
H5550007140	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1B3BM	BLUE B3	S3PR-P1B3BM, BLUE B3, GL	
H5550002452	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1BA	BLUE A1	S3PR-P1BA, BLUE A1, GL	
H5550007105	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1BA2B	BLUE A1 B2	S3PR-P1BA2B, BLUE A1 B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Синий, 1 Нормально открытый, 2

							нормально закрытых, 110В~/10А, 220В~/5А
H5550007155	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1BA2BM	BLUE A1 B2	S3PR-P1BA2BM, BLUE A1 B2, GL	
H5550007145	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1BABM	BLUE A1 B1	S3PR-P1BABM, BLUE A1 B1, GL	
H5550007111	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1BAM	BLUE A1	S3PR-P1BAM, BLUE A1, GL	
H5550002467	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1BB	BLUE B1	S3PR-P1BB, BLUE B1, GL	
H5550007130	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1BBM	BLUE B1	S3PR-P1BBM, BLUE B1, GL	
H5550007101	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1G2AB	GREEN A2 B1	S3PR-P1G2AB, GREEN A2 B1, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Зеленый, 2 нормально открытых, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007151	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1G2ABM	GREEN A2 B1	S3PR-P1G2ABM, GREEN A2 B1, GL	
H5550007121	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1G2AM	GREEN A2	S3PR-P1G2AM, GREEN A2, GL	
H5550007081	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1G2B	GREEN B2	S3PR-P1G2B, GREEN B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Зеленый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007136	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1G2BM	GREEN B2	S3PR-P1G2BM, GREEN B2, GL	
H5550007070	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1G3A	GREEN A3	S3PR-P1G3A, GREEN A3, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Зеленый, 3 нормально открытых, 110В~/10А, 220В~/5А
H5550007126	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1G3AM	GREEN A3	S3PR-P1G3AM, GREEN A3, GL	
H5550007086	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1G3B	GREEN B3	S3PR-P1G3B, GREEN B3, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Зеленый, 3 нормально закрытых, 110В~/10А, 220В~/5А
H5550007141	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1G3BM	GREEN B3	S3PR-P1G3BM, GREEN B3, GL	

H5550007106	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1GA2B	GREEN A1 B2	S3PR-P1GA2B, GREEN A1 B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Зеленый, 1 нормально открытый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007156	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1GA2BM	GREEN A1 B2	S3PR-P1GA2BM, GREEN A1 B2, GL	
H5550007093	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1GAB	GREEN A1 B1	S3PR-P1GAB, GREEN A1 B1, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Зеленый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007146	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1GABM	GREEN A1 B1	S3PR-P1GABM, GREEN A1 B1, GL	
H5550007113	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1GAM	GREEN A1	S3PR-P1GAM, GREEN A1, GL	
H5550002468	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1GB	GREEN B1	S3PR-P1GB, GREEN B1, GL	
H5550007131	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1GBM	GREEN B1	S3PR-P1GBM, GREEN B1, GL	
H5550007066	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1K2A	BLACK A2	S3PR-P1K2A, BLACK A2, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Чёрный, 2 нормально открытых, 110В~/10А, 220В~/5А
H5550007103	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1K2AB	BLACK A2 B1	S3PR-P1K2AB, BLACK A2 B1, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Чёрный, 2 нормально открытых, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007153	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1K2ABM	BLACK A2 B1	S3PR-P1K2ABM, BLACK A2 B1, GL	
H5550007123	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1K2AM	BLACK A2	S3PR-P1K2AM, BLACK A2, GL	
H5550007083	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1K2B	BLACK B2	S3PR-P1K2B, BLACK B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Чёрный, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007138	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1K2BM	BLACK B2	S3PR-P1K2BM, BLACK B2, GL	

H5550007072	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1K3A	BLACK A3	S3PR-P1K3A, BLACK A3, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Чёрный, 3 нормально открытых, 110В~/10А, 220В~/5А
H5550007128	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1K3AM	BLACK A3	S3PR-P1K3AM, BLACK A3, GL	
H5550007088	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1K3B	BLACK B3	S3PR-P1K3B, BLACK B3, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Чёрный, 3 нормально закрытых, 110В~/10А, 220В~/5А
H5550007143	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1K3BM	BLACK B3	S3PR-P1K3BM, BLACK B3, GL	
H5550007059	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1KA	BLACK A1	S3PR-P1KA, BLACK A1, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Чёрный, Нормально открытый, 110В~/10А, 220В~/5А
H5550007108	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1KA2B	BLACK A1 B2	S3PR-P1KA2B, BLACK A1 B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Чёрный, 1 нормально открытый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550010346	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1KA2BM	BLACK A1 B2	S3PR-P1KA2BM, BLACK A1 B2, GL	
H5550007097	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1KAB	BLACK A1 B1	S3PR-P1KAB, BLACK A1 B1, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Чёрный, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007148	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1KABM	BLACK A1 B1	S3PR-P1KABM, BLACK A1 B1, GL	
H5550007117	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1KAM	BLACK A1	S3PR-P1KAM, BLACK A1, GL	
H5550009817	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1KB	BLACK B1	S3PR-P1KB, BLACK B1, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Чёрный, Нормально закрытый, 110В~/10А, 220В~/5А
H5550007133	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1KBM	BLACK B1	S3PR-P1KBM, BLACK B1, GL	
H5550007065	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1Y2A	YELLOW A2	S3PR-P1Y2A, YELLOW A2, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Желтый, 2 нормально открытых, 110В~/10А,

							220В~/5А
H5550007102	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1Y2AB	YELLOW A2 B1	S3PR-P1Y2AB, YELLOW A2 B1, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Желтый, 2 нормально открытых, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007152	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1Y2ABM	YELLOW A2 B1	S3PR-P1Y2ABM, YELLOW A2 B1, GL	
H5550007122	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1Y2AM	YELLOW A2	S3PR-P1Y2AM, YELLOW A2, GL	
H5550007082	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1Y2B	YELLOW B2	S3PR-P1Y2B, YELLOW B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Желтый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007137	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1Y2BM	YELLOW B2	S3PR-P1Y2BM, YELLOW B2, GL	
H5550007071	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1Y3A	YELLOW A3	S3PR-P1Y3A, YELLOW A3, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Желтый, 3 нормально открытых, 110В~/10А, 220В~/5А
H5550007127	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1Y3AM	YELLOW A3	S3PR-P1Y3AM, YELLOW A3, GL	
H5550007087	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1Y3B	YELLOW B3	S3PR-P1Y3B, YELLOW B3, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Желтый, 3 нормально закрытых, 110В~/10А, 220В~/5А
H5550007142	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1Y3BM	YELLOW B3	S3PR-P1Y3BM, YELLOW B3, GL	
H5550007058	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1YA	YELLOW A1	S3PR-P1YA, YELLOW A1, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Желтый, Нормально открытый, 110В~/10А, 220В~/5А
H5550007107	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1YA2B	YELLOW A1 B2	S3PR-P1YA2B, YELLOW A1 B2, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Желтый, 1 нормально открытый, 2 нормально закрытых, 110В~/10А, 220В~/5А

H5550007157	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1YA2BM	YELLOW A1 B2	S3PR-P1YA2BM, YELLOW A1 B2, GL	
H5550007095	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1YAB	YELLOW A1 B1	S3PR-P1YAB, YELLOW A1 B1, GL	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Желтый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007147	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1YABM	YELLOW A1 B1	S3PR-P1YABM, YELLOW A1 B1, GL	
H5550007115	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1YAM	YELLOW A1	S3PR-P1YAM, YELLOW A1, GL	
H5550002469	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1YB	YELLOW B1	S3PR-P1YB, YELLOW B1, GL	
H5550007132	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1YBM	YELLOW B1	S3PR-P1YBM, YELLOW B1, GL	
H5550010904	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1R	RED (HEAD)	S3SF-S1R, RED (HEAD), GL	
H5550010915	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1W	WHITE (HEAD)	S3SF-S1W, WHITE (HEAD), GL	
H5550010917	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1W2AM	WHITE A2	S3SF-S1W2AM, WHITE A2, GL	
H5550010918	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1W2B	WHITE B2	S3SF-S1W2B, WHITE B2, GL	
H5550010919	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1W2BM	WHITE B2	S3SF-S1W2BM, WHITE B2, GL	
H5550010920	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1WA	WHITE A	S3SF-S1WA, WHITE A, GL	
H5550010921	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1WAB	WHITE AB	S3SF-S1WAB, WHITE AB, GL	
H5550010922	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1WABM	WHITE AB	S3SF-S1WABM, WHITE AB, GL	
H5550010923	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1WAM	WHITE A	S3SF-S1WAM, WHITE A, GL	

H5550010924	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1WB	WHITE B	S3SF-S1WB, WHITE B, GL	
H5550010925	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1WBM	WHITE B	S3SF-S1WBM, WHITE B, GL	
H5550010926	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2R	RED (HEAD)	S3SF-S2R, RED (HEAD), GL	
H5550010937	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2W	WHITE (HEAD)	S3SF-S2W, WHITE (HEAD), GL	
H5550010938	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2W2A	WHITE A2	S3SF-S2W2A, WHITE A2, GL	
H5550010939	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2W2AM	WHITE A2	S3SF-S2W2AM, WHITE A2, GL	
H5550010940	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2W2B	WHITE B2	S3SF-S2W2B, WHITE B2, GL	
H5550010941	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2W2BM	WHITE B2	S3SF-S2W2BM, WHITE B2, GL	
H5550010942	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2WA	WHITE A	S3SF-S2WA, WHITE A, GL	
H5550010943	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2WAB	WHITE AB	S3SF-S2WAB, WHITE AB, GL	
H5550010944	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2WABM	WHITE AB	S3SF-S2WABM, WHITE AB, GL	
H5550010945	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2WAM	WHITE A	S3SF-S2WAM, WHITE A, GL	
H5550010946	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2WB	WHITE B	S3SF-S2WB, WHITE B, GL	
H5550010947	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2WBM	WHITE B	S3SF-S2WBM, WHITE B, GL	
H5550007472	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3W2AM	WHITE A2	S3SF-S3W2AM, WHITE A2, GL	
H5550007412	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3W2B	WHITE B2	S3SF-S3W2B, WHITE B2, GL	Селекторный переключатель, 30мм, 2-позиционный, С фиксацией, С короткой рукояткой, Белый, 2 нормально закрытых, 110В~/10А, 220В~/5А

H5550007476	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3W2BM	WHITE B2	S3SF-S3W2BM, WHITE B2, GL	
H5550007402	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3WA	WHITE A1	S3SF-S3WA, WHITE A1, GL	Селекторный переключатель, 30мм, 2-позиционный, С фиксацией, С короткой рукояткой, Белый, 1 нормально открытый, 110В~/10А, 220В~/5А
H5550007414	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3WAB	WHITE A1 B1	S3SF-S3WAB, WHITE A1 B1, GL	Селекторный переключатель, 30мм, 2-позиционный, С фиксацией, С короткой рукояткой, Белый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007478	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3WABM	WHITE A1 B1	S3SF-S3WABM, WHITE A1 B1, GL	Селекторный переключатель, 30мм, 2-позиционный, С фиксацией, С короткой рукояткой, Белый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007468	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3WAM	WHITE A1	S3SF-S3WAM, WHITE A1, GL	
H5550007410	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3WB	WHITE B1	S3SF-S3WB, WHITE B1, GL	Селекторный переключатель, 30мм, 2-позиционный, С фиксацией, С короткой рукояткой, Белый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007474	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3WBM	WHITE B1	S3SF-S3WBM, WHITE B1, GL	
H5550002763	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4W2A	WHITE A2	S3SF-S4W2A, WHITE A2, GL	
H5550007484	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4W2AM	WHITE A2	S3SF-S4W2AM, WHITE A2, GL	
H5550007425	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4W2B	WHITE B2	S3SF-S4W2B, WHITE B2, GL	Селекторный переключатель, 30мм, 2-позиционный, С фиксацией, С длинной рукояткой, Белый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007488	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4W2BM	WHITE B2	S3SF-S4W2BM, WHITE B2, GL	
H5550007417	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4WA	WHITE A1	S3SF-S4WA, WHITE A1, GL	Селекторный переключатель, 30мм, 2-позиционный, С фиксацией, С длинной рукояткой, Белый, 1 нормально открытый, 110В~/10А, 220В~/5А

H5550007490	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4WABM	WHITE A1 B1	S3SF-S4WABM, WHITE A1 B1, GL	
H5550007480	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4WAM	WHITE A1	S3SF-S4WAM, WHITE A1, GL	
H5550009818	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4WB	WHITE B1	S3SF-S4WB, WHITE B1, GL	Селекторный переключатель, 30мм, 2-позиционный, С фиксацией, С длинной рукояткой, Белый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007486	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4WBM	WHITE B1	S3SF-S4WBM, WHITE B1, GL	
H5550010948	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5KR	RED (HEAD)	S3SF-S5KR, RED (HEAD), GL	
H5550010955	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5KW	WHITE (HEAD)	S3SF-S5KW, WHITE (HEAD), GL	
H5550010956	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5KW2A	WHITE A2	S3SF-S5KW2A, WHITE A2, GL	
H5550010957	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5KW2AM	WHITE A2	S3SF-S5KW2AM, WHITE A2, GL	
H5550010958	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5KW2B	WHITE B2	S3SF-S5KW2B, WHITE B2, GL	
H5550010959	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5KW2BM	WHITE B2	S3SF-S5KW2BM, WHITE B2, GL	
H5550010960	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5KWAB	WHITE AB	S3SF-S5KWAB, WHITE AB, GL	
H5550010961	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5KWABM	WHITE AB	S3SF-S5KWABM, WHITE AB, GL	
H5550007494	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5W2AM	WHITE A2	S3SF-S5W2AM, WHITE A2, GL	
H5550007434	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5W2B	WHITE B2	S3SF-S5W2B, WHITE B2, GL	Селекторный переключатель, 30мм, 3-позиционный, С самовозвратом, С короткой рукояткой, Белый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007496	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5W2BM	WHITE B2	S3SF-S5W2BM, WHITE B2, GL	
H5550010860	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5WA	WHITE A1	S3SF-S5WA, WHITE A1, GL	

H5550007436	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5WAB	WHITE A1 B1	S3SF-S5WAB, WHITE A1 B1, GL	Селекторный переключатель, 30мм, 3-позиционный, С самовозвратом, С короткой рукояткой, Белый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007498	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5WABM	WHITE A1 B1	S3SF-S5WABM, WHITE A1 B1, GL	
H5550010861	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5WAM	WHITE A1	S3SF-S5WAM, WHITE A1, GL	
H5550010864	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5WB	WHITE B1	S3SF-S5WB, WHITE B1, GL	
H5550010865	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5WBM	WHITE B1	S3SF-S5WBM, WHITE B1, GL	
H5550010962	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6KR	RED (HEAD)	S3SF-S6KR, RED (HEAD), GL	
H5550010969	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6KW	WHITE (HEAD)	S3SF-S6KW, WHITE (HEAD), GL	
H5550010970	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6KW2A	WHITE A2	S3SF-S6KW2A, WHITE A2, GL	
H5550010971	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6KW2AM	WHITE A2	S3SF-S6KW2AM, WHITE A2, GL	
H5550010972	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6KW2B	WHITE B2	S3SF-S6KW2B, WHITE B2, GL	
H5550010973	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6KW2BM	WHITE B2	S3SF-S6KW2BM, WHITE B2, GL	
H5550010974	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6KWAB	WHITE AB	S3SF-S6KWAB, WHITE AB, GL	
H5550010975	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6KWABM	WHITE AB	S3SF-S6KWABM, WHITE AB, GL	
H5550007502	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6W2AM	WHITE A2	S3SF-S6W2AM, WHITE A2, GL	
H5550007443	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6W2B	WHITE B2	S3SF-S6W2B, WHITE B2, GL	Селекторный переключатель, 30мм, 3-позиционный, С самовозвратом, С длинной рукояткой, Белый, 2 нормально закрытых, 110В~/10А, 220В~/5А

H5550007504	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6W2BM	WHITE B2	S3SF-S6W2BM, WHITE B2, GL	
H5550010874	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6WA	WHITE A1	S3SF-S6WA, WHITE A1, GL	
H5550002781	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6WAB	WHITE A1 B1	S3SF-S6WAB, WHITE A1 B1, GL	
H5550007506	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6WABM	WHITE A1 B1	S3SF-S6WABM, WHITE A1 B1, GL	
H5550010875	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6WAM	WHITE A1	S3SF-S6WAM, WHITE A1, GL	
H5550010877	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6WB	WHITE B1	S3SF-S6WB, WHITE B1, GL	
H5550010878	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6WBM	WHITE B1	S3SF-S6WBM, WHITE B1, GL	
H5550010976	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7KR	RED (HEAD)	S3SF-S7KR, RED (HEAD), GL	
H5550010983	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7KW	WHITE (HEAD)	S3SF-S7KW, WHITE (HEAD), GL	
H5550010984	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7KW2A	WHITE A2	S3SF-S7KW2A, WHITE A2, GL	
H5550010985	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7KW2AM	WHITE A2	S3SF-S7KW2AM, WHITE A2, GL	
H5550010986	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7KW2B	WHITE B2	S3SF-S7KW2B, WHITE B2, GL	
H5550010987	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7KW2BM	WHITE B2	S3SF-S7KW2BM, WHITE B2, GL	
H5550010988	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7KWAB	WHITE AB	S3SF-S7KWAB, WHITE AB, GL	
H5550010989	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7KWABM	WHITE AB	S3SF-S7KWABM, WHITE AB, GL	
H5550007510	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7W2AM	WHITE A2	S3SF-S7W2AM, WHITE A2, GL	
H5550007452	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7W2B	WHITE B2	S3SF-S7W2B, WHITE B2, GL	Селекторный переключатель, 30мм, 3-позиционный, С фиксацией, С короткой рукояткой, Белый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007512	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7W2BM	WHITE B2	S3SF-S7W2BM, WHITE B2, GL	

H5550010886	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7WA	WHITE A1	S3SF-S7WA, WHITE A1, GL	
H5550007454	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7WAB	WHITE A1 B1	S3SF-S7WAB, WHITE A1 B1, GL	Селекторный переключатель, 30мм, 3-позиционный, С фиксацией, С короткой рукояткой, Белый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007514	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7WABM	WHITE A1 B1	S3SF-S7WABM, WHITE A1 B1, GL	Селекторный переключатель, 30мм, 3-позиционный, С фиксацией, С длинной рукояткой, Белый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550010887	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7WAM	WHITE A1	S3SF-S7WAM, WHITE A1, GL	
H5550010890	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7WB	WHITE B1	S3SF-S7WB, WHITE B1, GL	
H5550010891	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7WBM	WHITE B1	S3SF-S7WBM, WHITE B1, GL	
H5550010990	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8KR	RED (HEAD)	S3SF-S8KR, RED (HEAD), GL	
H5550010997	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8KW	WHITE (HEAD)	S3SF-S8KW, WHITE (HEAD), GL	
H5550010998	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8KW2A	WHITE A2	S3SF-S8KW2A, WHITE A2, GL	
H5550010999	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8KW2AM	WHITE A2	S3SF-S8KW2AM, WHITE A2, GL	
H5550011000	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8KW2B	WHITE B2	S3SF-S8KW2B, WHITE B2, GL	
H5550011001	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8KW2BM	WHITE B2	S3SF-S8KW2BM, WHITE B2, GL	
H5550011002	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8KWAB	WHITE AB	S3SF-S8KWAB, WHITE AB, GL	
H5550011003	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8KWABM	WHITE AB	S3SF-S8KWABM, WHITE AB, GL	
H5550007458	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8W2A	WHITE A2	S3SF-S8W2A, WHITE A2, GL	Селекторный переключатель, 30мм, 3-позиционный, С фиксацией, С длинной рукояткой, Белый, 2 нормально

							открытых 110В~/10А, 220В~/5А
H5550007518	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8W2AM	WHITE A2	S3SF-S8W2AM, WHITE A2, GL	
H5550007462	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8W2B	WHITE B2	S3SF-S8W2B, WHITE B2, GL	Селекторный переключатель, 30мм, 3-позиционный, С фиксацией, С длинной рукояткой, Белый, 2 нормально закрытых, 110В~/10А, 220В~/5А
H5550007520	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8W2BM	WHITE B2	S3SF-S8W2BM, WHITE B2, GL	
H5550010899	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8WA	WHITE A1	S3SF-S8WA, WHITE A1, GL	
H5550007464	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8WAB	WHITE A1 B1	S3SF-S8WAB, WHITE A1 B1, GL	Селекторный переключатель, 30мм, 3-позиционный, С фиксацией, С длинной рукояткой, Белый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
H5550007522	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8WABM	WHITE A1 B1	S3SF-S8WABM, WHITE A1 B1, GL	
H5550010900	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8WAM	WHITE A1	S3SF-S8WAM, WHITE A1, GL	
H5550010902	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8WB	WHITE B1	S3SF-S8WB, WHITE B1, GL	
H5550010903	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8WBM	WHITE B1	S3SF-S8WBM, WHITE B1, GL	
H5550011004	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SAKR	RED (HEAD)	S3SF-SAKR, RED (HEAD), GL	
H5550011011	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SAKW	WHITE (HEAD)	S3SF-SAKW, WHITE (HEAD), GL	
H5550011012	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SAKW2A	WHITE A2	S3SF-SAKW2A, WHITE A2, GL	
H5550011013	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SAKW2AM	WHITE A2	S3SF-SAKW2AM, WHITE A2, GL	
H5550011014	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SAKW2B	WHITE B2	S3SF-SAKW2B, WHITE B2, GL	
H5550011015	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SAKW2BM	WHITE B2	S3SF-SAKW2BM, WHITE B2, GL	

H5550011016	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SAKWAB	WHITE AB	S3SF-SAKWAB, WHITE AB, GL
H5550011017	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SAKWABM	WHITE AB	S3SF-SAKWABM, WHITE AB, GL
H5550011018	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SBKR	RED (HEAD)	S3SF-SBKR, RED (HEAD), GL
H5550011025	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SBKW	WHITE (HEAD)	S3SF-SBKW, WHITE (HEAD), GL
H5550011026	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SBKW2A	WHITE A2	S3SF-SBKW2A, WHITE A2, GL
H5550011027	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SBKW2AM	WHITE A2	S3SF-SBKW2AM, WHITE A2, GL
H5550011028	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SBKW2B	WHITE B2	S3SF-SBKW2B, WHITE B2, GL
H5550011029	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SBKW2BM	WHITE B2	S3SF-SBKW2BM, WHITE B2, GL
H5550011030	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SBKWAB	WHITE AB	S3SF-SBKWAB, WHITE AB, GL
H5550011031	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SBKWABM	WHITE AB	S3SF-SBKWABM, WHITE AB, GL
H5550011032	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SCKR	RED (HEAD)	S3SF-SCKR, RED (HEAD), GL
H5550011039	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SCKW	WHITE (HEAD)	S3SF-SCKW, WHITE (HEAD), GL
H5550011040	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SCKW2A	WHITE A2	S3SF-SCKW2A, WHITE A2, GL
H5550011041	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SCKW2AM	WHITE A2	S3SF-SCKW2AM, WHITE A2, GL
H5550011042	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SCKW2B	WHITE B2	S3SF-SCKW2B, WHITE B2, GL
H5550011043	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SCKW2BM	WHITE B2	S3SF-SCKW2BM, WHITE B2, GL
H5550011044	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SCKWAB	WHITE AB	S3SF-SCKWAB, WHITE AB, GL
H5550011045	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SCKWABM	WHITE AB	S3SF-SCKWABM, WHITE AB, GL

H5550011046	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SDKR	RED (HEAD)	S3SF-SDKR, RED (HEAD), GL	
H5550011053	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SDKW	WHITE (HEAD)	S3SF-SDKW, WHITE (HEAD), GL	
H5550011054	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SDKW2A	WHITE A2	S3SF-SDKW2A, WHITE A2, GL	
H5550011055	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SDKW2AM	WHITE A2	S3SF-SDKW2AM, WHITE A2, GL	
H5550011056	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SDKW2B	WHITE B2	S3SF-SDKW2B, WHITE B2, GL	
H5550011057	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SDKW2BM	WHITE B2	S3SF-SDKW2BM, WHITE B2, GL	
H5550011058	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SDKWAB	WHITE AB	S3SF-SDKWAB, WHITE AB, GL	
H5550011059	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SDKWABM	WHITE AB	S3SF-SDKWABM, WHITE AB, GL	
H5550007670	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AB		S3SFN-L1AB, , GL	
H5550008020	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AB2AD	BLUE A2 DC	S3SFN-L1AB2AD, BLUE A2 DC, GL	
H5550008021	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AB2ADM	BLUE A2 DC	S3SFN-L1AB2ADM, BLUE A2 DC, GL	
H5550008532	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AB2AL	BLUE A2 AC	S3SFN-L1AB2AL, BLUE A2 AC, GL	
H5550008533	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AB2ALM	BLUE A2 AC	S3SFN-L1AB2ALM, BLUE A2 AC, GL	
H5550008068	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AB2BD	BLUE B2 DC	S3SFN-L1AB2BD, BLUE B2 DC, GL	
H5550008069	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AB2BDM	BLUE B2 DC	S3SFN-L1AB2BDM, BLUE B2 DC, GL	
H5550008580	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AB2BL	BLUE B2 AC	S3SFN-L1AB2BL, BLUE B2 AC, GL	
H5550008581	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AB2BLM	BLUE B2 AC	S3SFN-L1AB2BLM, BLUE B2 AC, GL	
H5550008100	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ABABD	BLUE A1 B1 DC	S3SFN-L1ABABD, BLUE A1 B1 DC, GL	

H5550008101	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ABABDM	BLUE A1 B1 DC	S3SFN-L1ABABDM, BLUE A1 B1 DC, GL
H5550008612	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ABABL	BLUE A1 B1 AC	S3SFN-L1ABABL, BLUE A1 B1 AC, GL
H5550008613	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ABABLM	BLUE A1 B1 AC	S3SFN-L1ABABLM, BLUE A1 B1 AC, GL
H5550008004	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ABAD	BLUE A1 DC	S3SFN-L1ABAD, BLUE A1 DC, GL
H5550008005	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ABADM	BLUE A1 DC	S3SFN-L1ABADM, BLUE A1 DC, GL
H5550008516	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ABAL	BLUE A1 AC	S3SFN-L1ABAL, BLUE A1 AC, GL
H5550008517	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ABALM	BLUE A1 AC	S3SFN-L1ABALM, BLUE A1 AC, GL
H5550008052	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ABBD	BLUE B1 DC	S3SFN-L1ABBD, BLUE B1 DC, GL
H5550008053	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ABBDM	BLUE B1 DC	S3SFN-L1ABBDM, BLUE B1 DC, GL
H5550008564	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ABBL	BLUE B1 AC	S3SFN-L1ABBL, BLUE B1 AC, GL
H5550008565	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ABBLM	BLUE B1 AC	S3SFN-L1ABBLM, BLUE B1 AC, GL
H5550007718	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AG		S3SFN-L1AG, , GL
H5550008148	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AG2AD	GREEN A2 DC	S3SFN-L1AG2AD, GREEN A2 DC, GL
H5550008149	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AG2ADM	GREEN A2 DC	S3SFN-L1AG2ADM, GREEN A2 DC, GL
H5550008660	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AG2AL	GREEN A2 AC	S3SFN-L1AG2AL, GREEN A2 AC, GL
H5550008661	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AG2ALM	GREEN A2 AC	S3SFN-L1AG2ALM, GREEN A2 AC, GL
H5550008196	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AG2BD	GREEN B2 DC	S3SFN-L1AG2BD, GREEN B2 DC, GL
H5550008197	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AG2BDM	GREEN B2 DC	S3SFN-L1AG2BDM, GREEN B2 DC, GL

H5550008708	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AG2BL	GREEN B2 AC	S3SFN-L1AG2BL, GREEN B2 AC, GL
H5550008709	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AG2BLM	GREEN B2 AC	S3SFN-L1AG2BLM, GREEN B2 AC, GL
H5550008228	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AGABD	GREEN A1 B1 DC	S3SFN-L1AGABD, GREEN A1 B1 DC, GL
H5550008229	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AGABDM	GREEN A1 B1 DC	S3SFN-L1AGABDM, GREEN A1 B1 DC, GL
H5550008740	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AGABL	GREEN A1 B1 AC	S3SFN-L1AGABL, GREEN A1 B1 AC, GL
H5550008741	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AGABLM	GREEN A1 B1 AC	S3SFN-L1AGABLM, GREEN A1 B1 AC, GL
H5550008132	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AGAD	GREEN A1 DC	S3SFN-L1AGAD, GREEN A1 DC, GL
H5550008133	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AGADM	GREEN A1 DC	S3SFN-L1AGADM, GREEN A1 DC, GL
H5550008644	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AGAL	GREEN A1 AC	S3SFN-L1AGAL, GREEN A1 AC, GL
H5550008645	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AGALM	GREEN A1 AC	S3SFN-L1AGALM, GREEN A1 AC, GL
H5550008180	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AGBD	GREEN B1 DC	S3SFN-L1AGBD, GREEN B1 DC, GL
H5550008181	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AGBDM	GREEN B1 DC	S3SFN-L1AGBDM, GREEN B1 DC, GL
H5550008692	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AGBL	GREEN B1 AC	S3SFN-L1AGBL, GREEN B1 AC, GL
H5550008693	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AGBLM	GREEN B1 AC	S3SFN-L1AGBLM, GREEN B1 AC, GL
H5550007766	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AY		S3SFN-L1AY, , GL
H5550008276	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AY2AD	YELLOW A2 DC	S3SFN-L1AY2AD, YELLOW A2 DC, GL
H5550008277	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AY2ADM	YELLOW A2 DC	S3SFN-L1AY2ADM, YELLOW A2 DC, GL

H5550008788	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AY2AL	YELLOW A2 AC	S3SFN-L1AY2AL, YELLOW A2 AC, GL
H5550008789	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AY2ALM	YELLOW A2 AC	S3SFN-L1AY2ALM, YELLOW A2 AC, GL
H5550008324	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AY2BD	YELLOW B2 DC	S3SFN-L1AY2BD, YELLOW B2 DC, GL
H5550008325	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AY2BDM	YELLOW B2 DC	S3SFN-L1AY2BDM, YELLOW B2 DC, GL
H5550008836	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AY2BL	YELLOW B2 AC	S3SFN-L1AY2BL, YELLOW B2 AC, GL
H5550008837	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AY2BLM	YELLOW B2 AC	S3SFN-L1AY2BLM, YELLOW B2 AC, GL
H5550008356	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AYABD	YELLOW A1 B1 DC	S3SFN-L1AYABD, YELLOW A1 B1 DC, GL
H5550008357	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AYABDM	YELLOW A1 B1 DC	S3SFN-L1AYABDM, YELLOW A1 B1 DC, GL
H5550008868	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AYABL	YELLOW A1 B1 AC	S3SFN-L1AYABL, YELLOW A1 B1 AC, GL
H5550008869	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AYABLM	YELLOW A1 B1 AC	S3SFN-L1AYABLM, YELLOW A1 B1 AC, GL
H5550008260	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AYAD	YELLOW A1 DC	S3SFN-L1AYAD, YELLOW A1 DC, GL
H5550008261	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AYADM	YELLOW A1 DC	S3SFN-L1AYADM, YELLOW A1 DC, GL
H5550008772	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AYAL	YELLOW A1 AC	S3SFN-L1AYAL, YELLOW A1 AC, GL
H5550008773	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AYALM	YELLOW A1 AC	S3SFN-L1AYALM, YELLOW A1 AC, GL
H5550008308	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AYBD	YELLOW B1 DC	S3SFN-L1AYBD, YELLOW B1 DC, GL
H5550008309	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AYBDM	YELLOW B1 DC	S3SFN-L1AYBDM, YELLOW B1 DC, GL
H5550008820	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AYBL	YELLOW B1 AC	S3SFN-L1AYBL, YELLOW B1 AC, GL

H5550008821	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AYBLM	YELLOW B1 AC	S3SFN-L1AYBLM, YELLOW B1 AC, GL
H5550011800	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1B	BLUE (HEAD)	S3SFN-L1B, BLUE (HEAD), GL
H5550011801	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1B2AD	BLUE A2 LED(DC)	S3SFN-L1B2AD, BLUE A2 LED(DC), GL
H5550011802	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1B2ADM	BLUE A2 LED(DC)	S3SFN-L1B2ADM, BLUE A2 LED(DC), GL
H5550011803	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1B2AL	BLUE A2 LED(AC)	S3SFN-L1B2AL, BLUE A2 LED(AC), GL
H5550011804	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1B2ALM	BLUE A2 LED(AC)	S3SFN-L1B2ALM, BLUE A2 LED(AC), GL
H5550011805	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1B2BD	BLUE B2 LED(DC)	S3SFN-L1B2BD, BLUE B2 LED(DC), GL
H5550011806	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1B2BDM	BLUE B2 LED(DC)	S3SFN-L1B2BDM, BLUE B2 LED(DC), GL
H5550011807	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1B2BL	BLUE B2 LED(AC)	S3SFN-L1B2BL, BLUE B2 LED(AC), GL
H5550011808	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1B2BLM	BLUE B2 LED(AC)	S3SFN-L1B2BLM, BLUE B2 LED(AC), GL
H5550011809	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BABD	BLUE AB LED(DC)	S3SFN-L1BABD, BLUE AB LED(DC), GL
H5550011810	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BABDM	BLUE AB LED(DC)	S3SFN-L1BABDM, BLUE AB LED(DC), GL
H5550011811	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BABL	BLUE AB LED(AC)	S3SFN-L1BABL, BLUE AB LED(AC), GL
H5550011812	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BABLM	BLUE AB LED(AC)	S3SFN-L1BABLM, BLUE AB LED(AC), GL
H5550011813	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BAD	BLUE A LED(DC)	S3SFN-L1BAD, BLUE A LED(DC), GL
H5550011814	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BADM	BLUE A LED(DC)	S3SFN-L1BADM, BLUE A LED(DC), GL
H5550011815	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BAL	BLUE A LED(AC)	S3SFN-L1BAL, BLUE A LED(AC), GL
H5550011816	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BALM	BLUE A LED(AC)	S3SFN-L1BALM, BLUE A LED(AC), GL

H5550007673	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BB		S3SFN-L1BB, , GL	
H5550008022	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BB2AD	BLUE A2 DC	S3SFN-L1BB2AD, BLUE A2 DC, GL	
H5550008023	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BB2ADM	BLUE A2 DC	S3SFN-L1BB2ADM, BLUE A2 DC, GL	
H5550008534	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BB2AL	BLUE A2 AC	S3SFN-L1BB2AL, BLUE A2 AC, GL	
H5550008535	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BB2ALM	BLUE A2 AC	S3SFN-L1BB2ALM, BLUE A2 AC, GL	
H5550008070	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BB2BD	BLUE B2 DC	S3SFN-L1BB2BD, BLUE B2 DC, GL	
H5550008071	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BB2BDM	BLUE B2 DC	S3SFN-L1BB2BDM, BLUE B2 DC, GL	
H5550008582	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BB2BL	BLUE B2 AC	S3SFN-L1BB2BL, BLUE B2 AC, GL	
H5550008583	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BB2BLM	BLUE B2 AC	S3SFN-L1BB2BLM, BLUE B2 AC, GL	
H5550008102	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBABD	BLUE A1 B1 DC	S3SFN-L1BBABD, BLUE A1 B1 DC, GL	
H5550008103	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBABDM	BLUE A1 B1 DC	S3SFN-L1BBABDM, BLUE A1 B1 DC, GL	
H5550008614	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBABL	BLUE A1 B1 AC	S3SFN-L1BBABL, BLUE A1 B1 AC, GL	
H5550008615	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBABLM	BLUE A1 B1 AC	S3SFN-L1BBABLM, BLUE A1 B1 AC, GL	
H5550008006	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBAD	BLUE A1 DC	S3SFN-L1BBAD, BLUE A1 DC, GL	
H5550008007	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBADM	BLUE A1 DC	S3SFN-L1BBADM, BLUE A1 DC, GL	
H5550008518	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBAL	BLUE A1 AC	S3SFN-L1BBAL, BLUE A1 AC, GL	
H5550008519	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBALM	BLUE A1 AC	S3SFN-L1BBALM, BLUE A1 AC, GL	
H5550008054	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBBD	BLUE B1 DC	S3SFN-L1BBBD, BLUE B1 DC, GL	

H5550008055	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBBDM	BLUE B1 DC	S3SFN-L1BBBDM, BLUE B1 DC, GL
H5550008566	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBBL	BLUE B1 AC	S3SFN-L1BBBL, BLUE B1 AC, GL
H5550008567	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBBLM	BLUE B1 AC	S3SFN-L1BBBLM, BLUE B1 AC, GL
H5550011817	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBD	BLUE B LED(DC)	S3SFN-L1BBD, BLUE B LED(DC), GL
H5550011818	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBDM	BLUE B LED(DC)	S3SFN-L1BBDM, BLUE B LED(DC), GL
H5550011819	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBL	BLUE B LED(AC)	S3SFN-L1BBL, BLUE B LED(AC), GL
H5550011820	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BBLM	BLUE B LED(AC)	S3SFN-L1BBLM, BLUE B LED(AC), GL
H5550007721	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BG		S3SFN-L1BG, , GL
H5550008150	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BG2AD	GREEN A2 DC	S3SFN-L1BG2AD, GREEN A2 DC, GL
H5550008151	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BG2ADM	GREEN A2 DC	S3SFN-L1BG2ADM, GREEN A2 DC, GL
H5550008662	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BG2AL	GREEN A2 AC	S3SFN-L1BG2AL, GREEN A2 AC, GL
H5550008663	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BG2ALM	GREEN A2 AC	S3SFN-L1BG2ALM, GREEN A2 AC, GL
H5550008198	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BG2BD	GREEN B2 DC	S3SFN-L1BG2BD, GREEN B2 DC, GL
H5550008199	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BG2BDM	GREEN B2 DC	S3SFN-L1BG2BDM, GREEN B2 DC, GL
H5550008710	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BG2BL	GREEN B2 AC	S3SFN-L1BG2BL, GREEN B2 AC, GL
H5550008711	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BG2BLM	GREEN B2 AC	S3SFN-L1BG2BLM, GREEN B2 AC, GL
H5550008230	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BGABD	GREEN A1 B1 DC	S3SFN-L1BGABD, GREEN A1 B1 DC, GL
H5550008231	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BGABDM	GREEN A1 B1 DC	S3SFN-L1BGABDM, GREEN A1 B1 DC, GL

H5550008742	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BGABL	GREEN A1 B1 AC	S3SFN-L1BGABL, GREEN A1 B1 AC, GL
H5550008743	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BGABLM	GREEN A1 B1 AC	S3SFN-L1BGABLM, GREEN A1 B1 AC, GL
H5550008134	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BGAD	GREEN A1 DC	S3SFN-L1BGAD, GREEN A1 DC, GL
H5550008135	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BGADM	GREEN A1 DC	S3SFN-L1BGADM, GREEN A1 DC, GL
H5550008646	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BGAL	GREEN A1 AC	S3SFN-L1BGAL, GREEN A1 AC, GL
H5550008647	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BGALM	GREEN A1 AC	S3SFN-L1BGALM, GREEN A1 AC, GL
H5550008182	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BGBD	GREEN B1 DC	S3SFN-L1BGBD, GREEN B1 DC, GL
H5550008183	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BGBDM	GREEN B1 DC	S3SFN-L1BGBDM, GREEN B1 DC, GL
H5550008694	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BGBL	GREEN B1 AC	S3SFN-L1BGBL, GREEN B1 AC, GL
H5550008695	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BGBLM	GREEN B1 AC	S3SFN-L1BGBLM, GREEN B1 AC, GL
H5550007769	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BY		S3SFN-L1BY, , GL
H5550008278	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BY2AD	YELLOW A2 DC	S3SFN-L1BY2AD, YELLOW A2 DC, GL
H5550008279	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BY2ADM	YELLOW A2 DC	S3SFN-L1BY2ADM, YELLOW A2 DC, GL
H5550008790	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BY2AL	YELLOW A2 AC	S3SFN-L1BY2AL, YELLOW A2 AC, GL
H5550008791	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BY2ALM	YELLOW A2 AC	S3SFN-L1BY2ALM, YELLOW A2 AC, GL
H5550008326	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BY2BD	YELLOW B2 DC	S3SFN-L1BY2BD, YELLOW B2 DC, GL
H5550008327	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BY2BDM	YELLOW B2 DC	S3SFN-L1BY2BDM, YELLOW B2 DC, GL

H5550008838	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BY2BL	YELLOW B2 AC	S3SFN-L1BY2BL, YELLOW B2 AC, GL
H5550008839	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BY2BLM	YELLOW B2 AC	S3SFN-L1BY2BLM, YELLOW B2 AC, GL
H5550008358	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BYABD	YELLOW A1 B1 DC	S3SFN-L1BYABD, YELLOW A1 B1 DC, GL
H5550008359	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BYABDM	YELLOW A1 B1 DC	S3SFN-L1BYABDM, YELLOW A1 B1 DC, GL
H5550008870	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BYABL	YELLOW A1 B1 AC	S3SFN-L1BYABL, YELLOW A1 B1 AC, GL
H5550008871	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BYABLM	YELLOW A1 B1 AC	S3SFN-L1BYABLM, YELLOW A1 B1 AC, GL
H5550008262	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BYAD	YELLOW A1 DC	S3SFN-L1BYAD, YELLOW A1 DC, GL
H5550008263	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BYADM	YELLOW A1 DC	S3SFN-L1BYADM, YELLOW A1 DC, GL
H5550008774	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BYAL	YELLOW A1 AC	S3SFN-L1BYAL, YELLOW A1 AC, GL
H5550008775	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BYALM	YELLOW A1 AC	S3SFN-L1BYALM, YELLOW A1 AC, GL
H5550008310	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BYBD	YELLOW B1 DC	S3SFN-L1BYBD, YELLOW B1 DC, GL
H5550008311	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BYBDM	YELLOW B1 DC	S3SFN-L1BYBDM, YELLOW B1 DC, GL
H5550008822	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BYBL	YELLOW B1 AC	S3SFN-L1BYBL, YELLOW B1 AC, GL
H5550008823	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BYBLM	YELLOW B1 AC	S3SFN-L1BYBLM, YELLOW B1 AC, GL
H5550011821	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1G	GREEN (HEAD)	S3SFN-L1G, GREEN (HEAD), GL
H5550011822	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1G2AD	GREEN A2 LED(DC)	S3SFN-L1G2AD, GREEN A2 LED(DC), GL

H5550011823	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1G2ADM	GREEN A2 LED(DC)	S3SFN-L1G2ADM, GREEN A2 LED(DC), GL
H5550011824	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1G2AL	GREEN A2 LED(AC)	S3SFN-L1G2AL, GREEN A2 LED(AC), GL
H5550011825	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1G2ALM	GREEN A2 LED(AC)	S3SFN-L1G2ALM, GREEN A2 LED(AC), GL
H5550011826	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1G2BD	GREEN B2 LED(DC)	S3SFN-L1G2BD, GREEN B2 LED(DC), GL
H5550011827	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1G2BDM	GREEN B2 LED(DC)	S3SFN-L1G2BDM, GREEN B2 LED(DC), GL
H5550011828	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1G2BL	GREEN B2 LED(AC)	S3SFN-L1G2BL, GREEN B2 LED(AC), GL
H5550011829	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1G2BLM	GREEN B2 LED(AC)	S3SFN-L1G2BLM, GREEN B2 LED(AC), GL
H5550011830	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1GABD	GREEN AB LED(DC)	S3SFN-L1GABD, GREEN AB LED(DC), GL
H5550011831	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1GABDM	GREEN AB LED(DC)	S3SFN-L1GABDM, GREEN AB LED(DC), GL
H5550011832	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1GABL	GREEN AB LED(AC)	S3SFN-L1GABL, GREEN AB LED(AC), GL
H5550011833	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1GABLM	GREEN AB LED(AC)	S3SFN-L1GABLM, GREEN AB LED(AC), GL
H5550011834	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1GAD	GREEN A LED(DC)	S3SFN-L1GAD, GREEN A LED(DC), GL
H5550011835	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1GADM	GREEN A LED(DC)	S3SFN-L1GADM, GREEN A LED(DC), GL
H5550011836	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1GAL	GREEN A LED(AC)	S3SFN-L1GAL, GREEN A LED(AC), GL
H5550011837	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1GALM	GREEN A LED(AC)	S3SFN-L1GALM, GREEN A LED(AC), GL
H5550011838	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1GBD	GREEN B LED(DC)	S3SFN-L1GBD, GREEN B LED(DC), GL
H5550011839	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1GBDM	GREEN B LED(DC)	S3SFN-L1GBDM, GREEN B LED(DC), GL

H5550011840	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1GBL	GREEN B LED(AC)	S3SFN-L1GBL, GREEN B LED(AC), GL
H5550011841	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1GBLM	GREEN B LED(AC)	S3SFN-L1GBLM, GREEN B LED(AC), GL
H5550011842	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1R	RED (HEAD)	S3SFN-L1R, RED (HEAD), GL
H5550011863	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1Y	YELLOW (HEAD)	S3SFN-L1Y, YELLOW (HEAD), GL
H5550011864	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1Y2AD	YELLOW A2 LED(DC)	S3SFN-L1Y2AD, YELLOW A2 LED(DC), GL
H5550011865	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1Y2ADM	YELLOW A2 LED(DC)	S3SFN-L1Y2ADM, YELLOW A2 LED(DC), GL
H5550011866	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1Y2AL	YELLOW A2 LED(AC)	S3SFN-L1Y2AL, YELLOW A2 LED(AC), GL
H5550011867	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1Y2ALM	YELLOW A2 LED(AC)	S3SFN-L1Y2ALM, YELLOW A2 LED(AC), GL
H5550011868	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1Y2BD	YELLOW B2 LED(DC)	S3SFN-L1Y2BD, YELLOW B2 LED(DC), GL
H5550011869	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1Y2BDM	YELLOW B2 LED(DC)	S3SFN-L1Y2BDM, YELLOW B2 LED(DC), GL
H5550011870	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1Y2BL	YELLOW B2 LED(AC)	S3SFN-L1Y2BL, YELLOW B2 LED(AC), GL
H5550011871	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1Y2BLM	YELLOW B2 LED(AC)	S3SFN-L1Y2BLM, YELLOW B2 LED(AC), GL
H5550011872	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1YABD	YELLOW AB LED(DC)	S3SFN-L1YABD, YELLOW AB LED(DC), GL
H5550011873	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1YABDM	YELLOW AB LED(DC)	S3SFN-L1YABDM, YELLOW AB LED(DC), GL
H5550011874	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1YABL	YELLOW AB LED(AC)	S3SFN-L1YABL, YELLOW AB LED(AC), GL
H5550011875	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1YABLM	YELLOW AB LED(AC)	S3SFN-L1YABLM, YELLOW AB LED(AC), GL
H5550011876	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1YAD	YELLOW A LED(DC)	S3SFN-L1YAD, YELLOW A LED(DC), GL

H5550011877	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1YADM	YELLOW A LED(DC)	S3SFN-L1YADM, YELLOW A LED(DC), GL
H5550011878	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1YAL	YELLOW A LED(AC)	S3SFN-L1YAL, YELLOW A LED(AC), GL
H5550011879	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1YALM	YELLOW A LED(AC)	S3SFN-L1YALM, YELLOW A LED(AC), GL
H5550011880	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1YBD	YELLOW B LED(DC)	S3SFN-L1YBD, YELLOW B LED(DC), GL
H5550011881	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1YBDM	YELLOW B LED(DC)	S3SFN-L1YBDM, YELLOW B LED(DC), GL
H5550011882	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1YBL	YELLOW B LED(AC)	S3SFN-L1YBL, YELLOW B LED(AC), GL
H5550011883	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1YBLM	YELLOW B LED(AC)	S3SFN-L1YBLM, YELLOW B LED(AC), GL
H5550007676	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AB		S3SFN-L2AB, , GL
H5550008024	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AB2AD	BLUE A2 DC	S3SFN-L2AB2AD, BLUE A2 DC, GL
H5550008025	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AB2ADM	BLUE A2 DC	S3SFN-L2AB2ADM, BLUE A2 DC, GL
H5550008536	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AB2AL	BLUE A2 AC	S3SFN-L2AB2AL, BLUE A2 AC, GL
H5550008537	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AB2ALM	BLUE A2 AC	S3SFN-L2AB2ALM, BLUE A2 AC, GL
H5550008072	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AB2BD	BLUE B2 DC	S3SFN-L2AB2BD, BLUE B2 DC, GL
H5550008073	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AB2BDM	BLUE B2 DC	S3SFN-L2AB2BDM, BLUE B2 DC, GL
H5550008584	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AB2BL	BLUE B2 AC	S3SFN-L2AB2BL, BLUE B2 AC, GL
H5550008585	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AB2BLM	BLUE B2 AC	S3SFN-L2AB2BLM, BLUE B2 AC, GL
H5550008104	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ABABD	BLUE A1 B1 DC	S3SFN-L2ABABD, BLUE A1 B1 DC, GL
H5550008105	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ABABDM	BLUE A1 B1 DC	S3SFN-L2ABABDM, BLUE A1 B1 DC, GL

H5550008616	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ABABL	BLUE A1 B1 AC	S3SFN-L2ABABL, BLUE A1 B1 AC, GL
H5550008617	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ABABLM	BLUE A1 B1 AC	S3SFN-L2ABABLM, BLUE A1 B1 AC, GL
H5550008008	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ABAD	BLUE A1 DC	S3SFN-L2ABAD, BLUE A1 DC, GL
H5550008009	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ABADM	BLUE A1 DC	S3SFN-L2ABADM, BLUE A1 DC, GL
H5550008520	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ABAL	BLUE A1 AC	S3SFN-L2ABAL, BLUE A1 AC, GL
H5550008521	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ABALM	BLUE A1 AC	S3SFN-L2ABALM, BLUE A1 AC, GL
H5550008056	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ABBD	BLUE B1 DC	S3SFN-L2ABBD, BLUE B1 DC, GL
H5550008057	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ABBDM	BLUE B1 DC	S3SFN-L2ABBDM, BLUE B1 DC, GL
H5550008568	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ABBL	BLUE B1 AC	S3SFN-L2ABBL, BLUE B1 AC, GL
H5550008569	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ABBLM	BLUE B1 AC	S3SFN-L2ABBLM, BLUE B1 AC, GL
H5550007724	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AG		S3SFN-L2AG, , GL
H5550008152	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AG2AD	GREEN A2 DC	S3SFN-L2AG2AD, GREEN A2 DC, GL
H5550008153	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AG2ADM	GREEN A2 DC	S3SFN-L2AG2ADM, GREEN A2 DC, GL
H5550008664	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AG2AL	GREEN A2 AC	S3SFN-L2AG2AL, GREEN A2 AC, GL
H5550008665	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AG2ALM	GREEN A2 AC	S3SFN-L2AG2ALM, GREEN A2 AC, GL
H5550008200	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AG2BD	GREEN B2 DC	S3SFN-L2AG2BD, GREEN B2 DC, GL
H5550008201	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AG2BDM	GREEN B2 DC	S3SFN-L2AG2BDM, GREEN B2 DC, GL
H5550008712	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AG2BL	GREEN B2 AC	S3SFN-L2AG2BL, GREEN B2 AC, GL

H5550008713	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AG2BLM	GREEN B2 AC	S3SFN-L2AG2BLM, GREEN B2 AC, GL
H5550008232	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AGABD	GREEN A1 B1 DC	S3SFN-L2AGABD, GREEN A1 B1 DC, GL
H5550008233	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AGABDM	GREEN A1 B1 DC	S3SFN-L2AGABDM, GREEN A1 B1 DC, GL
H5550008744	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AGABL	GREEN A1 B1 AC	S3SFN-L2AGABL, GREEN A1 B1 AC, GL
H5550008745	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AGABLM	GREEN A1 B1 AC	S3SFN-L2AGABLM, GREEN A1 B1 AC, GL
H5550008136	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AGAD	GREEN A1 DC	S3SFN-L2AGAD, GREEN A1 DC, GL
H5550008137	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AGADM	GREEN A1 DC	S3SFN-L2AGADM, GREEN A1 DC, GL
H5550008648	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AGAL	GREEN A1 AC	S3SFN-L2AGAL, GREEN A1 AC, GL
H5550008649	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AGALM	GREEN A1 AC	S3SFN-L2AGALM, GREEN A1 AC, GL
H5550008184	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AGBD	GREEN B1 DC	S3SFN-L2AGBD, GREEN B1 DC, GL
H5550008185	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AGBDM	GREEN B1 DC	S3SFN-L2AGBDM, GREEN B1 DC, GL
H5550008696	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AGBL	GREEN B1 AC	S3SFN-L2AGBL, GREEN B1 AC, GL
H5550008697	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AGBLM	GREEN B1 AC	S3SFN-L2AGBLM, GREEN B1 AC, GL
H5550007772	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AY		S3SFN-L2AY, , GL
H5550008280	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AY2AD	YELLOW A2 DC	S3SFN-L2AY2AD, YELLOW A2 DC, GL
H5550008281	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AY2ADM	YELLOW A2 DC	S3SFN-L2AY2ADM, YELLOW A2 DC, GL

H5550008792	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AY2AL	YELLOW A2 AC	S3SFN-L2AY2AL, YELLOW A2 AC, GL
H5550008793	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AY2ALM	YELLOW A2 AC	S3SFN-L2AY2ALM, YELLOW A2 AC, GL
H5550008328	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AY2BD	YELLOW B2 DC	S3SFN-L2AY2BD, YELLOW B2 DC, GL
H5550008329	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AY2BDM	YELLOW B2 DC	S3SFN-L2AY2BDM, YELLOW B2 DC, GL
H5550008840	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AY2BL	YELLOW B2 AC	S3SFN-L2AY2BL, YELLOW B2 AC, GL
H5550008841	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AY2BLM	YELLOW B2 AC	S3SFN-L2AY2BLM, YELLOW B2 AC, GL
H5550008360	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AYABD	YELLOW A1 B1 DC	S3SFN-L2AYABD, YELLOW A1 B1 DC, GL
H5550008361	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AYABDM	YELLOW A1 B1 DC	S3SFN-L2AYABDM, YELLOW A1 B1 DC, GL
H5550008872	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AYABL	YELLOW A1 B1 AC	S3SFN-L2AYABL, YELLOW A1 B1 AC, GL
H5550008873	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AYABLM	YELLOW A1 B1 AC	S3SFN-L2AYABLM, YELLOW A1 B1 AC, GL
H5550008264	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AYAD	YELLOW A1 DC	S3SFN-L2AYAD, YELLOW A1 DC, GL
H5550008265	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AYADM	YELLOW A1 DC	S3SFN-L2AYADM, YELLOW A1 DC, GL
H5550008776	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AYAL	YELLOW A1 AC	S3SFN-L2AYAL, YELLOW A1 AC, GL
H5550008777	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AYALM	YELLOW A1 AC	S3SFN-L2AYALM, YELLOW A1 AC, GL
H5550008312	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AYBD	YELLOW B1 DC	S3SFN-L2AYBD, YELLOW B1 DC, GL
H5550008313	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AYBDM	YELLOW B1 DC	S3SFN-L2AYBDM, YELLOW B1 DC, GL
H5550008824	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AYBL	YELLOW B1 AC	S3SFN-L2AYBL, YELLOW B1 AC, GL

H5550008825	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AYBLM	YELLOW B1 AC	S3SFN-L2AYBLM, YELLOW B1 AC, GL
H5550011884	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2B	BLUE (HEAD)	S3SFN-L2B, BLUE (HEAD), GL
H5550011885	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2B2AD	BLUE A2 LED(DC)	S3SFN-L2B2AD, BLUE A2 LED(DC), GL
H5550011886	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2B2ADM	BLUE A2 LED(DC)	S3SFN-L2B2ADM, BLUE A2 LED(DC), GL
H5550011887	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2B2AL	BLUE A2 LED(AC)	S3SFN-L2B2AL, BLUE A2 LED(AC), GL
H5550011888	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2B2ALM	BLUE A2 LED(AC)	S3SFN-L2B2ALM, BLUE A2 LED(AC), GL
H5550011889	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2B2BD	BLUE B2 LED(DC)	S3SFN-L2B2BD, BLUE B2 LED(DC), GL
H5550011890	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2B2BDM	BLUE B2 LED(DC)	S3SFN-L2B2BDM, BLUE B2 LED(DC), GL
H5550011891	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2B2BL	BLUE B2 LED(AC)	S3SFN-L2B2BL, BLUE B2 LED(AC), GL
H5550011892	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2B2BLM	BLUE B2 LED(AC)	S3SFN-L2B2BLM, BLUE B2 LED(AC), GL
H5550011893	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BABD	BLUE AB LED(DC)	S3SFN-L2BABD, BLUE AB LED(DC), GL
H5550011894	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BABDM	BLUE AB LED(DC)	S3SFN-L2BABDM, BLUE AB LED(DC), GL
H5550011895	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BABL	BLUE AB LED(AC)	S3SFN-L2BABL, BLUE AB LED(AC), GL
H5550011896	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BABLM	BLUE AB LED(AC)	S3SFN-L2BABLM, BLUE AB LED(AC), GL
H5550011897	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BAD	BLUE A LED(DC)	S3SFN-L2BAD, BLUE A LED(DC), GL
H5550011898	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BADM	BLUE A LED(DC)	S3SFN-L2BADM, BLUE A LED(DC), GL
H5550011899	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BAL	BLUE A LED(AC)	S3SFN-L2BAL, BLUE A LED(AC), GL
H5550011900	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BALM	BLUE A LED(AC)	S3SFN-L2BALM, BLUE A LED(AC), GL

H5550007679	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BB		S3SFN-L2BB, , GL	
H5550008026	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BB2AD	BLUE A2 DC	S3SFN-L2BB2AD, BLUE A2 DC, GL	
H5550008027	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BB2ADM	BLUE A2 DC	S3SFN-L2BB2ADM, BLUE A2 DC, GL	
H5550008538	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BB2AL	BLUE A2 AC	S3SFN-L2BB2AL, BLUE A2 AC, GL	
H5550008539	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BB2ALM	BLUE A2 AC	S3SFN-L2BB2ALM, BLUE A2 AC, GL	
H5550008074	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BB2BD	BLUE B2 DC	S3SFN-L2BB2BD, BLUE B2 DC, GL	
H5550008075	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BB2BDM	BLUE B2 DC	S3SFN-L2BB2BDM, BLUE B2 DC, GL	
H5550008586	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BB2BL	BLUE B2 AC	S3SFN-L2BB2BL, BLUE B2 AC, GL	
H5550008587	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BB2BLM	BLUE B2 AC	S3SFN-L2BB2BLM, BLUE B2 AC, GL	
H5550008106	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBABD	BLUE A1 B1 DC	S3SFN-L2BBABD, BLUE A1 B1 DC, GL	
H5550008107	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBABDM	BLUE A1 B1 DC	S3SFN-L2BBABDM, BLUE A1 B1 DC, GL	
H5550008618	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBABL	BLUE A1 B1 AC	S3SFN-L2BBABL, BLUE A1 B1 AC, GL	
H5550008619	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBABLM	BLUE A1 B1 AC	S3SFN-L2BBABLM, BLUE A1 B1 AC, GL	
H5550008010	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBAD	BLUE A1 DC	S3SFN-L2BBAD, BLUE A1 DC, GL	
H5550008011	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBADM	BLUE A1 DC	S3SFN-L2BBADM, BLUE A1 DC, GL	
H5550008522	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBAL	BLUE A1 AC	S3SFN-L2BBAL, BLUE A1 AC, GL	
H5550008523	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBALM	BLUE A1 AC	S3SFN-L2BBALM, BLUE A1 AC, GL	

H5550008058	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBBD	BLUE B1 DC	S3SFN-L2BBBD, BLUE B1 DC, GL
H5550008059	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBBDM	BLUE B1 DC	S3SFN-L2BBBDM, BLUE B1 DC, GL
H5550008570	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBBL	BLUE B1 AC	S3SFN-L2BBBL, BLUE B1 AC, GL
H5550008571	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBBLM	BLUE B1 AC	S3SFN-L2BBBLM, BLUE B1 AC, GL
H5550011901	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBD	BLUE B LED(DC)	S3SFN-L2BBD, BLUE B LED(DC), GL
H5550011902	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBDM	BLUE B LED(DC)	S3SFN-L2BBDM, BLUE B LED(DC), GL
H5550011903	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBL	BLUE B LED(AC)	S3SFN-L2BBL, BLUE B LED(AC), GL
H5550011904	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BBLM	BLUE B LED(AC)	S3SFN-L2BBLM, BLUE B LED(AC), GL
H5550007727	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BG		S3SFN-L2BG, , GL
H5550008154	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BG2AD	GREEN A2 DC	S3SFN-L2BG2AD, GREEN A2 DC, GL
H5550008155	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BG2ADM	GREEN A2 DC	S3SFN-L2BG2ADM, GREEN A2 DC, GL
H5550008666	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BG2AL	GREEN A2 AC	S3SFN-L2BG2AL, GREEN A2 AC, GL
H5550008667	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BG2ALM	GREEN A2 AC	S3SFN-L2BG2ALM, GREEN A2 AC, GL
H5550008202	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BG2BD	GREEN B2 DC	S3SFN-L2BG2BD, GREEN B2 DC, GL
H5550008203	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BG2BDM	GREEN B2 DC	S3SFN-L2BG2BDM, GREEN B2 DC, GL
H5550008714	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BG2BL	GREEN B2 AC	S3SFN-L2BG2BL, GREEN B2 AC, GL
H5550008715	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BG2BLM	GREEN B2 AC	S3SFN-L2BG2BLM, GREEN B2 AC, GL

H5550008234	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BGABD	GREEN A1 B1 DC	S3SFN-L2BGABD, GREEN A1 B1 DC, GL
H5550008235	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BGABDM	GREEN A1 B1 DC	S3SFN-L2BGABDM, GREEN A1 B1 DC, GL
H5550008746	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BGABL	GREEN A1 B1 AC	S3SFN-L2BGABL, GREEN A1 B1 AC, GL
H5550008747	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BGABLM	GREEN A1 B1 AC	S3SFN-L2BGABLM, GREEN A1 B1 AC, GL
H5550008138	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BGAD	GREEN A1 DC	S3SFN-L2BGAD, GREEN A1 DC, GL
H5550008139	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BGADM	GREEN A1 DC	S3SFN-L2BGADM, GREEN A1 DC, GL
H5550008650	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BGAL	GREEN A1 AC	S3SFN-L2BGAL, GREEN A1 AC, GL
H5550008651	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BGALM	GREEN A1 AC	S3SFN-L2BGALM, GREEN A1 AC, GL
H5550008186	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BGBD	GREEN B1 DC	S3SFN-L2BGBD, GREEN B1 DC, GL
H5550008187	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BGBDM	GREEN B1 DC	S3SFN-L2BGBDM, GREEN B1 DC, GL
H5550008698	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BGBL	GREEN B1 AC	S3SFN-L2BGBL, GREEN B1 AC, GL
H5550008699	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BGBLM	GREEN B1 AC	S3SFN-L2BGBLM, GREEN B1 AC, GL
H5550007775	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BY		S3SFN-L2BY, , GL
H5550008282	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BY2AD	YELLOW A2 DC	S3SFN-L2BY2AD, YELLOW A2 DC, GL
H5550008283	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BY2ADM	YELLOW A2 DC	S3SFN-L2BY2ADM, YELLOW A2 DC, GL
H5550008794	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BY2AL	YELLOW A2 AC	S3SFN-L2BY2AL, YELLOW A2 AC, GL
H5550008795	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BY2ALM	YELLOW A2 AC	S3SFN-L2BY2ALM, YELLOW A2 AC, GL
H5550008330	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BY2BD	YELLOW B2 DC	S3SFN-L2BY2BD, YELLOW B2 DC, GL

H5550008331	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BY2BDM	YELLOW B2 DC	S3SFN-L2BY2BDM, YELLOW B2 DC, GL
H5550008842	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BY2BL	YELLOW B2 AC	S3SFN-L2BY2BL, YELLOW B2 AC, GL
H5550008843	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BY2BLM	YELLOW B2 AC	S3SFN-L2BY2BLM, YELLOW B2 AC, GL
H5550008362	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BYABD	YELLOW A1 B1 DC	S3SFN-L2BYABD, YELLOW A1 B1 DC, GL
H5550008363	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BYABDM	YELLOW A1 B1 DC	S3SFN-L2BYABDM, YELLOW A1 B1 DC, GL
H5550008874	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BYABL	YELLOW A1 B1 AC	S3SFN-L2BYABL, YELLOW A1 B1 AC, GL
H5550008875	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BYABLM	YELLOW A1 B1 AC	S3SFN-L2BYABLM, YELLOW A1 B1 AC, GL
H5550008266	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BYAD	YELLOW A1 DC	S3SFN-L2BYAD, YELLOW A1 DC, GL
H5550008267	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BYADM	YELLOW A1 DC	S3SFN-L2BYADM, YELLOW A1 DC, GL
H5550008778	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BYAL	YELLOW A1 AC	S3SFN-L2BYAL, YELLOW A1 AC, GL
H5550008779	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BYALM	YELLOW A1 AC	S3SFN-L2BYALM, YELLOW A1 AC, GL
H5550008314	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BYBD	YELLOW B1 DC	S3SFN-L2BYBD, YELLOW B1 DC, GL
H5550008315	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BYBDM	YELLOW B1 DC	S3SFN-L2BYBDM, YELLOW B1 DC, GL
H5550008826	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BYBL	YELLOW B1 AC	S3SFN-L2BYBL, YELLOW B1 AC, GL
H5550008827	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BYBLM	YELLOW B1 AC	S3SFN-L2BYBLM, YELLOW B1 AC, GL
H5550011905	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2G	GREEN (HEAD)	S3SFN-L2G, GREEN (HEAD), GL
H5550011906	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2G2AD	GREEN A2 LED(DC)	S3SFN-L2G2AD, GREEN A2 LED(DC), GL
H5550011907	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2G2ADM	GREEN A2 LED(DC)	S3SFN-L2G2ADM, GREEN A2 LED(DC), GL

H5550011908	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2G2AL	GREEN A2 LED(AC)	S3SFN-L2G2AL, GREEN A2 LED(AC), GL
H5550011909	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2G2ALM	GREEN A2 LED(AC)	S3SFN-L2G2ALM, GREEN A2 LED(AC), GL
H5550011910	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2G2BD	GREEN B2 LED(DC)	S3SFN-L2G2BD, GREEN B2 LED(DC), GL
H5550011911	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2G2BDM	GREEN B2 LED(DC)	S3SFN-L2G2BDM, GREEN B2 LED(DC), GL
H5550011912	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2G2BL	GREEN B2 LED(AC)	S3SFN-L2G2BL, GREEN B2 LED(AC), GL
H5550011913	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2G2BLM	GREEN B2 LED(AC)	S3SFN-L2G2BLM, GREEN B2 LED(AC), GL
H5550011914	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2GABD	GREEN AB LED(DC)	S3SFN-L2GABD, GREEN AB LED(DC), GL
H5550011915	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2GABDM	GREEN AB LED(DC)	S3SFN-L2GABDM, GREEN AB LED(DC), GL
H5550011916	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2GABL	GREEN AB LED(AC)	S3SFN-L2GABL, GREEN AB LED(AC), GL
H5550011917	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2GABLM	GREEN AB LED(AC)	S3SFN-L2GABLM, GREEN AB LED(AC), GL
H5550011918	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2GAD	GREEN A LED(DC)	S3SFN-L2GAD, GREEN A LED(DC), GL
H5550011919	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2GADM	GREEN A LED(DC)	S3SFN-L2GADM, GREEN A LED(DC), GL
H5550011920	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2GAL	GREEN A LED(AC)	S3SFN-L2GAL, GREEN A LED(AC), GL
H5550011921	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2GALM	GREEN A LED(AC)	S3SFN-L2GALM, GREEN A LED(AC), GL
H5550011922	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2GBD	GREEN B LED(DC)	S3SFN-L2GBD, GREEN B LED(DC), GL
H5550011923	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2GBDM	GREEN B LED(DC)	S3SFN-L2GBDM, GREEN B LED(DC), GL
H5550011924	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2GBL	GREEN B LED(AC)	S3SFN-L2GBL, GREEN B LED(AC), GL
H5550011925	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2GBLM	GREEN B LED(AC)	S3SFN-L2GBLM, GREEN B LED(AC), GL

H5550011926	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2R	RED (HEAD)	S3SFN-L2R, RED (HEAD), GL
H5550011947	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2Y	YELLOW (HEAD)	S3SFN-L2Y, YELLOW (HEAD), GL
H5550011948	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2Y2AD	YELLOW A2 LED(DC)	S3SFN-L2Y2AD, YELLOW A2 LED(DC), GL
H5550011949	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2Y2ADM	YELLOW A2 LED(DC)	S3SFN-L2Y2ADM, YELLOW A2 LED(DC), GL
H5550011950	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2Y2AL	YELLOW A2 LED(AC)	S3SFN-L2Y2AL, YELLOW A2 LED(AC), GL
H5550011951	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2Y2ALM	YELLOW A2 LED(AC)	S3SFN-L2Y2ALM, YELLOW A2 LED(AC), GL
H5550011952	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2Y2BD	YELLOW B2 LED(DC)	S3SFN-L2Y2BD, YELLOW B2 LED(DC), GL
H5550011953	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2Y2BDM	YELLOW B2 LED(DC)	S3SFN-L2Y2BDM, YELLOW B2 LED(DC), GL
H5550011954	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2Y2BL	YELLOW B2 LED(AC)	S3SFN-L2Y2BL, YELLOW B2 LED(AC), GL
H5550011955	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2Y2BLM	YELLOW B2 LED(AC)	S3SFN-L2Y2BLM, YELLOW B2 LED(AC), GL
H5550011956	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2YABD	YELLOW AB LED(DC)	S3SFN-L2YABD, YELLOW AB LED(DC), GL
H5550011957	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2YABDM	YELLOW AB LED(DC)	S3SFN-L2YABDM, YELLOW AB LED(DC), GL
H5550011958	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2YABL	YELLOW AB LED(AC)	S3SFN-L2YABL, YELLOW AB LED(AC), GL
H5550011959	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2YABLM	YELLOW AB LED(AC)	S3SFN-L2YABLM, YELLOW AB LED(AC), GL
H5550011960	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2YAD	YELLOW A LED(DC)	S3SFN-L2YAD, YELLOW A LED(DC), GL
H5550011961	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2YADM	YELLOW A LED(DC)	S3SFN-L2YADM, YELLOW A LED(DC), GL
H5550011962	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2YAL	YELLOW A LED(AC)	S3SFN-L2YAL, YELLOW A LED(AC), GL

H5550011963	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2YALM	YELLOW A LED(AC)	S3SFN-L2YALM, YELLOW A LED(AC), GL
H5550011964	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2YBD	YELLOW B LED(DC)	S3SFN-L2YBD, YELLOW B LED(DC), GL
H5550011965	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2YBDM	YELLOW B LED(DC)	S3SFN-L2YBDM, YELLOW B LED(DC), GL
H5550011966	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2YBL	YELLOW B LED(AC)	S3SFN-L2YBL, YELLOW B LED(AC), GL
H5550011967	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2YBLM	YELLOW B LED(AC)	S3SFN-L2YBLM, YELLOW B LED(AC), GL
H5550007682	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AB		S3SFN-L3AB, , GL
H5550008028	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AB2AD	BLUE A2 DC	S3SFN-L3AB2AD, BLUE A2 DC, GL
H5550008029	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AB2ADM	BLUE A2 DC	S3SFN-L3AB2ADM, BLUE A2 DC, GL
H5550008540	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AB2AL	BLUE A2 AC	S3SFN-L3AB2AL, BLUE A2 AC, GL
H5550008541	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AB2ALM	BLUE A2 AC	S3SFN-L3AB2ALM, BLUE A2 AC, GL
H5550008076	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AB2BD	BLUE B2 DC	S3SFN-L3AB2BD, BLUE B2 DC, GL
H5550008077	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AB2BDM	BLUE B2 DC	S3SFN-L3AB2BDM, BLUE B2 DC, GL
H5550008588	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AB2BL	BLUE B2 AC	S3SFN-L3AB2BL, BLUE B2 AC, GL
H5550008589	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AB2BLM	BLUE B2 AC	S3SFN-L3AB2BLM, BLUE B2 AC, GL
H5550008108	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ABABD	BLUE A1 B1 DC	S3SFN-L3ABABD, BLUE A1 B1 DC, GL
H5550008109	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ABABDM	BLUE A1 B1 DC	S3SFN-L3ABABDM, BLUE A1 B1 DC, GL
H5550008620	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ABABL	BLUE A1 B1 AC	S3SFN-L3ABABL, BLUE A1 B1 AC, GL
H5550008621	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ABABLM	BLUE A1 B1 AC	S3SFN-L3ABABLM, BLUE A1 B1 AC, GL

H5550008012	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ABAD	BLUE A1 DC	S3SFN-L3ABAD, BLUE A1 DC, GL
H5550008013	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ABADM	BLUE A1 DC	S3SFN-L3ABADM, BLUE A1 DC, GL
H5550008524	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ABAL	BLUE A1 AC	S3SFN-L3ABAL, BLUE A1 AC, GL
H5550008525	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ABALM	BLUE A1 AC	S3SFN-L3ABALM, BLUE A1 AC, GL
H5550008060	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ABBDD	BLUE B1 DC	S3SFN-L3ABBDD, BLUE B1 DC, GL
H5550008061	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ABBDM	BLUE B1 DC	S3SFN-L3ABBDM, BLUE B1 DC, GL
H5550008572	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ABBLL	BLUE B1 AC	S3SFN-L3ABBLL, BLUE B1 AC, GL
H5550008573	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ABBLLM	BLUE B1 AC	S3SFN-L3ABBLLM, BLUE B1 AC, GL
H5550008156	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AG2AD	GREEN A2 DC	S3SFN-L3AG2AD, GREEN A2 DC, GL
H5550008157	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AG2ADM	GREEN A2 DC	S3SFN-L3AG2ADM, GREEN A2 DC, GL
H5550008668	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AG2AL	GREEN A2 AC	S3SFN-L3AG2AL, GREEN A2 AC, GL
H5550008669	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AG2ALM	GREEN A2 AC	S3SFN-L3AG2ALM, GREEN A2 AC, GL
H5550008204	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AG2BD	GREEN B2 DC	S3SFN-L3AG2BD, GREEN B2 DC, GL
H5550008205	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AG2BDM	GREEN B2 DC	S3SFN-L3AG2BDM, GREEN B2 DC, GL
H5550008716	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AG2BL	GREEN B2 AC	S3SFN-L3AG2BL, GREEN B2 AC, GL
H5550008717	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AG2BLM	GREEN B2 AC	S3SFN-L3AG2BLM, GREEN B2 AC, GL
H5550008236	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AGABD	GREEN A1 B1 DC	S3SFN-L3AGABD, GREEN A1 B1 DC, GL
H5550008237	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AGABDM	GREEN A1 B1 DC	S3SFN-L3AGABDM, GREEN A1 B1 DC, GL

H5550008748	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AGABL	GREEN A1 B1 AC	S3SFN-L3AGABL, GREEN A1 B1 AC, GL	Селекторный переключатель, 30мм, утопленный, С подсветкой, Короткая ручка, Зеленый, 2-позиционный, 1 нормально открытый, 1 нормально закрытый, 110 - 220 В~ 50/60 Hz
H5550008749	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AGABLM	GREEN A1 B1 AC	S3SFN-L3AGABLM, GREEN A1 B1 AC, GL	
H5550008140	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AGAD	GREEN A1 DC	S3SFN-L3AGAD, GREEN A1 DC, GL	
H5550008141	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AGADM	GREEN A1 DC	S3SFN-L3AGADM, GREEN A1 DC, GL	
H5550008652	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AGAL	GREEN A1 AC	S3SFN-L3AGAL, GREEN A1 AC, GL	
H5550008653	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AGALM	GREEN A1 AC	S3SFN-L3AGALM, GREEN A1 AC, GL	
H5550008188	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AGBD	GREEN B1 DC	S3SFN-L3AGBD, GREEN B1 DC, GL	
H5550008189	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AGBDM	GREEN B1 DC	S3SFN-L3AGBDM, GREEN B1 DC, GL	
H5550008700	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AGBL	GREEN B1 AC	S3SFN-L3AGBL, GREEN B1 AC, GL	
H5550008701	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AGBLM	GREEN B1 AC	S3SFN-L3AGBLM, GREEN B1 AC, GL	
H5550007778	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AY		S3SFN-L3AY, , GL	
H5550008284	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AY2AD	YELLOW A2 DC	S3SFN-L3AY2AD, YELLOW A2 DC, GL	
H5550008285	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AY2ADM	YELLOW A2 DC	S3SFN-L3AY2ADM, YELLOW A2 DC, GL	
H5550008796	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AY2AL	YELLOW A2 AC	S3SFN-L3AY2AL, YELLOW A2 AC, GL	
H5550008797	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AY2ALM	YELLOW A2 AC	S3SFN-L3AY2ALM, YELLOW A2 AC, GL	
H5550008332	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AY2BD	YELLOW B2 DC	S3SFN-L3AY2BD, YELLOW B2 DC, GL	
H5550008333	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AY2BDM	YELLOW B2 DC	S3SFN-L3AY2BDM, YELLOW B2 DC, GL	

H5550008844	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AY2BL	YELLOW B2 AC	S3SFN-L3AY2BL, YELLOW B2 AC, GL
H5550008845	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AY2BLM	YELLOW B2 AC	S3SFN-L3AY2BLM, YELLOW B2 AC, GL
H5550008364	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AYABD	YELLOW A1 B1 DC	S3SFN-L3AYABD, YELLOW A1 B1 DC, GL
H5550008365	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AYABDM	YELLOW A1 B1 DC	S3SFN-L3AYABDM, YELLOW A1 B1 DC, GL
H5550008876	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AYABL	YELLOW A1 B1 AC	S3SFN-L3AYABL, YELLOW A1 B1 AC, GL
H5550008877	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AYABLM	YELLOW A1 B1 AC	S3SFN-L3AYABLM, YELLOW A1 B1 AC, GL
H5550008268	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AYAD	YELLOW A1 DC	S3SFN-L3AYAD, YELLOW A1 DC, GL
H5550008269	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AYADM	YELLOW A1 DC	S3SFN-L3AYADM, YELLOW A1 DC, GL
H5550008780	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AYAL	YELLOW A1 AC	S3SFN-L3AYAL, YELLOW A1 AC, GL
H5550008781	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AYALM	YELLOW A1 AC	S3SFN-L3AYALM, YELLOW A1 AC, GL
H5550008316	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AYBD	YELLOW B1 DC	S3SFN-L3AYBD, YELLOW B1 DC, GL
H5550008317	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AYBDM	YELLOW B1 DC	S3SFN-L3AYBDM, YELLOW B1 DC, GL
H5550008828	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AYBL	YELLOW B1 AC	S3SFN-L3AYBL, YELLOW B1 AC, GL
H5550008829	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AYBLM	YELLOW B1 AC	S3SFN-L3AYBLM, YELLOW B1 AC, GL
H5550007685	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BB		S3SFN-L3BB, , GL
H5550008030	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BB2AD	BLUE A2 DC	S3SFN-L3BB2AD, BLUE A2 DC, GL

H5550008031	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BB2ADM	BLUE A2 DC	S3SFN-L3BB2ADM, BLUE A2 DC, GL
H5550008542	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BB2AL	BLUE A2 AC	S3SFN-L3BB2AL, BLUE A2 AC, GL
H5550008543	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BB2ALM	BLUE A2 AC	S3SFN-L3BB2ALM, BLUE A2 AC, GL
H5550008078	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BB2BD	BLUE B2 DC	S3SFN-L3BB2BD, BLUE B2 DC, GL
H5550008079	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BB2BDM	BLUE B2 DC	S3SFN-L3BB2BDM, BLUE B2 DC, GL
H5550008590	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BB2BL	BLUE B2 AC	S3SFN-L3BB2BL, BLUE B2 AC, GL
H5550008591	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BB2BLM	BLUE B2 AC	S3SFN-L3BB2BLM, BLUE B2 AC, GL
H5550008110	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BBABD	BLUE A1 B1 DC	S3SFN-L3BBABD, BLUE A1 B1 DC, GL
H5550008111	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BBABDM	BLUE A1 B1 DC	S3SFN-L3BBABDM, BLUE A1 B1 DC, GL
H5550008622	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BBABL	BLUE A1 B1 AC	S3SFN-L3BBABL, BLUE A1 B1 AC, GL
H5550008623	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BBABLM	BLUE A1 B1 AC	S3SFN-L3BBABLM, BLUE A1 B1 AC, GL
H5550008014	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BBAD	BLUE A1 DC	S3SFN-L3BBAD, BLUE A1 DC, GL
H5550008015	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BBADM	BLUE A1 DC	S3SFN-L3BBADM, BLUE A1 DC, GL
H5550008526	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BBAL	BLUE A1 AC	S3SFN-L3BBAL, BLUE A1 AC, GL
H5550008527	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BBALM	BLUE A1 AC	S3SFN-L3BBALM, BLUE A1 AC, GL
H5550008062	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BBBD	BLUE B1 DC	S3SFN-L3BBBD, BLUE B1 DC, GL
H5550008063	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BBBDM	BLUE B1 DC	S3SFN-L3BBBDM, BLUE B1 DC, GL

H5550008574	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BBBL	BLUE B1 AC	S3SFN-L3BBBL, BLUE B1 AC, GL
H5550008575	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BBBLM	BLUE B1 AC	S3SFN-L3BBBLM, BLUE B1 AC, GL
H5550007733	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BG		S3SFN-L3BG, , GL
H5550008158	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BG2AD	GREEN A2 DC	S3SFN-L3BG2AD, GREEN A2 DC, GL
H5550008159	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BG2ADM	GREEN A2 DC	S3SFN-L3BG2ADM, GREEN A2 DC, GL
H5550008670	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BG2AL	GREEN A2 AC	S3SFN-L3BG2AL, GREEN A2 AC, GL
H5550008671	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BG2ALM	GREEN A2 AC	S3SFN-L3BG2ALM, GREEN A2 AC, GL
H5550008206	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BG2BD	GREEN B2 DC	S3SFN-L3BG2BD, GREEN B2 DC, GL
H5550008207	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BG2BDM	GREEN B2 DC	S3SFN-L3BG2BDM, GREEN B2 DC, GL
H5550008718	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BG2BL	GREEN B2 AC	S3SFN-L3BG2BL, GREEN B2 AC, GL
H5550008719	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BG2BLM	GREEN B2 AC	S3SFN-L3BG2BLM, GREEN B2 AC, GL
H5550008238	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BGABD	GREEN A1 B1 DC	S3SFN-L3BGABD, GREEN A1 B1 DC, GL
H5550008239	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BGABDM	GREEN A1 B1 DC	S3SFN-L3BGABDM, GREEN A1 B1 DC, GL
H5550008750	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BGABL	GREEN A1 B1 AC	S3SFN-L3BGABL, GREEN A1 B1 AC, GL
H5550008751	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BGABLM	GREEN A1 B1 AC	S3SFN-L3BGABLM, GREEN A1 B1 AC, GL
H5550008143	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BGADM	GREEN A1 DC	S3SFN-L3BGADM, GREEN A1 DC, GL
H5550008654	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BGAL	GREEN A1 AC	S3SFN-L3BGAL, GREEN A1 AC, GL
H5550008655	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BGALM	GREEN A1 AC	S3SFN-L3BGALM, GREEN A1 AC, GL

H5550008190	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BGBD	GREEN B1 DC	S3SFN-L3BGBD, GREEN B1 DC, GL
H5550008191	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BGBDM	GREEN B1 DC	S3SFN-L3BGBDM, GREEN B1 DC, GL
H5550008702	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BGBL	GREEN B1 AC	S3SFN-L3BGBL, GREEN B1 AC, GL
H5550008703	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BGBLM	GREEN B1 AC	S3SFN-L3BGBLM, GREEN B1 AC, GL
H5550008286	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BY2AD	YELLOW A2 DC	S3SFN-L3BY2AD, YELLOW A2 DC, GL
H5550008287	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BY2ADM	YELLOW A2 DC	S3SFN-L3BY2ADM, YELLOW A2 DC, GL
H5550008798	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BY2AL	YELLOW A2 AC	S3SFN-L3BY2AL, YELLOW A2 AC, GL
H5550008799	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BY2ALM	YELLOW A2 AC	S3SFN-L3BY2ALM, YELLOW A2 AC, GL
H5550008334	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BY2BD	YELLOW B2 DC	S3SFN-L3BY2BD, YELLOW B2 DC, GL
H5550008335	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BY2BDM	YELLOW B2 DC	S3SFN-L3BY2BDM, YELLOW B2 DC, GL
H5550008846	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BY2BL	YELLOW B2 AC	S3SFN-L3BY2BL, YELLOW B2 AC, GL
H5550008847	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BY2BLM	YELLOW B2 AC	S3SFN-L3BY2BLM, YELLOW B2 AC, GL
H5550008366	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BYABD	YELLOW A1 B1 DC	S3SFN-L3BYABD, YELLOW A1 B1 DC, GL
H5550008367	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BYABDM	YELLOW A1 B1 DC	S3SFN-L3BYABDM, YELLOW A1 B1 DC, GL
H5550008878	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BYABL	YELLOW A1 B1 AC	S3SFN-L3BYABL, YELLOW A1 B1 AC, GL
H5550008879	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BYABLM	YELLOW A1 B1 AC	S3SFN-L3BYABLM, YELLOW A1 B1 AC, GL
H5550008270	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BYAD	YELLOW A1 DC	S3SFN-L3BYAD, YELLOW A1 DC, GL
H5550008271	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BYADM	YELLOW A1 DC	S3SFN-L3BYADM, YELLOW A1 DC, GL

H5550008783	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BYALM	YELLOW A1 AC	S3SFN-L3BYALM, YELLOW A1 AC, GL
H5550008318	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BYBD	YELLOW B1 DC	S3SFN-L3BYBD, YELLOW B1 DC, GL
H5550008319	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BYBDM	YELLOW B1 DC	S3SFN-L3BYBDM, YELLOW B1 DC, GL
H5550008830	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BYBL	YELLOW B1 AC	S3SFN-L3BYBL, YELLOW B1 AC, GL
H5550008831	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BYBLM	YELLOW B1 AC	S3SFN-L3BYBLM, YELLOW B1 AC, GL
H5550007688	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AB		S3SFN-L4AB, , GL
H5550008032	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AB2AD	BLUE A2 DC	S3SFN-L4AB2AD, BLUE A2 DC, GL
H5550008033	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AB2ADM	BLUE A2 DC	S3SFN-L4AB2ADM, BLUE A2 DC, GL
H5550008544	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AB2AL	BLUE A2 AC	S3SFN-L4AB2AL, BLUE A2 AC, GL
H5550008545	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AB2ALM	BLUE A2 AC	S3SFN-L4AB2ALM, BLUE A2 AC, GL
H5550008080	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AB2BD	BLUE B2 DC	S3SFN-L4AB2BD, BLUE B2 DC, GL
H5550008081	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AB2BDM	BLUE B2 DC	S3SFN-L4AB2BDM, BLUE B2 DC, GL
H5550008592	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AB2BL	BLUE B2 AC	S3SFN-L4AB2BL, BLUE B2 AC, GL
H5550008593	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AB2BLM	BLUE B2 AC	S3SFN-L4AB2BLM, BLUE B2 AC, GL
H5550008112	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ABABD	BLUE A1 B1 DC	S3SFN-L4ABABD, BLUE A1 B1 DC, GL
H5550008113	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ABABDM	BLUE A1 B1 DC	S3SFN-L4ABABDM, BLUE A1 B1 DC, GL
H5550008624	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ABABL	BLUE A1 B1 AC	S3SFN-L4ABABL, BLUE A1 B1 AC, GL
H5550008625	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ABABLM	BLUE A1 B1 AC	S3SFN-L4ABABLM, BLUE A1 B1 AC, GL

H5550008016	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ABAD	BLUE A1 DC	S3SFN-L4ABAD, BLUE A1 DC, GL
H5550008017	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ABADM	BLUE A1 DC	S3SFN-L4ABADM, BLUE A1 DC, GL
H5550008528	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ABAL	BLUE A1 AC	S3SFN-L4ABAL, BLUE A1 AC, GL
H5550008529	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ABALM	BLUE A1 AC	S3SFN-L4ABALM, BLUE A1 AC, GL
H5550008064	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ABBD	BLUE B1 DC	S3SFN-L4ABBD, BLUE B1 DC, GL
H5550008065	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ABBDM	BLUE B1 DC	S3SFN-L4ABBDM, BLUE B1 DC, GL
H5550008576	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ABBL	BLUE B1 AC	S3SFN-L4ABBL, BLUE B1 AC, GL
H5550008577	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ABBLM	BLUE B1 AC	S3SFN-L4ABBLM, BLUE B1 AC, GL
H5550008160	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AG2AD	GREEN A2 DC	S3SFN-L4AG2AD, GREEN A2 DC, GL
H5550008161	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AG2ADM	GREEN A2 DC	S3SFN-L4AG2ADM, GREEN A2 DC, GL
H5550008672	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AG2AL	GREEN A2 AC	S3SFN-L4AG2AL, GREEN A2 AC, GL
H5550008673	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AG2ALM	GREEN A2 AC	S3SFN-L4AG2ALM, GREEN A2 AC, GL
H5550008208	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AG2BD	GREEN B2 DC	S3SFN-L4AG2BD, GREEN B2 DC, GL
H5550008209	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AG2BDM	GREEN B2 DC	S3SFN-L4AG2BDM, GREEN B2 DC, GL
H5550008720	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AG2BL	GREEN B2 AC	S3SFN-L4AG2BL, GREEN B2 AC, GL
H5550008721	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AG2BLM	GREEN B2 AC	S3SFN-L4AG2BLM, GREEN B2 AC, GL
H5550008240	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AGABD	GREEN A1 B1 DC	S3SFN-L4AGABD, GREEN A1 B1 DC, GL

H5550008241	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AGABDM	GREEN A1 B1 DC	S3SFN-L4AGABDM, GREEN A1 B1 DC, GL
H5550008752	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AGABL	GREEN A1 B1 AC	S3SFN-L4AGABL, GREEN A1 B1 AC, GL
H5550008753	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AGABLM	GREEN A1 B1 AC	S3SFN-L4AGABLM, GREEN A1 B1 AC, GL
H5550008144	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AGAD	GREEN A1 DC	S3SFN-L4AGAD, GREEN A1 DC, GL
H5550008145	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AGADM	GREEN A1 DC	S3SFN-L4AGADM, GREEN A1 DC, GL
H5550008656	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AGAL	GREEN A1 AC	S3SFN-L4AGAL, GREEN A1 AC, GL
H5550008657	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AGALM	GREEN A1 AC	S3SFN-L4AGALM, GREEN A1 AC, GL
H5550008192	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AGBD	GREEN B1 DC	S3SFN-L4AGBD, GREEN B1 DC, GL
H5550008193	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AGBDM	GREEN B1 DC	S3SFN-L4AGBDM, GREEN B1 DC, GL
H5550008704	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AGBL	GREEN B1 AC	S3SFN-L4AGBL, GREEN B1 AC, GL
H5550008705	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AGBLM	GREEN B1 AC	S3SFN-L4AGBLM, GREEN B1 AC, GL
H5550007640	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AR		S3SFN-L4AR, , GL
H5550007784	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AY		S3SFN-L4AY, , GL
H5550008288	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AY2AD	YELLOW A2 DC	S3SFN-L4AY2AD, YELLOW A2 DC, GL
H5550008289	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AY2ADM	YELLOW A2 DC	S3SFN-L4AY2ADM, YELLOW A2 DC, GL
H5550008800	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AY2AL	YELLOW A2 AC	S3SFN-L4AY2AL, YELLOW A2 AC, GL

H5550008801	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AY2ALM	YELLOW A2 AC	S3SFN-L4AY2ALM, YELLOW A2 AC, GL
H5550008336	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AY2BD	YELLOW B2 DC	S3SFN-L4AY2BD, YELLOW B2 DC, GL
H5550008337	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AY2BDM	YELLOW B2 DC	S3SFN-L4AY2BDM, YELLOW B2 DC, GL
H5550008848	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AY2BL	YELLOW B2 AC	S3SFN-L4AY2BL, YELLOW B2 AC, GL
H5550008849	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AY2BLM	YELLOW B2 AC	S3SFN-L4AY2BLM, YELLOW B2 AC, GL
H5550008368	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AYABD	YELLOW A1 B1 DC	S3SFN-L4AYABD, YELLOW A1 B1 DC, GL
H5550008369	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AYABDM	YELLOW A1 B1 DC	S3SFN-L4AYABDM, YELLOW A1 B1 DC, GL
H5550008880	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AYABL	YELLOW A1 B1 AC	S3SFN-L4AYABL, YELLOW A1 B1 AC, GL
H5550008881	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AYABLM	YELLOW A1 B1 AC	S3SFN-L4AYABLM, YELLOW A1 B1 AC, GL
H5550008272	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AYAD	YELLOW A1 DC	S3SFN-L4AYAD, YELLOW A1 DC, GL
H5550008273	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AYADM	YELLOW A1 DC	S3SFN-L4AYADM, YELLOW A1 DC, GL
H5550008784	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AYAL	YELLOW A1 AC	S3SFN-L4AYAL, YELLOW A1 AC, GL
H5550008785	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AYALM	YELLOW A1 AC	S3SFN-L4AYALM, YELLOW A1 AC, GL
H5550008320	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AYBD	YELLOW B1 DC	S3SFN-L4AYBD, YELLOW B1 DC, GL
H5550008321	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AYBDM	YELLOW B1 DC	S3SFN-L4AYBDM, YELLOW B1 DC, GL
H5550008832	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AYBL	YELLOW B1 AC	S3SFN-L4AYBL, YELLOW B1 AC, GL
H5550008833	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AYBLM	YELLOW B1 AC	S3SFN-L4AYBLM, YELLOW B1 AC, GL

H5550007691	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BB		S3SFN-L4BB, , GL	
H5550008034	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BB2AD	BLUE A2 DC	S3SFN-L4BB2AD, BLUE A2 DC, GL	
H5550008035	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BB2ADM	BLUE A2 DC	S3SFN-L4BB2ADM, BLUE A2 DC, GL	
H5550008546	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BB2AL	BLUE A2 AC	S3SFN-L4BB2AL, BLUE A2 AC, GL	
H5550008547	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BB2ALM	BLUE A2 AC	S3SFN-L4BB2ALM, BLUE A2 AC, GL	
H5550008082	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BB2BD	BLUE B2 DC	S3SFN-L4BB2BD, BLUE B2 DC, GL	
H5550008083	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BB2BDM	BLUE B2 DC	S3SFN-L4BB2BDM, BLUE B2 DC, GL	
H5550008594	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BB2BL	BLUE B2 AC	S3SFN-L4BB2BL, BLUE B2 AC, GL	
H5550008595	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BB2BLM	BLUE B2 AC	S3SFN-L4BB2BLM, BLUE B2 AC, GL	
H5550008114	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BBABD	BLUE A1 B1 DC	S3SFN-L4BBABD, BLUE A1 B1 DC, GL	
H5550008115	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BBABDM	BLUE A1 B1 DC	S3SFN-L4BBABDM, BLUE A1 B1 DC, GL	
H5550008626	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BBABL	BLUE A1 B1 AC	S3SFN-L4BBABL, BLUE A1 B1 AC, GL	
H5550008627	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BBABL M	BLUE A1 B1 AC	S3SFN-L4BBABL M, BLUE A1 B1 AC, GL	
H5550008018	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BBAD	BLUE A1 DC	S3SFN-L4BBAD, BLUE A1 DC, GL	
H5550008019	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BBADM	BLUE A1 DC	S3SFN-L4BBADM, BLUE A1 DC, GL	
H5550008530	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BBAL	BLUE A1 AC	S3SFN-L4BBAL, BLUE A1 AC, GL	

H5550008531	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BBALM	BLUE A1 AC	S3SFN-L4BBALM, BLUE A1 AC, GL
H5550008066	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BBBD	BLUE B1 DC	S3SFN-L4BBBD, BLUE B1 DC, GL
H5550008067	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BBBDM	BLUE B1 DC	S3SFN-L4BBBDM, BLUE B1 DC, GL
H5550008578	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BBBL	BLUE B1 AC	S3SFN-L4BBBL, BLUE B1 AC, GL
H5550008579	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BBBLM	BLUE B1 AC	S3SFN-L4BBBLM, BLUE B1 AC, GL
H5550007739	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BG		S3SFN-L4BG, , GL
H5550008162	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BG2AD	GREEN A2 DC	S3SFN-L4BG2AD, GREEN A2 DC, GL
H5550008163	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BG2ADM	GREEN A2 DC	S3SFN-L4BG2ADM, GREEN A2 DC, GL
H5550008674	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BG2AL	GREEN A2 AC	S3SFN-L4BG2AL, GREEN A2 AC, GL
H5550008675	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BG2ALM	GREEN A2 AC	S3SFN-L4BG2ALM, GREEN A2 AC, GL
H5550008210	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BG2BD	GREEN B2 DC	S3SFN-L4BG2BD, GREEN B2 DC, GL
H5550008211	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BG2BDM	GREEN B2 DC	S3SFN-L4BG2BDM, GREEN B2 DC, GL
H5550008722	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BG2BL	GREEN B2 AC	S3SFN-L4BG2BL, GREEN B2 AC, GL
H5550008723	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BG2BLM	GREEN B2 AC	S3SFN-L4BG2BLM, GREEN B2 AC, GL
H5550008242	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BGABD	GREEN A1 B1 DC	S3SFN-L4BGABD, GREEN A1 B1 DC, GL

H5550008243	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BGABDM	GREEN A1 B1 DC	S3SFN-L4BGABDM, GREEN A1 B1 DC, GL	
H5550008754	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BGABL	GREEN A1 B1 AC	S3SFN-L4BGABL, GREEN A1 B1 AC, GL	
H5550008755	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BGABLM	GREEN A1 B1 AC	S3SFN-L4BGABLM, GREEN A1 B1 AC, GL	
H5550008146	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BGAD	GREEN A1 DC	S3SFN-L4BGAD, GREEN A1 DC, GL	
H5550008147	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BGADM	GREEN A1 DC	S3SFN-L4BGADM, GREEN A1 DC, GL	
H5550008658	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BGAL	GREEN A1 AC	S3SFN-L4BGAL, GREEN A1 AC, GL	
H5550008659	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BGALM	GREEN A1 AC	S3SFN-L4BGALM, GREEN A1 AC, GL	
H5550008194	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BGBD	GREEN B1 DC	S3SFN-L4BGBD, GREEN B1 DC, GL	
H5550008195	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BGBDM	GREEN B1 DC	S3SFN-L4BGBDM, GREEN B1 DC, GL	
H5550008706	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BGBL	GREEN B1 AC	S3SFN-L4BGBL, GREEN B1 AC, GL	
H5550008707	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BGBLM	GREEN B1 AC	S3SFN-L4BGBLM, GREEN B1 AC, GL	
H5550007643	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BR		S3SFN-L4BR, , GL	
H5550007787	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BY		S3SFN-L4BY, , GL	
H5550008290	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BY2AD	YELLOW A2 DC	S3SFN-L4BY2AD, YELLOW A2 DC, GL	
H5550008291	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BY2ADM	YELLOW A2 DC	S3SFN-L4BY2ADM, YELLOW A2 DC, GL	
H5550008802	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BY2AL	YELLOW A2 AC	S3SFN-L4BY2AL, YELLOW A2 AC, GL	
H5550008803	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BY2ALM	YELLOW A2 AC	S3SFN-L4BY2ALM, YELLOW A2 AC, GL	
H5550008338	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BY2BD	YELLOW B2 DC	S3SFN-L4BY2BD, YELLOW B2 DC, GL	

H555008339	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BY2BDM	YELLOW B2 DC	S3SFN-L4BY2BDM, YELLOW B2 DC, GL
H555008850	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BY2BL	YELLOW B2 AC	S3SFN-L4BY2BL, YELLOW B2 AC, GL
H555008851	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BY2BLM	YELLOW B2 AC	S3SFN-L4BY2BLM, YELLOW B2 AC, GL
H555008370	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BYABD	YELLOW A1 B1 DC	S3SFN-L4BYABD, YELLOW A1 B1 DC, GL
H555008371	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BYABDM	YELLOW A1 B1 DC	S3SFN-L4BYABDM, YELLOW A1 B1 DC, GL
H555008882	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BYABL	YELLOW A1 B1 AC	S3SFN-L4BYABL, YELLOW A1 B1 AC, GL
H555008883	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BYABLM	YELLOW A1 B1 AC	S3SFN-L4BYABLM, YELLOW A1 B1 AC, GL
H555008274	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BYAD	YELLOW A1 DC	S3SFN-L4BYAD, YELLOW A1 DC, GL
H555008275	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BYADM	YELLOW A1 DC	S3SFN-L4BYADM, YELLOW A1 DC, GL
H555008786	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BYAL	YELLOW A1 AC	S3SFN-L4BYAL, YELLOW A1 AC, GL
H555008787	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BYALM	YELLOW A1 AC	S3SFN-L4BYALM, YELLOW A1 AC, GL
H555008322	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BYBD	YELLOW B1 DC	S3SFN-L4BYBD, YELLOW B1 DC, GL
H555008323	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BYBDM	YELLOW B1 DC	S3SFN-L4BYBDM, YELLOW B1 DC, GL
H555008834	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BYBL	YELLOW B1 AC	S3SFN-L4BYBL, YELLOW B1 AC, GL
H555008835	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BYBLM	YELLOW B1 AC	S3SFN-L4BYBLM, YELLOW B1 AC, GL
H555007694	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5B		S3SFN-L5B, , GL
H555008036	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5B2AD	BLUE A2 DC	S3SFN-L5B2AD, BLUE A2 DC, GL

H5550008037	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5B2ADM	BLUE A2 DC	S3SFN-L5B2ADM, BLUE A2 DC, GL
H5550008548	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5B2AL	BLUE A2 AC	S3SFN-L5B2AL, BLUE A2 AC, GL
H5550008549	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5B2ALM	BLUE A2 AC	S3SFN-L5B2ALM, BLUE A2 AC, GL
H5550008084	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5B2BD	BLUE B2 DC	S3SFN-L5B2BD, BLUE B2 DC, GL
H5550008085	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5B2BDM	BLUE B2 DC	S3SFN-L5B2BDM, BLUE B2 DC, GL
H5550008596	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5B2BL	BLUE B2 AC	S3SFN-L5B2BL, BLUE B2 AC, GL
H5550008597	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5B2BLM	BLUE B2 AC	S3SFN-L5B2BLM, BLUE B2 AC, GL
H5550008116	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5BABD	BLUE A1 B1 DC	S3SFN-L5BABD, BLUE A1 B1 DC, GL
H5550008117	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5BABDM	BLUE A1 B1 DC	S3SFN-L5BABDM, BLUE A1 B1 DC, GL
H5550008628	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5BABL	BLUE A1 B1 AC	S3SFN-L5BABL, BLUE A1 B1 AC, GL
H5550008629	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5BABL M	BLUE A1 B1 AC	S3SFN-L5BABL M, BLUE A1 B1 AC, GL
H5550007742	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5G		S3SFN-L5G, , GL
H5550008164	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5G2AD	GREEN A2 DC	S3SFN-L5G2AD, GREEN A2 DC, GL
H5550008165	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5G2ADM	GREEN A2 DC	S3SFN-L5G2ADM, GREEN A2 DC, GL
H5550008676	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5G2AL	GREEN A2 AC	S3SFN-L5G2AL, GREEN A2 AC, GL
H5550008677	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5G2ALM	GREEN A2 AC	S3SFN-L5G2ALM, GREEN A2 AC, GL
H5550008212	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5G2BD	GREEN B2 DC	S3SFN-L5G2BD, GREEN B2 DC, GL

H5550008213	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5G2BDM	GREEN B2 DC	S3SFN-L5G2BDM, GREEN B2 DC, GL
H5550008724	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5G2BL	GREEN B2 AC	S3SFN-L5G2BL, GREEN B2 AC, GL
H5550008725	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5G2BLM	GREEN B2 AC	S3SFN-L5G2BLM, GREEN B2 AC, GL
H5550008244	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5GABD	GREEN A1 B1 DC	S3SFN-L5GABD, GREEN A1 B1 DC, GL
H5550008245	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5GABDM	GREEN A1 B1 DC	S3SFN-L5GABDM, GREEN A1 B1 DC, GL
H5550008756	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5GABL	GREEN A1 B1 AC	S3SFN-L5GABL, GREEN A1 B1 AC, GL
H5550008757	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5GABLM	GREEN A1 B1 AC	S3SFN-L5GABLM, GREEN A1 B1 AC, GL
H5550011968	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KB	BLUE (HEAD)	S3SFN-L5KB, BLUE (HEAD), GL
H5550011969	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KB2AD	BLUE A2 LED(DC)	S3SFN-L5KB2AD, BLUE A2 LED(DC), GL
H5550011970	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KB2ADM	BLUE A2 LED(DC)	S3SFN-L5KB2ADM, BLUE A2 LED(DC), GL
H5550011971	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KB2AL	BLUE A2 LED(AC)	S3SFN-L5KB2AL, BLUE A2 LED(AC), GL
H5550011972	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KB2ALM	BLUE A2 LED(AC)	S3SFN-L5KB2ALM, BLUE A2 LED(AC), GL
H5550011973	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KB2BD	BLUE B2 LED(DC)	S3SFN-L5KB2BD, BLUE B2 LED(DC), GL
H5550011974	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KB2BDM	BLUE B2 LED(DC)	S3SFN-L5KB2BDM, BLUE B2 LED(DC), GL
H5550011975	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KB2BL	BLUE B2 LED(AC)	S3SFN-L5KB2BL, BLUE B2 LED(AC), GL
H5550011976	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KB2BLM	BLUE B2 LED(AC)	S3SFN-L5KB2BLM, BLUE B2 LED(AC), GL

H5550011977	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KBABD	BLUE AB LED(DC)	S3SFN-L5KBABD, BLUE AB LED(DC), GL
H5550011978	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KBABDM	BLUE AB LED(DC)	S3SFN-L5KBABDM, BLUE AB LED(DC), GL
H5550011979	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KBABL	BLUE AB LED(AC)	S3SFN-L5KBABL, BLUE AB LED(AC), GL
H5550011980	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KBABLM	BLUE AB LED(AC)	S3SFN-L5KBABLM, BLUE AB LED(AC), GL
H5550011981	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KG	GREEN (HEAD)	S3SFN-L5KG, GREEN (HEAD), GL
H5550011982	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KG2AD	GREEN A2 LED(DC)	S3SFN-L5KG2AD, GREEN A2 LED(DC), GL
H5550011983	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KG2ADM	GREEN A2 LED(DC)	S3SFN-L5KG2ADM, GREEN A2 LED(DC), GL
H5550011984	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KG2AL	GREEN A2 LED(AC)	S3SFN-L5KG2AL, GREEN A2 LED(AC), GL
H5550011985	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KG2ALM	GREEN A2 LED(AC)	S3SFN-L5KG2ALM, GREEN A2 LED(AC), GL
H5550011986	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KG2BD	GREEN B2 LED(DC)	S3SFN-L5KG2BD, GREEN B2 LED(DC), GL
H5550011987	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KG2BDM	GREEN B2 LED(DC)	S3SFN-L5KG2BDM, GREEN B2 LED(DC), GL
H5550011988	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KG2BL	GREEN B2 LED(AC)	S3SFN-L5KG2BL, GREEN B2 LED(AC), GL
H5550011989	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KG2BLM	GREEN B2 LED(AC)	S3SFN-L5KG2BLM, GREEN B2 LED(AC), GL
H5550011990	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KGABD	GREEN AB LED(DC)	S3SFN-L5KGABD, GREEN AB LED(DC), GL
H5550011991	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KGABDM	GREEN AB LED(DC)	S3SFN-L5KGABDM, GREEN AB LED(DC), GL

H5550011992	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KGABL	GREEN AB LED(AC)	S3SFN-L5KGABL, GREEN AB LED(AC), GL	
H5550011993	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KGABLM	GREEN AB LED(AC)	S3SFN-L5KGABLM, GREEN AB LED(AC), GL	
H5550011994	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KR	RED (HEAD)	S3SFN-L5KR, RED (HEAD), GL	
H5550012007	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KY	YELLOW (HEAD)	S3SFN-L5KY, YELLOW (HEAD), GL	
H5550012008	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KY2AD	YELLOW A2 LED(DC)	S3SFN-L5KY2AD, YELLOW A2 LED(DC), GL	
H5550012009	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KY2ADM	YELLOW A2 LED(DC)	S3SFN-L5KY2ADM, YELLOW A2 LED(DC), GL	
H5550012010	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KY2AL	YELLOW A2 LED(AC)	S3SFN-L5KY2AL, YELLOW A2 LED(AC), GL	
H5550012011	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KY2ALM	YELLOW A2 LED(AC)	S3SFN-L5KY2ALM, YELLOW A2 LED(AC), GL	
H5550012012	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KY2BD	YELLOW B2 LED(DC)	S3SFN-L5KY2BD, YELLOW B2 LED(DC), GL	
H5550012013	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KY2BDM	YELLOW B2 LED(DC)	S3SFN-L5KY2BDM, YELLOW B2 LED(DC), GL	
H5550012014	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KY2BL	YELLOW B2 LED(AC)	S3SFN-L5KY2BL, YELLOW B2 LED(AC), GL	
H5550012015	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KY2BLM	YELLOW B2 LED(AC)	S3SFN-L5KY2BLM, YELLOW B2 LED(AC), GL	
H5550012016	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KYABD	YELLOW AB LED(DC)	S3SFN-L5KYABD, YELLOW AB LED(DC), GL	
H5550012017	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KYABDM	YELLOW AB LED(DC)	S3SFN-L5KYABDM, YELLOW AB LED(DC), GL	
H5550012018	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KYABL	YELLOW AB LED(AC)	S3SFN-L5KYABL, YELLOW AB LED(AC), GL	
H5550012019	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KYABLM	YELLOW AB LED(AC)	S3SFN-L5KYABLM, YELLOW AB LED(AC), GL	
H5550007790	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5Y		S3SFN-L5Y, , GL	

H5550008292	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5Y2AD	YELLOW A2 DC	S3SFN-L5Y2AD, YELLOW A2 DC, GL
H5550008293	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5Y2ADM	YELLOW A2 DC	S3SFN-L5Y2ADM, YELLOW A2 DC, GL
H5550008804	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5Y2AL	YELLOW A2 AC	S3SFN-L5Y2AL, YELLOW A2 AC, GL
H5550008805	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5Y2ALM	YELLOW A2 AC	S3SFN-L5Y2ALM, YELLOW A2 AC, GL
H5550008340	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5Y2BD	YELLOW B2 DC	S3SFN-L5Y2BD, YELLOW B2 DC, GL
H5550008341	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5Y2BDM	YELLOW B2 DC	S3SFN-L5Y2BDM, YELLOW B2 DC, GL
H5550008852	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5Y2BL	YELLOW B2 AC	S3SFN-L5Y2BL, YELLOW B2 AC, GL
H5550008853	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5Y2BLM	YELLOW B2 AC	S3SFN-L5Y2BLM, YELLOW B2 AC, GL
H5550008372	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5YABD	YELLOW A1 B1 DC	S3SFN-L5YABD, YELLOW A1 B1 DC, GL
H5550008373	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5YABDM	YELLOW A1 B1 DC	S3SFN-L5YABDM, YELLOW A1 B1 DC, GL
H5550008884	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5YABL	YELLOW A1 B1 AC	S3SFN-L5YABL, YELLOW A1 B1 AC, GL

H5550008885	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5YABLM	YELLOW A1 B1 AC	S3SFN-L5YABLM, YELLOW A1 B1 AC, GL	
H5550007697	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6B		S3SFN-L6B, , GL	
H5550008038	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6B2AD	BLUE A2 DC	S3SFN-L6B2AD, BLUE A2 DC, GL	
H5550008039	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6B2ADM	BLUE A2 DC	S3SFN-L6B2ADM, BLUE A2 DC, GL	
H5550008550	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6B2AL	BLUE A2 AC	S3SFN-L6B2AL, BLUE A2 AC, GL	
H5550008551	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6B2ALM	BLUE A2 AC	S3SFN-L6B2ALM, BLUE A2 AC, GL	
H5550008086	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6B2BD	BLUE B2 DC	S3SFN-L6B2BD, BLUE B2 DC, GL	
H5550008087	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6B2BDM	BLUE B2 DC	S3SFN-L6B2BDM, BLUE B2 DC, GL	
H5550008598	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6B2BL	BLUE B2 AC	S3SFN-L6B2BL, BLUE B2 AC, GL	
H5550008599	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6B2BLM	BLUE B2 AC	S3SFN-L6B2BLM, BLUE B2 AC, GL	
H5550008118	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6BABD	BLUE A1 B1 DC	S3SFN-L6BABD, BLUE A1 B1 DC, GL	
H5550008119	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6BABDM	BLUE A1 B1 DC	S3SFN-L6BABDM, BLUE A1 B1 DC, GL	Селекторный переключатель, Ø30, с длинной ручкой shark утолщенного типа, 3-позиционный самовозврат из 2-х положений, синий, модульный, СИД 12-24 В=~/~ ,50/60 Гц, 1 контакт нормально открытый, 1 контакт нормально закрытый, коммутация до 250В~ 6А ,110В~ 10 А.
H5550008630	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6BABL	BLUE A1 B1 AC	S3SFN-L6BABL, BLUE A1 B1 AC, GL	

H5550008631	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6BABLM	BLUE A1 B1 AC	S3SFN-L6BABLM, BLUE A1 B1 AC, GL
H5550007745	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6G		S3SFN-L6G, , GL
H5550008166	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6G2AD	GREEN A2 DC	S3SFN-L6G2AD, GREEN A2 DC, GL
H5550008167	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6G2ADM	GREEN A2 DC	S3SFN-L6G2ADM, GREEN A2 DC, GL
H5550008678	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6G2AL	GREEN A2 AC	S3SFN-L6G2AL, GREEN A2 AC, GL
H5550008679	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6G2ALM	GREEN A2 AC	S3SFN-L6G2ALM, GREEN A2 AC, GL
H5550008214	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6G2BD	GREEN B2 DC	S3SFN-L6G2BD, GREEN B2 DC, GL
H5550008215	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6G2BDM	GREEN B2 DC	S3SFN-L6G2BDM, GREEN B2 DC, GL
H5550008726	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6G2BL	GREEN B2 AC	S3SFN-L6G2BL, GREEN B2 AC, GL
H5550008727	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6G2BLM	GREEN B2 AC	S3SFN-L6G2BLM, GREEN B2 AC, GL
H5550008246	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6GABD	GREEN A1 B1 DC	S3SFN-L6GABD, GREEN A1 B1 DC, GL
H5550008247	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6GABDM	GREEN A1 B1 DC	S3SFN-L6GABDM, GREEN A1 B1 DC, GL
H5550008758	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6GABL	GREEN A1 B1 AC	S3SFN-L6GABL, GREEN A1 B1 AC, GL
H5550008759	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6GABLM	GREEN A1 B1 AC	S3SFN-L6GABLM, GREEN A1 B1 AC, GL

H5550012020	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KB	BLUE (HEAD)	S3SFN-L6KB, BLUE (HEAD), GL
H5550012021	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KB2AD	BLUE A2 LED(DC)	S3SFN-L6KB2AD, BLUE A2 LED(DC), GL
H5550012022	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KB2ADM	BLUE A2 LED(DC)	S3SFN-L6KB2ADM, BLUE A2 LED(DC), GL
H5550012023	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KB2AL	BLUE A2 LED(AC)	S3SFN-L6KB2AL, BLUE A2 LED(AC), GL
H5550012024	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KB2ALM	BLUE A2 LED(AC)	S3SFN-L6KB2ALM, BLUE A2 LED(AC), GL
H5550012025	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KB2BD	BLUE B2 LED(DC)	S3SFN-L6KB2BD, BLUE B2 LED(DC), GL
H5550012026	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KB2BDM	BLUE B2 LED(DC)	S3SFN-L6KB2BDM, BLUE B2 LED(DC), GL
H5550012027	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KB2BL	BLUE B2 LED(AC)	S3SFN-L6KB2BL, BLUE B2 LED(AC), GL
H5550012028	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KB2BLM	BLUE B2 LED(AC)	S3SFN-L6KB2BLM, BLUE B2 LED(AC), GL
H5550012029	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KBABD	BLUE AB LED(DC)	S3SFN-L6KBABD, BLUE AB LED(DC), GL
H5550012030	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KBABDM	BLUE AB LED(DC)	S3SFN-L6KBABDM, BLUE AB LED(DC), GL
H5550012031	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KBABL	BLUE AB LED(AC)	S3SFN-L6KBABL, BLUE AB LED(AC), GL
H5550012032	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KBABLM	BLUE AB LED(AC)	S3SFN-L6KBABLM, BLUE AB LED(AC), GL

H5550012033	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KG	GREEN (HEAD)	S3SFN-L6KG, GREEN (HEAD), GL
H5550012034	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KG2AD	GREEN A2 LED(DC)	S3SFN-L6KG2AD, GREEN A2 LED(DC), GL
H5550012035	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KG2ADM	GREEN A2 LED(DC)	S3SFN-L6KG2ADM, GREEN A2 LED(DC), GL
H5550012036	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KG2AL	GREEN A2 LED(AC)	S3SFN-L6KG2AL, GREEN A2 LED(AC), GL
H5550012037	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KG2ALM	GREEN A2 LED(AC)	S3SFN-L6KG2ALM, GREEN A2 LED(AC), GL
H5550012038	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KG2BD	GREEN B2 LED(DC)	S3SFN-L6KG2BD, GREEN B2 LED(DC), GL
H5550012039	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KG2BDM	GREEN B2 LED(DC)	S3SFN-L6KG2BDM, GREEN B2 LED(DC), GL
H5550012040	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KG2BL	GREEN B2 LED(AC)	S3SFN-L6KG2BL, GREEN B2 LED(AC), GL
H5550012041	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KG2BLM	GREEN B2 LED(AC)	S3SFN-L6KG2BLM, GREEN B2 LED(AC), GL
H5550012042	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KGABD	GREEN AB LED(DC)	S3SFN-L6KGABD, GREEN AB LED(DC), GL
H5550012043	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KGABDM	GREEN AB LED(DC)	S3SFN-L6KGABDM, GREEN AB LED(DC), GL
H5550012044	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KGABL	GREEN AB LED(AC)	S3SFN-L6KGABL, GREEN AB LED(AC), GL
H5550012045	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KGABLM	GREEN AB LED(AC)	S3SFN-L6KGABLM, GREEN AB LED(AC), GL
H5550012046	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KR	RED (HEAD)	S3SFN-L6KR, RED (HEAD), GL
H5550012059	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KY	YELLOW (HEAD)	S3SFN-L6KY, YELLOW (HEAD), GL
H5550012060	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KY2AD	YELLOW A2 LED(DC)	S3SFN-L6KY2AD, YELLOW A2 LED(DC), GL

H5550012061	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KY2ADM	YELLOW A2 LED(DC)	S3SFN-L6KY2ADM, YELLOW A2 LED(DC), GL
H5550012062	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KY2AL	YELLOW A2 LED(AC)	S3SFN-L6KY2AL, YELLOW A2 LED(AC), GL
H5550012063	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KY2ALM	YELLOW A2 LED(AC)	S3SFN-L6KY2ALM, YELLOW A2 LED(AC), GL
H5550012064	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KY2BD	YELLOW B2 LED(DC)	S3SFN-L6KY2BD, YELLOW B2 LED(DC), GL
H5550012065	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KY2BDM	YELLOW B2 LED(DC)	S3SFN-L6KY2BDM, YELLOW B2 LED(DC), GL
H5550012066	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KY2BL	YELLOW B2 LED(AC)	S3SFN-L6KY2BL, YELLOW B2 LED(AC), GL
H5550012067	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KY2BLM	YELLOW B2 LED(AC)	S3SFN-L6KY2BLM, YELLOW B2 LED(AC), GL
H5550012068	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KYABD	YELLOW AB LED(DC)	S3SFN-L6KYABD, YELLOW AB LED(DC), GL
H5550012069	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KYABDM	YELLOW AB LED(DC)	S3SFN-L6KYABDM, YELLOW AB LED(DC), GL
H5550012070	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KYABL	YELLOW AB LED(AC)	S3SFN-L6KYABL, YELLOW AB LED(AC), GL
H5550012071	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KYABLM	YELLOW AB LED(AC)	S3SFN-L6KYABLM, YELLOW AB LED(AC), GL
H5550007793	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6Y		S3SFN-L6Y, , GL
H5550008294	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6Y2AD	YELLOW A2 DC	S3SFN-L6Y2AD, YELLOW A2 DC, GL
H5550008295	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6Y2ADM	YELLOW A2 DC	S3SFN-L6Y2ADM, YELLOW A2 DC, GL
H5550008806	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6Y2AL	YELLOW A2 AC	S3SFN-L6Y2AL, YELLOW A2 AC, GL

H5550008807	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6Y2ALM	YELLOW A2 AC	S3SFN-L6Y2ALM, YELLOW A2 AC, GL
H5550008342	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6Y2BD	YELLOW B2 DC	S3SFN-L6Y2BD, YELLOW B2 DC, GL
H5550008343	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6Y2BDM	YELLOW B2 DC	S3SFN-L6Y2BDM, YELLOW B2 DC, GL
H5550008854	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6Y2BL	YELLOW B2 AC	S3SFN-L6Y2BL, YELLOW B2 AC, GL
H5550008855	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6Y2BLM	YELLOW B2 AC	S3SFN-L6Y2BLM, YELLOW B2 AC, GL
H5550008374	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6YABD	YELLOW A1 B1 DC	S3SFN-L6YABD, YELLOW A1 B1 DC, GL
H5550008375	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6YABDM	YELLOW A1 B1 DC	S3SFN-L6YABDM, YELLOW A1 B1 DC, GL
H5550008886	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6YABL	YELLOW A1 B1 AC	S3SFN-L6YABL, YELLOW A1 B1 AC, GL
H5550008887	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6YABLM	YELLOW A1 B1 AC	S3SFN-L6YABLM, YELLOW A1 B1 AC, GL
H5550007700	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7B		S3SFN-L7B, , GL
H5550008040	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7B2AD	BLUE A2 DC	S3SFN-L7B2AD, BLUE A2 DC, GL
H5550008041	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7B2ADM	BLUE A2 DC	S3SFN-L7B2ADM, BLUE A2 DC, GL
H5550008552	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7B2AL	BLUE A2 AC	S3SFN-L7B2AL, BLUE A2 AC, GL

H5550008553	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7B2ALM	BLUE A2 AC	S3SFN-L7B2ALM, BLUE A2 AC, GL
H5550008088	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7B2BD	BLUE B2 DC	S3SFN-L7B2BD, BLUE B2 DC, GL
H5550008089	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7B2BDM	BLUE B2 DC	S3SFN-L7B2BDM, BLUE B2 DC, GL
H5550008600	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7B2BL	BLUE B2 AC	S3SFN-L7B2BL, BLUE B2 AC, GL
H5550008601	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7B2BLM	BLUE B2 AC	S3SFN-L7B2BLM, BLUE B2 AC, GL
H5550008120	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7BABD	BLUE A1 B1 DC	S3SFN-L7BABD, BLUE A1 B1 DC, GL
H5550008121	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7BABDM	BLUE A1 B1 DC	S3SFN-L7BABDM, BLUE A1 B1 DC, GL
H5550008632	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7BABL	BLUE A1 B1 AC	S3SFN-L7BABL, BLUE A1 B1 AC, GL
H5550008633	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7BABLM	BLUE A1 B1 AC	S3SFN-L7BABLM, BLUE A1 B1 AC, GL
H5550007748	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7G		S3SFN-L7G, , GL
H5550008168	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7G2AD	GREEN A2 DC	S3SFN-L7G2AD, GREEN A2 DC, GL
H5550008169	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7G2ADM	GREEN A2 DC	S3SFN-L7G2ADM, GREEN A2 DC, GL
H5550008680	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7G2AL	GREEN A2 AC	S3SFN-L7G2AL, GREEN A2 AC, GL
H5550008681	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7G2ALM	GREEN A2 AC	S3SFN-L7G2ALM, GREEN A2 AC, GL
H5550008216	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7G2BD	GREEN B2 DC	S3SFN-L7G2BD, GREEN B2 DC, GL
H5550008217	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7G2BDM	GREEN B2 DC	S3SFN-L7G2BDM, GREEN B2 DC, GL
H5550008728	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7G2BL	GREEN B2 AC	S3SFN-L7G2BL, GREEN B2 AC, GL
H5550008729	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7G2BLM	GREEN B2 AC	S3SFN-L7G2BLM, GREEN B2 AC, GL
H5550008248	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7GABD	GREEN A1 B1 DC	S3SFN-L7GABD, GREEN A1 B1 DC, GL

H5550008249	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7GABDM	GREEN A1 B1 DC	S3SFN-L7GABDM, GREEN A1 B1 DC, GL	
H5550008760	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7GABL	GREEN A1 B1 AC	S3SFN-L7GABL, GREEN A1 B1 AC, GL	Селекторный переключатель, 30мм, утопленный, С подсветкой, Короткая ручка, Зеленый, 3-позиционный, 1 нормально открытый, 1 нормально закрытый, 110 - 220 В~ 50/60 Hz
H5550008761	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7GABLM	GREEN A1 B1 AC	S3SFN-L7GABLM, GREEN A1 B1 AC, GL	Селекторный переключатель, 30мм, утопленный, С подсветкой, Короткая ручка, Зеленый, 3-позиционный, 1 нормально открытый, 1 нормально закрытый, 110 - 220 В~ 50/60 Hz
H5550012072	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KB	BLUE (HEAD)	S3SFN-L7KB, BLUE (HEAD), GL	
H5550012073	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KB2AD	BLUE A2 LED(DC)	S3SFN-L7KB2AD, BLUE A2 LED(DC), GL	
H5550012074	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KB2ADM	BLUE A2 LED(DC)	S3SFN-L7KB2ADM, BLUE A2 LED(DC), GL	
H5550012075	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KB2AL	BLUE A2 LED(AC)	S3SFN-L7KB2AL, BLUE A2 LED(AC), GL	
H5550012076	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KB2ALM	BLUE A2 LED(AC)	S3SFN-L7KB2ALM, BLUE A2 LED(AC), GL	
H5550012077	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KB2BD	BLUE B2 LED(DC)	S3SFN-L7KB2BD, BLUE B2 LED(DC), GL	
H5550012078	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KB2BDM	BLUE B2 LED(DC)	S3SFN-L7KB2BDM, BLUE B2 LED(DC), GL	
H5550012079	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KB2BL	BLUE B2 LED(AC)	S3SFN-L7KB2BL, BLUE B2 LED(AC), GL	
H5550012080	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KB2BLM	BLUE B2 LED(AC)	S3SFN-L7KB2BLM, BLUE B2 LED(AC), GL	
H5550012081	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KBABD	BLUE AB LED(DC)	S3SFN-L7KBABD, BLUE AB LED(DC), GL	
H5550012082	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KBABDM	BLUE AB LED(DC)	S3SFN-L7KBABDM, BLUE AB LED(DC), GL	

H5550012083	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KBABL	BLUE AB LED(AC)	S3SFN-L7KBABL, BLUE AB LED(AC), GL
H5550012084	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KBABLM	BLUE AB LED(AC)	S3SFN-L7KBABLM, BLUE AB LED(AC), GL
H5550012085	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KG	GREEN (HEAD)	S3SFN-L7KG, GREEN (HEAD), GL
H5550012086	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KG2AD	GREEN A2 LED(DC)	S3SFN-L7KG2AD, GREEN A2 LED(DC), GL
H5550012087	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KG2ADM	GREEN A2 LED(DC)	S3SFN-L7KG2ADM, GREEN A2 LED(DC), GL
H5550012088	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KG2AL	GREEN A2 LED(AC)	S3SFN-L7KG2AL, GREEN A2 LED(AC), GL
H5550012089	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KG2ALM	GREEN A2 LED(AC)	S3SFN-L7KG2ALM, GREEN A2 LED(AC), GL
H5550012090	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KG2BD	GREEN B2 LED(DC)	S3SFN-L7KG2BD, GREEN B2 LED(DC), GL
H5550012091	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KG2BDM	GREEN B2 LED(DC)	S3SFN-L7KG2BDM, GREEN B2 LED(DC), GL
H5550012092	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KG2BL	GREEN B2 LED(AC)	S3SFN-L7KG2BL, GREEN B2 LED(AC), GL
H5550012093	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KG2BLM	GREEN B2 LED(AC)	S3SFN-L7KG2BLM, GREEN B2 LED(AC), GL
H5550012094	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KGABD	GREEN AB LED(DC)	S3SFN-L7KGABD, GREEN AB LED(DC), GL
H5550012095	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KGABDM	GREEN AB LED(DC)	S3SFN-L7KGABDM, GREEN AB LED(DC), GL
H5550012096	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KGABL	GREEN AB LED(AC)	S3SFN-L7KGABL, GREEN AB LED(AC), GL
H5550012097	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KGABLM	GREEN AB LED(AC)	S3SFN-L7KGABLM, GREEN AB LED(AC), GL
H5550012098	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KR	RED (HEAD)	S3SFN-L7KR, RED (HEAD), GL

H5550012111	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KY	YELLOW (HEAD)	S3SFN-L7KY, YELLOW (HEAD), GL
H5550012112	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KY2AD	YELLOW A2 LED(DC)	S3SFN-L7KY2AD, YELLOW A2 LED(DC), GL
H5550012113	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KY2ADM	YELLOW A2 LED(DC)	S3SFN-L7KY2ADM, YELLOW A2 LED(DC), GL
H5550012115	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KY2ALM	YELLOW A2 LED(AC)	S3SFN-L7KY2ALM, YELLOW A2 LED(AC), GL
H5550012116	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KY2BD	YELLOW B2 LED(DC)	S3SFN-L7KY2BD, YELLOW B2 LED(DC), GL
H5550012117	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KY2BDM	YELLOW B2 LED(DC)	S3SFN-L7KY2BDM, YELLOW B2 LED(DC), GL
H5550012118	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KY2BL	YELLOW B2 LED(AC)	S3SFN-L7KY2BL, YELLOW B2 LED(AC), GL
H5550012119	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KY2BLM	YELLOW B2 LED(AC)	S3SFN-L7KY2BLM, YELLOW B2 LED(AC), GL
H5550012120	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KYABD	YELLOW AB LED(DC)	S3SFN-L7KYABD, YELLOW AB LED(DC), GL
H5550012121	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KYABDM	YELLOW AB LED(DC)	S3SFN-L7KYABDM, YELLOW AB LED(DC), GL
H5550012122	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KYABL	YELLOW AB LED(AC)	S3SFN-L7KYABL, YELLOW AB LED(AC), GL
H5550012123	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KYABLM	YELLOW AB LED(AC)	S3SFN-L7KYABLM, YELLOW AB LED(AC), GL
H5550007796	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7Y		S3SFN-L7Y, , GL
H5550008296	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7Y2AD	YELLOW A2 DC	S3SFN-L7Y2AD, YELLOW A2 DC, GL
H5550008297	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7Y2ADM	YELLOW A2 DC	S3SFN-L7Y2ADM, YELLOW A2 DC, GL
H5550008808	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7Y2AL	YELLOW A2 AC	S3SFN-L7Y2AL, YELLOW A2 AC, GL
H5550008809	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7Y2ALM	YELLOW A2 AC	S3SFN-L7Y2ALM, YELLOW A2 AC, GL
H5550008344	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7Y2BD	YELLOW B2 DC	S3SFN-L7Y2BD, YELLOW B2 DC, GL

H5550008345	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7Y2BDM	YELLOW B2 DC	S3SFN-L7Y2BDM, YELLOW B2 DC, GL
H5550008856	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7Y2BL	YELLOW B2 AC	S3SFN-L7Y2BL, YELLOW B2 AC, GL
H5550008857	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7Y2BLM	YELLOW B2 AC	S3SFN-L7Y2BLM, YELLOW B2 AC, GL
H5550008376	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7YABD	YELLOW A1 B1 DC	S3SFN-L7YABD, YELLOW A1 B1 DC, GL
H5550008377	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7YABDM	YELLOW A1 B1 DC	S3SFN-L7YABDM, YELLOW A1 B1 DC, GL
H5550008888	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7YABL	YELLOW A1 B1 AC	S3SFN-L7YABL, YELLOW A1 B1 AC, GL
H5550008889	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7YABLM	YELLOW A1 B1 AC	S3SFN-L7YABLM, YELLOW A1 B1 AC, GL
H5550007703	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8B		S3SFN-L8B, , GL
H5550008042	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8B2AD	BLUE A2 DC	S3SFN-L8B2AD, BLUE A2 DC, GL
H5550008043	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8B2ADM	BLUE A2 DC	S3SFN-L8B2ADM, BLUE A2 DC, GL
H5550008554	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8B2AL	BLUE A2 AC	S3SFN-L8B2AL, BLUE A2 AC, GL
H5550008555	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8B2ALM	BLUE A2 AC	S3SFN-L8B2ALM, BLUE A2 AC, GL
H5550008090	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8B2BD	BLUE B2 DC	S3SFN-L8B2BD, BLUE B2 DC, GL
H5550008091	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8B2BDM	BLUE B2 DC	S3SFN-L8B2BDM, BLUE B2 DC, GL
H5550008602	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8B2BL	BLUE B2 AC	S3SFN-L8B2BL, BLUE B2 AC, GL
H5550008603	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8B2BLM	BLUE B2 AC	S3SFN-L8B2BLM, BLUE B2 AC, GL

H5550008122	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8BABD	BLUE A1 B1 DC	S3SFN-L8BABD, BLUE A1 B1 DC, GL	
H5550008123	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8BABDM	BLUE A1 B1 DC	S3SFN-L8BABDM, BLUE A1 B1 DC, GL	Селекторный переключатель, Ø30, с длинной ручкой shark утопленного типа, 3-позиционный с фиксацией, синий, модульный, СИД 12-24 В~/~ 50/60 Гц, 1 контакт нормально открытый, 1 контакт нормально закрытый, коммутация до 250В~ 6А, 110В~ 10 А.
H5550008634	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8BABL	BLUE A1 B1 AC	S3SFN-L8BABL, BLUE A1 B1 AC, GL	
H5550008635	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8BABLM	BLUE A1 B1 AC	S3SFN-L8BABLM, BLUE A1 B1 AC, GL	
H5550007751	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8G		S3SFN-L8G, , GL	
H5550008170	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8G2AD	GREEN A2 DC	S3SFN-L8G2AD, GREEN A2 DC, GL	
H5550008171	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8G2ADM	GREEN A2 DC	S3SFN-L8G2ADM, GREEN A2 DC, GL	
H5550008682	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8G2AL	GREEN A2 AC	S3SFN-L8G2AL, GREEN A2 AC, GL	
H5550008683	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8G2ALM	GREEN A2 AC	S3SFN-L8G2ALM, GREEN A2 AC, GL	
H5550008218	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8G2BD	GREEN B2 DC	S3SFN-L8G2BD, GREEN B2 DC, GL	
H5550008219	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8G2BDM	GREEN B2 DC	S3SFN-L8G2BDM, GREEN B2 DC, GL	
H5550008730	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8G2BL	GREEN B2 AC	S3SFN-L8G2BL, GREEN B2 AC, GL	
H5550008731	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8G2BLM	GREEN B2 AC	S3SFN-L8G2BLM, GREEN B2 AC, GL	
H5550008250	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8GABD	GREEN A1 B1 DC	S3SFN-L8GABD, GREEN A1 B1 DC, GL	
H5550008251	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8GABDM	GREEN A1 B1 DC	S3SFN-L8GABDM, GREEN A1 B1 DC, GL	
H5550008762	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8GABL	GREEN A1 B1 AC	S3SFN-L8GABL, GREEN A1 B1 AC, GL	Селекторный переключатель, 30мм, утопленный, С подсветкой, Короткая ручка, Зеленый, 3-позиционный, 1 нормально открытый, 1 нормально закрытый, 110 - 220

							B~ 50/60 Hz
H5550008763	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8GABLM	GREEN A1 B1 AC	S3SFN-L8GABLM, GREEN A1 B1 AC, GL	Селекторный переключатель, 30мм, утопленный, С подсветкой, Короткая ручка, Зеленый, 3-позиционный, 1 нормально открытый, 1 нормально закрытый, 110 - 220 В~ 50/60 Hz
H5550012124	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KB	BLUE (HEAD)	S3SFN-L8KB, BLUE (HEAD), GL	
H5550012125	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KB2AD	BLUE A2 LED(DC)	S3SFN-L8KB2AD, BLUE A2 LED(DC), GL	
H5550012126	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KB2ADM	BLUE A2 LED(DC)	S3SFN-L8KB2ADM, BLUE A2 LED(DC), GL	
H5550012127	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KB2AL	BLUE A2 LED(AC)	S3SFN-L8KB2AL, BLUE A2 LED(AC), GL	
H5550012128	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KB2ALM	BLUE A2 LED(AC)	S3SFN-L8KB2ALM, BLUE A2 LED(AC), GL	
H5550012129	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KB2BD	BLUE B2 LED(DC)	S3SFN-L8KB2BD, BLUE B2 LED(DC), GL	
H5550012130	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KB2BDM	BLUE B2 LED(DC)	S3SFN-L8KB2BDM, BLUE B2 LED(DC), GL	
H5550012131	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KB2BL	BLUE B2 LED(AC)	S3SFN-L8KB2BL, BLUE B2 LED(AC), GL	
H5550012132	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KB2BLM	BLUE B2 LED(AC)	S3SFN-L8KB2BLM, BLUE B2 LED(AC), GL	
H5550012133	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KBABD	BLUE AB LED(DC)	S3SFN-L8KBABD, BLUE AB LED(DC), GL	
H5550012134	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KBABDM	BLUE AB LED(DC)	S3SFN-L8KBABDM, BLUE AB LED(DC), GL	
H5550012135	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KBABL	BLUE AB LED(AC)	S3SFN-L8KBABL, BLUE AB LED(AC), GL	
H5550012136	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KBABLM	BLUE AB LED(AC)	S3SFN-L8KBABLM, BLUE AB LED(AC), GL	
H5550012137	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KG	GREEN (HEAD)	S3SFN-L8KG, GREEN (HEAD), GL	

H5550012138	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KG2AD	GREEN A2 LED(DC)	S3SFN-L8KG2AD, GREEN A2 LED(DC), GL
H5550012139	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KG2ADM	GREEN A2 LED(DC)	S3SFN-L8KG2ADM, GREEN A2 LED(DC), GL
H5550012140	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KG2AL	GREEN A2 LED(AC)	S3SFN-L8KG2AL, GREEN A2 LED(AC), GL
H5550012141	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KG2ALM	GREEN A2 LED(AC)	S3SFN-L8KG2ALM, GREEN A2 LED(AC), GL
H5550012142	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KG2BD	GREEN B2 LED(DC)	S3SFN-L8KG2BD, GREEN B2 LED(DC), GL
H5550012143	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KG2BDM	GREEN B2 LED(DC)	S3SFN-L8KG2BDM, GREEN B2 LED(DC), GL
H5550012144	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KG2BL	GREEN B2 LED(AC)	S3SFN-L8KG2BL, GREEN B2 LED(AC), GL
H5550012145	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KG2BLM	GREEN B2 LED(AC)	S3SFN-L8KG2BLM, GREEN B2 LED(AC), GL
H5550012146	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KGABD	GREEN AB LED(DC)	S3SFN-L8KGABD, GREEN AB LED(DC), GL
H5550012147	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KGABDM	GREEN AB LED(DC)	S3SFN-L8KGABDM, GREEN AB LED(DC), GL
H5550012148	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KGABL	GREEN AB LED(AC)	S3SFN-L8KGABL, GREEN AB LED(AC), GL
H5550012149	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KGABLM	GREEN AB LED(AC)	S3SFN-L8KGABLM, GREEN AB LED(AC), GL
H5550012150	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KR	RED (HEAD)	S3SFN-L8KR, RED (HEAD), GL
H5550012163	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KY	YELLOW (HEAD)	S3SFN-L8KY, YELLOW (HEAD), GL
H5550012164	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KY2AD	YELLOW A2 LED(DC)	S3SFN-L8KY2AD, YELLOW A2 LED(DC), GL
H5550012165	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KY2ADM	YELLOW A2 LED(DC)	S3SFN-L8KY2ADM, YELLOW A2 LED(DC), GL

H5550012166	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KY2AL	YELLOW A2 LED(AC)	S3SFN-L8KY2AL, YELLOW A2 LED(AC), GL
H5550012167	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KY2ALM	YELLOW A2 LED(AC)	S3SFN-L8KY2ALM, YELLOW A2 LED(AC), GL
H5550012168	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KY2BD	YELLOW B2 LED(DC)	S3SFN-L8KY2BD, YELLOW B2 LED(DC), GL
H5550012169	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KY2BDM	YELLOW B2 LED(DC)	S3SFN-L8KY2BDM, YELLOW B2 LED(DC), GL
H5550012170	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KY2BL	YELLOW B2 LED(AC)	S3SFN-L8KY2BL, YELLOW B2 LED(AC), GL
H5550012171	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KY2BLM	YELLOW B2 LED(AC)	S3SFN-L8KY2BLM, YELLOW B2 LED(AC), GL
H5550012172	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KYABD	YELLOW AB LED(DC)	S3SFN-L8KYABD, YELLOW AB LED(DC), GL
H5550012173	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KYABDM	YELLOW AB LED(DC)	S3SFN-L8KYABDM, YELLOW AB LED(DC), GL
H5550012174	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KYABL	YELLOW AB LED(AC)	S3SFN-L8KYABL, YELLOW AB LED(AC), GL
H5550012175	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KYABLM	YELLOW AB LED(AC)	S3SFN-L8KYABLM, YELLOW AB LED(AC), GL
H5550007799	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8Y		S3SFN-L8Y, , GL
H5550008298	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8Y2AD	YELLOW A2 DC	S3SFN-L8Y2AD, YELLOW A2 DC, GL
H5550008299	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8Y2ADM	YELLOW A2 DC	S3SFN-L8Y2ADM, YELLOW A2 DC, GL
H5550008810	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8Y2AL	YELLOW A2 AC	S3SFN-L8Y2AL, YELLOW A2 AC, GL
H5550008811	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8Y2ALM	YELLOW A2 AC	S3SFN-L8Y2ALM, YELLOW A2 AC, GL
H5550008346	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8Y2BD	YELLOW B2 DC	S3SFN-L8Y2BD, YELLOW B2 DC, GL
H5550008347	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8Y2BDM	YELLOW B2 DC	S3SFN-L8Y2BDM, YELLOW B2 DC, GL
H5550008858	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8Y2BL	YELLOW B2 AC	S3SFN-L8Y2BL, YELLOW B2 AC, GL
H5550008859	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8Y2BLM	YELLOW B2 AC	S3SFN-L8Y2BLM, YELLOW B2 AC, GL

H5550008378	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8YABD	YELLOW A1 B1 DC	S3SFN-L8YABD, YELLOW A1 B1 DC, GL
H5550008379	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8YABDM	YELLOW A1 B1 DC	S3SFN-L8YABDM, YELLOW A1 B1 DC, GL
H5550008890	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8YABL	YELLOW A1 B1 AC	S3SFN-L8YABL, YELLOW A1 B1 AC, GL
H5550008891	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8YABLM	YELLOW A1 B1 AC	S3SFN-L8YABLM, YELLOW A1 B1 AC, GL
H5550007706	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAB		S3SFN-LAB, , GL
H5550008044	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAB2AD	BLUE A2 DC	S3SFN-LAB2AD, BLUE A2 DC, GL
H5550008045	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAB2ADM	BLUE A2 DC	S3SFN-LAB2ADM, BLUE A2 DC, GL
H5550008556	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAB2AL	BLUE A2 AC	S3SFN-LAB2AL, BLUE A2 AC, GL
H5550008557	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAB2ALM	BLUE A2 AC	S3SFN-LAB2ALM, BLUE A2 AC, GL
H5550008092	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAB2BD	BLUE B2 DC	S3SFN-LAB2BD, BLUE B2 DC, GL
H5550008093	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAB2BDM	BLUE B2 DC	S3SFN-LAB2BDM, BLUE B2 DC, GL
H5550008604	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAB2BL	BLUE B2 AC	S3SFN-LAB2BL, BLUE B2 AC, GL
H5550008605	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAB2BLM	BLUE B2 AC	S3SFN-LAB2BLM, BLUE B2 AC, GL
H5550008124	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LABABD	BLUE A1 B1 DC	S3SFN-LABABD, BLUE A1 B1 DC, GL
H5550008125	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LABABDM	BLUE A1 B1 DC	S3SFN-LABABDM, BLUE A1 B1 DC, GL
H5550008636	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LABABL	BLUE A1 B1 AC	S3SFN-LABABL, BLUE A1 B1 AC, GL
H5550008637	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LABABLM	BLUE A1 B1 AC	S3SFN-LABABLM, BLUE A1 B1 AC, GL
H5550007754	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAG		S3SFN-LAG, , GL
H5550008172	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAG2AD	GREEN A2 DC	S3SFN-LAG2AD, GREEN A2 DC, GL

H5550008173	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAG2ADM	GREEN A2 DC	S3SFN-LAG2ADM, GREEN A2 DC, GL
H5550008684	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAG2AL	GREEN A2 AC	S3SFN-LAG2AL, GREEN A2 AC, GL
H5550008685	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAG2ALM	GREEN A2 AC	S3SFN-LAG2ALM, GREEN A2 AC, GL
H5550008220	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAG2BD	GREEN B2 DC	S3SFN-LAG2BD, GREEN B2 DC, GL
H5550008221	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAG2BDM	GREEN B2 DC	S3SFN-LAG2BDM, GREEN B2 DC, GL
H5550008732	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAG2BL	GREEN B2 AC	S3SFN-LAG2BL, GREEN B2 AC, GL
H5550008733	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAG2BLM	GREEN B2 AC	S3SFN-LAG2BLM, GREEN B2 AC, GL
H5550008252	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAGABD	GREEN A1 B1 DC	S3SFN-LAGABD, GREEN A1 B1 DC, GL
H5550008253	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAGABDM	GREEN A1 B1 DC	S3SFN-LAGABDM, GREEN A1 B1 DC, GL
H5550008764	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAGABL	GREEN A1 B1 AC	S3SFN-LAGABL, GREEN A1 B1 AC, GL
H5550008765	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAGABLM	GREEN A1 B1 AC	S3SFN-LAGABLM, GREEN A1 B1 AC, GL
H5550012176	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKB	BLUE (HEAD)	S3SFN-LAKB, BLUE (HEAD), GL
H5550012177	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKB2AD	BLUE A2 LED(DC)	S3SFN-LAKB2AD, BLUE A2 LED(DC), GL
H5550012178	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKB2ADM	BLUE A2 LED(DC)	S3SFN-LAKB2ADM, BLUE A2 LED(DC), GL
H5550012179	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKB2AL	BLUE A2 LED(AC)	S3SFN-LAKB2AL, BLUE A2 LED(AC), GL
H5550012180	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKB2ALM	BLUE A2 LED(AC)	S3SFN-LAKB2ALM, BLUE A2 LED(AC), GL
H5550012181	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKB2BD	BLUE B2 LED(DC)	S3SFN-LAKB2BD, BLUE B2 LED(DC), GL
H5550012182	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKB2BDM	BLUE B2 LED(DC)	S3SFN-LAKB2BDM, BLUE B2 LED(DC), GL
H5550012183	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKB2BL	BLUE B2 LED(AC)	S3SFN-LAKB2BL, BLUE B2 LED(AC), GL

H5550012184	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKB2BLM	BLUE B2 LED(AC)	S3SFN-LAKB2BLM, BLUE B2 LED(AC), GL
H5550012185	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKBABD	BLUE AB LED(DC)	S3SFN-LAKBABD, BLUE AB LED(DC), GL
H5550012186	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKBADM	BLUE AB LED(DC)	S3SFN-LAKBADM, BLUE AB LED(DC), GL
H5550012187	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKBABL	BLUE AB LED(AC)	S3SFN-LAKBABL, BLUE AB LED(AC), GL
H5550012188	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKBBLM	BLUE AB LED(AC)	S3SFN-LAKBBLM, BLUE AB LED(AC), GL
H5550012189	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKG	GREEN (HEAD)	S3SFN-LAKG, GREEN (HEAD), GL
H5550012190	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKG2AD	GREEN A2 LED(DC)	S3SFN-LAKG2AD, GREEN A2 LED(DC), GL
H5550012191	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKG2ADM	GREEN A2 LED(DC)	S3SFN-LAKG2ADM, GREEN A2 LED(DC), GL
H5550012192	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKG2AL	GREEN A2 LED(AC)	S3SFN-LAKG2AL, GREEN A2 LED(AC), GL
H5550012193	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKG2ALM	GREEN A2 LED(AC)	S3SFN-LAKG2ALM, GREEN A2 LED(AC), GL
H5550012194	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKG2BD	GREEN B2 LED(DC)	S3SFN-LAKG2BD, GREEN B2 LED(DC), GL
H5550012195	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKG2BDM	GREEN B2 LED(DC)	S3SFN-LAKG2BDM, GREEN B2 LED(DC), GL
H5550012196	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKG2BL	GREEN B2 LED(AC)	S3SFN-LAKG2BL, GREEN B2 LED(AC), GL
H5550012197	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKG2BLM	GREEN B2 LED(AC)	S3SFN-LAKG2BLM, GREEN B2 LED(AC), GL
H5550012198	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKGABD	GREEN AB LED(DC)	S3SFN-LAKGABD, GREEN AB LED(DC), GL
H5550012199	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKGABDM	GREEN AB LED(DC)	S3SFN-LAKGABDM, GREEN AB LED(DC), GL
H5550012200	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKGABL	GREEN AB LED(AC)	S3SFN-LAKGABL, GREEN AB LED(AC), GL
H5550012201	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKGABLM	GREEN AB LED(AC)	S3SFN-LAKGABLM, GREEN AB LED(AC), GL
H5550012202	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKR	RED (HEAD)	S3SFN-LAKR, RED (HEAD), GL

H5550012215	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKY	YELLOW (HEAD)	S3SFN-LAKY, YELLOW (HEAD), GL
H5550012216	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKY2AD	YELLOW A2 LED(DC)	S3SFN-LAKY2AD, YELLOW A2 LED(DC), GL
H5550012217	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKY2ADM	YELLOW A2 LED(DC)	S3SFN-LAKY2ADM, YELLOW A2 LED(DC), GL
H5550012218	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKY2AL	YELLOW A2 LED(AC)	S3SFN-LAKY2AL, YELLOW A2 LED(AC), GL
H5550012219	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKY2ALM	YELLOW A2 LED(AC)	S3SFN-LAKY2ALM, YELLOW A2 LED(AC), GL
H5550012220	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKY2BD	YELLOW B2 LED(DC)	S3SFN-LAKY2BD, YELLOW B2 LED(DC), GL
H5550012221	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKY2BDM	YELLOW B2 LED(DC)	S3SFN-LAKY2BDM, YELLOW B2 LED(DC), GL
H5550012222	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKY2BL	YELLOW B2 LED(AC)	S3SFN-LAKY2BL, YELLOW B2 LED(AC), GL
H5550012223	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKY2BLM	YELLOW B2 LED(AC)	S3SFN-LAKY2BLM, YELLOW B2 LED(AC), GL
H5550012224	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKYABD	YELLOW AB LED(DC)	S3SFN-LAKYABD, YELLOW AB LED(DC), GL
H5550012225	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKYABDM	YELLOW AB LED(DC)	S3SFN-LAKYABDM, YELLOW AB LED(DC), GL
H5550012226	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKYABL	YELLOW AB LED(AC)	S3SFN-LAKYABL, YELLOW AB LED(AC), GL
H5550012227	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKYABLM	YELLOW AB LED(AC)	S3SFN-LAKYABLM, YELLOW AB LED(AC), GL
H5550007802	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAY		S3SFN-LAY, , GL
H5550008300	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAY2AD	YELLOW A2 DC	S3SFN-LAY2AD, YELLOW A2 DC, GL
H5550008301	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAY2ADM	YELLOW A2 DC	S3SFN-LAY2ADM, YELLOW A2 DC, GL
H5550008812	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAY2AL	YELLOW A2 AC	S3SFN-LAY2AL, YELLOW A2 AC, GL
H5550008813	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAY2ALM	YELLOW A2 AC	S3SFN-LAY2ALM, YELLOW A2 AC, GL
H5550008348	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAY2BD	YELLOW B2 DC	S3SFN-LAY2BD, YELLOW B2 DC, GL

H5550008349	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAY2BDM	YELLOW B2 DC	S3SFN-LAY2BDM, YELLOW B2 DC, GL
H5550008860	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAY2BL	YELLOW B2 AC	S3SFN-LAY2BL, YELLOW B2 AC, GL
H5550008861	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAY2BLM	YELLOW B2 AC	S3SFN-LAY2BLM, YELLOW B2 AC, GL
H5550008380	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAYABD	YELLOW A1 B1 DC	S3SFN-LAYABD, YELLOW A1 B1 DC, GL
H5550008381	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAYABDM	YELLOW A1 B1 DC	S3SFN-LAYABDM, YELLOW A1 B1 DC, GL
H5550008892	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAYABL	YELLOW A1 B1 AC	S3SFN-LAYABL, YELLOW A1 B1 AC, GL
H5550008893	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAYABLM	YELLOW A1 B1 AC	S3SFN-LAYABLM, YELLOW A1 B1 AC, GL
H5550007709	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBB		S3SFN-LBB, , GL
H5550008046	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBB2AD	BLUE A2 DC	S3SFN-LBB2AD, BLUE A2 DC, GL
H5550008047	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBB2ADM	BLUE A2 DC	S3SFN-LBB2ADM, BLUE A2 DC, GL
H5550008558	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBB2AL	BLUE A2 AC	S3SFN-LBB2AL, BLUE A2 AC, GL
H5550008559	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBB2ALM	BLUE A2 AC	S3SFN-LBB2ALM, BLUE A2 AC, GL
H5550008094	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBB2BD	BLUE B2 DC	S3SFN-LBB2BD, BLUE B2 DC, GL
H5550008095	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBB2BDM	BLUE B2 DC	S3SFN-LBB2BDM, BLUE B2 DC, GL
H5550008606	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBB2BL	BLUE B2 AC	S3SFN-LBB2BL, BLUE B2 AC, GL
H5550008607	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBB2BLM	BLUE B2 AC	S3SFN-LBB2BLM, BLUE B2 AC, GL
H5550008126	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBBABD	BLUE A1 B1 DC	S3SFN-LBBABD, BLUE A1 B1 DC, GL
H5550008127	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBBABDM	BLUE A1 B1 DC	S3SFN-LBBABDM, BLUE A1 B1 DC, GL

H5550008638	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBBABL	BLUE A1 B1 AC	S3SFN-LBBABL, BLUE A1 B1 AC, GL
H5550008639	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBBABLM	BLUE A1 B1 AC	S3SFN-LBBABLM, BLUE A1 B1 AC, GL
H5550007757	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBG		S3SFN-LBG, , GL
H5550008174	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBG2AD	GREEN A2 DC	S3SFN-LBG2AD, GREEN A2 DC, GL
H5550008175	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBG2ADM	GREEN A2 DC	S3SFN-LBG2ADM, GREEN A2 DC, GL
H5550008686	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBG2AL	GREEN A2 AC	S3SFN-LBG2AL, GREEN A2 AC, GL
H5550008687	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBG2ALM	GREEN A2 AC	S3SFN-LBG2ALM, GREEN A2 AC, GL
H5550008222	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBG2BD	GREEN B2 DC	S3SFN-LBG2BD, GREEN B2 DC, GL
H5550008223	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBG2BDM	GREEN B2 DC	S3SFN-LBG2BDM, GREEN B2 DC, GL
H5550008734	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBG2BL	GREEN B2 AC	S3SFN-LBG2BL, GREEN B2 AC, GL
H5550008735	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBG2BLM	GREEN B2 AC	S3SFN-LBG2BLM, GREEN B2 AC, GL
H5550008254	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBGABD	GREEN A1 B1 DC	S3SFN-LBGABD, GREEN A1 B1 DC, GL
H5550008255	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBGABDM	GREEN A1 B1 DC	S3SFN-LBGABDM, GREEN A1 B1 DC, GL
H5550008766	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBGABL	GREEN A1 B1 AC	S3SFN-LBGABL, GREEN A1 B1 AC, GL
H5550008767	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBGABLM	GREEN A1 B1 AC	S3SFN-LBGABLM, GREEN A1 B1 AC, GL
H5550012228	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKB	BLUE (HEAD)	S3SFN-LBKB, BLUE (HEAD), GL
H5550012229	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKB2AD	BLUE A2 LED(DC)	S3SFN-LBKB2AD, BLUE A2 LED(DC), GL
H5550012230	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKB2ADM	BLUE A2 LED(DC)	S3SFN-LBKB2ADM, BLUE A2 LED(DC), GL

H5550012231	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKB2AL	BLUE A2 LED(AC)	S3SFN-LBKB2AL, BLUE A2 LED(AC), GL
H5550012232	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKB2ALM	BLUE A2 LED(AC)	S3SFN-LBKB2ALM, BLUE A2 LED(AC), GL
H5550012233	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKB2BD	BLUE B2 LED(DC)	S3SFN-LBKB2BD, BLUE B2 LED(DC), GL
H5550012234	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKB2BDM	BLUE B2 LED(DC)	S3SFN-LBKB2BDM, BLUE B2 LED(DC), GL
H5550012235	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKB2BL	BLUE B2 LED(AC)	S3SFN-LBKB2BL, BLUE B2 LED(AC), GL
H5550012236	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKB2BLM	BLUE B2 LED(AC)	S3SFN-LBKB2BLM, BLUE B2 LED(AC), GL
H5550012237	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKBABD	BLUE AB LED(DC)	S3SFN-LBKBABD, BLUE AB LED(DC), GL
H5550012238	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKBABDM	BLUE AB LED(DC)	S3SFN-LBKBABDM, BLUE AB LED(DC), GL
H5550012239	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKBABL	BLUE AB LED(AC)	S3SFN-LBKBABL, BLUE AB LED(AC), GL
H5550012240	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKBABLM	BLUE AB LED(AC)	S3SFN-LBKBABLM, BLUE AB LED(AC), GL
H5550012241	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKG	GREEN (HEAD)	S3SFN-LBKG, GREEN (HEAD), GL
H5550012242	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKG2AD	GREEN A2 LED(DC)	S3SFN-LBKG2AD, GREEN A2 LED(DC), GL
H5550012243	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKG2ADM	GREEN A2 LED(DC)	S3SFN-LBKG2ADM, GREEN A2 LED(DC), GL
H5550012244	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKG2AL	GREEN A2 LED(AC)	S3SFN-LBKG2AL, GREEN A2 LED(AC), GL
H5550012245	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKG2ALM	GREEN A2 LED(AC)	S3SFN-LBKG2ALM, GREEN A2 LED(AC), GL

H5550012246	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKG2BD	GREEN B2 LED(DC)	S3SFN-LBKG2BD, GREEN B2 LED(DC), GL
H5550012247	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKG2BDM	GREEN B2 LED(DC)	S3SFN-LBKG2BDM, GREEN B2 LED(DC), GL
H5550012248	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKG2BL	GREEN B2 LED(AC)	S3SFN-LBKG2BL, GREEN B2 LED(AC), GL
H5550012249	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKG2BLM	GREEN B2 LED(AC)	S3SFN-LBKG2BLM, GREEN B2 LED(AC), GL
H5550012250	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKGABD	GREEN AB LED(DC)	S3SFN-LBKGABD, GREEN AB LED(DC), GL
H5550012251	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKGABDM	GREEN AB LED(DC)	S3SFN-LBKGABDM, GREEN AB LED(DC), GL
H5550012252	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKGABL	GREEN AB LED(AC)	S3SFN-LBKGABL, GREEN AB LED(AC), GL
H5550012253	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKGABLM	GREEN AB LED(AC)	S3SFN-LBKGABLM, GREEN AB LED(AC), GL
H5550012254	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKR	RED (HEAD)	S3SFN-LBKR, RED (HEAD), GL
H5550012267	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKY	YELLOW (HEAD)	S3SFN-LBKY, YELLOW (HEAD), GL
H5550012268	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKY2AD	YELLOW A2 LED(DC)	S3SFN-LBKY2AD, YELLOW A2 LED(DC), GL
H5550012269	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKY2ADM	YELLOW A2 LED(DC)	S3SFN-LBKY2ADM, YELLOW A2 LED(DC), GL
H5550012270	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKY2AL	YELLOW A2 LED(AC)	S3SFN-LBKY2AL, YELLOW A2 LED(AC), GL
H5550012271	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKY2ALM	YELLOW A2 LED(AC)	S3SFN-LBKY2ALM, YELLOW A2 LED(AC), GL

H5550012272	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKY2BD	YELLOW B2 LED(DC)	S3SFN-LBKY2BD, YELLOW B2 LED(DC), GL	
H5550012273	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKY2BDM	YELLOW B2 LED(DC)	S3SFN-LBKY2BDM, YELLOW B2 LED(DC), GL	
H5550012274	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKY2BL	YELLOW B2 LED(AC)	S3SFN-LBKY2BL, YELLOW B2 LED(AC), GL	
H5550012275	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKY2BLM	YELLOW B2 LED(AC)	S3SFN-LBKY2BLM, YELLOW B2 LED(AC), GL	
H5550012276	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKYABD	YELLOW AB LED(DC)	S3SFN-LBKYABD, YELLOW AB LED(DC), GL	
H5550012277	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKYABDM	YELLOW AB LED(DC)	S3SFN-LBKYABDM, YELLOW AB LED(DC), GL	
H5550012278	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKYABL	YELLOW AB LED(AC)	S3SFN-LBKYABL, YELLOW AB LED(AC), GL	
H5550012279	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKYABLM	YELLOW AB LED(AC)	S3SFN-LBKYABLM, YELLOW AB LED(AC), GL	
H5550007661	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBR		S3SFN-LBR, , GL	
H5550007805	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBY		S3SFN-LBY, , GL	
H5550008302	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBY2AD	YELLOW A2 DC	S3SFN-LBY2AD, YELLOW A2 DC, GL	
H5550008303	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBY2ADM	YELLOW A2 DC	S3SFN-LBY2ADM, YELLOW A2 DC, GL	
H5550008814	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBY2AL	YELLOW A2 AC	S3SFN-LBY2AL, YELLOW A2 AC, GL	
H5550008815	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBY2ALM	YELLOW A2 AC	S3SFN-LBY2ALM, YELLOW A2 AC, GL	
H5550008350	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBY2BD	YELLOW B2 DC	S3SFN-LBY2BD, YELLOW B2 DC, GL	

H5550008351	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBY2BDM	YELLOW B2 DC	S3SFN-LBY2BDM, YELLOW B2 DC, GL
H5550008862	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBY2BL	YELLOW B2 AC	S3SFN-LBY2BL, YELLOW B2 AC, GL
H5550008863	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBY2BLM	YELLOW B2 AC	S3SFN-LBY2BLM, YELLOW B2 AC, GL
H5550008382	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBYABD	YELLOW A1 B1 DC	S3SFN-LBYABD, YELLOW A1 B1 DC, GL
H5550008383	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBYABDM	YELLOW A1 B1 DC	S3SFN-LBYABDM, YELLOW A1 B1 DC, GL
H5550008894	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBYABL	YELLOW A1 B1 AC	S3SFN-LBYABL, YELLOW A1 B1 AC, GL
H5550008895	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBYABLM	YELLOW A1 B1 AC	S3SFN-LBYABLM, YELLOW A1 B1 AC, GL
H5550007712	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCB		S3SFN-LCB, , GL
H5550008048	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCB2AD	BLUE A2 DC	S3SFN-LCB2AD, BLUE A2 DC, GL
H5550008049	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCB2ADM	BLUE A2 DC	S3SFN-LCB2ADM, BLUE A2 DC, GL
H5550008560	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCB2AL	BLUE A2 AC	S3SFN-LCB2AL, BLUE A2 AC, GL
H5550008561	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCB2ALM	BLUE A2 AC	S3SFN-LCB2ALM, BLUE A2 AC, GL
H5550008096	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCB2BD	BLUE B2 DC	S3SFN-LCB2BD, BLUE B2 DC, GL
H5550008097	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCB2BDM	BLUE B2 DC	S3SFN-LCB2BDM, BLUE B2 DC, GL

H5550008608	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCB2BL	BLUE B2 AC	S3SFN-LCB2BL, BLUE B2 AC, GL
H5550008609	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCB2BLM	BLUE B2 AC	S3SFN-LCB2BLM, BLUE B2 AC, GL
H5550008128	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCBABD	BLUE A1 B1 DC	S3SFN-LCBABD, BLUE A1 B1 DC, GL
H5550008129	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCBABDM	BLUE A1 B1 DC	S3SFN-LCBABDM, BLUE A1 B1 DC, GL
H5550008640	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCBABL	BLUE A1 B1 AC	S3SFN-LCBABL, BLUE A1 B1 AC, GL
H5550008641	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCBABLM	BLUE A1 B1 AC	S3SFN-LCBABLM, BLUE A1 B1 AC, GL
H5550008176	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCG2AD	GREEN A2 DC	S3SFN-LCG2AD, GREEN A2 DC, GL
H5550008177	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCG2ADM	GREEN A2 DC	S3SFN-LCG2ADM, GREEN A2 DC, GL
H5550008688	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCG2AL	GREEN A2 AC	S3SFN-LCG2AL, GREEN A2 AC, GL
H5550008689	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCG2ALM	GREEN A2 AC	S3SFN-LCG2ALM, GREEN A2 AC, GL
H5550008224	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCG2BD	GREEN B2 DC	S3SFN-LCG2BD, GREEN B2 DC, GL
H5550008225	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCG2BDM	GREEN B2 DC	S3SFN-LCG2BDM, GREEN B2 DC, GL
H5550008736	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCG2BL	GREEN B2 AC	S3SFN-LCG2BL, GREEN B2 AC, GL
H5550008737	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCG2BLM	GREEN B2 AC	S3SFN-LCG2BLM, GREEN B2 AC, GL

H5550008256	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCGABD	GREEN A1 B1 DC	S3SFN-LCGABD, GREEN A1 B1 DC, GL
H5550008257	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCGABDM	GREEN A1 B1 DC	S3SFN-LCGABDM, GREEN A1 B1 DC, GL
H5550008768	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCGABL	GREEN A1 B1 AC	S3SFN-LCGABL, GREEN A1 B1 AC, GL
H5550008769	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCGABLM	GREEN A1 B1 AC	S3SFN-LCGABLM, GREEN A1 B1 AC, GL
H5550012280	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKB	BLUE (HEAD)	S3SFN-LCKB, BLUE (HEAD), GL
H5550012281	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKB2AD	BLUE A2 LED(DC)	S3SFN-LCKB2AD, BLUE A2 LED(DC), GL
H5550012282	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKB2ADM	BLUE A2 LED(DC)	S3SFN-LCKB2ADM, BLUE A2 LED(DC), GL
H5550012283	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKB2AL	BLUE A2 LED(AC)	S3SFN-LCKB2AL, BLUE A2 LED(AC), GL
H5550012284	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKB2ALM	BLUE A2 LED(AC)	S3SFN-LCKB2ALM, BLUE A2 LED(AC), GL
H5550012285	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKB2BD	BLUE B2 LED(DC)	S3SFN-LCKB2BD, BLUE B2 LED(DC), GL
H5550012286	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKB2BDM	BLUE B2 LED(DC)	S3SFN-LCKB2BDM, BLUE B2 LED(DC), GL
H5550012287	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKB2BL	BLUE B2 LED(AC)	S3SFN-LCKB2BL, BLUE B2 LED(AC), GL
H5550012288	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKB2BLM	BLUE B2 LED(AC)	S3SFN-LCKB2BLM, BLUE B2 LED(AC), GL
H5550012289	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKBABD	BLUE AB LED(DC)	S3SFN-LCKBABD, BLUE AB LED(DC), GL
H5550012290	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKBABDM	BLUE AB LED(DC)	S3SFN-LCKBABDM, BLUE AB LED(DC), GL
H5550012291	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKBABL	BLUE AB LED(AC)	S3SFN-LCKBABL, BLUE AB LED(AC), GL
H5550012292	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKBABL M	BLUE AB LED(AC)	S3SFN-LCKBABL M, BLUE AB LED(AC), GL

H5550012293	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKG	GREEN (HEAD)	S3SFN-LCKG, GREEN (HEAD), GL
H5550012294	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKG2AD	GREEN A2 LED(DC)	S3SFN-LCKG2AD, GREEN A2 LED(DC), GL
H5550012295	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKG2ADM	GREEN A2 LED(DC)	S3SFN-LCKG2ADM, GREEN A2 LED(DC), GL
H5550012296	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKG2AL	GREEN A2 LED(AC)	S3SFN-LCKG2AL, GREEN A2 LED(AC), GL
H5550012297	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKG2ALM	GREEN A2 LED(AC)	S3SFN-LCKG2ALM, GREEN A2 LED(AC), GL
H5550012298	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKG2BD	GREEN B2 LED(DC)	S3SFN-LCKG2BD, GREEN B2 LED(DC), GL
H5550012299	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKG2BDM	GREEN B2 LED(DC)	S3SFN-LCKG2BDM, GREEN B2 LED(DC), GL
H5550012300	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKG2BL	GREEN B2 LED(AC)	S3SFN-LCKG2BL, GREEN B2 LED(AC), GL
H5550012301	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKG2BLM	GREEN B2 LED(AC)	S3SFN-LCKG2BLM, GREEN B2 LED(AC), GL
H5550012302	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKGABD	GREEN AB LED(DC)	S3SFN-LCKGABD, GREEN AB LED(DC), GL
H5550012303	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKGABDM	GREEN AB LED(DC)	S3SFN-LCKGABDM, GREEN AB LED(DC), GL
H5550012304	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKGABL	GREEN AB LED(AC)	S3SFN-LCKGABL, GREEN AB LED(AC), GL
H5550012305	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKGABLM	GREEN AB LED(AC)	S3SFN-LCKGABLM, GREEN AB LED(AC), GL
H5550012306	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKR	RED (HEAD)	S3SFN-LCKR, RED (HEAD), GL
H5550012319	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKY	YELLOW (HEAD)	S3SFN-LCKY, YELLOW (HEAD), GL

H5550012320	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKY2AD	YELLOW A2 LED(DC)	S3SFN-LCKY2AD, YELLOW A2 LED(DC), GL
H5550012321	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKY2ADM	YELLOW A2 LED(DC)	S3SFN-LCKY2ADM, YELLOW A2 LED(DC), GL
H5550012322	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKY2AL	YELLOW A2 LED(AC)	S3SFN-LCKY2AL, YELLOW A2 LED(AC), GL
H5550012323	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKY2ALM	YELLOW A2 LED(AC)	S3SFN-LCKY2ALM, YELLOW A2 LED(AC), GL
H5550012324	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKY2BD	YELLOW B2 LED(DC)	S3SFN-LCKY2BD, YELLOW B2 LED(DC), GL
H5550012325	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKY2BDM	YELLOW B2 LED(DC)	S3SFN-LCKY2BDM, YELLOW B2 LED(DC), GL
H5550012326	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKY2BL	YELLOW B2 LED(AC)	S3SFN-LCKY2BL, YELLOW B2 LED(AC), GL
H5550012327	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKY2BLM	YELLOW B2 LED(AC)	S3SFN-LCKY2BLM, YELLOW B2 LED(AC), GL
H5550012328	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKYABD	YELLOW AB LED(DC)	S3SFN-LCKYABD, YELLOW AB LED(DC), GL
H5550012329	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKYABDM	YELLOW AB LED(DC)	S3SFN-LCKYABDM, YELLOW AB LED(DC), GL
H5550012330	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKYABL	YELLOW AB LED(AC)	S3SFN-LCKYABL, YELLOW AB LED(AC), GL
H5550012331	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKYABLM	YELLOW AB LED(AC)	S3SFN-LCKYABLM, YELLOW AB LED(AC), GL
H5550007808	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCY		S3SFN-LCY, , GL
H5550008304	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCY2AD	YELLOW A2 DC	S3SFN-LCY2AD, YELLOW A2 DC, GL
H5550008305	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCY2ADM	YELLOW A2 DC	S3SFN-LCY2ADM, YELLOW A2 DC, GL
H5550008816	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCY2AL	YELLOW A2 AC	S3SFN-LCY2AL, YELLOW A2 AC, GL

H5550008817	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCY2ALM	YELLOW A2 AC	S3SFN-LCY2ALM, YELLOW A2 AC, GL	
H5550008352	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCY2BD	YELLOW B2 DC	S3SFN-LCY2BD, YELLOW B2 DC, GL	
H5550008353	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCY2BDM	YELLOW B2 DC	S3SFN-LCY2BDM, YELLOW B2 DC, GL	
H5550008864	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCY2BL	YELLOW B2 AC	S3SFN-LCY2BL, YELLOW B2 AC, GL	
H5550008865	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCY2BLM	YELLOW B2 AC	S3SFN-LCY2BLM, YELLOW B2 AC, GL	
H5550008384	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCYABD	YELLOW A1 B1 DC	S3SFN-LCYABD, YELLOW A1 B1 DC, GL	
H5550008385	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCYABDM	YELLOW A1 B1 DC	S3SFN-LCYABDM, YELLOW A1 B1 DC, GL	
H5550008896	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCYABL	YELLOW A1 B1 AC	S3SFN-LCYABL, YELLOW A1 B1 AC, GL	
H5550008897	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCYABLM	YELLOW A1 B1 AC	S3SFN-LCYABLM, YELLOW A1 B1 AC, GL	
H5550007715	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDB		S3SFN-LDB, , GL	
H5550008050	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDB2AD	BLUE A2 DC	S3SFN-LDB2AD, BLUE A2 DC, GL	
H5550008051	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDB2ADM	BLUE A2 DC	S3SFN-LDB2ADM, BLUE A2 DC, GL	
H5550008562	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDB2AL	BLUE A2 AC	S3SFN-LDB2AL, BLUE A2 AC, GL	
H5550008563	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDB2ALM	BLUE A2 AC	S3SFN-LDB2ALM, BLUE A2 AC, GL	
H5550008098	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDB2BD	BLUE B2 DC	S3SFN-LDB2BD, BLUE B2 DC, GL	
H5550008099	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDB2BDM	BLUE B2 DC	S3SFN-LDB2BDM, BLUE B2 DC, GL	
H5550008610	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDB2BL	BLUE B2 AC	S3SFN-LDB2BL, BLUE B2 AC, GL	

H5550008611	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDB2BLM	BLUE B2 AC	S3SFN-LDB2BLM, BLUE B2 AC, GL
H5550008130	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDBABD	BLUE A1 B1 DC	S3SFN-LDBABD, BLUE A1 B1 DC, GL
H5550008131	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDBABDM	BLUE A1 B1 DC	S3SFN-LDBABDM, BLUE A1 B1 DC, GL
H5550008642	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDBABL	BLUE A1 B1 AC	S3SFN-LDBABL, BLUE A1 B1 AC, GL
H5550008643	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDBABLM	BLUE A1 B1 AC	S3SFN-LDBABLM, BLUE A1 B1 AC, GL
H5550007763	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDG		S3SFN-LDG, , GL
H5550008178	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDG2AD	GREEN A2 DC	S3SFN-LDG2AD, GREEN A2 DC, GL
H5550008179	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDG2ADM	GREEN A2 DC	S3SFN-LDG2ADM, GREEN A2 DC, GL
H5550008690	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDG2AL	GREEN A2 AC	S3SFN-LDG2AL, GREEN A2 AC, GL
H5550008691	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDG2ALM	GREEN A2 AC	S3SFN-LDG2ALM, GREEN A2 AC, GL
H5550008226	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDG2BD	GREEN B2 DC	S3SFN-LDG2BD, GREEN B2 DC, GL
H5550008227	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDG2BDM	GREEN B2 DC	S3SFN-LDG2BDM, GREEN B2 DC, GL
H5550008738	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDG2BL	GREEN B2 AC	S3SFN-LDG2BL, GREEN B2 AC, GL
H5550008739	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDG2BLM	GREEN B2 AC	S3SFN-LDG2BLM, GREEN B2 AC, GL
H5550008258	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDGABD	GREEN A1 B1 DC	S3SFN-LDGABD, GREEN A1 B1 DC, GL
H5550008259	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDGABDM	GREEN A1 B1 DC	S3SFN-LDGABDM, GREEN A1 B1 DC, GL
H5550008770	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDGABL	GREEN A1 B1 AC	S3SFN-LDGABL, GREEN A1 B1 AC, GL
H5550008771	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDGABLM	GREEN A1 B1 AC	S3SFN-LDGABLM, GREEN A1 B1 AC, GL

H5550012332	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKB	BLUE (HEAD)	S3SFN-LDKB, BLUE (HEAD), GL
H5550012333	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKB2AD	BLUE A2 LED(DC)	S3SFN-LDKB2AD, BLUE A2 LED(DC), GL
H5550012334	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKB2ADM	BLUE A2 LED(DC)	S3SFN-LDKB2ADM, BLUE A2 LED(DC), GL
H5550012335	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKB2AL	BLUE A2 LED(AC)	S3SFN-LDKB2AL, BLUE A2 LED(AC), GL
H5550012336	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKB2ALM	BLUE A2 LED(AC)	S3SFN-LDKB2ALM, BLUE A2 LED(AC), GL
H5550012337	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKB2BD	BLUE B2 LED(DC)	S3SFN-LDKB2BD, BLUE B2 LED(DC), GL
H5550012338	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKB2BDM	BLUE B2 LED(DC)	S3SFN-LDKB2BDM, BLUE B2 LED(DC), GL
H5550012339	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKB2BL	BLUE B2 LED(AC)	S3SFN-LDKB2BL, BLUE B2 LED(AC), GL
H5550012340	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKB2BLM	BLUE B2 LED(AC)	S3SFN-LDKB2BLM, BLUE B2 LED(AC), GL
H5550012341	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKBABD	BLUE AB LED(DC)	S3SFN-LDKBABD, BLUE AB LED(DC), GL
H5550012342	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKBABDM	BLUE AB LED(DC)	S3SFN-LDKBABDM, BLUE AB LED(DC), GL
H5550012343	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKBABL	BLUE AB LED(AC)	S3SFN-LDKBABL, BLUE AB LED(AC), GL
H5550012344	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKBABL M	BLUE AB LED(AC)	S3SFN-LDKBABL M, BLUE AB LED(AC), GL
H5550012345	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKG	GREEN (HEAD)	S3SFN-LDKG, GREEN (HEAD), GL
H5550012346	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKG2AD	GREEN A2 LED(DC)	S3SFN-LDKG2AD, GREEN A2 LED(DC), GL
H5550012347	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKG2ADM	GREEN A2 LED(DC)	S3SFN-LDKG2ADM, GREEN A2 LED(DC), GL

H5550012348	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKG2AL	GREEN A2 LED(AC)	S3SFN-LDKG2AL, GREEN A2 LED(AC), GL
H5550012349	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKG2ALM	GREEN A2 LED(AC)	S3SFN-LDKG2ALM, GREEN A2 LED(AC), GL
H5550012350	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKG2BD	GREEN B2 LED(DC)	S3SFN-LDKG2BD, GREEN B2 LED(DC), GL
H5550012351	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKG2BDM	GREEN B2 LED(DC)	S3SFN-LDKG2BDM, GREEN B2 LED(DC), GL
H5550012352	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKG2BL	GREEN B2 LED(AC)	S3SFN-LDKG2BL, GREEN B2 LED(AC), GL
H5550012353	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKG2BLM	GREEN B2 LED(AC)	S3SFN-LDKG2BLM, GREEN B2 LED(AC), GL
H5550012354	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKGABD	GREEN AB LED(DC)	S3SFN-LDKGABD, GREEN AB LED(DC), GL
H5550012355	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKGABDM	GREEN AB LED(DC)	S3SFN-LDKGABDM, GREEN AB LED(DC), GL
H5550012356	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKGABL	GREEN AB LED(AC)	S3SFN-LDKGABL, GREEN AB LED(AC), GL
H5550012357	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKGABLM	GREEN AB LED(AC)	S3SFN-LDKGABLM, GREEN AB LED(AC), GL
H5550012358	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKR	RED (HEAD)	S3SFN-LDKR, RED (HEAD), GL
H5550012371	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKY	YELLOW (HEAD)	S3SFN-LDKY, YELLOW (HEAD), GL
H5550012372	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKY2AD	YELLOW A2 LED(DC)	S3SFN-LDKY2AD, YELLOW A2 LED(DC), GL
H5550012373	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKY2ADM	YELLOW A2 LED(DC)	S3SFN-LDKY2ADM, YELLOW A2 LED(DC), GL
H5550012374	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKY2AL	YELLOW A2 LED(AC)	S3SFN-LDKY2AL, YELLOW A2 LED(AC), GL
H5550012375	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKY2ALM	YELLOW A2 LED(AC)	S3SFN-LDKY2ALM, YELLOW A2 LED(AC), GL

H5550012376	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKY2BD	YELLOW B2 LED(DC)	S3SFN-LDKY2BD, YELLOW B2 LED(DC), GL
H5550012377	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKY2BDM	YELLOW B2 LED(DC)	S3SFN-LDKY2BDM, YELLOW B2 LED(DC), GL
H5550012378	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKY2BL	YELLOW B2 LED(AC)	S3SFN-LDKY2BL, YELLOW B2 LED(AC), GL
H5550012379	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKY2BLM	YELLOW B2 LED(AC)	S3SFN-LDKY2BLM, YELLOW B2 LED(AC), GL
H5550012380	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKYABD	YELLOW AB LED(DC)	S3SFN-LDKYABD, YELLOW AB LED(DC), GL
H5550012381	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKYABDM	YELLOW AB LED(DC)	S3SFN-LDKYABDM, YELLOW AB LED(DC), GL
H5550012382	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKYABL	YELLOW AB LED(AC)	S3SFN-LDKYABL, YELLOW AB LED(AC), GL
H5550012383	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKYABLM	YELLOW AB LED(AC)	S3SFN-LDKYABLM, YELLOW AB LED(AC), GL
H5550007811	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDY		S3SFN-LDY, , GL
H5550008306	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDY2AD	YELLOW A2 DC	S3SFN-LDY2AD, YELLOW A2 DC, GL
H5550008307	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDY2ADM	YELLOW A2 DC	S3SFN-LDY2ADM, YELLOW A2 DC, GL
H5550008818	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDY2AL	YELLOW A2 AC	S3SFN-LDY2AL, YELLOW A2 AC, GL

H5550008819	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDY2ALM	YELLOW A2 AC	S3SFN-LDY2ALM, YELLOW A2 AC, GL	
H5550008354	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDY2BD	YELLOW B2 DC	S3SFN-LDY2BD, YELLOW B2 DC, GL	
H5550008355	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDY2BDM	YELLOW B2 DC	S3SFN-LDY2BDM, YELLOW B2 DC, GL	
H5550008866	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDY2BL	YELLOW B2 AC	S3SFN-LDY2BL, YELLOW B2 AC, GL	
H5550008867	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDY2BLM	YELLOW B2 AC	S3SFN-LDY2BLM, YELLOW B2 AC, GL	
H5550008386	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDYABD	YELLOW A1 B1 DC	S3SFN-LDYABD, YELLOW A1 B1 DC, GL	
H5550008387	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDYABDM	YELLOW A1 B1 DC	S3SFN-LDYABDM, YELLOW A1 B1 DC, GL	
H5550008898	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDYABL	YELLOW A1 B1 AC	S3SFN-LDYABL, YELLOW A1 B1 AC, GL	
H5550008899	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDYABLM	YELLOW A1 B1 AC	S3SFN-LDYABLM, YELLOW A1 B1 AC, GL	
H5550007574	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AW		S3SFN-S1AW, , GL	
H5550007740	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AW2A	WHITE A2	S3SFN-S1AW2A, WHITE A2, GL	
H5550007741	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AW2AM	WHITE A2	S3SFN-S1AW2AM, WHITE A2, GL	
H5550007812	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AW2B	WHITE B2	S3SFN-S1AW2B, WHITE B2, GL	
H5550007813	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AW2BM	WHITE B2	S3SFN-S1AW2BM, WHITE B2, GL	
H5550007716	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AWA	WHITE A1	S3SFN-S1AWA, WHITE A1, GL	
H5550007844	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AWAB	WHITE A1 B1	S3SFN-S1AWAB, WHITE A1 B1, GL	
H5550007845	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AWABM	WHITE A1 B1	S3SFN-S1AWABM, WHITE A1 B1, GL	

H5550007717	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AWAM	WHITE A1	S3SFN-S1AWAM, WHITE A1, GL	
H5550007788	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AWB	WHITE B1	S3SFN-S1AWB, WHITE B1, GL	
H5550007789	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AWBM	WHITE B1	S3SFN-S1AWBM, WHITE B1, GL	
H5550007577	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BW		S3SFN-S1BW, , GL	
H5550007743	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BW2A	WHITE A2	S3SFN-S1BW2A, WHITE A2, GL	
H5550007744	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BW2AM	WHITE A2	S3SFN-S1BW2AM, WHITE A2, GL	
H5550007814	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BW2B	WHITE B2	S3SFN-S1BW2B, WHITE B2, GL	
H5550007815	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BW2BM	WHITE B2	S3SFN-S1BW2BM, WHITE B2, GL	
H5550007719	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BWA	WHITE A1	S3SFN-S1BWA, WHITE A1, GL	
H5550007846	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1WAB	WHITE A1 B1	S3SFN-S1WAB, WHITE A1 B1, GL	
H5550007847	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1WABM	WHITE A1 B1	S3SFN-S1WABM, WHITE A1 B1, GL	
H5550007720	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BWAM	WHITE A1	S3SFN-S1BWAM, WHITE A1, GL	
H5550007791	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BWB	WHITE B1	S3SFN-S1BWB, WHITE B1, GL	
H5550007792	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1WBWM	WHITE B1	S3SFN-S1WBWM, WHITE B1, GL	
H5550012384	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1R	RED (HEAD)	S3SFN-S1R, RED (HEAD), GL	
H5550012395	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1W	WHITE (HEAD)	S3SFN-S1W, WHITE (HEAD), GL	
H5550012396	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1W2A	WHITE A2	S3SFN-S1W2A, WHITE A2, GL	
H5550012397	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1W2AM	WHITE A2	S3SFN-S1W2AM, WHITE A2, GL	
H5550012398	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1W2B	WHITE B2	S3SFN-S1W2B, WHITE B2, GL	
H5550012399	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1W2BM	WHITE B2	S3SFN-S1W2BM, WHITE B2, GL	
H5550012400	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1WA	WHITE A	S3SFN-S1WA, WHITE A, GL	
H5550012401	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1WAB	WHITE AB	S3SFN-S1WAB, WHITE AB, GL	
H5550012402	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1WABM	WHITE AB	S3SFN-S1WABM, WHITE AB, GL	
H5550012403	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1WAM	WHITE A	S3SFN-S1WAM, WHITE A, GL	
H5550012404	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1WB	WHITE B	S3SFN-S1WB, WHITE B, GL	
H5550012405	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1WBWM	WHITE B	S3SFN-S1WBWM, WHITE B, GL	
H5550007580	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AW		S3SFN-S2AW, , GL	

H5550007746	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AW2A	WHITE A2	S3SFN-S2AW2A, WHITE A2, GL
H5550007747	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AW2AM	WHITE A2	S3SFN-S2AW2AM, WHITE A2, GL
H5550007816	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AW2B	WHITE B2	S3SFN-S2AW2B, WHITE B2, GL
H5550007817	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AW2BM	WHITE B2	S3SFN-S2AW2BM, WHITE B2, GL
H5550007722	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AWA	WHITE A1	S3SFN-S2AWA, WHITE A1, GL
H5550007848	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AWAB	WHITE A1 B1	S3SFN-S2AWAB, WHITE A1 B1, GL
H5550007849	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AWABM	WHITE A1 B1	S3SFN-S2AWABM, WHITE A1 B1, GL
H5550007723	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AWAM	WHITE A1	S3SFN-S2AWAM, WHITE A1, GL
H5550007794	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AWB	WHITE B1	S3SFN-S2AWB, WHITE B1, GL
H5550007795	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AWBM	WHITE B1	S3SFN-S2AWBM, WHITE B1, GL
H5550007583	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BW		S3SFN-S2BW, , GL
H5550007749	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BW2A	WHITE A2	S3SFN-S2BW2A, WHITE A2, GL
H5550007750	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BW2AM	WHITE A2	S3SFN-S2BW2AM, WHITE A2, GL
H5550007818	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BW2B	WHITE B2	S3SFN-S2BW2B, WHITE B2, GL
H5550007819	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BW2BM	WHITE B2	S3SFN-S2BW2BM, WHITE B2, GL
H5550007725	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BWA	WHITE A1	S3SFN-S2BWA, WHITE A1, GL
H5550007850	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BWAB	WHITE A1 B1	S3SFN-S2BWAB, WHITE A1 B1, GL
H5550007851	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BWABM	WHITE A1 B1	S3SFN-S2BWABM, WHITE A1 B1, GL
H5550007726	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BWAM	WHITE A1	S3SFN-S2BWAM, WHITE A1, GL
H5550007797	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BWB	WHITE B1	S3SFN-S2BWB, WHITE B1, GL

H5550007798	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BWBM	WHITE B1	S3SFN-S2BWBM, WHITE B1, GL	
H5550012406	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2R	RED (HEAD)	S3SFN-S2R, RED (HEAD), GL	
H5550012417	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2W	WHITE (HEAD)	S3SFN-S2W, WHITE (HEAD), GL	
H5550012418	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2W2A	WHITE A2	S3SFN-S2W2A, WHITE A2, GL	
H5550012419	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2W2AM	WHITE A2	S3SFN-S2W2AM, WHITE A2, GL	
H5550012420	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2W2B	WHITE B2	S3SFN-S2W2B, WHITE B2, GL	
H5550012421	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2W2BM	WHITE B2	S3SFN-S2W2BM, WHITE B2, GL	
H5550012422	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2WA	WHITE A	S3SFN-S2WA, WHITE A, GL	
H5550012423	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2WAB	WHITE AB	S3SFN-S2WAB, WHITE AB, GL	
H5550012424	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2WABM	WHITE AB	S3SFN-S2WABM, WHITE AB, GL	
H5550012425	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2WAM	WHITE A	S3SFN-S2WAM, WHITE A, GL	
H5550012426	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2WB	WHITE B	S3SFN-S2WB, WHITE B, GL	
H5550012427	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2WBM	WHITE B	S3SFN-S2WBM, WHITE B, GL	
H5550007752	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AW2A	WHITE A2	S3SFN-S3AW2A, WHITE A2, GL	Селекторный переключатель, 30мм, утопленный, Без подсветки, Короткая ручка "акула", Белый, 2-позиционный с удержанием, 2 нормально открытых, 110 - 220 В~ 50/60 Hz
H5550007753	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AW2AM	WHITE A2	S3SFN-S3AW2AM, WHITE A2, GL	
H5550007820	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AW2B	WHITE B2	S3SFN-S3AW2B, WHITE B2, GL	
H5550007821	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AW2BM	WHITE B2	S3SFN-S3AW2BM, WHITE B2, GL	
H5550007728	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AWA	WHITE A1	S3SFN-S3AWA, WHITE A1, GL	
H5550007852	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AWAB	WHITE A1 B1	S3SFN-S3AWAB, WHITE A1 B1, GL	
H5550007853	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AWABM	WHITE A1 B1	S3SFN-S3AWABM, WHITE A1 B1, GL	
H5550007729	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AWAM	WHITE A1, GL	S3SFN-S3AWAM, WHITE A1, GL, GL	Селекторный переключатель, 30мм, утопленный, Без подсветки, Короткая ручка "акула", Белый, 2-позиционный с

							удержанием, 1 нормально открытый, 110 - 220 В~ 50/60 Hz, модульного типа
H5550007800	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AWB	WHITE B1	S3SFN-S3AWB, WHITE B1, GL	
H5550007801	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AWBM	WHITE B1	S3SFN-S3AWBM, WHITE B1, GL	
H5550007755	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BW2A	WHITE A2	S3SFN-S3BW2A, WHITE A2, GL	
H5550007756	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BW2AM	WHITE A2	S3SFN-S3BW2AM, WHITE A2, GL	
H5550007822	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BW2B	WHITE B2	S3SFN-S3BW2B, WHITE B2, GL	
H5550007823	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BW2BM	WHITE B2	S3SFN-S3BW2BM, WHITE B2, GL	
H5550007731	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BWA	WHITE A1	S3SFN-S3BWA, WHITE A1, GL	
H5550007854	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BWB	WHITE A1 B1	S3SFN-S3BWB, WHITE A1 B1, GL	
H5550007855	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BWBAM	WHITE A1 B1	S3SFN-S3BWBAM, WHITE A1 B1, GL	
H5550007732	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BWAM	WHITE A1	S3SFN-S3BWAM, WHITE A1, GL	
H5550007803	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BWB	WHITE B1	S3SFN-S3BWB, WHITE B1, GL	
H5550007804	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BWBAM	WHITE B1	S3SFN-S3BWBAM, WHITE B1, GL	
H5550007544	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AR		S3SFN-S4AR, , GL	
H5550007592	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AW		S3SFN-S4AW, , GL	
H5550007758	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AW2A	WHITE A2	S3SFN-S4AW2A, WHITE A2, GL	
H5550007759	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AW2AM	WHITE A2	S3SFN-S4AW2AM, WHITE A2, GL	
H5550007824	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AW2B	WHITE B2	S3SFN-S4AW2B, WHITE B2, GL	
H5550007825	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AW2BM	WHITE B2	S3SFN-S4AW2BM, WHITE B2, GL	
H5550007734	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AWA	WHITE A1	S3SFN-S4AWA, WHITE A1, GL	
H5550007856	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AWAB	WHITE A1 B1	S3SFN-S4AWAB, WHITE A1 B1, GL	

H5550007857	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AWABM	WHITE A1 B1	S3SFN-S4AWABM, WHITE A1 B1, GL	
H5550007735	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AWAM	WHITE A1	S3SFN-S4AWAM, WHITE A1, GL	
H5550007806	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AWB	WHITE B1	S3SFN-S4AWB, WHITE B1, GL	
H5550007807	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AWBM	WHITE B1	S3SFN-S4AWBM, WHITE B1, GL	
H5550007595	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BW		S3SFN-S4BW, , GL	
H5550007761	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BW2A	WHITE A2	S3SFN-S4BW2A, WHITE A2, GL	
H5550007762	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BW2AM	WHITE A2	S3SFN-S4BW2AM, WHITE A2, GL	
H5550007826	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BW2B	WHITE B2	S3SFN-S4BW2B, WHITE B2, GL	
H5550007827	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BW2BM	WHITE B2	S3SFN-S4BW2BM, WHITE B2, GL	
H5550007737	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BWA	WHITE A1	S3SFN-S4BWA, WHITE A1, GL	
H5550007858	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4WBAB	WHITE A1 B1	S3SFN-S4WBAB, WHITE A1 B1, GL	
H5550007859	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4WBABM	WHITE A1 B1	S3SFN-S4WBABM, WHITE A1 B1, GL	
H5550007738	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BWAM	WHITE A1	S3SFN-S4BWAM, WHITE A1, GL	
H5550007809	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BWB	WHITE B1	S3SFN-S4BWB, WHITE B1, GL	
H5550007810	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4WBWM	WHITE B1	S3SFN-S4WBWM, WHITE B1, GL	
H5550012428	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5KR	RED (HEAD)	S3SFN-S5KR, RED (HEAD), GL	
H5550012435	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5KW	WHITE (HEAD)	S3SFN-S5KW, WHITE (HEAD), GL	
H5550012436	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5KW2A	WHITE A2	S3SFN-S5KW2A, WHITE A2, GL	
H5550012437	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5KW2AM	WHITE A2	S3SFN-S5KW2AM, WHITE A2, GL	
H5550012438	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5KW2B	WHITE B2	S3SFN-S5KW2B, WHITE B2, GL	
H5550012439	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5KW2BM	WHITE B2	S3SFN-S5KW2BM, WHITE B2, GL	
H5550012440	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5KWAB	WHITE AB	S3SFN-S5KWAB, WHITE AB, GL	
H5550012441	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5KWABM	WHITE AB	S3SFN-S5KWABM, WHITE AB, GL	
H5550007598	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5W		S3SFN-S5W, , GL	

H5550007764	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5W2A	WHITE A2	S3SFN-S5W2A, WHITE A2, GL
H5550007765	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5W2AM	WHITE A2	S3SFN-S5W2AM, WHITE A2, GL
H5550007828	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5W2B	WHITE B2	S3SFN-S5W2B, WHITE B2, GL
H5550007829	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5W2BM	WHITE B2	S3SFN-S5W2BM, WHITE B2, GL
H5550007860	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5WAB	WHITE A1 B1	S3SFN-S5WAB, WHITE A1 B1, GL
H5550007861	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5WABM	WHITE A1 B1	S3SFN-S5WABM, WHITE A1 B1, GL
H5550012442	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6KR	RED (HEAD)	S3SFN-S6KR, RED (HEAD), GL
H5550012449	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6KW	WHITE (HEAD)	S3SFN-S6KW, WHITE (HEAD), GL
H5550012450	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6KW2A	WHITE A2	S3SFN-S6KW2A, WHITE A2, GL
H5550012451	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6KW2AM	WHITE A2	S3SFN-S6KW2AM, WHITE A2, GL
H5550012452	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6KW2B	WHITE B2	S3SFN-S6KW2B, WHITE B2, GL
H5550012453	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6KW2BM	WHITE B2	S3SFN-S6KW2BM, WHITE B2, GL
H5550012454	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6KWAB	WHITE AB	S3SFN-S6KWAB, WHITE AB, GL
H5550012455	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6KWABM	WHITE AB	S3SFN-S6KWABM, WHITE AB, GL
H5550007601	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6W		S3SFN-S6W, , GL
H5550007767	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6W2A	WHITE A2	S3SFN-S6W2A, WHITE A2, GL
H5550007768	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6W2AM	WHITE A2	S3SFN-S6W2AM, WHITE A2, GL
H5550007830	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6W2B	WHITE B2	S3SFN-S6W2B, WHITE B2, GL
H5550007831	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6W2BM	WHITE B2	S3SFN-S6W2BM, WHITE B2, GL
H5550007862	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6WAB	WHITE A1 B1	S3SFN-S6WAB, WHITE A1 B1, GL
H5550007863	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6WABM	WHITE A1 B1	S3SFN-S6WABM, WHITE A1 B1, GL
H5550012456	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7KR	RED (HEAD)	S3SFN-S7KR, RED (HEAD), GL

H5550012463	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7KW	WHITE (HEAD)	S3SFN-S7KW, WHITE (HEAD), GL	
H5550012465	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7KW2AM	WHITE A2	S3SFN-S7KW2AM, WHITE A2, GL	
H5550012466	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7KW2B	WHITE B2	S3SFN-S7KW2B, WHITE B2, GL	
H5550012467	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7KW2BM	WHITE B2	S3SFN-S7KW2BM, WHITE B2, GL	
H5550012468	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7KWAB	WHITE AB	S3SFN-S7KWAB, WHITE AB, GL	
H5550012469	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7KWABM	WHITE AB	S3SFN-S7KWABM, WHITE AB, GL	
H5550007770	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7W2A	WHITE A2	S3SFN-S7W2A, WHITE A2, GL	Селекторный переключатель, 30мм, утопленный, Короткая ручка "акула", Белый, 2-позиционный, 2 нормально открытый, 110 - 220 В~ 50/60 Hz
H5550007771	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7W2AM	WHITE A2	S3SFN-S7W2AM, WHITE A2, GL	Селекторный переключатель, 30мм, утопленный, Короткая ручка "акула", Белый, 2-позиционный, 2 нормально открытый, 110 - 220 В~ 50/60 Hz, модульного типа
H5550007832	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7W2B	WHITE B2	S3SFN-S7W2B, WHITE B2, GL	
H5550007833	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7W2BM	WHITE B2	S3SFN-S7W2BM, WHITE B2, GL	
H5550007864	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7WAB	WHITE A1 B1	S3SFN-S7WAB, WHITE A1 B1, GL	
H5550007865	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7WABM	WHITE A1 B1	S3SFN-S7WABM, WHITE A1 B1, GL	
H5550012470	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8KR	RED (HEAD)	S3SFN-S8KR, RED (HEAD), GL	
H5550012477	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8KW	WHITE (HEAD)	S3SFN-S8KW, WHITE (HEAD), GL	

H5550012479	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8KW2AM	WHITE A2	S3SFN-S8KW2AM, WHITE A2, GL
H5550012480	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8KW2B	WHITE B2	S3SFN-S8KW2B, WHITE B2, GL
H5550012481	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8KW2BM	WHITE B2	S3SFN-S8KW2BM, WHITE B2, GL
H5550012482	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8KWAB	WHITE AB	S3SFN-S8KWAB, WHITE AB, GL
H5550012483	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8KWABM	WHITE AB	S3SFN-S8KWABM, WHITE AB, GL
H5550007607	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8W		S3SFN-S8W, , GL
H5550007773	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8W2A	WHITE A2	S3SFN-S8W2A, WHITE A2, GL
H5550007774	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8W2AM	WHITE A2	S3SFN-S8W2AM, WHITE A2, GL
H5550007834	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8W2B	WHITE B2	S3SFN-S8W2B, WHITE B2, GL
H5550007835	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8W2BM	WHITE B2	S3SFN-S8W2BM, WHITE B2, GL
H5550007866	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8WAB	WHITE A1 B1	S3SFN-S8WAB, WHITE A1 B1, GL
H5550007867	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8WABM	WHITE A1 B1	S3SFN-S8WABM, WHITE A1 B1, GL
H5550012484	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAKR	RED (HEAD)	S3SFN-SAKR, RED (HEAD), GL
H5550012491	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAKW	WHITE (HEAD)	S3SFN-SAKW, WHITE (HEAD), GL
H5550012492	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAKW2A	WHITE A2	S3SFN-SAKW2A, WHITE A2, GL
H5550012493	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAKW2AM	WHITE A2	S3SFN-SAKW2AM, WHITE A2, GL

H5550012494	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAKW2B	WHITE B2	S3SFN-SAKW2B, WHITE B2, GL
H5550012495	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAKW2BM	WHITE B2	S3SFN-SAKW2BM, WHITE B2, GL
H5550012496	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAKWAB	WHITE AB	S3SFN-SAKWAB, WHITE AB, GL
H5550012497	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAKWABM	WHITE AB	S3SFN-SAKWABM, WHITE AB, GL
H5550007610	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAW		S3SFN-SAW, , GL
H5550007776	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAW2A	WHITE A2	S3SFN-SAW2A, WHITE A2, GL
H5550007777	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAW2AM	WHITE A2	S3SFN-SAW2AM, WHITE A2, GL
H5550007836	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAW2B	WHITE B2	S3SFN-SAW2B, WHITE B2, GL
H5550007837	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAW2BM	WHITE B2	S3SFN-SAW2BM, WHITE B2, GL
H5550007868	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAWAB	WHITE A1 B1	S3SFN-SAWAB, WHITE A1 B1, GL
H5550007869	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAWABM	WHITE A1 B1	S3SFN-SAWABM, WHITE A1 B1, GL
H5550012498	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBKR	RED (HEAD)	S3SFN-SBKR, RED (HEAD), GL
H5550012505	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBKW	WHITE (HEAD)	S3SFN-SBKW, WHITE (HEAD), GL
H5550012506	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBKW2A	WHITE A2	S3SFN-SBKW2A, WHITE A2, GL
H5550012507	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBKW2AM	WHITE A2	S3SFN-SBKW2AM, WHITE A2, GL
H5550012508	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBKW2B	WHITE B2	S3SFN-SBKW2B, WHITE B2, GL

H5550012509	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBKW2BM	WHITE B2	S3SFN-SBKW2BM, WHITE B2, GL
H5550012510	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBKWAB	WHITE AB	S3SFN-SBKWAB, WHITE AB, GL
H5550012511	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBKWABM	WHITE AB	S3SFN-SBKWABM, WHITE AB, GL
H5550007613	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBW		S3SFN-SBW, , GL
H5550007779	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBW2A	WHITE A2	S3SFN-SBW2A, WHITE A2, GL
H5550007780	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBW2AM	WHITE A2	S3SFN-SBW2AM, WHITE A2, GL
H5550007838	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBW2B	WHITE B2	S3SFN-SBW2B, WHITE B2, GL
H5550007839	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBW2BM	WHITE B2	S3SFN-SBW2BM, WHITE B2, GL
H5550007870	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBWAB	WHITE A1 B1	S3SFN-SBWAB, WHITE A1 B1, GL
H5550007871	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBWABM	WHITE A1 B1	S3SFN-SBWABM, WHITE A1 B1, GL
H5550012512	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCKR	RED (HEAD)	S3SFN-SCKR, RED (HEAD), GL
H5550012519	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCKW	WHITE (HEAD)	S3SFN-SCKW, WHITE (HEAD), GL
H5550012520	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCKW2A	WHITE A2	S3SFN-SCKW2A, WHITE A2, GL
H5550012521	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCKW2AM	WHITE A2	S3SFN-SCKW2AM, WHITE A2, GL

H5550012522	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCKW2B	WHITE B2	S3SFN-SCKW2B, WHITE B2, GL
H5550012523	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCKW2BM	WHITE B2	S3SFN-SCKW2BM, WHITE B2, GL
H5550012524	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCKWAB	WHITE AB	S3SFN-SCKWAB, WHITE AB, GL
H5550012525	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCKWABM	WHITE AB	S3SFN-SCKWABM, WHITE AB, GL
H5550007616	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCW		S3SFN-SCW, , GL
H5550007782	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCW2A	WHITE A2	S3SFN-SCW2A, WHITE A2, GL
H5550007783	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCW2AM	WHITE A2	S3SFN-SCW2AM, WHITE A2, GL
H5550007840	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCW2B	WHITE B2	S3SFN-SCW2B, WHITE B2, GL
H5550007841	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCW2BM	WHITE B2	S3SFN-SCW2BM, WHITE B2, GL
H5550007872	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCWAB	WHITE A1 B1	S3SFN-SCWAB, WHITE A1 B1, GL
H5550007873	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCWABM	WHITE A1 B1	S3SFN-SCWABM, WHITE A1 B1, GL
H5550012526	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDKR	RED (HEAD)	S3SFN-SDKR, RED (HEAD), GL
H5550012533	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDKW	WHITE (HEAD)	S3SFN-SDKW, WHITE (HEAD), GL
H5550012534	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDKW2A	WHITE A2	S3SFN-SDKW2A, WHITE A2, GL
H5550012535	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDKW2AM	WHITE A2	S3SFN-SDKW2AM, WHITE A2, GL
H5550012536	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDKW2B	WHITE B2	S3SFN-SDKW2B, WHITE B2, GL
H5550012537	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDKW2BM	WHITE B2	S3SFN-SDKW2BM, WHITE B2, GL

H5550012538	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDKWAB	WHITE AB	S3SFN-SDKWAB, WHITE AB, GL	
H5550012539	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDKWABM	WHITE AB	S3SFN-SDKWABM, WHITE AB, GL	
H5550007619	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDW		S3SFN-SDW, , GL	
H5550007785	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDW2A	WHITE A2	S3SFN-SDW2A, WHITE A2, GL	
H5550007786	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDW2AM	WHITE A2	S3SFN-SDW2AM, WHITE A2, GL	
H5550007842	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDW2B	WHITE B2	S3SFN-SDW2B, WHITE B2, GL	
H5550007843	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDW2BM	WHITE B2	S3SFN-SDW2BM, WHITE B2, GL	
H5550007874	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDWAB	WHITE A1 B1	S3SFN-SDWAB, WHITE A1 B1, GL	
H5550007875	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDWABM	WHITE A1 B1	S3SFN-SDWABM, WHITE A1 B1, GL	
A5550009342	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-1ES		S3KF-1ES, ,	Селекторный переключатель с ключом утопленного типа 30 мм, 2 положения с фиксацией, Снятие ключа в центральной позиции, Серый
A5550009343	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-1ES2A	2(0-R)/C/A2	S3KF-1ES2A, 2(0-R)/C/A2,	
A5550009344	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-1ES2AM	2(0-R)/C/A2	S3KF-1ES2AM, 2(0-R)/C/A2,	
A5550009347	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-1ES2B	2(0-R)/C/B2	S3KF-1ES2B, 2(0-R)/C/B2,	
A5550009348	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-1ES2BM	2(0-R)/C/B2	S3KF-1ES2BM, 2(0-R)/C/B2,	
A5550009340	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-1ESA	2(0-R)/C/A1	S3KF-1ESA, 2(0-R)/C/A1,	
A5550009349	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-1ESAB	2(0-R)/C/A1B1	S3KF-1ESAB, 2(0-R)/C/A1B1,	
A5550009350	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-1ESABM	2(0-R)/C/A1B1	S3KF-1ESABM, 2(0-R)/C/A1B1,	

A5550009341	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-1ESAM	2(0-R)/C/A1	S3KF-1ESAM, 2(0-R)/C/A1,	
A5550009345	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-1ESB	2(0-R)/C/B1	S3KF-1ESB, 2(0-R)/C/B1,	
A5550009346	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-1ESBM	2(0-R)/C/B1	S3KF-1ESBM, 2(0-R)/C/B1,	
A5550009353	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2DS		S3KF-2DS, ,	
A5550009354	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2DS2A	2(0-S)/R/A2	S3KF-2DS2A, 2(0-S)/R/A2,	
A5550009355	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2DS2AM	2(0-S)/R/A2	S3KF-2DS2AM, 2(0-S)/R/A2,	
A5550009358	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2DS2B	2(0-S)/R/B2	S3KF-2DS2B, 2(0-S)/R/B2,	
A5550009359	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2DS2BM	2(0-S)/R/B2	S3KF-2DS2BM, 2(0-S)/R/B2,	
A5550009351	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2DSA	2(0-S)/R/A1	S3KF-2DSA, 2(0-S)/R/A1,	
A5550009360	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2DSAB	2(0-S)/R/A1B1	S3KF-2DSAB, 2(0-S)/R/A1B1,	
A5550009361	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2DSABM	2(0-S)/R/A1B1	S3KF-2DSABM, 2(0-S)/R/A1B1,	
A5550009352	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2DSAM	2(0-S)/R/A1	S3KF-2DSAM, 2(0-S)/R/A1,	
A5550009356	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2DSB	2(0-S)/R/B1	S3KF-2DSB, 2(0-S)/R/B1,	
A5550009357	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2DSBM	2(0-S)/R/B1	S3KF-2DSBM, 2(0-S)/R/B1,	
A5550009450	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2ES		S3KF-2ES, ,	Селекторный переключатель с ключом утопленного типа 30 мм, 2 положения с фиксацией, Снятие ключа в центральной позиции, Серый
A5550009364	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2ES2A	2(0-S)/C/A2	S3KF-2ES2A, 2(0-S)/C/A2,	
A5550009365	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2ES2AM	2(0-S)/C/A2	S3KF-2ES2AM, 2(0-S)/C/A2,	
A5550009368	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2ES2B	2(0-S)/C/B2	S3KF-2ES2B, 2(0-S)/C/B2,	
A5550009369	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2ES2BM	2(0-S)/C/B2	S3KF-2ES2BM, 2(0-S)/C/B2,	
A5550009362	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2ESA	2(0-S)/C/A1	S3KF-2ESA, 2(0-S)/C/A1,	Селекторный переключатель с ключом утопленного типа, Ø30, 2-позиционный, без возврата, ключ

Вынимается в
положении: центр

							Вынимается в положении: центр
A5550009370	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2ESAB	2(0-S)/C/A1B1	S3KF-2ESAB, 2(0-S)/C/A1B1,	
A5550009371	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2ESABM	2(0-S)/C/A1B1	S3KF-2ESABM, 2(0-S)/C/A1B1,	
A5550009363	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2ESAM	2(0-S)/C/A1	S3KF-2ESAM, 2(0-S)/C/A1,	
A5550009366	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2ESB	2(0-S)/C/B1	S3KF-2ESB, 2(0-S)/C/B1,	
A5550009367	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2ESBM	2(0-S)/C/B1	S3KF-2ESBM, 2(0-S)/C/B1,	
A5550009374	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2FS		S3KF-2FS, ,	
A5550009375	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2FS2A	2(0-S)/C+R/A2	S3KF-2FS2A, 2(0-S)/C+R/A2,	
A5550009376	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2FS2AM	2(0-S)/C+R/A2	S3KF-2FS2AM, 2(0-S)/C+R/A2,	
A5550009372	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2FSA	2(0-S)/C+R/A1	S3KF-2FSA, 2(0-S)/C+R/A1,	
A5550009379	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2FSAB	2(0-S)/C+R/A1B1	S3KF-2FSAB, 2(0-S)/C+R/A1B1,	
A5550009380	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2FSABM	2(0-S)/C+R/A1B1	S3KF-2FSABM, 2(0-S)/C+R/A1B1,	
A5550009373	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2FSAM	2(0-S)/C+R/A1	S3KF-2FSAM, 2(0-S)/C+R/A1,	
A5550009377	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2FSB	2(0-S)/C+R/B1	S3KF-2FSB, 2(0-S)/C+R/B1,	
A5550009378	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-2FSBM	2(0-S)/C+R/B1	S3KF-2FSBM, 2(0-S)/C+R/B1,	
A5550009383	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-3ES		S3KF-3ES, ,	
A5550009381	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-3ES2A	3(R-0-R)/C/A2	S3KF-3ES2A, 3(R-0-R)/C/A2,	
A5550009382	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-3ES2AM	3(R-0-R)/C/A2	S3KF-3ES2AM, 3(R-0-R)/C/A2,	
A5550009384	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-3ES2B	3(R-0-R)/C/B2	S3KF-3ES2B, 3(R-0-R)/C/B2,	
A5550009385	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-3ES2BM	3(R-0-R)/C/B2	S3KF-3ES2BM, 3(R-0-R)/C/B2,	
A5550009386	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-3ESAB	3(R-0-R)/C/A1B1	S3KF-3ESAB, 3(R-0-R)/C/A1B1,	
A5550009387	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-3ESABM	3(R-0-R)/C/A1B1	S3KF-3ESABM, 3(R-0-R)/C/A1B1,	

A5550009390	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4BS		S3KF-4BS, ,
A5550009388	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4BS2A	3(S-0-S)/L+R/A2	S3KF-4BS2A, 3(S-0-S)/L+R/A2,
A5550009389	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4BS2AM	3(S-0-S)/L+R/A2	S3KF-4BS2AM, 3(S-0-S)/L+R/A2,
A5550009391	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4BS2B	3(S-0-S)/L+R/B2	S3KF-4BS2B, 3(S-0-S)/L+R/B2,
A5550009392	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4BS2BM	3(S-0-S)/L+R/B2	S3KF-4BS2BM, 3(S-0-S)/L+R/B2,
A5550009393	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4BSAB	3(S-0-S)/L+R/A1B1	S3KF-4BSAB, 3(S-0-S)/L+R/A1B1,
A5550009394	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4BSABM	3(S-0-S)/L+R/A1B1	S3KF-4BSABM, 3(S-0-S)/L+R/A1B1,
A5550009397	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4CS		S3KF-4CS, ,
A5550009395	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4CS2A	3(S-0-S)/L+C+R/A2	S3KF-4CS2A, 3(S-0-S)/L+C+R/A2,
A5550009396	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4CS2AM	3(S-0-S)/L+C+R/A2	S3KF-4CS2AM, 3(S-0-S)/L+C+R/A2,
A5550009398	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4CS2B	3(S-0-S)/L+C+R/B2	S3KF-4CS2B, 3(S-0-S)/L+C+R/B2,
A5550009399	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4CS2BM	3(S-0-S)/L+C+R/B2	S3KF-4CS2BM, 3(S-0-S)/L+C+R/B2,
A5550009400	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4CSAB	3(S-0-S)/L+C+R/A1B1	S3KF-4CSAB, 3(S-0-S)/L+C+R/A1B1,
A5550009401	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4CSABM	3(S-0-S)/L+C+R/A1B1	S3KF-4CSABM, 3(S-0-S)/L+C+R/A1B1,
A5550009404	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4ES		S3KF-4ES, ,
A5550009402	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4ES2A	3(S-0-S)/C/A2	S3KF-4ES2A, 3(S-0-S)/C/A2,
A5550009403	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4ES2AM	3(S-0-S)/C/A2	S3KF-4ES2AM, 3(S-0-S)/C/A2,
A5550009405	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4ES2B	3(S-0-S)/C/B2	S3KF-4ES2B, 3(S-0-S)/C/B2,
A5550009406	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4ES2BM	3(S-0-S)/C/B2	S3KF-4ES2BM, 3(S-0-S)/C/B2,
A5550009407	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4ESAB	3(S-0-S)/C/A1B1	S3KF-4ESAB, 3(S-0-S)/C/A1B1,
A5550009408	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-4ESABM	3(S-0-S)/C/A1B1	S3KF-4ESABM, 3(S-0-S)/C/A1B1,
A5550009411	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5AS		S3KF-5AS, ,

A5550009409	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5AS2A	3(S-0-R)/L/A2	S3KF-5AS2A, 3(S-0-R)/L/A2,	
A5550009410	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5AS2AM	3(S-0-R)/L/A2	S3KF-5AS2AM, 3(S-0-R)/L/A2,	
A5550009412	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5AS2B	3(S-0-R)/L/B2	S3KF-5AS2B, 3(S-0-R)/L/B2,	
A5550009413	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5AS2BM	3(S-0-R)/L/B2	S3KF-5AS2BM, 3(S-0-R)/L/B2,	
A5550009414	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5ASAB	3(S-0-R)/L/A1B1	S3KF-5ASAB, 3(S-0-R)/L/A1B1,	
A5550009417	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5ES		S3KF-5ES, ,	
A5550009415	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5ES2A	3(S-0-R)/C/A2	S3KF-5ES2A, 3(S-0-R)/C/A2,	
A5550009416	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5ES2AM	3(S-0-R)/C/A2	S3KF-5ES2AM, 3(S-0-R)/C/A2,	
A5550009418	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5ES2B	3(S-0-R)/C/B2	S3KF-5ES2B, 3(S-0-R)/C/B2,	
A5550009419	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5ES2BM	3(S-0-R)/C/B2	S3KF-5ES2BM, 3(S-0-R)/C/B2,	
A5550009420	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5ESAB	3(S-0-R)/C/A1B1	S3KF-5ESAB, 3(S-0-R)/C/A1B1,	
A5550009421	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5ESABM	3(S-0-R)/C/A1B1	S3KF-5ESABM, 3(S-0-R)/C/A1B1,	
A5550009424	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5GS		S3KF-5GS, ,	
A5550009422	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5GS2A	3(S-0-R)/L+C/A2	S3KF-5GS2A, 3(S-0-R)/L+C/A2,	
A5550009423	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5GS2AM	3(S-0-R)/L+C/A2	S3KF-5GS2AM, 3(S-0-R)/L+C/A2,	
A5550009425	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5GS2B	3(S-0-R)/L+C/B2	S3KF-5GS2B, 3(S-0-R)/L+C/B2,	
A5550009426	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5GS2BM	3(S-0-R)/L+C/B2	S3KF-5GS2BM, 3(S-0-R)/L+C/B2,	
A5550009427	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5GSAB	3(S-0-R)/L+C/A1B1	S3KF-5GSAB, 3(S-0-R)/L+C/A1B1,	
A5550009428	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-5GSABM	3(S-0-R)/L+C/A1B1	S3KF-5GSABM, 3(S-0-R)/L+C/A1B1,	
A5550009431	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6DS		S3KF-6DS, ,	
A5550009429	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6DS2A	3(R-0-S)/R/A2	S3KF-6DS2A, 3(R-0-S)/R/A2,	

A5550009430	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6DS2AM	3(R-0-S)/R/A2	S3KF-6DS2AM, 3(R-0-S)/R/A2,	
A5550009432	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6DS2B	3(R-0-S)/R/B2	S3KF-6DS2B, 3(R-0-S)/R/B2,	
A5550009433	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6DS2BM	3(R-0-S)/R/B2	S3KF-6DS2BM, 3(R-0-S)/R/B2,	
A5550009434	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6DSAB	3(R-0-S)/R/A1B1	S3KF-6DSAB, 3(R-0-S)/R/A1B1,	
A5550009435	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6DSABM	3(R-0-S)/R/A1B1	S3KF-6DSABM, 3(R-0-S)/R/A1B1,	
A5550009436	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6ES		S3KF-6ES, ,	
A5550009437	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6ES2A	3(R-0-S)/C/A2	S3KF-6ES2A, 3(R-0-S)/C/A2,	
A5550009438	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6ES2AM	3(R-0-S)/C/A2	S3KF-6ES2AM, 3(R-0-S)/C/A2,	
A5550009439	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6ES2B	3(R-0-S)/C/B2	S3KF-6ES2B, 3(R-0-S)/C/B2,	
A5550009440	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6ES2BM	3(R-0-S)/C/B2	S3KF-6ES2BM, 3(R-0-S)/C/B2,	
A5550009441	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6ESAB	3(R-0-S)/C/A1B1	S3KF-6ESAB, 3(R-0-S)/C/A1B1,	
A5550009442	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6ESABM	3(R-0-S)/C/A1B1	S3KF-6ESABM, 3(R-0-S)/C/A1B1,	
A5550009445	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6FS		S3KF-6FS, ,	
A5550009443	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6FS2A	3(R-0-S)/C+R/A2	S3KF-6FS2A, 3(R-0-S)/C+R/A2,	
A5550009444	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6FS2AM	3(R-0-S)/C+R/A2	S3KF-6FS2AM, 3(R-0-S)/C+R/A2,	
A5550009446	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6FS2B	3(R-0-S)/C+R/B2	S3KF-6FS2B, 3(R-0-S)/C+R/B2,	
A5550009447	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6FS2BM	3(R-0-S)/C+R/B2	S3KF-6FS2BM, 3(R-0-S)/C+R/B2,	
A5550009448	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6FSAB	3(R-0-S)/C+R/A1B1	S3KF-6FSAB, 3(R-0-S)/C+R/A1B1,	
A5550009449	CONTROL SWITCH	KEY SELECTOR SWITCH	S3KF SERIES	S3KF-6FSABM	3(R-0-S)/C+R/A1B1	S3KF-6FSABM, 3(R-0-S)/C+R/A1B1,	
A5550009722	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3B	BLUE	L3RF-L3B, BLUE,	Сигнальная лампа, плоская, круглая (утопленная), Ø 30, Синий

A5550009720	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3BD	BLUE LED(DC)	L3RF-L3BD, BLUE LED(DC),	
A5550009740	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3BL	BLUE LED(AC)	L3RF-L3BL, BLUE LED(AC),	
A5550009727	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3G	GREEN	L3RF-L3G, GREEN,	Сигнальная лампа, плоская, круглая (утопленная), Ø30, Зеленый
A5550009724	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3GD	GREEN LED(DC)	L3RF-L3GD, GREEN LED(DC),	
A5550009742	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3GL	GREEN LED(AC)	L3RF-L3GL, GREEN LED(AC),	
A5550009718	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3R	RED	L3RF-L3R, RED,	Сигнальная лампа, плоская, круглая (утопленная), Ø30, Красная
A5550009716	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3RD	RED LED(DC)	L3RF-L3RD, RED LED(DC),	
A5550009717	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3RDM	RED LED(DC)	L3RF-L3RDM, RED LED(DC),	
A5550009739	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3RL	RED LED(AC)	L3RF-L3RL, RED LED(AC),	
A5550009737	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3RL	RED.MAIN	L3RF-L3RL, RED.MAIN,	
A5550009738	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3RLM	RED LED(AC)	L3RF-L3RLM, RED LED(AC),	
A5550009735	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3W	WHITE	L3RF-L3W, WHITE,	Сигнальная лампа, плоская, круглая (утопленная), Ø30, белая
A5550009733	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3WD	WHITE LED(DC)	L3RF-L3WD, WHITE LED(DC),	
A5550009746	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3WL	WHITE LED(AC)	L3RF-L3WL, WHITE LED(AC),	
A5550009731	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3Y	YELLOW	L3RF-L3Y, YELLOW,	Сигнальная лампа, плоская, круглая (утопленная), Ø30, желтый
A5550009729	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3YD	YELLOW LED(DC) GL	L3RF-L3YD, YELLOW LED(DC),	Сигнальная лампа 30 мм, Желтый, Плоская головка, СИД 12-24 В=В~
A5550009744	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3YL	YELLOW LED(AC)	L3RF-L3YL, YELLOW LED(AC),	
A5550009745	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RF-L3YLM	YELLOW LED(AC)	L3RF-L3YLM, YELLOW LED(AC),	
A5550009719	CONTROL SWITCH	PILOT LAMP	L3RF SERIES	L3RFU-L3R	RED(NO PRINTING)	L3RFU-L3R, RED(NO PRINTING),	
A5550002289	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1B	BLUE	S3PF-P1B, BLUE,	Кнопочный выключатель, без подсветки, утопленный, 30 мм, Синий, без контактов

A5550002287	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1BA	BLUE A1	S3PF-P1BA, BLUE A1,	Кнопочный выключатель, без подсветки, утопленный, 30, Синий, Нормально открытый, 110В~/10А, 220В~/5А
A5550002292	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1G	GREEN	S3PF-P1G, GREEN,	Кнопочный выключатель, без подсветки, утопленный, 30 мм, Зеленый, без контактов
A5550002290	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1GA	GREEN A1	S3PF-P1GA, GREEN A1,	Кнопочный выключатель, без подсветки, утопленный, 30, Зеленый, Нормально открытый, 110В~/10А, 220В~/5А
A5550002298	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1K	BLACK	S3PF-P1K, BLACK,	Кнопочный выключатель, без подсветки, утопленный, 30 мм, Чёрный, без контактов
A5550002296	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1KA	BLACK A1	S3PF-P1KA, BLACK A1,	Кнопочный выключатель, без подсветки, утопленный, 30, Чёрный, Нормально открытый, 110В~/10А, 220В~/5А
A5550002286	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1R	RED	S3PF-P1R, RED,	Кнопочный выключатель, без подсветки, утопленный, 30 мм, Красный, без контактов
A5550002309	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1R2A	RED A2	S3PF-P1R2A, RED A2,	Кнопочный выключатель, без подсветки, утопленный, 30, Красный, 2 нормально открытых, 110В~/10А, 220В~/5А
A5550002369	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1R2AB	RED A2 B1	S3PF-P1R2AB, RED A2 B1,	
A5550002370	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1R2ABM	RED A2 B1	S3PF-P1R2ABM, RED A2 B1,	
A5550002310	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1R2AM	RED A2	S3PF-P1R2AM, RED A2,	
A5550002339	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1R2B	RED B2	S3PF-P1R2B, RED B2,	
A5550002340	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1R2BM	RED B2	S3PF-P1R2BM, RED B2,	
A5550002319	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1R3A	RED A3	S3PF-P1R3A, RED A3,	Кнопочный выключатель, без подсветки, утопленный, 30, Красный, 3 нормально открытых, 110В~/10А, 220В~/5А

A5550002320	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1R3AM	RED A3	S3PF-P1R3AM, RED A3,	
A5550002349	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1R3B	RED B3	S3PF-P1R3B, RED B3,	
A5550002350	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1R3BM	RED B3	S3PF-P1R3BM, RED B3,	
A5550002284	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1RA	RED A1	S3PF-P1RA, RED A1,	Кнопочный выключатель, без подсветки, утопленный, 30, Красный, Нормально открытый, 110В~/10А, 220В~/5А
A5550002379	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1RA2B	RED A1 B2	S3PF-P1RA2B, RED A1 B2,	
A5550002380	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1RA2BM	RED A1 B2	S3PF-P1RA2BM, RED A1 B2,	
A5550002359	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1RAB	RED A1 B1	S3PF-P1RAB, RED A1 B1,	
A5550002360	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1RABM	RED A1 B1	S3PF-P1RABM, RED A1 B1,	
A5550002285	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1RAM	RED A1	S3PF-P1RAM, RED A1,	
A5550002329	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1RB	RED B1	S3PF-P1RB, RED B1,	
A5550002330	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1RBM	RED B1	S3PF-P1RBM, RED B1,	
A5550002295	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1Y	YELLOW	S3PF-P1Y, YELLOW,	Кнопочный выключатель, без подсветки, утопленный, 30 мм, Желтый, без контактов
A5550002293	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1YA	YELLOW A1	S3PF-P1YA, YELLOW A1,	
A5550002335	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P1YB	YELLOW B1	S3PF-P1YB, YELLOW B1,	

A5550002301	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3B	BLUE	S3PF-P3B, BLUE,	Кнопочный выключатель, с подсветкой, утопленный, 30 мм, Синий
A5550002484	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3BABL	BLUE A1 B1 LED(AC)	S3PF-P3BABL, BLUE A1 B1 LED(AC),	
A5550002392	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3BAD	BLUE A1 LED(DC)	S3PF-P3BAD, BLUE A1 LED(DC),	
A5550002444	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3BAL	BLUE A1 LED(AC)	S3PF-P3BAL, BLUE A1 LED(AC),	
A5550002414	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3BBD	BLUE B1 LED(DC)	S3PF-P3BBD, BLUE B1 LED(DC),	
A5550002303	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3G	GREEN	S3PF-P3G, GREEN,	Кнопочный выключатель, с подсветкой, утопленный, 30 мм, Зелённый
A5550002406	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3G2AD	GREEN A2 LED(DC)	S3PF-P3G2AD, GREEN A2 LED(DC),	
A5550002436	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3GABD	GREEN A1 B1 LED(DC)	S3PF-P3GABD, GREEN A1 B1 LED(DC),	
A5550002396	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3GAD	GREEN A1 LED(DC)	S3PF-P3GAD, GREEN A1 LED(DC),	Кнопочный выключатель, с подсветкой, утопленный, 30, Зелёный, Нормально открытый, СИД 12-30 В=В~
A5550002446	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3GAL	GREEN A1 LED(AC)	S3PF-P3GAL, GREEN A1 LED(AC),	
A5550002299	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3R	RED	S3PF-P3R, RED,	Кнопочный выключатель, с подсветкой, утопленный, 30 мм, Красный
A5550002402	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3R2AD	RED A2 LED(DC)	S3PF-P3R2AD, RED A2 LED(DC),	
A5550002403	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3R2ADM	RED A2 LED(DC)	S3PF-P3R2ADM, RED A2 LED(DC),	
A5550002452	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3R2AL	RED A2 LED(AC)	S3PF-P3R2AL, RED A2 LED(AC),	

A5550002453	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3R2ALM	RED A2 LED(AC)	S3PF-P3R2ALM, RED A2 LED(AC),	
A5550002422	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3R2BD	RED B2 LED(DC)	S3PF-P3R2BD, RED B2 LED(DC),	
A5550002423	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3R2BDM	RED B2 LED(DC)	S3PF-P3R2BDM, RED B2 LED(DC),	
A5550002472	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3R2BL	RED B2 LED(AC)	S3PF-P3R2BL, RED B2 LED(AC),	
A5550002473	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3R2BLM	RED B2 LED(AC)	S3PF-P3R2BLM, RED B2 LED(AC),	
A5550002432	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3RABD	RED A1 B1 LED(DC)	S3PF-P3RABD, RED A1 B1 LED(DC),	Кнопочный выключатель, с подсветкой, утопленный, 30, Красный, 1 нормально открытый, 1 нормально закрытый, СИД 12-30 В=/В~
A5550002433	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3RABDM	RED A1 B1 LED(DC)	S3PF-P3RABDM, RED A1 B1 LED(DC),	Кнопочный выключатель, с подсветкой, утопленный, 30, Красный, 1 нормально открытый, 1 нормально закрытый, СИД 12-30 В=/В~, модульного типа
A5550002482	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3RABL	RED A1 B1 LED(AC)	S3PF-P3RABL, RED A1 B1 LED(AC),	
A5550002483	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3RABLM	RED A1 B1 LED(AC)	S3PF-P3RABLM, RED A1 B1 LED(AC),	
A5550002391	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3RAD	RED.STOP	S3PF-P3RAD, RED.STOP,	
A5550002389	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3RAD	RED A1 LED(DC)	S3PF-P3RAD, RED A1 LED(DC),	
A5550002390	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3RADM	RED A1 LED(DC)	S3PF-P3RADM, RED A1 LED(DC),	
A5550002442	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3RAL	RED A1 LED(AC)	S3PF-P3RAL, RED A1 LED(AC),	

A5550002443	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3RALM	RED A1 LED(AC)	S3PF-P3RALM, RED A1 LED(AC),	
A5550002412	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3RBD	RED B1 LED(DC)	S3PF-P3RBD, RED B1 LED(DC),	
A5550002413	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3RBDM	RED B1 LED(DC)	S3PF-P3RBDM, RED B1 LED(DC),	
A5550002462	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3RBL	RED B1 LED(AC)	S3PF-P3RBL, RED B1 LED(AC),	
A5550002463	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3RBLM	RED B1 LED(AC)	S3PF-P3RBLM, RED B1 LED(AC),	
A5550002307	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3W	WHITE	S3PF-P3W, WHITE,	Кнопочный выключатель, с подсветкой, утопленный, 30 мм, Белый
A5550002400	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3WAD	WHITE A1 LED(DC)	S3PF-P3WAD, WHITE A1 LED(DC),	
A5550002305	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3Y	YELLOW	S3PF-P3Y, YELLOW,	Кнопочный выключатель, с подсветкой, утопленный, 30 мм, Желтый
A5550002398	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3YAD	YELLOW A1 LED(DC)	S3PF-P3YAD, YELLOW A1 LED(DC),	
A5550002418	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3YBD	YELLOW B1 LED(DC)	S3PF-P3YBD, YELLOW B1 LED(DC),	
A5550002468	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PF SERIES	S3PF-P3YBL	YELLOW B1 LED(AC)	S3PF-P3YBL, YELLOW B1 LED(AC),	
A5550002302	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PFU SERIES	S3PFU-P3B	BLUE(NO PRINTING)	S3PFU-P3B, BLUE(NO PRINTING),	Круглый кнопочный выключатель, Ø30, утопленный (с подсветкой), синий
A5550002304	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PFU SERIES	S3PFU-P3G	GREEN(NO PRINTING)	S3PFU-P3G, GREEN(NO PRINTING),	Круглый кнопочный выключатель, Ø30, утопленный (с подсветкой), зеленый
A5550002300	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PFU SERIES	S3PFU-P3R	RED(NO PRINTING)	S3PFU-P3R, RED(NO PRINTING),	Круглый кнопочный выключатель, Ø30, утопленный (с подсветкой), красный

A5550002308	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PFU SERIES	S3PFU-P3W	WHITE(NO PRINTING)	S3PFU-P3W, WHITE(NO PRINTING),	Круглый кнопочный выключатель, Ø30, утопленный (с подсветкой), белый
A5550002306	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PFU SERIES	S3PFU-P3Y	YELLOW(NO PRINTING)	S3PFU-P3Y, YELLOW(NO PRINTING),	Круглый кнопочный выключатель, Ø30, утопленный (с подсветкой), желтый
A5550002194	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1B	BLUE	S3PR-P1B, BLUE,	Кнопочный выключатель, 30мм, без подсветки, выступающего типа, Синий
A5550002256	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1BAB	BLUE A1 B1	S3PR-P1BAB, BLUE A1 B1,	
A5550002197	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1G	GREEN	S3PR-P1G, GREEN,	Кнопочный выключатель, 30мм, без подсветки, выступающего типа, Зелённый
A5550002208	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1G2A	GREEN A2	S3PR-P1G2A, GREEN A2,	
A5550002195	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1GA	GREEN A1	S3PR-P1GA, GREEN A1,	
A5550002203	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1K	BLACK	S3PR-P1K, BLACK,	Кнопочный выключатель, 30мм, без подсветки, выступающего типа, Чёрный
A5550002191	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1R	RED	S3PR-P1R, RED,	Кнопочный выключатель, 30мм, без подсветки, выступающего типа, Красный
A5550002204	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1R2A	RED A2	S3PR-P1R2A, RED A2,	
A5550002264	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1R2AB	RED A2 B1	S3PR-P1R2AB, RED A2 B1,	Кнопочный выключатель, без подсветки, выступающего типа, Красный, 2 нормально открытых, 1 нормально закрытый, 110В~/10А, 220В~/5А
A5550002265	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1R2ABM	RED A2 B1	S3PR-P1R2ABM, RED A2 B1,	Кнопочный выключатель, без подсветки, выступающего типа, Красный, 2 нормально открытых, 1 нормально закрытый, 110В~/10А, 220В~/5А, модульного типа
A5550002205	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1R2AM	RED A2	S3PR-P1R2AM, RED A2,	

A5550002234	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1R2B	RED B2	S3PR-P1R2B, RED B2,	
A5550002235	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1R2BM	RED B2	S3PR-P1R2BM, RED B2,	
A5550002214	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1R3A	RED A3	S3PR-P1R3A, RED A3,	Кнопочный выключатель, без подсветки, выступающего типа, Красный, 3 нормально открытых, 110В~/10А, 220В~/5А
A5550002215	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1R3AM	RED A3	S3PR-P1R3AM, RED A3,	Кнопочный выключатель, без подсветки, выступающего типа, Красный, 3 нормально открытых, 110В~/10А, 220В~/5А, модульный тип
A5550002244	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1R3B	RED B3	S3PR-P1R3B, RED B3,	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Красный, 3 нормально закрытых, 110В~/10А, 220В~/5А
A5550002245	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1R3BM	RED B3	S3PR-P1R3BM, RED B3,	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Красный, 3 нормально закрытых, 110В~/10А, 220В~/5А, модульного типа
A5550002189	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1RA	RED A1	S3PR-P1RA, RED A1,	Кнопочный выключатель, без подсветки, выступающего типа, Красный, Нормально открытый, 110В~/10А, 220В~/5А
A5550002274	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1RA2B	RED A1 B2	S3PR-P1RA2B, RED A1 B2,	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Красный, 1 нормально открытый, 2 нормально закрытых, 110В~/10А, 220В~/5А
A5550002275	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1RA2BM	RED A1 B2	S3PR-P1RA2BM, RED A1 B2,	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Красный, 1 нормально открытый, 2 нормально закрытых, 110В~/10А, 220В~/5А, модульного типа
A5550002254	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1RAB	RED A1 B1	S3PR-P1RAB, RED A1 B1,	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Красный, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
A5550002255	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1RABM	RED A1 B1	S3PR-P1RABM, RED A1 B1,	Кнопочный выключатель, без подсветки, выступающего типа, ?0, Красный, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А, модульного типа

A5550002190	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1RAM	RED A1	S3PR-P1RAM, RED A1,	Кнопочный выключатель, без подсветки, выступающего типа, Красный, Нормально открытый, 110В~/10А, 220В~/5А, модульного типа
A5550002224	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1RB	RED B1	S3PR-P1RB, RED B1,	
A5550002225	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1RBM	RED B1	S3PR-P1RBM, RED B1,	
A5550002200	CONTROL SWITCH	PUSH BUTTON SWITCH	S3PR SERIES	S3PR-P1Y	YELLOW	S3PR-P1Y, YELLOW,	Кнопочный выключатель, 30мм, без подсветки, выступающего типа, Желтый
A5550002626	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1R2A	RED A2	S3SF-S1R2A, RED A2,	
A5550002627	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1R2AM	RED A2	S3SF-S1R2AM, RED A2,	
A5550002630	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1R2B	RED B2	S3SF-S1R2B, RED B2,	
A5550002631	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1R2BM	RED B2	S3SF-S1R2BM, RED B2,	
A5550002624	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1RA	RED A	S3SF-S1RA, RED A,	
A5550002632	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1RAB	RED AB	S3SF-S1RAB, RED AB,	
A5550002633	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1RABM	RED AB	S3SF-S1RABM, RED AB,	
A5550002625	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1RAM	RED A	S3SF-S1RAM, RED A,	
A5550002628	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1RB	RED B	S3SF-S1RB, RED B,	
A5550002629	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1RBM	RED B	S3SF-S1RBM, RED B,	
A5550002636	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S1W2A	WHITE A2	S3SF-S1W2A, WHITE A2,	
A5550002646	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2R2A	RED A2	S3SF-S2R2A, RED A2,	
A5550002647	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2R2AM	RED A2	S3SF-S2R2AM, RED A2,	
A5550002650	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2R2B	RED B2	S3SF-S2R2B, RED B2,	
A5550002651	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2R2BM	RED B2	S3SF-S2R2BM, RED B2,	
A5550002644	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2RA	RED A	S3SF-S2RA, RED A,	
A5550002652	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2RAB	RED AB	S3SF-S2RAB, RED AB,	
A5550002653	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2RABM	RED AB	S3SF-S2RABM, RED AB,	
A5550002645	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2RAM	RED A	S3SF-S2RAM, RED A,	
A5550002648	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2RB	RED B	S3SF-S2RB, RED B,	

A5550002649	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S2RBM	RED B	S3SF-S2RBM, RED B,	
A5550002497	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3R	RED	S3SF-S3R, RED,	Селекторный переключатель, 30мм, 2-позиционный, С фиксацией, С короткой рукояткой, Красный
A5550002500	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3R2A	RED A2	S3SF-S3R2A, RED A2,	
A5550002501	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3R2AM	RED A2	S3SF-S3R2AM, RED A2,	
A5550002508	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3R2B	RED B2	S3SF-S3R2B, RED B2,	
A5550002509	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3R2BM	RED B2	S3SF-S3R2BM, RED B2,	
A5550002495	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3RA	RED A1	S3SF-S3RA, RED A1,	
A5550002512	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3RAB	RED A1 B1	S3SF-S3RAB, RED A1 B1,	
A5550002513	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3RABM	RED A1 B1	S3SF-S3RABM, RED A1 B1,	
A5550002496	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3RAM	RED A1	S3SF-S3RAM, RED A1,	
A5550002504	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3RB	RED B1	S3SF-S3RB, RED B1,	
A5550002505	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3RBM	RED B1	S3SF-S3RBM, RED B1,	
A5550002494	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3W	WHITE	S3SF-S3W, WHITE,	Селекторный переключатель, 30мм, 2-позиционный, С фиксацией, С короткой рукояткой, Белый
A5550002498	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S3W2A	WHITE A2	S3SF-S3W2A, WHITE A2,	
A5550002519	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4R	RED	S3SF-S4R, RED,	Селекторный переключатель, 30мм, 2-позиционный, С фиксацией, С длинной рукояткой, Красный
A5550002522	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4R2A	RED A2	S3SF-S4R2A, RED A2,	
A5550002523	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4R2AM	RED A2	S3SF-S4R2AM, RED A2,	
A5550002530	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4R2B	RED B2	S3SF-S4R2B, RED B2,	
A5550002531	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4R2BM	RED B2	S3SF-S4R2BM, RED B2,	
A5550002517	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4RA	RED A1	S3SF-S4RA, RED A1,	
A5550002534	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4RAB	RED A1 B1	S3SF-S4RAB, RED A1 B1,	
A5550002535	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4RABM	RED A1 B1	S3SF-S4RABM, RED A1 B1,	
A5550002518	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4RAM	RED A1	S3SF-S4RAM, RED A1,	
A5550002526	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4RB	RED B1	S3SF-S4RB, RED B1,	
A5550002527	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4RBM	RED B1	S3SF-S4RBM, RED B1,	
A5550002516	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4W	WHITE	S3SF-S4W, WHITE,	Селекторный переключатель, 30мм, 2-позиционный, С

							фиксацией, С длинной ручкой, Белый
A5550002532	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S4WAB	WHITE A1 B1	S3SF-S4WAB, WHITE A1 B1,	Селекторный переключатель, 30мм, 2-позиционный, С фиксацией, С длинной ручкой, Белый, 1 нормально открытый, 1 нормально закрытый, 110В~/10А, 220В~/5А
A5550002664	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5KR2A	RED A2	S3SF-S5KR2A, RED A2,	
A5550002665	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5KR2AM	RED A2	S3SF-S5KR2AM, RED A2,	
A5550002666	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5KR2B	RED B2	S3SF-S5KR2B, RED B2,	
A5550002667	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5KR2BM	RED B2	S3SF-S5KR2BM, RED B2,	
A5550002668	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5KRAB	RED AB	S3SF-S5KRAB, RED AB,	
A5550002669	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5KRABM	RED AB	S3SF-S5KRABM, RED AB,	
A5550002541	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5R	RED	S3SF-S5R, RED,	Селекторный переключатель с короткой ручкой утопленного типа, ø30, 3 позиционный, пружинный самовозврат из двух положений, красный
A5550002544	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5R2A	RED A2	S3SF-S5R2A, RED A2,	
A5550002545	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5R2AM	RED A2	S3SF-S5R2AM, RED A2,	
A5550002552	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5R2B	RED B2	S3SF-S5R2B, RED B2,	
A5550002553	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5R2BM	RED B2	S3SF-S5R2BM, RED B2,	
A5550002539	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5RA	RED A1	S3SF-S5RA, RED A1,	
A5550002556	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5RAB	RED A1 B1	S3SF-S5RAB, RED A1 B1,	
A5550002557	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5RABM	RED A1 B1	S3SF-S5RABM, RED A1 B1,	
A5550002540	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5RAM	RED A1	S3SF-S5RAM, RED A1,	
A5550002548	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5RB	RED B1	S3SF-S5RB, RED B1,	
A5550002549	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5RBM	RED B1	S3SF-S5RBM, RED B1,	
A5550002538	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5W	WHITE	S3SF-S5W, WHITE,	Селекторный переключатель с короткой ручкой утопленного типа, ø30, 3 позиционный, пружинный самовозврат из двух положений, белый
A5550002542	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S5W2A	WHITE A2	S3SF-S5W2A, WHITE A2,	
A5550002676	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6KR2A	RED A2	S3SF-S6KR2A, RED A2,	
A5550002677	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6KR2AM	RED A2	S3SF-S6KR2AM, RED A2,	
A5550002678	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6KR2B	RED B2	S3SF-S6KR2B, RED B2,	

A5550002679	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6KR2BM	RED B2	S3SF-S6KR2BM, RED B2,	
A5550002680	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6KRAB	RED AB	S3SF-S6KRAB, RED AB,	
A5550002681	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6KRABM	RED AB	S3SF-S6KRABM, RED AB,	
A5550002563	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6R	RED	S3SF-S6R, RED,	Селекторный переключатель с короткой ручкой утопленного типа, ø30, 3 позиционный, пружинный самовозврат из двух положений, красный
A5550002566	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6R2A	RED A2	S3SF-S6R2A, RED A2,	
A5550002567	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6R2AM	RED A2	S3SF-S6R2AM, RED A2,	
A5550002574	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6R2B	RED B2	S3SF-S6R2B, RED B2,	
A5550002575	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6R2BM	RED B2	S3SF-S6R2BM, RED B2,	
A5550002561	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6RA	RED A1	S3SF-S6RA, RED A1,	
A5550002578	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6RAB	RED A1 B1	S3SF-S6RAB, RED A1 B1,	Селекторный переключатель, 30мм, 3-позиционный, С самовозвратом, С длинной рукояткой, Красный, 1 нормально открытый, 1 нормально закрытый, коммутация до 110В~/10А, 250В~/5А
A5550002579	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6RABM	RED A1 B1	S3SF-S6RABM, RED A1 B1,	
A5550002562	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6RAM	RED A1	S3SF-S6RAM, RED A1,	
A5550002570	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6RB	RED B1	S3SF-S6RB, RED B1,	
A5550002571	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6RBM	RED B1	S3SF-S6RBM, RED B1,	
A5550002560	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6W	WHITE	S3SF-S6W, WHITE,	Селекторный переключатель с короткой ручкой утопленного типа, ø30, 3 позиционный, пружинный самовозврат из двух положений, белый
A5550002564	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S6W2A	WHITE A2	S3SF-S6W2A, WHITE A2,	
A5550002688	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7KR2A	RED A2	S3SF-S7KR2A, RED A2,	

A5550002689	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7KR2AM	RED A2	S3SF-S7KR2AM, RED A2,	
A5550002690	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7KR2B	RED B2	S3SF-S7KR2B, RED B2,	
A5550002691	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7KR2BM	RED B2	S3SF-S7KR2BM, RED B2,	
A5550002692	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7KRAB	RED AB	S3SF-S7KRAB, RED AB,	
A5550002693	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7KRABM	RED AB	S3SF-S7KRABM, RED AB,	
A5550002585	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7R	RED	S3SF-S7R, RED,	Селекторный переключатель с короткой ручкой утопленного типа, ø30, 3 позиционный, без возврата, красный
A5550002588	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7R2A	RED A2	S3SF-S7R2A, RED A2,	
A5550002589	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7R2AM	RED A2	S3SF-S7R2AM, RED A2,	
A5550002596	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7R2B	RED B2	S3SF-S7R2B, RED B2,	
A5550002597	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7R2BM	RED B2	S3SF-S7R2BM, RED B2,	
A5550002583	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7RA	RED A1	S3SF-S7RA, RED A1,	
A5550002600	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7RAB	RED A1 B1	S3SF-S7RAB, RED A1 B1,	
A5550002601	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7RABM	RED A1 B1	S3SF-S7RABM, RED A1 B1,	
A5550002584	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7RAM	RED A1	S3SF-S7RAM, RED A1,	
A5550002592	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7RB	RED B1	S3SF-S7RB, RED B1,	
A5550002593	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7RBM	RED B1	S3SF-S7RBM, RED B1,	
A5550002582	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7W	WHITE	S3SF-S7W, WHITE,	Селекторный переключатель с короткой ручкой утопленного типа, ø30, 3 позиционный, без возврата, белый
A5550002586	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S7W2A	WHITE A2	S3SF-S7W2A, WHITE A2,	
A5550002700	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8KR2A	RED A2	S3SF-S8KR2A, RED A2,	
A5550002701	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8KR2AM	RED A2	S3SF-S8KR2AM, RED A2,	
A5550002702	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8KR2B	RED B2	S3SF-S8KR2B, RED B2,	
A5550002703	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8KR2BM	RED B2	S3SF-S8KR2BM, RED B2,	
A5550002704	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8KRAB	RED AB	S3SF-S8KRAB, RED AB,	
A5550002705	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8KRABM	RED AB	S3SF-S8KRABM, RED AB,	
A5550002607	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8R	RED	S3SF-S8R, RED,	Селекторный переключатель с короткой ручкой утопленного типа, ø30, 3 позиционный, без возврата, красный
A5550002610	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8R2A	RED A2	S3SF-S8R2A, RED A2,	
A5550002611	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8R2AM	RED A2	S3SF-S8R2AM, RED A2,	
A5550002618	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8R2B	RED B2	S3SF-S8R2B, RED B2,	
A5550002619	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8R2BM	RED B2	S3SF-S8R2BM, RED B2,	
A5550002605	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8RA	RED A1	S3SF-S8RA, RED A1,	
A5550002622	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8RAB	RED A1 B1	S3SF-S8RAB, RED A1 B1,	
A5550002623	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8RABM	RED A1 B1	S3SF-S8RABM, RED A1 B1,	
A5550002606	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8RAM	RED A1	S3SF-S8RAM, RED A1,	
A5550002614	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8RB	RED B1	S3SF-S8RB, RED B1,	
A5550002615	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8RBM	RED B1	S3SF-S8RBM, RED B1,	
A5550002604	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-S8W	WHITE	S3SF-S8W, WHITE,	Селекторный переключатель с короткой ручкой утопленного типа, ø30, 3 позиционный, без возврата, белый
A5550002712	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SAKR2A	RED A2	S3SF-SAKR2A, RED A2,	
A5550002713	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SAKR2AM	RED A2	S3SF-SAKR2AM, RED A2,	
A5550002714	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SAKR2B	RED B2	S3SF-SAKR2B, RED B2,	
A5550002715	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SAKR2BM	RED B2	S3SF-SAKR2BM, RED B2,	
A5550002716	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SAKRAB	RED AB	S3SF-SAKRAB, RED AB,	

A5550002717	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SAKRABM	RED AB	S3SF-SAKRABM, RED AB,
A5550002724	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SBKR2A	RED A2	S3SF-SBKR2A, RED A2,
A5550002725	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SBKR2AM	RED A2	S3SF-SBKR2AM, RED A2,
A5550002726	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SBKR2B	RED B2	S3SF-SBKR2B, RED B2,
A5550002727	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SBKR2BM	RED B2	S3SF-SBKR2BM, RED B2,
A5550002728	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SBKCRAB	RED AB	S3SF-SBKCRAB, RED AB,
A5550002729	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SBKCRABM	RED AB	S3SF-SBKCRABM, RED AB,
A5550002736	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SCKR2A	RED A2	S3SF-SCKR2A, RED A2,
A5550002737	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SCKR2AM	RED A2	S3SF-SCKR2AM, RED A2,
A5550002738	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SCKR2B	RED B2	S3SF-SCKR2B, RED B2,
A5550002739	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SCKR2BM	RED B2	S3SF-SCKR2BM, RED B2,
A5550002740	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SCKRAB	RED AB	S3SF-SCKRAB, RED AB,
A5550002741	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SCKRABM	RED AB	S3SF-SCKRABM, RED AB,
A5550002748	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SDKR2A	RED A2	S3SF-SDKR2A, RED A2,
A5550002749	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SDKR2AM	RED A2	S3SF-SDKR2AM, RED A2,
A5550002750	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SDKR2B	RED B2	S3SF-SDKR2B, RED B2,
A5550002751	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SDKR2BM	RED B2	S3SF-SDKR2BM, RED B2,
A5550002752	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SDKRAB	RED AB	S3SF-SDKRAB, RED AB,
A5550002753	CONTROL SWITCH	SELECTOR SWITCH	S3SF SERIES	S3SF-SDKRABM	RED AB	S3SF-SDKRABM, RED AB,
A5550005742	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AR		S3SFN-L1AR, ,
A5550006012	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AR2AD	RED A2 DC	S3SFN-L1AR2AD, RED A2 DC,
A5550006013	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AR2ADM	RED A2 DC	S3SFN-L1AR2ADM, RED A2 DC,
A5550006525	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AR2AL	RED A2 AC	S3SFN-L1AR2AL, RED A2 AC,
A5550006526	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AR2ALM	RED A2 AC	S3SFN-L1AR2ALM, RED A2 AC,
A5550006060	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AR2BD	RED B2 DC	S3SFN-L1AR2BD, RED B2 DC,
A5550006061	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AR2BDM	RED B2 DC	S3SFN-L1AR2BDM, RED B2 DC,
A5550006573	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AR2BL	RED B2 AC	S3SFN-L1AR2BL, RED B2 AC,
A5550006574	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1AR2BLM	RED B2 AC	S3SFN-L1AR2BLM, RED B2 AC,
A5550006092	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ARABD	RED A1 B1 DC	S3SFN-L1ARABD, RED A1 B1 DC,
A5550006093	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ARABDM	RED A1 B1 DC	S3SFN-L1ARABDM, RED A1 B1 DC,
A5550006605	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ARABL	RED A1 B1 AC	S3SFN-L1ARABL, RED A1 B1 AC,
A5550006606	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ARABLM	RED A1 B1 AC	S3SFN-L1ARABLM, RED A1 B1 AC,
A5550005996	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ARAD	RED A1 DC	S3SFN-L1ARAD, RED A1 DC,
A5550005997	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ARADM	RED A1 DC	S3SFN-L1ARADM, RED A1 DC,
A5550006509	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ARAL	RED A1 AC	S3SFN-L1ARAL, RED A1 AC,
A5550006510	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ARALM	RED A1 AC	S3SFN-L1ARALM, RED A1 AC,
A5550006044	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ARBD	RED B1 DC	S3SFN-L1ARBD, RED B1 DC,
A5550006045	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ARBDM	RED B1 DC	S3SFN-L1ARBDM, RED B1 DC,
A5550006557	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ARBL	RED B1 AC	S3SFN-L1ARBL, RED B1 AC,
A5550006558	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1ARBLM	RED B1 AC	S3SFN-L1ARBLM, RED B1 AC,
A5550005745	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BR		S3SFN-L1BR, ,
A5550006014	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BR2AD	RED A2 DC	S3SFN-L1BR2AD, RED A2 DC,
A5550006015	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BR2ADM	RED A2 DC	S3SFN-L1BR2ADM, RED A2 DC,
A5550006527	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BR2AL	RED A2 AC	S3SFN-L1BR2AL, RED A2 AC,
A5550006528	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BR2ALM	RED A2 AC	S3SFN-L1BR2ALM, RED A2 AC,
A5550006062	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BR2BD	RED B2 DC	S3SFN-L1BR2BD, RED B2 DC,
A5550006063	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BR2BDM	RED B2 DC	S3SFN-L1BR2BDM, RED B2 DC,

A5550006575	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BR2BL	RED B2 AC	S3SFN-L1BR2BL, RED B2 AC,
A5550006576	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BR2BLM	RED B2 AC	S3SFN-L1BR2BLM, RED B2 AC,
A5550006094	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BRABD	RED A1 B1 DC	S3SFN-L1BRABD, RED A1 B1 DC,
A5550006095	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BRABDM	RED A1 B1 DC	S3SFN-L1BRABDM, RED A1 B1 DC,
A5550006607	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BRABL	RED A1 B1 AC	S3SFN-L1BRABL, RED A1 B1 AC,
A5550006608	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BRABLM	RED A1 B1 AC	S3SFN-L1BRABLM, RED A1 B1 AC,
A5550005998	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BRAD	RED A1 DC	S3SFN-L1BRAD, RED A1 DC,
A5550005999	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BRADM	RED A1 DC	S3SFN-L1BRADM, RED A1 DC,
A5550006511	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BRAL	RED A1 AC	S3SFN-L1BRAL, RED A1 AC,
A5550006512	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BRALM	RED A1 AC	S3SFN-L1BRALM, RED A1 AC,
A5550006046	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BRBD	RED B1 DC	S3SFN-L1BRBD, RED B1 DC,
A5550006047	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BRBDM	RED B1 DC	S3SFN-L1BRBDM, RED B1 DC,
A5550006559	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BRBL	RED B1 AC	S3SFN-L1BRBL, RED B1 AC,
A5550006560	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1BRBLM	RED B1 AC	S3SFN-L1BRBLM, RED B1 AC,
A5550007161	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1R2AD	RED A2 LED(DC)	S3SFN-L1R2AD, RED A2 LED(DC),
A5550007162	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1R2ADM	RED A2 LED(DC)	S3SFN-L1R2ADM, RED A2 LED(DC),
A5550007163	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1R2AL	RED A2 LED(AC)	S3SFN-L1R2AL, RED A2 LED(AC),
A5550007164	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1R2ALM	RED A2 LED(AC)	S3SFN-L1R2ALM, RED A2 LED(AC),
A5550007169	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1R2BD	RED B2 LED(DC)	S3SFN-L1R2BD, RED B2 LED(DC),
A5550007170	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1R2BDM	RED B2 LED(DC)	S3SFN-L1R2BDM, RED B2 LED(DC),
A5550007171	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1R2BL	RED B2 LED(AC)	S3SFN-L1R2BL, RED B2 LED(AC),
A5550007172	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1R2BLM	RED B2 LED(AC)	S3SFN-L1R2BLM, RED B2 LED(AC),
A5550007173	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1RABD	RED AB LED(DC)	S3SFN-L1RABD, RED AB LED(DC),
A5550007174	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1RABDM	RED AB LED(DC)	S3SFN-L1RABDM, RED AB LED(DC),
A5550007175	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1RABL	RED AB LED(AC)	S3SFN-L1RABL, RED AB LED(AC),
A5550007176	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1RABLM	RED AB LED(AC)	S3SFN-L1RABLM, RED AB LED(AC),
A5550007157	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1RAD	RED A LED(DC)	S3SFN-L1RAD, RED A LED(DC),
A5550007158	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1RADM	RED A LED(DC)	S3SFN-L1RADM, RED A LED(DC),
A5550007159	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1RAL	RED A LED(AC)	S3SFN-L1RAL, RED A LED(AC),
A5550007160	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1RALM	RED A LED(AC)	S3SFN-L1RALM, RED A LED(AC),
A5550007165	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1RBD	RED B LED(DC)	S3SFN-L1RBD, RED B LED(DC),
A5550007166	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1RBDM	RED B LED(DC)	S3SFN-L1RBDM, RED B LED(DC),
A5550007167	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1RBL	RED B LED(AC)	S3SFN-L1RBL, RED B LED(AC),
A5550007168	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L1RBLM	RED B LED(AC)	S3SFN-L1RBLM, RED B LED(AC),
A5550005748	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AR		S3SFN-L2AR, ,
A5550006016	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AR2AD	RED A2 DC	S3SFN-L2AR2AD, RED A2 DC,
A5550006017	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AR2ADM	RED A2 DC	S3SFN-L2AR2ADM, RED A2 DC,
A5550006529	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AR2AL	RED A2 AC	S3SFN-L2AR2AL, RED A2 AC,
A5550006530	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AR2ALM	RED A2 AC	S3SFN-L2AR2ALM, RED A2 AC,
A5550006064	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AR2BD	RED B2 DC	S3SFN-L2AR2BD, RED B2 DC,
A5550006065	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AR2BDM	RED B2 DC	S3SFN-L2AR2BDM, RED B2 DC,
A5550006577	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AR2BL	RED B2 AC	S3SFN-L2AR2BL, RED B2 AC,
A5550006578	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2AR2BLM	RED B2 AC	S3SFN-L2AR2BLM, RED B2 AC,
A5550006096	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ARABD	RED A1 B1 DC	S3SFN-L2ARABD, RED A1 B1 DC,

A5550006097	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ARABDM	RED A1 B1 DC	S3SFN-L2ARABDM, RED A1 B1 DC,	
A5550006609	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ARABL	RED A1 B1 AC	S3SFN-L2ARABL, RED A1 B1 AC,	
A5550006610	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ARABLM	RED A1 B1 AC	S3SFN-L2ARABLM, RED A1 B1 AC,	
A5550006000	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ARAD	RED A1 DC	S3SFN-L2ARAD, RED A1 DC,	
A5550006001	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ARADM	RED A1 DC	S3SFN-L2ARADM, RED A1 DC,	
A5550006513	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ARAL	RED A1 AC	S3SFN-L2ARAL, RED A1 AC,	
A5550006514	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ARALM	RED A1 AC	S3SFN-L2ARALM, RED A1 AC,	
A5550006048	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ARBD	RED B1 DC	S3SFN-L2ARBD, RED B1 DC,	
A5550006049	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ARBDM	RED B1 DC	S3SFN-L2ARBDM, RED B1 DC,	
A5550006561	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ARBL	RED B1 AC	S3SFN-L2ARBL, RED B1 AC,	
A5550006562	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2ARBLM	RED B1 AC	S3SFN-L2ARBLM, RED B1 AC,	
A5550005751	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BR		S3SFN-L2BR, ,	
A5550006018	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BR2AD	RED A2 DC	S3SFN-L2BR2AD, RED A2 DC,	
A5550006019	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BR2ADM	RED A2 DC	S3SFN-L2BR2ADM, RED A2 DC,	
A5550006531	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BR2AL	RED A2 AC	S3SFN-L2BR2AL, RED A2 AC,	
A5550006532	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BR2ALM	RED A2 AC	S3SFN-L2BR2ALM, RED A2 AC,	
A5550006066	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BR2BD	RED B2 DC	S3SFN-L2BR2BD, RED B2 DC,	
A5550006067	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BR2BDM	RED B2 DC	S3SFN-L2BR2BDM, RED B2 DC,	
A5550006579	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BR2BL	RED B2 AC	S3SFN-L2BR2BL, RED B2 AC,	
A5550006580	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BR2BLM	RED B2 AC	S3SFN-L2BR2BLM, RED B2 AC,	
A5550006098	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BRABD	RED A1 B1 DC	S3SFN-L2BRABD, RED A1 B1 DC,	
A5550006099	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BRABDM	RED A1 B1 DC	S3SFN-L2BRABDM, RED A1 B1 DC,	
A5550006611	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BRABL	RED A1 B1 AC	S3SFN-L2BRABL, RED A1 B1 AC,	
A5550006612	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BRABLM	RED A1 B1 AC	S3SFN-L2BRABLM, RED A1 B1 AC,	
A5550006002	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BRAD	RED A1 DC	S3SFN-L2BRAD, RED A1 DC,	
A5550006003	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BRADM	RED A1 DC	S3SFN-L2BRADM, RED A1 DC,	
A5550006515	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BRAL	RED A1 AC	S3SFN-L2BRAL, RED A1 AC,	
A5550006516	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BRALM	RED A1 AC	S3SFN-L2BRALM, RED A1 AC,	
A5550006050	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BRBD	RED B1 DC	S3SFN-L2BRBD, RED B1 DC,	
A5550006051	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BRBDM	RED B1 DC	S3SFN-L2BRBDM, RED B1 DC,	
A5550006563	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BRBL	RED B1 AC	S3SFN-L2BRBL, RED B1 AC,	
A5550006564	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2BRBLM	RED B1 AC	S3SFN-L2BRBLM, RED B1 AC,	
A5550007241	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2R2AD	RED A2 LED(DC)	S3SFN-L2R2AD, RED A2 LED(DC),	
A5550007242	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2R2ADM	RED A2 LED(DC)	S3SFN-L2R2ADM, RED A2 LED(DC),	
A5550007243	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2R2AL	RED A2 LED(AC)	S3SFN-L2R2AL, RED A2 LED(AC),	
A5550007244	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2R2ALM	RED A2 LED(AC)	S3SFN-L2R2ALM, RED A2 LED(AC),	
A5550007249	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2R2BD	RED B2 LED(DC)	S3SFN-L2R2BD, RED B2 LED(DC),	
A5550007250	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2R2BDM	RED B2 LED(DC)	S3SFN-L2R2BDM, RED B2 LED(DC),	
A5550007251	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2R2BL	RED B2 LED(AC)	S3SFN-L2R2BL, RED B2 LED(AC),	
A5550007252	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2R2BLM	RED B2 LED(AC)	S3SFN-L2R2BLM, RED B2 LED(AC),	
A5550007253	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2RABD	RED AB LED(DC)	S3SFN-L2RABD, RED AB LED(DC),	
A5550007254	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2RABDM	RED AB LED(DC)	S3SFN-L2RABDM, RED AB LED(DC),	
A5550007255	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2RABL	RED AB LED(AC)	S3SFN-L2RABL, RED AB LED(AC),	
A5550007256	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2RABLM	RED AB LED(AC)	S3SFN-L2RABLM, RED AB LED(AC),	

A5550007237	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2RAD	RED A LED(DC)	S3SFN-L2RAD, RED A LED(DC),	
A5550007238	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2RADM	RED A LED(DC)	S3SFN-L2RADM, RED A LED(DC),	
A5550007239	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2RAL	RED A LED(AC)	S3SFN-L2RAL, RED A LED(AC),	
A5550007240	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2RALM	RED A LED(AC)	S3SFN-L2RALM, RED A LED(AC),	
A5550007245	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2RBD	RED B LED(DC)	S3SFN-L2RBD, RED B LED(DC),	
A5550007246	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2RBDM	RED B LED(DC)	S3SFN-L2RBDM, RED B LED(DC),	
A5550007247	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2RBL	RED B LED(AC)	S3SFN-L2RBL, RED B LED(AC),	
A5550007248	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L2RBLM	RED B LED(AC)	S3SFN-L2RBLM, RED B LED(AC),	
A5550005850	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AG		S3SFN-L3AG, ,	Селекторные переключатели, Ø30, переключатель утопленного типа с короткой ручкой shark (с подсветкой), 2-позиционный, без возврата, зеленый
A5550005754	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AR		S3SFN-L3AR, ,	
A5550006020	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AR2AD	RED A2 DC	S3SFN-L3AR2AD, RED A2 DC,	
A5550006021	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AR2ADM	RED A2 DC	S3SFN-L3AR2ADM, RED A2 DC,	
A5550006533	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AR2AL	RED A2 AC	S3SFN-L3AR2AL, RED A2 AC,	
A5550006534	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AR2ALM	RED A2 AC	S3SFN-L3AR2ALM, RED A2 AC,	
A5550006068	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AR2BD	RED B2 DC	S3SFN-L3AR2BD, RED B2 DC,	
A5550006069	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AR2BDM	RED B2 DC	S3SFN-L3AR2BDM, RED B2 DC,	
A5550006581	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AR2BL	RED B2 AC	S3SFN-L3AR2BL, RED B2 AC,	
A5550006582	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3AR2BLM	RED B2 AC	S3SFN-L3AR2BLM, RED B2 AC,	
A5550006100	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ARABD	RED A1 B1 DC	S3SFN-L3ARABD, RED A1 B1 DC,	
A5550006101	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ARABDM	RED A1 B1 DC	S3SFN-L3ARABDM, RED A1 B1 DC,	
A5550006613	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ARABL	RED A1 B1 AC	S3SFN-L3ARABL, RED A1 B1 AC,	
A5550006614	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ARABLM	RED A1 B1 AC	S3SFN-L3ARABLM, RED A1 B1 AC,	
A5550006004	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ARAD	RED A1 DC	S3SFN-L3ARAD, RED A1 DC,	
A5550006005	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ARADM	RED A1 DC	S3SFN-L3ARADM, RED A1 DC,	
A5550006517	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ARAL	RED A1 AC	S3SFN-L3ARAL, RED A1 AC,	
A5550006518	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ARALM	RED A1 AC	S3SFN-L3ARALM, RED A1 AC,	
A5550006052	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ARBD	RED B1 DC	S3SFN-L3ARBD, RED B1 DC,	
A5550006053	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ARBDM	RED B1 DC	S3SFN-L3ARBDM, RED B1 DC,	
A5550006565	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ARBL	RED B1 AC	S3SFN-L3ARBL, RED B1 AC,	
A5550006566	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3ARBLM	RED B1 AC	S3SFN-L3ARBLM, RED B1 AC,	
A5550006262	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BGAD	GREEN A1 DC	S3SFN-L3BGAD, GREEN A1 DC,	Селекторный переключатель, Ø30, с короткой ручкой shark утопленного типа (с подсветкой), 2-позиционный без возврата, зеленый
A5550005757	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BR		S3SFN-L3BR, ,	
A5550006022	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BR2AD	RED A2 DC	S3SFN-L3BR2AD, RED A2 DC,	
A5550006023	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BR2ADM	RED A2 DC	S3SFN-L3BR2ADM, RED A2 DC,	
A5550006535	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BR2AL	RED A2 AC	S3SFN-L3BR2AL, RED A2 AC,	
A5550006536	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BR2ALM	RED A2 AC	S3SFN-L3BR2ALM, RED A2 AC,	
A5550006070	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BR2BD	RED B2 DC	S3SFN-L3BR2BD, RED B2 DC,	
A5550006071	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BR2BDM	RED B2 DC	S3SFN-L3BR2BDM, RED B2 DC,	
A5550006583	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BR2BL	RED B2 AC	S3SFN-L3BR2BL, RED B2 AC,	

A5550006584	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BR2BLM	RED B2 AC	S3SFN-L3BR2BLM, RED B2 AC,	
A5550006102	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BRABD	RED A1 B1 DC	S3SFN-L3BRABD, RED A1 B1 DC,	
A5550006103	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BRABDM	RED A1 B1 DC	S3SFN-L3BRABDM, RED A1 B1 DC,	
A5550006615	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BRABL	RED A1 B1 AC	S3SFN-L3BRABL, RED A1 B1 AC,	
A5550006616	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BRABLM	RED A1 B1 AC	S3SFN-L3BRABLM, RED A1 B1 AC,	
A5550006006	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BRAD	RED A1 DC	S3SFN-L3BRAD, RED A1 DC,	
A5550006007	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BRADM	RED A1 DC	S3SFN-L3BRADM, RED A1 DC,	
A5550006519	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BRAL	RED A1 AC	S3SFN-L3BRAL, RED A1 AC,	
A5550006520	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BRALM	RED A1 AC	S3SFN-L3BRALM, RED A1 AC,	
A5550006054	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BRBD	RED B1 DC	S3SFN-L3BRBD, RED B1 DC,	
A5550006055	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BRBDM	RED B1 DC	S3SFN-L3BRBDM, RED B1 DC,	
A5550006567	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BRBL	RED B1 AC	S3SFN-L3BRBL, RED B1 AC,	
A5550006568	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BRBLM	RED B1 AC	S3SFN-L3BRBLM, RED B1 AC,	
A5550005901	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BY		S3SFN-L3BY, ,	Селекторные переключатели, Ø30, переключатель утопленного типа с короткой ручкой shark (с подстветкой), 2-позиционный, фиксируемый, желтый
A5550006903	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L3BYAL	YELLOW A1 AC	S3SFN-L3BYAL, YELLOW A1 AC,	
A5550005856	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AG		S3SFN-L4AG, ,	Селекторный переключатель, 30мм, утопленный, Короткая ручка "акула", Зелённый, 2-позиционный, без возврата
A5550006024	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AR2AD	RED A2 DC	S3SFN-L4AR2AD, RED A2 DC,	
A5550006025	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AR2ADM	RED A2 DC	S3SFN-L4AR2ADM, RED A2 DC,	
A5550006537	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AR2AL	RED A2 AC	S3SFN-L4AR2AL, RED A2 AC,	
A5550006538	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AR2ALM	RED A2 AC	S3SFN-L4AR2ALM, RED A2 AC,	
A5550006072	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AR2BD	RED B2 DC	S3SFN-L4AR2BD, RED B2 DC,	
A5550006073	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AR2BDM	RED B2 DC	S3SFN-L4AR2BDM, RED B2 DC,	
A5550006585	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AR2BL	RED B2 AC	S3SFN-L4AR2BL, RED B2 AC,	
A5550006586	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4AR2BLM	RED B2 AC	S3SFN-L4AR2BLM, RED B2 AC,	
A5550006104	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ARABD	RED A1 B1 DC	S3SFN-L4ARABD, RED A1 B1 DC,	
A5550006105	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ARABDM	RED A1 B1 DC	S3SFN-L4ARABDM, RED A1 B1 DC,	
A5550006617	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ARABL	RED A1 B1 AC	S3SFN-L4ARABL, RED A1 B1 AC,	
A5550006618	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ARABLM	RED A1 B1 AC	S3SFN-L4ARABLM, RED A1 B1 AC,	
A5550006008	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ARAD	RED A1 DC	S3SFN-L4ARAD, RED A1 DC,	
A5550006009	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ARADM	RED A1 DC	S3SFN-L4ARADM, RED A1 DC,	
A5550006521	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ARAL	RED A1 AC	S3SFN-L4ARAL, RED A1 AC,	
A5550006522	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ARALM	RED A1 AC	S3SFN-L4ARALM, RED A1 AC,	
A5550006056	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ARBD	RED B1 DC	S3SFN-L4ARBD, RED B1 DC,	
A5550006057	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ARBDM	RED B1 DC	S3SFN-L4ARBDM, RED B1 DC,	
A5550006569	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ARBL	RED B1 AC	S3SFN-L4ARBL, RED B1 AC,	
A5550006570	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4ARBLM	RED B1 AC	S3SFN-L4ARBLM, RED B1 AC,	
A5550006026	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BR2AD	RED A2 DC	S3SFN-L4BR2AD, RED A2 DC,	
A5550006027	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BR2ADM	RED A2 DC	S3SFN-L4BR2ADM, RED A2 DC,	
A5550006539	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BR2AL	RED A2 AC	S3SFN-L4BR2AL, RED A2 AC,	

A5550006540	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BR2ALM	RED A2 AC	S3SFN-L4BR2ALM, RED A2 AC,	
A5550006074	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BR2BD	RED B2 DC	S3SFN-L4BR2BD, RED B2 DC,	
A5550006075	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BR2BDM	RED B2 DC	S3SFN-L4BR2BDM, RED B2 DC,	
A5550006587	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BR2BL	RED B2 AC	S3SFN-L4BR2BL, RED B2 AC,	
A5550006588	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BR2BLM	RED B2 AC	S3SFN-L4BR2BLM, RED B2 AC,	
A5550006106	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BRABD	RED A1 B1 DC	S3SFN-L4BRABD, RED A1 B1 DC,	
A5550006107	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BRABDM	RED A1 B1 DC	S3SFN-L4BRABDM, RED A1 B1 DC,	
A5550006619	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BRABL	RED A1 B1 AC	S3SFN-L4BRABL, RED A1 B1 AC,	
A5550006620	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BRABLM	RED A1 B1 AC	S3SFN-L4BRABLM, RED A1 B1 AC,	
A5550006010	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BRAD	RED A1 DC	S3SFN-L4BRAD, RED A1 DC,	
A5550006011	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BRADM	RED A1 DC	S3SFN-L4BRADM, RED A1 DC,	
A5550006523	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BRAL	RED A1 AC	S3SFN-L4BRAL, RED A1 AC,	
A5550006524	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BRALM	RED A1 AC	S3SFN-L4BRALM, RED A1 AC,	
A5550006058	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BRBD	RED B1 DC	S3SFN-L4BRBD, RED B1 DC,	
A5550006059	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BRBDM	RED B1 DC	S3SFN-L4BRBDM, RED B1 DC,	
A5550006571	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BRBL	RED B1 AC	S3SFN-L4BRBL, RED B1 AC,	
A5550006572	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L4BRBLM	RED B1 AC	S3SFN-L4BRBLM, RED B1 AC,	
A5550007317	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KR2AD	RED A2 LED(DC)	S3SFN-L5KR2AD, RED A2 LED(DC),	
A5550007318	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KR2ADM	RED A2 LED(DC)	S3SFN-L5KR2ADM, RED A2 LED(DC),	
A5550007319	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KR2AL	RED A2 LED(AC)	S3SFN-L5KR2AL, RED A2 LED(AC),	
A5550007320	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KR2ALM	RED A2 LED(AC)	S3SFN-L5KR2ALM, RED A2 LED(AC),	
A5550007321	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KR2BD	RED B2 LED(DC)	S3SFN-L5KR2BD, RED B2 LED(DC),	
A5550007322	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KR2BDM	RED B2 LED(DC)	S3SFN-L5KR2BDM, RED B2 LED(DC),	
A5550007323	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KR2BL	RED B2 LED(AC)	S3SFN-L5KR2BL, RED B2 LED(AC),	
A5550007324	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KR2BLM	RED B2 LED(AC)	S3SFN-L5KR2BLM, RED B2 LED(AC),	
A5550007325	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KRABD	RED AB LED(DC)	S3SFN-L5KRABD, RED AB LED(DC),	
A5550007326	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KRABDM	RED AB LED(DC)	S3SFN-L5KRABDM, RED AB LED(DC),	
A5550007327	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KRABL	RED AB LED(AC)	S3SFN-L5KRABL, RED AB LED(AC),	
A5550007328	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5KRABLM	RED AB LED(AC)	S3SFN-L5KRABLM, RED AB LED(AC),	
A5550005766	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5R		S3SFN-L5R, ,	
A5550006028	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5R2AD	RED A2 DC	S3SFN-L5R2AD, RED A2 DC,	
A5550006029	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5R2ADM	RED A2 DC	S3SFN-L5R2ADM, RED A2 DC,	
A5550006541	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5R2AL	RED A2 AC	S3SFN-L5R2AL, RED A2 AC,	
A5550006542	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5R2ALM	RED A2 AC	S3SFN-L5R2ALM, RED A2 AC,	
A5550006076	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5R2BD	RED B2 DC	S3SFN-L5R2BD, RED B2 DC,	
A5550006077	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5R2BDM	RED B2 DC	S3SFN-L5R2BDM, RED B2 DC,	
A5550006589	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5R2BL	RED B2 AC	S3SFN-L5R2BL, RED B2 AC,	
A5550006590	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5R2BLM	RED B2 AC	S3SFN-L5R2BLM, RED B2 AC,	
A5550006108	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5RABD	RED A1 B1 DC	S3SFN-L5RABD, RED A1 B1 DC,	
A5550006109	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5RABDM	RED A1 B1 DC	S3SFN-L5RABDM, RED A1 B1 DC,	
A5550006621	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5RABL	RED A1 B1 AC	S3SFN-L5RABL, RED A1 B1 AC,	
A5550006622	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L5RABLM	RED A1 B1 AC	S3SFN-L5RABLM, RED A1 B1 AC,	
A5550007365	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KR2AD	RED A2 LED(DC)	S3SFN-L6KR2AD, RED A2 LED(DC),	
A5550007366	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KR2ADM	RED A2 LED(DC)	S3SFN-L6KR2ADM, RED A2 LED(DC),	

A5550007367	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KR2AL	RED A2 LED(AC)	S3SFN-L6KR2AL, RED A2 LED(AC),	
A5550007368	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KR2ALM	RED A2 LED(AC)	S3SFN-L6KR2ALM, RED A2 LED(AC),	
A5550007369	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KR2BD	RED B2 LED(DC)	S3SFN-L6KR2BD, RED B2 LED(DC),	
A5550007370	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KR2BDM	RED B2 LED(DC)	S3SFN-L6KR2BDM, RED B2 LED(DC),	
A5550007371	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KR2BL	RED B2 LED(AC)	S3SFN-L6KR2BL, RED B2 LED(AC),	
A5550007372	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KR2BLM	RED B2 LED(AC)	S3SFN-L6KR2BLM, RED B2 LED(AC),	
A5550007373	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KRABD	RED AB LED(DC)	S3SFN-L6KRABD, RED AB LED(DC),	
A5550007374	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KRABDM	RED AB LED(DC)	S3SFN-L6KRABDM, RED AB LED(DC),	
A5550007375	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KRABL	RED AB LED(AC)	S3SFN-L6KRABL, RED AB LED(AC),	
A5550007376	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6KRABLM	RED AB LED(AC)	S3SFN-L6KRABLM, RED AB LED(AC),	
A5550005769	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6R		S3SFN-L6R, ,	
A5550006030	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6R2AD	RED A2 DC	S3SFN-L6R2AD, RED A2 DC,	
A5550006031	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6R2ADM	RED A2 DC	S3SFN-L6R2ADM, RED A2 DC,	
A5550006543	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6R2AL	RED A2 AC	S3SFN-L6R2AL, RED A2 AC,	
A5550006544	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6R2ALM	RED A2 AC	S3SFN-L6R2ALM, RED A2 AC,	
A5550006078	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6R2BD	RED B2 DC	S3SFN-L6R2BD, RED B2 DC,	
A5550006079	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6R2BDM	RED B2 DC	S3SFN-L6R2BDM, RED B2 DC,	
A5550006591	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6R2BL	RED B2 AC	S3SFN-L6R2BL, RED B2 AC,	
A5550006592	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6R2BLM	RED B2 AC	S3SFN-L6R2BLM, RED B2 AC,	
A5550006110	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6RABD	RED A1 B1 DC	S3SFN-L6RABD, RED A1 B1 DC,	
A5550006111	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6RABDM	RED A1 B1 DC	S3SFN-L6RABDM, RED A1 B1 DC,	
A5550006623	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6RABL	RED A1 B1 AC	S3SFN-L6RABL, RED A1 B1 AC,	
A5550006624	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L6RABLM	RED A1 B1 AC	S3SFN-L6RABLM, RED A1 B1 AC,	
A5550007413	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KR2AD	RED A2 LED(DC)	S3SFN-L7KR2AD, RED A2 LED(DC),	
A5550007414	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KR2ADM	RED A2 LED(DC)	S3SFN-L7KR2ADM, RED A2 LED(DC),	
A5550007415	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KR2AL	RED A2 LED(AC)	S3SFN-L7KR2AL, RED A2 LED(AC),	
A5550007416	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KR2ALM	RED A2 LED(AC)	S3SFN-L7KR2ALM, RED A2 LED(AC),	
A5550007417	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KR2BD	RED B2 LED(DC)	S3SFN-L7KR2BD, RED B2 LED(DC),	
A5550007418	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KR2BDM	RED B2 LED(DC)	S3SFN-L7KR2BDM, RED B2 LED(DC),	
A5550007419	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KR2BL	RED B2 LED(AC)	S3SFN-L7KR2BL, RED B2 LED(AC),	
A5550007420	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KR2BLM	RED B2 LED(AC)	S3SFN-L7KR2BLM, RED B2 LED(AC),	
A5550007421	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KRABD	RED AB LED(DC)	S3SFN-L7KRABD, RED AB LED(DC),	
A5550007422	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KRABDM	RED AB LED(DC)	S3SFN-L7KRABDM, RED AB LED(DC),	
A5550007423	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KRABL	RED AB LED(AC)	S3SFN-L7KRABL, RED AB LED(AC),	
A5550007424	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KRABLM	RED AB LED(AC)	S3SFN-L7KRABLM, RED AB LED(AC),	
A5550007451	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7KY2AL	YELLOW A2 LED(AC)	S3SFN-L7KY2AL, YELLOW A2 LED(AC),	
A5550005772	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7R		S3SFN-L7R, ,	
A5550006032	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7R2AD	RED A2 DC	S3SFN-L7R2AD, RED A2 DC,	
A5550006033	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7R2ADM	RED A2 DC	S3SFN-L7R2ADM, RED A2 DC,	
A5550006545	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7R2AL	RED A2 AC	S3SFN-L7R2AL, RED A2 AC,	
A5550006546	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7R2ALM	RED A2 AC	S3SFN-L7R2ALM, RED A2 AC,	
A5550006080	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7R2BD	RED B2 DC	S3SFN-L7R2BD, RED B2 DC,	
A5550006081	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7R2BDM	RED B2 DC	S3SFN-L7R2BDM, RED B2 DC,	
A5550006593	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7R2BL	RED B2 AC	S3SFN-L7R2BL, RED B2 AC,	

A5550006594	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7R2BLM	RED B2 AC	S3SFN-L7R2BLM, RED B2 AC,	
A5550006112	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7RABD	RED A1 B1 DC	S3SFN-L7RABD, RED A1 B1 DC,	
A5550006113	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7RABDM	RED A1 B1 DC	S3SFN-L7RABDM, RED A1 B1 DC,	
A5550006625	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7RABL	RED A1 B1 AC	S3SFN-L7RABL, RED A1 B1 AC,	
A5550006626	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L7RABLM	RED A1 B1 AC	S3SFN-L7RABLM, RED A1 B1 AC,	
A5550007461	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KR2AD	RED A2 LED(DC)	S3SFN-L8KR2AD, RED A2 LED(DC),	
A5550007462	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KR2ADM	RED A2 LED(DC)	S3SFN-L8KR2ADM, RED A2 LED(DC),	
A5550007463	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KR2AL	RED A2 LED(AC)	S3SFN-L8KR2AL, RED A2 LED(AC),	
A5550007464	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KR2ALM	RED A2 LED(AC)	S3SFN-L8KR2ALM, RED A2 LED(AC),	
A5550007465	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KR2BD	RED B2 LED(DC)	S3SFN-L8KR2BD, RED B2 LED(DC),	
A5550007466	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KR2BDM	RED B2 LED(DC)	S3SFN-L8KR2BDM, RED B2 LED(DC),	
A5550007467	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KR2BL	RED B2 LED(AC)	S3SFN-L8KR2BL, RED B2 LED(AC),	
A5550007468	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KR2BLM	RED B2 LED(AC)	S3SFN-L8KR2BLM, RED B2 LED(AC),	
A5550007469	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KRABD	RED AB LED(DC)	S3SFN-L8KRABD, RED AB LED(DC),	
A5550007470	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KRABDM	RED AB LED(DC)	S3SFN-L8KRABDM, RED AB LED(DC),	
A5550007471	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KRABL	RED AB LED(AC)	S3SFN-L8KRABL, RED AB LED(AC),	
A5550007472	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8KRABLM	RED AB LED(AC)	S3SFN-L8KRABLM, RED AB LED(AC),	
A5550005775	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8R		S3SFN-L8R, ,	
A5550006034	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8R2AD	RED A2 DC	S3SFN-L8R2AD, RED A2 DC,	
A5550006035	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8R2ADM	RED A2 DC	S3SFN-L8R2ADM, RED A2 DC,	
A5550006547	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8R2AL	RED A2 AC	S3SFN-L8R2AL, RED A2 AC,	
A5550006548	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8R2ALM	RED A2 AC	S3SFN-L8R2ALM, RED A2 AC,	
A5550006082	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8R2BD	RED B2 DC	S3SFN-L8R2BD, RED B2 DC,	
A5550006083	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8R2BDM	RED B2 DC	S3SFN-L8R2BDM, RED B2 DC,	
A5550006595	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8R2BL	RED B2 AC	S3SFN-L8R2BL, RED B2 AC,	
A5550006596	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8R2BLM	RED B2 AC	S3SFN-L8R2BLM, RED B2 AC,	
A5550006114	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8RABD	RED A1 B1 DC	S3SFN-L8RABD, RED A1 B1 DC,	
A5550006115	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8RABDM	RED A1 B1 DC	S3SFN-L8RABDM, RED A1 B1 DC,	
A5550006627	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8RABL	RED A1 B1 AC	S3SFN-L8RABL, RED A1 B1 AC,	
A5550006628	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-L8RABLM	RED A1 B1 AC	S3SFN-L8RABLM, RED A1 B1 AC,	
A5550007509	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKR2AD	RED A2 LED(DC)	S3SFN-LAKR2AD, RED A2 LED(DC),	
A5550007510	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKR2ADM	RED A2 LED(DC)	S3SFN-LAKR2ADM, RED A2 LED(DC),	
A5550007511	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKR2AL	RED A2 LED(AC)	S3SFN-LAKR2AL, RED A2 LED(AC),	
A5550007512	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKR2ALM	RED A2 LED(AC)	S3SFN-LAKR2ALM, RED A2 LED(AC),	
A5550007513	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKR2BD	RED B2 LED(DC)	S3SFN-LAKR2BD, RED B2 LED(DC),	
A5550007514	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKR2BDM	RED B2 LED(DC)	S3SFN-LAKR2BDM, RED B2 LED(DC),	
A5550007515	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKR2BL	RED B2 LED(AC)	S3SFN-LAKR2BL, RED B2 LED(AC),	
A5550007516	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKR2BLM	RED B2 LED(AC)	S3SFN-LAKR2BLM, RED B2 LED(AC),	
A5550007517	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKRABD	RED AB LED(DC)	S3SFN-LAKRABD, RED AB LED(DC),	
A5550007518	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKRABDM	RED AB LED(DC)	S3SFN-LAKRABDM, RED AB LED(DC),	
A5550007519	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKRABL	RED AB LED(AC)	S3SFN-LAKRABL, RED AB LED(AC),	
A5550007520	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAKRABLM	RED AB LED(AC)	S3SFN-LAKRABLM, RED AB LED(AC),	
A5550005778	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAR		S3SFN-LAR, ,	
A5550006036	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAR2AD	RED A2 DC	S3SFN-LAR2AD, RED A2 DC,	

A5550006037	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAR2ADM	RED A2 DC	S3SFN-LAR2ADM, RED A2 DC,	
A5550006549	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAR2AL	RED A2 AC	S3SFN-LAR2AL, RED A2 AC,	
A5550006550	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAR2ALM	RED A2 AC	S3SFN-LAR2ALM, RED A2 AC,	
A5550006084	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAR2BD	RED B2 DC	S3SFN-LAR2BD, RED B2 DC,	
A5550006085	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAR2BDM	RED B2 DC	S3SFN-LAR2BDM, RED B2 DC,	
A5550006597	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAR2BL	RED B2 AC	S3SFN-LAR2BL, RED B2 AC,	
A5550006598	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LAR2BLM	RED B2 AC	S3SFN-LAR2BLM, RED B2 AC,	
A5550006116	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LARABD	RED A1 B1 DC	S3SFN-LARABD, RED A1 B1 DC,	
A5550006117	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LARABDM	RED A1 B1 DC	S3SFN-LARABDM, RED A1 B1 DC,	
A5550006629	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LARABL	RED A1 B1 AC	S3SFN-LARABL, RED A1 B1 AC,	
A5550006630	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LARABLM	RED A1 B1 AC	S3SFN-LARABLM, RED A1 B1 AC,	
A5550007557	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKR2AD	RED A2 LED(DC)	S3SFN-LBKR2AD, RED A2 LED(DC),	
A5550007558	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKR2ADM	RED A2 LED(DC)	S3SFN-LBKR2ADM, RED A2 LED(DC),	
A5550007559	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKR2AL	RED A2 LED(AC)	S3SFN-LBKR2AL, RED A2 LED(AC),	
A5550007560	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKR2ALM	RED A2 LED(AC)	S3SFN-LBKR2ALM, RED A2 LED(AC),	
A5550007561	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKR2BD	RED B2 LED(DC)	S3SFN-LBKR2BD, RED B2 LED(DC),	
A5550007562	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKR2BDM	RED B2 LED(DC)	S3SFN-LBKR2BDM, RED B2 LED(DC),	
A5550007563	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKR2BL	RED B2 LED(AC)	S3SFN-LBKR2BL, RED B2 LED(AC),	
A5550007564	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKR2BLM	RED B2 LED(AC)	S3SFN-LBKR2BLM, RED B2 LED(AC),	
A5550007565	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKRABD	RED AB LED(DC)	S3SFN-LBKRABD, RED AB LED(DC),	
A5550007566	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKRAADM	RED AB LED(DC)	S3SFN-LBKRAADM, RED AB LED(DC),	
A5550007567	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKRABL	RED AB LED(AC)	S3SFN-LBKRABL, RED AB LED(AC),	
A5550007568	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBKRABLM	RED AB LED(AC)	S3SFN-LBKRABLM, RED AB LED(AC),	
A5550006038	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBR2AD	RED A2 DC	S3SFN-LBR2AD, RED A2 DC,	
A5550006039	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBR2ADM	RED A2 DC	S3SFN-LBR2ADM, RED A2 DC,	
A5550006551	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBR2AL	RED A2 AC	S3SFN-LBR2AL, RED A2 AC,	
A5550006552	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBR2ALM	RED A2 AC	S3SFN-LBR2ALM, RED A2 AC,	
A5550006086	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBR2BD	RED B2 DC	S3SFN-LBR2BD, RED B2 DC,	
A5550006087	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBR2BDM	RED B2 DC	S3SFN-LBR2BDM, RED B2 DC,	
A5550006599	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBR2BL	RED B2 AC	S3SFN-LBR2BL, RED B2 AC,	
A5550006600	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBR2BLM	RED B2 AC	S3SFN-LBR2BLM, RED B2 AC,	
A5550006118	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBRABD	RED A1 B1 DC	S3SFN-LBRABD, RED A1 B1 DC,	
A5550006119	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBRABDM	RED A1 B1 DC	S3SFN-LBRABDM, RED A1 B1 DC,	
A5550006631	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBRABL	RED A1 B1 AC	S3SFN-LBRABL, RED A1 B1 AC,	
A5550006632	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LBRABLM	RED A1 B1 AC	S3SFN-LBRABLM, RED A1 B1 AC,	
A5550005880	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCG		S3SFN-LCG, ,	Селекторные переключатели, Ø30, переключатель утопленного типа с короткой ручкой shark (с подцветкой), 3-позиционный, пружинный самовозврат из левого положения, зеленый
A5550007605	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKR2AD	RED A2 LED(DC)	S3SFN-LCKR2AD, RED A2 LED(DC),	
A5550007606	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKR2ADM	RED A2 LED(DC)	S3SFN-LCKR2ADM, RED A2 LED(DC),	
A5550007607	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKR2AL	RED A2 LED(AC)	S3SFN-LCKR2AL, RED A2 LED(AC),	
A5550007608	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKR2ALM	RED A2 LED(AC)	S3SFN-LCKR2ALM, RED A2 LED(AC),	

A5550007609	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKR2BD	RED B2 LED(DC)	S3SFN-LCKR2BD, RED B2 LED(DC),	
A5550007610	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKR2BDM	RED B2 LED(DC)	S3SFN-LCKR2BDM, RED B2 LED(DC),	
A5550007611	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKR2BL	RED B2 LED(AC)	S3SFN-LCKR2BL, RED B2 LED(AC),	
A5550007612	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKR2BLM	RED B2 LED(AC)	S3SFN-LCKR2BLM, RED B2 LED(AC),	
A5550007613	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKRABD	RED AB LED(DC)	S3SFN-LCKRABD, RED AB LED(DC),	
A5550007614	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKRABDM	RED AB LED(DC)	S3SFN-LCKRABDM, RED AB LED(DC),	
A5550007615	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKRABL	RED AB LED(AC)	S3SFN-LCKRABL, RED AB LED(AC),	
A5550007616	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCKRABLM	RED AB LED(AC)	S3SFN-LCKRABLM, RED AB LED(AC),	
A5550005784	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCR		S3SFN-LCR, ,	
A5550006040	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCR2AD	RED A2 DC	S3SFN-LCR2AD, RED A2 DC,	
A5550006041	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCR2ADM	RED A2 DC	S3SFN-LCR2ADM, RED A2 DC,	
A5550006553	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCR2AL	RED A2 AC	S3SFN-LCR2AL, RED A2 AC,	
A5550006554	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCR2ALM	RED A2 AC	S3SFN-LCR2ALM, RED A2 AC,	
A5550006088	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCR2BD	RED B2 DC	S3SFN-LCR2BD, RED B2 DC,	
A5550006089	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCR2BDM	RED B2 DC	S3SFN-LCR2BDM, RED B2 DC,	
A5550006601	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCR2BL	RED B2 AC	S3SFN-LCR2BL, RED B2 AC,	
A5550006602	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCR2BLM	RED B2 AC	S3SFN-LCR2BLM, RED B2 AC,	
A5550006120	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCRABD	RED A1 B1 DC	S3SFN-LCRABD, RED A1 B1 DC,	
A5550006121	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCRABDM	RED A1 B1 DC	S3SFN-LCRABDM, RED A1 B1 DC,	
A5550006633	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCRABL	RED A1 B1 AC	S3SFN-LCRABL, RED A1 B1 AC,	
A5550006634	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LCRABLM	RED A1 B1 AC	S3SFN-LCRABLM, RED A1 B1 AC,	
A5550007653	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKR2AD	RED A2 LED(DC)	S3SFN-LDKR2AD, RED A2 LED(DC),	
A5550007654	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKR2ADM	RED A2 LED(DC)	S3SFN-LDKR2ADM, RED A2 LED(DC),	
A5550007655	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKR2AL	RED A2 LED(AC)	S3SFN-LDKR2AL, RED A2 LED(AC),	
A5550007656	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKR2ALM	RED A2 LED(AC)	S3SFN-LDKR2ALM, RED A2 LED(AC),	
A5550007657	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKR2BD	RED B2 LED(DC)	S3SFN-LDKR2BD, RED B2 LED(DC),	
A5550007658	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKR2BDM	RED B2 LED(DC)	S3SFN-LDKR2BDM, RED B2 LED(DC),	
A5550007659	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKR2BL	RED B2 LED(AC)	S3SFN-LDKR2BL, RED B2 LED(AC),	
A5550007660	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKR2BLM	RED B2 LED(AC)	S3SFN-LDKR2BLM, RED B2 LED(AC),	
A5550007661	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKRABD	RED AB LED(DC)	S3SFN-LDKRABD, RED AB LED(DC),	
A5550007662	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKRABDM	RED AB LED(DC)	S3SFN-LDKRABDM, RED AB LED(DC),	
A5550007663	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKRABL	RED AB LED(AC)	S3SFN-LDKRABL, RED AB LED(AC),	
A5550007664	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDKRABLM	RED AB LED(AC)	S3SFN-LDKRABLM, RED AB LED(AC),	
A5550005787	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDR		S3SFN-LDR, ,	
A5550006042	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDR2AD	RED A2 DC	S3SFN-LDR2AD, RED A2 DC,	
A5550006043	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDR2ADM	RED A2 DC	S3SFN-LDR2ADM, RED A2 DC,	
A5550006555	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDR2AL	RED A2 AC	S3SFN-LDR2AL, RED A2 AC,	
A5550006556	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDR2ALM	RED A2 AC	S3SFN-LDR2ALM, RED A2 AC,	
A5550006090	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDR2BD	RED B2 DC	S3SFN-LDR2BD, RED B2 DC,	
A5550006091	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDR2BDM	RED B2 DC	S3SFN-LDR2BDM, RED B2 DC,	
A5550006603	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDR2BL	RED B2 AC	S3SFN-LDR2BL, RED B2 AC,	
A5550006604	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDR2BLM	RED B2 AC	S3SFN-LDR2BLM, RED B2 AC,	
A5550006122	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDRABD	RED A1 B1 DC	S3SFN-LDRABD, RED A1 B1 DC,	
A5550006123	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDRABDM	RED A1 B1 DC	S3SFN-LDRABDM, RED A1 B1 DC,	

A5550006635	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDRABL	RED A1 B1 AC	S3SFN-LDRABL, RED A1 B1 AC,	
A5550006636	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-LDRABLM	RED A1 B1 AC	S3SFN-LDRABLM, RED A1 B1 AC,	
A5550005647	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AR		S3SFN-S1AR, ,	
A5550005669	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AR2A	RED A2	S3SFN-S1AR2A, RED A2,	
A5550005670	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AR2AM	RED A2	S3SFN-S1AR2AM, RED A2,	
A5550005740	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AR2B	RED B2	S3SFN-S1AR2B, RED B2,	
A5550005741	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1AR2BM	RED B2	S3SFN-S1AR2BM, RED B2,	
A5550005645	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1ARA	RED A1	S3SFN-S1ARA, RED A1,	
A5550005788	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1ARAB	RED A1 B1	S3SFN-S1ARAB, RED A1 B1,	
A5550005789	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1ARABM	RED A1 B1	S3SFN-S1ARABM, RED A1 B1,	
A5550005646	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1ARAM	RED A1	S3SFN-S1ARAM, RED A1,	
A5550005716	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1ARB	RED B1	S3SFN-S1ARB, RED B1,	
A5550005717	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1ARBM	RED B1	S3SFN-S1ARBM, RED B1,	
A5550005650	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BR		S3SFN-S1BR, ,	
A5550005672	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BR2A	RED A2	S3SFN-S1BR2A, RED A2,	
A5550005673	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BR2AM	RED A2	S3SFN-S1BR2AM, RED A2,	
A5550005743	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BR2B	RED B2	S3SFN-S1BR2B, RED B2,	
A5550005744	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BR2BM	RED B2	S3SFN-S1BR2BM, RED B2,	
A5550005648	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BRA	RED A1	S3SFN-S1BRA, RED A1,	Селекторный переключатель, Ø30, с короткой ручкой shark утолщенного типа, 2-позиционный самовозврат, красный
A5550005791	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BRAB	RED A1 B1	S3SFN-S1BRAB, RED A1 B1,	
A5550005792	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BRABM	RED A1 B1	S3SFN-S1BRABM, RED A1 B1,	
A5550005649	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BRAM	RED A1	S3SFN-S1BRAM, RED A1,	
A5550005719	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BRB	RED B1	S3SFN-S1BRB, RED B1,	
A5550005720	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1BRBM	RED B1	S3SFN-S1BRBM, RED B1,	
A5550007023	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1R2A	RED A2	S3SFN-S1R2A, RED A2,	
A5550007024	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1R2AM	RED A2	S3SFN-S1R2AM, RED A2,	
A5550007027	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1R2B	RED B2	S3SFN-S1R2B, RED B2,	
A5550007028	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1R2BM	RED B2	S3SFN-S1R2BM, RED B2,	
A5550007021	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1RA	RED A	S3SFN-S1RA, RED A,	
A5550007029	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1RAB	RED AB	S3SFN-S1RAB, RED AB,	
A5550007030	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1RABM	RED AB	S3SFN-S1RABM, RED AB,	
A5550007022	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1RAM	RED A	S3SFN-S1RAM, RED A,	
A5550007025	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1RB	RED B	S3SFN-S1RB, RED B,	
A5550007026	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S1RBM	RED B	S3SFN-S1RBM, RED B,	
A5550005653	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AR		S3SFN-S2AR, ,	
A5550005675	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AR2A	RED A2	S3SFN-S2AR2A, RED A2,	
A5550005676	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AR2AM	RED A2	S3SFN-S2AR2AM, RED A2,	
A5550005746	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AR2B	RED B2	S3SFN-S2AR2B, RED B2,	
A5550005747	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2AR2BM	RED B2	S3SFN-S2AR2BM, RED B2,	
A5550005651	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2ARA	RED A1	S3SFN-S2ARA, RED A1,	
A5550005794	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2ARAB	RED A1 B1	S3SFN-S2ARAB, RED A1 B1,	
A5550005795	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2ARABM	RED A1 B1	S3SFN-S2ARABM, RED A1 B1,	
A5550005652	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2ARAM	RED A1	S3SFN-S2ARAM, RED A1,	
A5550005722	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2ARB	RED B1	S3SFN-S2ARB, RED B1,	
A5550005723	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2ARBM	RED B1	S3SFN-S2ARBM, RED B1,	
A5550005656	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BR		S3SFN-S2BR, ,	
A5550005677	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BR2A	RED A2	S3SFN-S2BR2A, RED A2,	

A5550005678	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BR2AM	RED A2	S3SFN-S2BR2AM, RED A2,	
A5550005749	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BR2B	RED B2	S3SFN-S2BR2B, RED B2,	
A5550005750	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BR2BM	RED B2	S3SFN-S2BR2BM, RED B2,	
A5550005654	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BRA	RED A1	S3SFN-S2BRA, RED A1,	
A5550005797	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BRAB	RED A1 B1	S3SFN-S2BRAB, RED A1 B1,	
A5550005798	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BRABM	RED A1 B1	S3SFN-S2BRABM, RED A1 B1,	
A5550005655	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BRAM	RED A1	S3SFN-S2BRAM, RED A1,	
A5550005725	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BRB	RED B1	S3SFN-S2BRB, RED B1,	
A5550005726	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2BRBM	RED B1	S3SFN-S2BRBM, RED B1,	
A5550007043	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2R2A	RED A2	S3SFN-S2R2A, RED A2,	
A5550007044	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2R2AM	RED A2	S3SFN-S2R2AM, RED A2,	
A5550007047	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2R2B	RED B2	S3SFN-S2R2B, RED B2,	
A5550007048	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2R2BM	RED B2	S3SFN-S2R2BM, RED B2,	
A5550007041	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2RA	RED A	S3SFN-S2RA, RED A,	
A5550007049	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2RAB	RED AB	S3SFN-S2RAB, RED AB,	
A5550007050	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2RABM	RED AB	S3SFN-S2RABM, RED AB,	
A5550007042	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2RAM	RED A	S3SFN-S2RAM, RED A,	
A5550007045	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2RB	RED B	S3SFN-S2RB, RED B,	
A5550007046	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S2RBM	RED B	S3SFN-S2RBM, RED B,	
A5550005659	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AR		S3SFN-S3AR, ,	
A5550005680	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AR2A	RED A2	S3SFN-S3AR2A, RED A2,	
A5550005681	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AR2AM	RED A2	S3SFN-S3AR2AM, RED A2,	
A5550005752	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AR2B	RED B2	S3SFN-S3AR2B, RED B2,	
A5550005753	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AR2BM	RED B2	S3SFN-S3AR2BM, RED B2,	
A5550005657	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3ARA	RED A1	S3SFN-S3ARA, RED A1,	
A5550005800	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3ARAB	RED A1 B1	S3SFN-S3ARAB, RED A1 B1,	
A5550005801	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3ARABM	RED A1 B1	S3SFN-S3ARABM, RED A1 B1,	
A5550005658	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3ARAM	RED A1	S3SFN-S3ARAM, RED A1,	
A5550005728	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3ARB	RED B1	S3SFN-S3ARB, RED B1,	
A5550005729	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3ARB	RED B1	S3SFN-S3ARB, RED B1,	
A5550005706	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3AW		S3SFN-S3AW, ,	Селекторный переключатель, 30мм, утопленный, короткая ручка "акула", Белый, 2-позиционный, без возврата
A5550005662	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BR		S3SFN-S3BR, ,	
A5550005683	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BR2A	RED A2	S3SFN-S3BR2A, RED A2,	
A5550005684	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BR2AM	RED A2	S3SFN-S3BR2AM, RED A2,	
A5550005755	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BR2B	RED B2	S3SFN-S3BR2B, RED B2,	
A5550005756	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BR2BM	RED B2	S3SFN-S3BR2BM, RED B2,	
A5550005660	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BRA	RED A1	S3SFN-S3BRA, RED A1,	
A5550005803	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BRAB	RED A1 B1	S3SFN-S3BRAB, RED A1 B1,	
A5550005804	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BRABM	RED A1 B1	S3SFN-S3BRABM, RED A1 B1,	
A5550005661	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BRAM	RED A1	S3SFN-S3BRAM, RED A1,	
A5550005731	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BRB	RED B1	S3SFN-S3BRB, RED B1,	
A5550005732	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BRBM	RED B1	S3SFN-S3BRBM, RED B1,	
A5550005709	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S3BW		S3SFN-S3BW, ,	Селекторные переключатели, Ø30, с короткой ручкой shark, 2-позиционный, без возврата, белый
A5550005686	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AR2A	RED A2	S3SFN-S4AR2A, RED A2,	
A5550005687	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AR2AM	RED A2	S3SFN-S4AR2AM, RED A2,	
A5550005758	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AR2B	RED B2	S3SFN-S4AR2B, RED B2,	

A5550005759	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4AR2BM	RED B2	S3SFN-S4AR2BM, RED B2,	
A5550005663	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4ARA	RED A1	S3SFN-S4ARA, RED A1,	
A5550005806	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4ARAB	RED A1 B1	S3SFN-S4ARAB, RED A1 B1,	
A5550005807	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4ARABM	RED A1 B1	S3SFN-S4ARABM, RED A1 B1,	
A5550005664	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4ARAM	RED A1	S3SFN-S4ARAM, RED A1,	
A5550005734	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4ARB	RED B1	S3SFN-S4ARB, RED B1,	
A5550005735	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4ARBM	RED B1	S3SFN-S4ARBM, RED B1,	
A5550005668	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BR		S3SFN-S4BR, ,	Селекторные переключатели, Ø30, с длинной ручкой shark, утопленные, 2-позиционный, без возврата, красный
A5550005689	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BR2A	RED A2	S3SFN-S4BR2A, RED A2,	
A5550005690	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BR2AM	RED A2	S3SFN-S4BR2AM, RED A2,	
A5550005761	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BR2B	RED B2	S3SFN-S4BR2B, RED B2,	
A5550005762	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BR2BM	RED B2	S3SFN-S4BR2BM, RED B2,	
A5550005666	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BRA	RED A1	S3SFN-S4BRA, RED A1,	
A5550005809	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BRAB	RED A1 B1	S3SFN-S4BRAB, RED A1 B1,	
A5550005810	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BRABM	RED A1 B1	S3SFN-S4BRABM, RED A1 B1,	
A5550005667	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BRAM	RED A1	S3SFN-S4BRAM, RED A1,	
A5550005737	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BRB	RED B1	S3SFN-S4BRB, RED B1,	
A5550005738	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S4BRBM	RED B1	S3SFN-S4BRBM, RED B1,	
A5550007061	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5KR2A	RED A2	S3SFN-S5KR2A, RED A2,	
A5550007062	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5KR2AM	RED A2	S3SFN-S5KR2AM, RED A2,	
A5550007063	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5KR2B	RED B2	S3SFN-S5KR2B, RED B2,	
A5550007064	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5KR2BM	RED B2	S3SFN-S5KR2BM, RED B2,	
A5550007065	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5KRAB	RED AB	S3SFN-S5KRAB, RED AB,	
A5550007066	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5KRABM	RED AB	S3SFN-S5KRABM, RED AB,	
A5550005671	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5R		S3SFN-S5R, ,	
A5550005692	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5R2A	RED A2	S3SFN-S5R2A, RED A2,	
A5550005693	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5R2AM	RED A2	S3SFN-S5R2AM, RED A2,	
A5550005764	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5R2B	RED B2	S3SFN-S5R2B, RED B2,	
A5550005765	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5R2BM	RED B2	S3SFN-S5R2BM, RED B2,	
A5550005812	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5RAB	RED A1 B1	S3SFN-S5RAB, RED A1 B1,	
A5550005813	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S5RABM	RED A1 B1	S3SFN-S5RABM, RED A1 B1,	
A5550007073	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6KR2A	RED A2	S3SFN-S6KR2A, RED A2,	
A5550007074	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6KR2AM	RED A2	S3SFN-S6KR2AM, RED A2,	
A5550007075	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6KR2B	RED B2	S3SFN-S6KR2B, RED B2,	
A5550007076	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6KR2BM	RED B2	S3SFN-S6KR2BM, RED B2,	
A5550007077	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6KRAB	RED AB	S3SFN-S6KRAB, RED AB,	
A5550007078	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6KRABM	RED AB	S3SFN-S6KRABM, RED AB,	
A5550005674	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6R		S3SFN-S6R, ,	
A5550005695	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6R2A	RED A2	S3SFN-S6R2A, RED A2,	
A5550005696	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6R2AM	RED A2	S3SFN-S6R2AM, RED A2,	
A5550005767	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6R2B	RED B2	S3SFN-S6R2B, RED B2,	
A5550005768	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6R2BM	RED B2	S3SFN-S6R2BM, RED B2,	
A5550005815	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6RAB	RED A1 B1	S3SFN-S6RAB, RED A1 B1,	
A5550005816	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S6RABM	RED A1 B1	S3SFN-S6RABM, RED A1 B1,	
A5550007085	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7KR2A	RED A2	S3SFN-S7KR2A, RED A2,	
A5550007086	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7KR2AM	RED A2	S3SFN-S7KR2AM, RED A2,	
A5550007087	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7KR2B	RED B2	S3SFN-S7KR2B, RED B2,	
A5550007088	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7KR2BM	RED B2	S3SFN-S7KR2BM, RED B2,	

A5550007089	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7KRAB	RED AB	S3SFN-S7KRAB, RED AB,	
A5550007090	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7KRABM	RED AB	S3SFN-S7KRABM, RED AB,	
A5550007091	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7KW2A	WHITE A2	S3SFN-S7KW2A, WHITE A2,	
A5550006302	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7R		S3SFN-S7R, ,	
A5550005698	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7R2A	RED A2	S3SFN-S7R2A, RED A2,	
A5550005699	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7R2AM	RED A2	S3SFN-S7R2AM, RED A2,	
A5550005770	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7R2B	RED B2	S3SFN-S7R2B, RED B2,	
A5550005771	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7R2BM	RED B2	S3SFN-S7R2BM, RED B2,	
A5550005818	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7RAB	RED A1 B1	S3SFN-S7RAB, RED A1 B1,	
A5550005819	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7RABM	RED A1 B1	S3SFN-S7RABM, RED A1 B1,	
A5550005724	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S7W		S3SFN-S7W, ,	Селекторный переключатель, 30мм, утопленный, Короткая ручка "акула", Белый, 3-позиционный, без возврата
A5550007097	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8KR2A	RED A2	S3SFN-S8KR2A, RED A2,	
A5550007098	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8KR2AM	RED A2	S3SFN-S8KR2AM, RED A2,	
A5550007099	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8KR2B	RED B2	S3SFN-S8KR2B, RED B2,	
A5550007100	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8KR2BM	RED B2	S3SFN-S8KR2BM, RED B2,	
A5550007101	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8KRAB	RED AB	S3SFN-S8KRAB, RED AB,	
A5550007102	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8KRABM	RED AB	S3SFN-S8KRABM, RED AB,	
A5550007103	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8KW2A	WHITE A2	S3SFN-S8KW2A, WHITE A2,	
A5550005679	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8R		S3SFN-S8R, ,	
A5550005701	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8R2A	RED A2	S3SFN-S8R2A, RED A2,	
A5550005702	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8R2AM	RED A2	S3SFN-S8R2AM, RED A2,	
A5550005773	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8R2B	RED B2	S3SFN-S8R2B, RED B2,	
A5550005774	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8R2BM	RED B2	S3SFN-S8R2BM, RED B2,	
A5550005821	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8RAB	RED A1 B1	S3SFN-S8RAB, RED A1 B1,	
A5550005822	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-S8RABM	RED A1 B1	S3SFN-S8RABM, RED A1 B1,	
A5550007109	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAKR2A	RED A2	S3SFN-SAKR2A, RED A2,	
A5550007110	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAKR2AM	RED A2	S3SFN-SAKR2AM, RED A2,	
A5550007111	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAKR2B	RED B2	S3SFN-SAKR2B, RED B2,	
A5550007112	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAKR2BM	RED B2	S3SFN-SAKR2BM, RED B2,	
A5550007113	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAKRAB	RED AB	S3SFN-SAKRAB, RED AB,	
A5550007114	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAKRABM	RED AB	S3SFN-SAKRABM, RED AB,	
A5550005682	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAR		S3SFN-SAR, ,	
A5550005704	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAR2A	RED A2	S3SFN-SAR2A, RED A2,	
A5550005705	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAR2AM	RED A2	S3SFN-SAR2AM, RED A2,	
A5550005776	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAR2B	RED B2	S3SFN-SAR2B, RED B2,	
A5550005777	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SAR2BM	RED B2	S3SFN-SAR2BM, RED B2,	
A5550005824	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SARAB	RED A1 B1	S3SFN-SARAB, RED A1 B1,	
A5550005825	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SARABM	RED A1 B1	S3SFN-SARABM, RED A1 B1,	
A5550007121	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBKR2A	RED A2	S3SFN-SBKR2A, RED A2,	
A5550007122	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBKR2AM	RED A2	S3SFN-SBKR2AM, RED A2,	
A5550007123	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBKR2B	RED B2	S3SFN-SBKR2B, RED B2,	
A5550007124	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBKR2BM	RED B2	S3SFN-SBKR2BM, RED B2,	
A5550007125	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBKRAB	RED AB	S3SFN-SBKRAB, RED AB,	
A5550007126	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBKRABM	RED AB	S3SFN-SBKRABM, RED AB,	
A5550005685	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBR		S3SFN-SBR, ,	
A5550005707	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBR2A	RED A2	S3SFN-SBR2A, RED A2,	
A5550005708	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBR2AM	RED A2	S3SFN-SBR2AM, RED A2,	
A5550005779	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBR2B	RED B2	S3SFN-SBR2B, RED B2,	

A5550005780	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBR2BM	RED B2	S3SFN-SBR2BM, RED B2,
A5550005827	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBRAB	RED A1 B1	S3SFN-SBRAB, RED A1 B1,
A5550005828	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SBRABM	RED A1 B1	S3SFN-SBRABM, RED A1 B1,
A5550007133	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCKR2A	RED A2	S3SFN-SCKR2A, RED A2,
A5550007134	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCKR2AM	RED A2	S3SFN-SCKR2AM, RED A2,
A5550007135	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCKR2B	RED B2	S3SFN-SCKR2B, RED B2,
A5550007136	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCKR2BM	RED B2	S3SFN-SCKR2BM, RED B2,
A5550007137	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCKRAB	RED AB	S3SFN-SCKRAB, RED AB,
A5550007138	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCKRABM	RED AB	S3SFN-SCKRABM, RED AB,
A5550005688	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCR		S3SFN-SCR, ,
A5550005710	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCR2A	RED A2	S3SFN-SCR2A, RED A2,
A5550005711	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCR2AM	RED A2	S3SFN-SCR2AM, RED A2,
A5550005782	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCR2B	RED B2	S3SFN-SCR2B, RED B2,
A5550005783	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCR2BM	RED B2	S3SFN-SCR2BM, RED B2,
A5550005830	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCRAB	RED A1 B1	S3SFN-SCRAB, RED A1 B1,
A5550005831	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SCRABM	RED A1 B1	S3SFN-SCRABM, RED A1 B1,
A5550007145	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDKR2A	RED A2	S3SFN-SDKR2A, RED A2,
A5550007146	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDKR2AM	RED A2	S3SFN-SDKR2AM, RED A2,
A5550007147	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDKR2B	RED B2	S3SFN-SDKR2B, RED B2,
A5550007148	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDKR2BM	RED B2	S3SFN-SDKR2BM, RED B2,
A5550007149	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDKRAB	RED AB	S3SFN-SDKRAB, RED AB,
A5550007150	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDKRABM	RED AB	S3SFN-SDKRABM, RED AB,
A5550005691	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDR		S3SFN-SDR, ,
A5550005713	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDR2A	RED A2	S3SFN-SDR2A, RED A2,
A5550005714	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDR2AM	RED A2	S3SFN-SDR2AM, RED A2,
A5550005785	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDR2B	RED B2	S3SFN-SDR2B, RED B2,
A5550005786	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDR2BM	RED B2	S3SFN-SDR2BM, RED B2,
A5550005833	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDRAB	RED A1 B1	S3SFN-SDRAB, RED A1 B1,
A5550005834	CONTROL SWITCH	SELECTOR SWITCH	S3SFN SERIES	S3SFN-SDRABM	RED A1 B1	S3SFN-SDRABM, RED A1 B1,

Принадлежности к переключателям

Артикул	Категория продукции 1 (Группа товаров)	Категория продукции 2 (Серия)	Категория продукции 3 (Подсерия)	Наименование модели	Спецификация (1)	Наименование модели + Спецификация	Описание товара
A5550009778	CONTROL SWITCH	SWITCH ACCESSORY	SA16 SERIES	SA16-CB	B CONTACT BLOCK	SA16-CB, B CONTACT BLOCK,	Блок контактов, Контакт В (нормально замкнут), для ø16 аварийных выключателей
A5550009779	CONTROL SWITCH	SWITCH ACCESSORY	SA16 SERIES	SA16-CC	C CONTACT BLOCK	SA16-CC, C CONTACT BLOCK,	Блок контактов, Контакт С (нормально разомкнут, нормально замкнут)
A5550009788	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-L12B	12VDC BLUE	SA16-L12B, 12VDC BLUE,	Блок индикации для ø16 переключателей, ток 12В=, синий
A5550009789	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-L12G	12VDC GREEN	SA16-L12G, 12VDC GREEN,	Блок индикации для ø16 переключателей, ток 12В=, зеленый
A5550009787	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-L12R	12VDC RED	SA16-L12R, 12VDC RED,	Блок индикации для ø16 переключателей, ток 12В=, красный
A5550009791	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-L12W	12VDC WHITE	SA16-L12W, 12VDC WHITE,	Блок индикации для ø16 переключателей, ток 12В=, белый

A5550009790	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-L12Y	12VDC YELLOW	SA16-L12Y, 12VDC YELLOW,	Блок индикации для $\varnothing 16$ переключателей, ток 12В=, жёлтый
A5550009793	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-L24B	24VDC BLUE	SA16-L24B, 24VDC BLUE,	Блок индикации для $\varnothing 16$ переключателей, ток 24В=, синий
A5550009794	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-L24G	24VDC GREEN	SA16-L24G, 24VDC GREEN,	Блок индикации для $\varnothing 16$ переключателей, ток 24В=, зелёный
A5550009792	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-L24R	24VDC RED	SA16-L24R, 24VDC RED,	Блок индикации для $\varnothing 16$ переключателей, ток 24В=, красный
A5550009796	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-L24W	24VDC WHITE	SA16-L24W, 24VDC WHITE,	Блок индикации для $\varnothing 16$ переключателей, ток 24В=, белый
A5550009795	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-L24Y	24VDC YELLOW	SA16-L24Y, 24VDC YELLOW,	Блок индикации для $\varnothing 16$ переключателей, ток 24В=, жёлтый
A5550009783	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-L5B	5VDC BLUE	SA16-L5B, 5VDC BLUE,	Блок индикации для $\varnothing 16$ переключателей, ток 5В=, синий
A5550009784	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-L5G	5VDC GREEN	SA16-L5G, 5VDC GREEN,	Блок индикации для $\varnothing 16$ переключателей, ток 5В=, зелёный
A5550009782	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-L5R	5VDC RED	SA16-L5R, 5VDC RED,	Блок индикации для $\varnothing 16$ переключателей, ток 5В=, красный
A5550009786	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-L5W	5VDC WHITE	SA16-L5W, 5VDC WHITE,	Блок индикации для $\varnothing 16$ переключателей, ток 5В=, белый
A5550009785	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-L5Y	5VDC YELLOW	SA16-L5Y, 5VDC YELLOW,	Блок индикации для $\varnothing 16$ переключателей, ток 5В=, жёлтый
A5550012281	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-LH	$\varnothing 16$ HANDLE	SA16-LH, $\varnothing 16$ HANDLE,	
A5550012282	CONTROL SWITCH	SWITCH ACCESSORY	SA16-L SERIES	SA16-RM	$\varnothing 16$ LENS	SA16-RM, $\varnothing 16$ LENS, REMOVAL EQUIPMENT	
A5550010439	CONTROL SWITCH	SWITCH ACCESSORY	SA-C SERIES	SA-CA	SWITCH CONTACT-A NEW	SA-CA, SWITCH CONTACT-A NEW,	Блок контактов, нормально открытый, 110В~/10А, 220В~/5А
A5550010443	CONTROL SWITCH	SWITCH ACCESSORY	SA-C SERIES	SA-CAM	SWITCH CONTACT-A OLD	SA-CAM, SWITCH CONTACT-A OLD,	Блок контактов, модульного типа, Нормально открытый, 110В~/10А, 220В~/5А
A5550010440	CONTROL SWITCH	SWITCH ACCESSORY	SA-C SERIES	SA-CB	SWITCH CONTACT-B NEW	SA-CB, SWITCH CONTACT-B NEW,	Блок контактов, нормально закрытый, 110В~/10А, 220В~/5А
A5550010444	CONTROL SWITCH	SWITCH ACCESSORY	SA-C SERIES	SA-CBM	SWITCH CONTACT-B OLD	SA-CBM, SWITCH CONTACT-B OLD,	Блок контактов, модульного типа, Нормально закрытый, 110В~/10А, 220В~/5А
A5550010472	CONTROL SWITCH	SWITCH ACCESSORY	SA-E SERIES	SA-EG1	D60XD22	SA-EG1, D60XD22,	Защитная манжета, D60 X D22, Маленькая
A5550010473	CONTROL SWITCH	SWITCH ACCESSORY	SA-E SERIES	SA-EG2	D80XD22	SA-EG2, D80XD22,	Защитная манжета, D80 X D22, Большая

A5550010474	CONTROL SWITCH	SWITCH ACCESSORY	SA-E SERIES	SA-EG3	D80XD25	SA-EG3, D80XD25,	Защитная манжета, D80 X D25, Большая
A5550010446	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LA	LED-WHITE	SA-LA, LED-WHITE,	Блок СИД, 100-220В~
H5550009819	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LAB	110-220VAC(N)	SA-LAB, 110-220VAC(N), GL	Блок СИД, Синий, 100-220В~
A5550010456	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LABM	LED-BLUE	SA-LABM, LED-BLUE,	Блок СИД, модульного типа, Чёрный, 100-220В~
A5550010448	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LAG	LED-GREEN	SA-LAG, LED-GREEN,	
A5550010457	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LAGM	LED-GREEN	SA-LAGM, LED-GREEN,	
H5550009775	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LAM	110-220VAC,50/60HZ	SA-LAM, 110-220VAC,50/60HZ, GL	Блок СИД, модульного типа, 100-220В~
A5550010449	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LAR	LED-RED	SA-LAR, LED-RED,	
A5550010458	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LARM	LED-RED	SA-LARM, LED-RED,	Блок СИД, модульного типа, Красный, 100-220В~
A5550010450	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LAY	LED-YELLOW	SA-LAY, LED-YELLOW,	
A5550010459	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LAYM	LED-YELLOW	SA-LAYM, LED-YELLOW,	Блок СИД, модульного типа, Жёлтый, 100-220В~
A5550010445	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LD	LED-WHITE	SA-LD, LED-WHITE,	Блок СИД, 12-30 В=В~
H5550009838	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LDB	12-24VDC/AC(N)	SA-LDB, 12-24VDC/AC(N), GL	Блок СИД, Синий, 12-30 В=В~
A5550010461	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LDBM	LED-BLUE	SA-LDBM, LED-BLUE,	
A5550010452	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LDG	LED-GREEN	SA-LDG, LED-GREEN,	
A5550010462	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LDGM	LED-GREEN	SA-LDGM, LED-GREEN,	Блок СИД, Зеленый, модульного типа, 12-30 В=В~
A5550010460	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LDM	LED-WHITE	SA-LDM, LED-WHITE,	Блок СИД, модульного типа, 12-24 В=В~
A5550010453	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LDR	LED-RED	SA-LDR, LED-RED,	
A5550010463	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LDRM	LED-RED	SA-LDRM, LED-RED,	Блок СИД, Красный, модульного типа, 12-30 В=В~
A5550010454	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LDY	LED-YELLOW	SA-LDY, LED-YELLOW,	
A5550010464	CONTROL SWITCH	SWITCH ACCESSORY	SA-L SERIES	SA-LDYM	LED-YELLOW	SA-LDYM, LED-YELLOW,	Блок СИД, Желтый, модульного типа, 12-30 В=В~
A5550000384	CONTROL SWITCH	SWITCH ACCESSORY	SA-LH SERIES	SA-LH	HANDLE	SA-LH, HANDLE,	Зажимная ручка для выключателей, диаметр 22/25 мм
A5550010468	CONTROL SWITCH	SWITCH ACCESSORY	SA-N SERIES	SA-NL	D80XD25	SA-NL, D80XD25,	Табличка для аварийных выключателей D80 X D25, большая
A5550010465	CONTROL SWITCH	SWITCH ACCESSORY	SA-N SERIES	SA-NS	D60XD25	SA-NS, D60XD25,	Табличка для аварийных выключателей D60 X D25, маленькая

H5550009778	CONTROL SWITCH	SWITCH ACCESSORY	SA-S SERIES	SA-SB1	SQUARE 1HOLE	SA-SB1, SQUARE 1HOLE,	Кнопочный пост, Квадратный, 1 кнопочное отверстие, L=86мм
H5550009780	CONTROL SWITCH	SWITCH ACCESSORY	SA-S SERIES	SA-SB2	SQUARE 2HOLE	SA-SB2, SQUARE 2HOLE ,	Кнопочный пост, Квадратный, 2 кнопочных отверстия, L=136мм
H5550009782	CONTROL SWITCH	SWITCH ACCESSORY	SA-S SERIES	SA-SB3	SQUARE 3HOLE	SA-SB3, SQUARE 3HOLE,	Кнопочный пост, Квадратный, 3 кнопочных отверстий, L=186мм
H5550009784	CONTROL SWITCH	SWITCH ACCESSORY	SA-S SERIES	SA-SB4	SQUARE 4HOLE	SA-SB4, SQUARE 4HOLE,	Кнопочный пост, Квадратный, 4 кнопочных отверстий, L=236мм
H5550009785	CONTROL SWITCH	SWITCH ACCESSORY	SA-S SERIES	SA-SB5	SQUARE 5HOLE	SA-SB5, SQUARE 5HOLE,	Кнопочный пост, Квадратный, 5 кнопочных отверстий, L=286мм
A5550010441	CONTROL SWITCH	SWITCH ACCESSORY	SA-S SERIES	SA-SW2	SWITCHWASHER(Ø22/Ø25)	SA-SW2, SWITCHWASHER(Ø22/Ø25),	
A5550010442	CONTROL SWITCH	SWITCH ACCESSORY	SA-S SERIES	SA-SW3	SWITCHWASHER(Ø30)	SA-SW3, SWITCHWASHER(Ø30),	
H5550009787	CONTROL SWITCH	SWITCH ACCESSORY	SA-T SERIES	SA-TB1	TRIANGLE 1HOLE	SA-TB1, TRIANGLE 1HOLE,	Кнопочный пост, Треугольный, 1 кнопочное отверстие, L=86мм
H5550009789	CONTROL SWITCH	SWITCH ACCESSORY	SA-T SERIES	SA-TB2	TRIANGLE 2HOLE	SA-TB2, TRIANGLE 2HOLE,	Кнопочный пост, Треугольный, 2 кнопочных отверстия, L=136мм
H5550009791	CONTROL SWITCH	SWITCH ACCESSORY	SA-T SERIES	SA-TB3	TRIANGLE 3HOLE	SA-TB3, TRIANGLE 3HOLE,	Кнопочный пост, Треугольный, 3 кнопочных отверстий, L=186мм
H5550009793	CONTROL SWITCH	SWITCH ACCESSORY	SA-T SERIES	SA-TB4	TRIANGLE 4HOLE	SA-TB4, TRIANGLE 4HOLE,	Кнопочный пост, Треугольный, 4 кнопочных отверстий, L=236мм
H5550009794	CONTROL SWITCH	SWITCH ACCESSORY	SA-T SERIES	SA-TB5	TRIANGLE 5HOLE	SA-TB5, TRIANGLE 5HOLE,	Кнопочный пост, Треугольный, 5 кнопочных отверстий, L=286мм
A5550010476	CONTROL SWITCH	SWITCH ACCESSORY	SA-W SERIES	SA-WL	PUSH BUTTON	SA-WL, PUSH BUTTON,	Водонепроницаемый колпачок, 22/25, Для кнопочного выключателя, с подсветкой, выступающего типа
A5550010475	CONTROL SWITCH	SWITCH ACCESSORY	SA-W SERIES	SA-WP	PUSH BUTTON	SA-WP, PUSH BUTTON,	Водонепроницаемый колпачок, 22/25, Для кнопочного выключателя, без подсветки, выступающего типа

Зуммеры

Артикул	Категория продукции 1 (Группа товаров)	Категория продукции 2 (Серия)	Категория продукции 3 (Подсерия)	Наименование модели	Спецификация (1)	Наименование модели + Спецификация	Описание товара
A5550000380	CONTROL SWITCH	BUZZER MELODY	B6MA SERIES	B6MA-4GDN	12-24VDC, NPN	B6MA-4GDN, 12-24VDC, NPN,	Музыкальный зуммер, 12-24В=, Макс. 105dB (0.1m) Макс. 95dB(1m), 4 типа мелодий, IP65, Зелёный СИД, NPN вход с открытым коллектором
A5550000381	CONTROL SWITCH	BUZZER MELODY	B6MA SERIES	B6MA-4GDP	12-24VDC, PNP	B6MA-4GDP, 12-24VDC, PNP,	Музыкальный зуммер, 12-24В=, Макс. 105dB (0.1m) Макс. 95dB(1m), 4 типа мелодий, IP65, Зелёный СИД, PNP вход с открытым коллектором
A5550000382	CONTROL SWITCH	BUZZER MELODY	B6MA SERIES	B6MA-4GLN	110-220VAC, 50/60HZ, NPN	B6MA-4GLN, 110-220VAC, 50/60HZ, NPN,	Музыкальный зуммер, 110 - 220 В~ 50/60 Hz, Макс. 105dB (0.1m) Макс. 95dB(1m), 4 типа

							мелодий, IP65, Зелёный СИД, NPN вход с открытым коллектором
A5550000383	CONTROL SWITCH	BUZZER MELODY	B6MA SERIES	B6MA-4GLP	110-220VAC, 50/60HZ, PNP	B6MA-4GLP, 110-220VAC, 50/60HZ, PNP,	Музыкальный зуммер, 110 - 220 В~ 50/60 Hz, Макс. 105dB (0.1m) Макс. 95dB(1m), 4 типа мелодий, IP65, Зелёный СИД, PNP вход с открытым коллектором
A5550009773	CONTROL SWITCH	BUZZER MAGNETIC	B2NB SERIES	B2NB-B1D	12-24VDC(GREEN LED)	B2NB-B1D, 12-24VDC(GREEN LED),	Магнитный Зуммер, 22/25, 12-24 В~, 75dB(1M) 85dB(0.1M), По выбору постоянный или прерывистый звук, IP30, Зеленый СИД
A5550009775	CONTROL SWITCH	BUZZER MAGNETIC	B2NB SERIES	B2NB-B1D-R	12-24VDC(RED LED)	B2NB-B1D-R, 12-24VDC(RED LED),	Зуммер, 22/25, 12-24 В~, 75dB(1M) 85dB(0.1M), По выбору постоянный или прерывистый звук, Красный СИД
A5550000482	CONTROL SWITCH	BUZZER PIEZO	B2PB SERIES	B2PB-B1D	24VDC	B2PB-B1D, 24VDC, CAP NO PRINTING	Зуммер, 22/25, 12-24 В~, 98dB(0.1M), По выбору постоянный или прерывистый звук, IP65, Зеленый СИД
A5550000483	CONTROL SWITCH	BUZZER PIEZO	B2PB SERIES	B2PB-B1D-R	24VDC(RED LED)	B2PB-B1D-R, 24VDC(RED LED), CAP NO PRINTING	Зуммер, 22/25, 12-24 В~, 98dB(0.1M), По выбору постоянный или прерывистый звук, IP65, Зеленый и красный СИД

Дисковые переключатели

Артикул	Категория продукции 1 (Группа товаров)	Категория продукции 2 (Серия)	Категория продукции 3 (Подсерия)	Наименование модели	Спецификация (1)	Спецификация (2)	Наименование модели + Спецификация
B5900000507	DIGITAL SWITCH	DIGITAL SWITCH	COMMON	AD105-IN	D/SW	SUBASSEMBLY	AD105-IN, D/SW, SUBASSEMBLY
B5900000516	DIGITAL SWITCH	ACCESSORY	COVER	AD105-LI	AD105 COVER(L)	SUBASSEMBLY	AD105-LI, AD105 COVER(L), SUBASSEMBLY
B5900000515	DIGITAL SWITCH	ACCESSORY	COVER	AD105-RI	AD105 COVER(R)	SUBASSEMBLY	AD105-RI, AD105 COVER(R), SUBASSEMBLY

B5900000543	DIGITAL SWITCH	ACCESSORY	COVER	AD605-LB	AD605 BLACK COVER(L)	SUBASSEMBLY	AD605-LB, AD605 BLACK COVER(L), SUBASSEMBLY
B5900000542	DIGITAL SWITCH	ACCESSORY	COVER	AD605-RB	AD605 BLACK COVER(R)	SUBASSEMBLY	AD605-RB, AD605 BLACK COVER(R), SUBASSEMBLY
B5900000537	DIGITAL SWITCH	DIGITAL SWITCH	DIGITAL SWITCH	AD604-BN	D/SW	SUBASSEMBLY	AD604-BN, D/SW, SUBASSEMBLY
B5900000532	DIGITAL SWITCH	DIGITAL SWITCH	DIGITAL SWITCH	AD604-IN	D/SW	SUBASSEMBLY	AD604-IN, D/SW, SUBASSEMBLY
B5900000534	DIGITAL SWITCH	DIGITAL SWITCH	DIGITAL SWITCH	AD605-BN(N)	D/SW(0-9)	SUBASSEMBLY	AD605-BN(N), D/SW(0-9), SUBASSEMBLY
B5900000521	DIGITAL SWITCH	DIGITAL SWITCH	DIGITAL SWITCH	AD605-IN(N)	D/SW(0-9)	SUBASSEMBLY	AD605-IN(N), D/SW(0-9), SUBASSEMBLY

ПО_DAQMaster

Артикул	Категория продукции 1 (Группа товаров)	Категория продукции 2 (Серия)	Категория продукции 3 (Подсерия)	Наименование модели	Наименование модели + Спецификация
A1960000007	SOFTWARE	SOFTWARE	DAQMaster	DAQ-000-USB	DAQ-000-USB, ,
A1960000006	SOFTWARE	SOFTWARE	DAQMaster	DAQ-100-USB	DAQ-100-USB, ,
A1960000008	SOFTWARE	SOFTWARE	DAQMaster	DAQ-256-USB	DAQ-256-USB, ,
A1960000009	SOFTWARE	SOFTWARE	DAQMaster	DAQ-512-USB	DAQ-512-USB, ,

Autonics, Минск +375447584780 viber email minsk17@tut.by

каталог, описание, технические, характеристики, datasheet, параметры, маркировка, габариты, фото, модуль, **Autonics, даташит, Твёрдотельное реле, трехфазное, однофазное, датчик**

КАТАЛОГ 2019г.

Autonics в Беларуси

купить, продажа в **Минске, Беларусь**

ЭЛЕКТРОННЫЕ КОМПОНЕНТЫ

[где и как купить в Минске?](#)



Продукция Autonics