

COMPACT SIZE LIMIT SWITCHES

VL (AZ8) Limit Switches



- Compact design
- Au-clad contacts that can even use low level circuit and little chattering and bouncing
- · Easy wiring with full-open terminals
- Mounting are possible to both front and back
- Type with a lamp is available
- Dust-proof, waterproof, oil resistant construction (IP64)
- Zinc coated* type available (bolts and nuts)

*roller arm type

PRODUCT TYPE

1. Standard type

Actuator	Part No.
Push plunger	AZ8111
Roller plunger	AZ8112
Cross roller plunger	AZ8122
Roller arm	AZ8104
Adjustable roller arm	AZ8108
Adjustable rod	AZ8107
Flexible rod	AZ8166
Spring wire	AZ8169

Note) When ordering an overseas-specified product, refer to the Overseas Standards given below.

FOREIGN STANDARDS

Standard	Applicable product	Part No.
UL	File No. : E122222 Ratings : 5A 250V AC Pilot duty B300 Product type : Standard model, with neon lamp	Order by standard part No. However, add "9" to the end of the part No. for the
CSA	File No. : LR55880 Ratings : 5A 250V AC Pilot duty B300 Product type : Standard model, with neon lamp	model with neon lamp.
ΤÜV	File No. : J9551203 Ratings : AC-15 2A/250V~ Product type : Standard model only	Order by standard part No.

2. With neon lamp

Lamp connection	Actuator	Lamp rating	Part No.
	Push plunger		AZ811106
	Roller plunger		AZ811206
	Cross roller plunger		AZ812206
On when the sec	Roller arm		AZ810406
Spring type	Adjustable roller arm	100 to 200V AC	AZ810806
	Adjustable rod		AZ810706
	Flexible rod		AZ816606
	Spring wire		AZ816906

Note) When ordering an overseas-specified product, refer to the Overseas Standards given below.

3. With LED

		Lamp	rating
Lamp connection	Actuator	12V DC	24 to 48V DC
		Part	No.
	Push plunger	AZ8111161	AZ811116
	Roller plunger	AZ8112161	AZ811216
	Cross roller plunger	AZ8122161	AZ812216
	Roller arm	AZ8104161	AZ810416
Spring type	Adjustable roller arm	AZ8108161	AZ810816
	Adjustable rod	AZ8107161	AZ810716
	Flexible rod	AZ8166161	AZ816616
-	Spring wire	AZ8169161	AZ816916
	Remote wire control plunger	AZ8181161	AZ818116
	Push plunger	AZ8111661	AZ811166
	Roller plunger	AZ8122661	AZ811266
	Cross roller plunger	AZ8122661	AZ812266
Lead wire type	Roller arm	AZ8104661	AZ810466
	Adjustable roller arm	AZ8108661	AZ810866
	Adjustable rod	AZ8107661	AZ810766
	Flexible rod	AZ8166661	AZ816666
	Spring wire	AZ8169661	AZ816966

Notes 1. LED rating 6V DC type is available. When ordering, add suffix 162(spring type) or 662(lead wire type) to the standard part No. 2. The DC24-48V rated lamp is recommended for PC input use.

4. Option

	Application	Part No.
VL limit conduit adapter	VL, VL with lamp, VL-T	AZ8801

5. Protective construction

Protective construction IEC	VL mini limit SW	VL mini limit SW (with indicator)
IP60	0	0
IP64	0	0

6.Lamp rating

Types	Rated operating voltage	Operating voltage range	Internal resister
Neon lamp	100 to 200V AC	80 to 240V AC	120kΩ
	6V DC	5 to 15V DC	2.4kΩ
LED	12V DC	9 to 28V DC	4.7kΩ
	24 to 48V DC	20 to 55V DC	15kΩ

VL (AZ8)

SPECIFICATIONS

1. Rating

1) Standard type

2) Type with indicator Load Resistive load Inductive load Rated control Resistive load Inductive load Types Rated control voltage $(\cos \phi \, \doteqdot \, 1)$ voltage $(\cos \phi \, \doteqdot \, 1)$ 125V AC 5A ЗA 125V AC 5A ЗA With neon lamp 250V AC 5A 2A 240V AC 5A 2A With LED 125V DC 0.4A 0.1A 24V DC ЗA

2. Characteristics

Contact arrangement		1 Form Z	
Initial contact resistance, max.		15m≯ (By voltage drop 6 to 8V DC at rated current)	
Contact material		Gold clad over silver	
Initial insulation resistance (At 500V DC)		Min. 100M ≯	
Initial breakdown voltage		1,000Vrms for 1 min Between non-consecutive terminals 2,000Vrms for 1 min Between dead metal parts and each terminal 2,000Vrms for 1 min Between ground and each terminal	
In the free position		Max. 98m/s ² {10G}	
Shock resistance max. In the full operating position		Max. 294m/s²{30G}	
Vibration resistance		Standard type: Max. 55Hz Type with indicator: 10 to 50Hz, double amplitude of 1.5mm	
	Mechanical	10 ⁷ (at 120 cpm)	
Expected life (Min. operations) Electrical		3×10^5 (at rated resistive load) 5×10^6 (Magnetic contactor FC-100 200V AC load)	
Life of lamp		Min. 2×10 ⁴ hours (Neon lamp type)	
Ambient temperature/Ambient humidity		−20 to +60°C −4 to +140°F/Max. 95%	
Max. operating speed		120 cpm	

3. EN60947-5-1 performance

Item	Rating
Rated insulation voltage (Ui)	250VAC
Rated impulse withstand voltage (Uimp)	2.5kV
Switching overvoltage	2.5kV
Rated enclosed thermal current (Ithe)	5A
Conditional short-circuit current	100A
Short-circuit protection device	10A fuse
Protective construction	IP64
Pollution degree	3

4. Operating characteristics


Characteristics Actuator	O.F. (N {gf}) max.	R.F. (N {gf}) min.	Pretravel (P.T.), max. mm inch	Movement Differential (M.D.), max. mm inch	Overtravel (O.T.), min. mm inch	Totaltravel (T.T.), min. mm inch
Push plunger Roller plunger Cross roller plunger	8.83 {900}	1.47 {150}	1.5 .059	0.7 .028	4 .028	5.5 .217
Roller arm	5.88 {600}	0.49 {50}	20°	10°	75°	95°
Adjustable roller arm	7.84 {800}~3.35 {342}	0.49 {50}~0.21 {21}	20°	10°	75°	95°
Adjustable rod	7.84 {800}~1.99 {203}	0.49 {50}~0.12 {12}	20°	10°	75°	95°
Flexible spring wire	0.88 {90}	-	30 (1.181)	-	20 (.787)	50 (1.969)
Remote wire control plunger	19.61 {2,000}~ 24.52 {2,500}*	1.96 {200}~ 1.96 {200}*	1.5 .059 4 .157*	0.7 .028 2.0 .079*	4.5 .177 2.0 .079*	6.236 6.236*

*Characteristics measured at bent condition: min. radius 100mm 3.937inch


Notes 1. Keep the total travel values in the specified range. Otherwise the actuator force may rise to several times the operating force, resulting in a mechanical failure or much shorter service life. 2. For the operating characteristics, refer to the TECHNICAL INFORMATION.

DATA

1. Life curve




2. Actual load life curve (relay coil load)





Note: The FC magnetic contactor series is 200V AC. The K is 2 Form C 24V DC type.

WIRING DIAGRAM




VL (AZ8)






VL (AZ8)



1. Spring type

1) When connecting load to N.O. side: When the switch is at free position, the indicator is lit, and when the switch operates, the indicator turns off. (Use the indicator holder in the same condition as when it was at the time of shipment.)



2. Lead wire type (only for types with LED)

and N.C. side, operation is same as that

in the case of the spring type. However,

when load is connected to both N.O. side

and N.C. side, indication can be given on

both N.C. side and N.O. side.

1) When giving indication on N.O. side

2) When connecting load to N.C. side: When connecting switch is at free position, the indicator turns off, and when the switch operates, the indicator is lit. (Use the lamp holder, changing it direction by 180°.)


(With LED)


(With neon lamp)

2) When the indication circuit is connected with load in parallel:

Load performs the same operation as the indication circuit does.

- (When load operates, the lamp is lit, and when load is turned off, the lamp goes out.)
- More loads than for one circuit cannot be controlled.
- There is no leakage current.





10/2010

mounting nut

21±0.3


56±0.3

vashei

-4.5 .177 dia.

VL (AZ8)


MOUNTING DIMENSIONS



Depth of screw holes > 15mm .591inch

HEAD DIRECTION CHANGE

(Roller arm, adjustable roller arm, adjustable rol types) Actuator heads may be moved in 90° increments to any of four directions, by removing one screw.



M4 .157 tap (P=0.7)


M4 .157 mounting screv

Thickness of panel < 5mm .197inch

Through hole mounting



mm inch



Length of bolt < panel thickness t+7mm .276inch

CAUTIONS

1. When overtravel is too large, life is shortened due to possible damage to the mechanism. Please use in the following appropriate range.

Types	Overtravel
Plunger (AZ8111, 8112, 8122)	1.5 to 2.0mm .059 to .079inch
Roller Arm (AZ8104, 8107, 8108)	20 to 30°
Flexible Rod (AZ8166, 8169)	15 to 20mm .591 to .787inch (at the top)

2. Because these switches are not of immersion protected construction, their use in water or oil should be avoided. Also, locations where water or oil can normally impinge upon the switch or where there is an excessive accumulation of dust should be avoided.

3. The use of these switches under the following conditions should be avoided. If the following conditions should become necessary, we recommend consulting us first. Use where there will be direct contact with organic solvents, strong acids or alkalis, or direct exposure to their vapors.
Use where inflammable or corrosive gases exist.

4. In order to maintain the reliability at a high level under practical conditions of use, the actual operating conditions should be checked for the benefit of the quality of the product.

5. Mounting

Three cover screws should be fasten uniformly. The rubber for opening cord should be corrected as normal condition after connecting the wire.

6. How to change the indicator holder.

1) As shown in the photograph, wrench a minus-driver in the gap between the cover and the part of the indicator holder indicated by the arrow in the direction of insertion, and raise the lamp a little.


 After removing the indicator holder, insert it in the reverse direction, and push it in until a snap is heard.

3) After changing the direction of the indicator holder, put the cover on it in such a way that the spring touches the top of the terminal screw.

(Unless the spring rests completely on the terminal screw, distortion of the spring, failure in lighting of the lamp or short circuit may result.) 7. Matters to be attended to in using spring type VL Limit Switch with indicator.

1) When loads are connected to both N.O. and N.C. only the indicatin at non-operation time can be used.

2) Take special care not to damage or deform the contact spring during change of indicator holder direction or during connection work.



3) In the case of VL Limit Switch with Neon lamp, if the indicator is connected in series in a 100V circuit, the indicator ceases to be lighted.

However, for a 200V circuit, up to 2 lamps can be connected in series.

8. Matters to be attended to in using lead wire type VL with lamp.

1) When loads are connected to both N.O. and N.C. indication can be given on both N.O. and N.C. sides, but it is impossible to connect the indication circuit to the load in series.