


каталог, описание, технические, характеристики, datasheet, параметры, маркировка, габариты, фото, даташит,

## Предохранитель, вставка плавкая

### аналог, замена



Automatic Sectionalizing Link  
The Cooper Bussmann Automatic Sectionalizing Link (ASL) is a self-commutated circuit-breaking device.

Capacitor Fusing  
Explosive and current-limiting capacitor fusing for protection and medium energy interrupter capabilities.

Current-Limiting  
An integral part of many distribution systems due to noiseless interruption, no separation release, current-limiting action, and very high current-interrupting capability.

Edison Modular Fuse  
Fully shielded and insulated in-line fuses for use in dead-front, overhead or underground, submersible cable distribution systems.

Fuse-Links  
Fuse links can be applied to a variety of applications requiring overcurrent protection of distribution systems and equipment.

Fuses - electronic PCB and small dimension  
Electronic and small dimension fuses.

Fuses - high speed  
Compact, North American square body, BS 88 and female high speed fuses.

Fuses - IEC and British Standard  
IEC and British Standard industrial fuses.

Fuses - low voltage midget and supplemental  
Automotive, inline, limiters, midget and pin indicating.

Fuses - low voltage UL, CSA branch circuit  
Classes CC, CP, G, J, RS and H, L, RK1, RK5 and T, and plug fuses.

Fuses - medium voltage  
Medium voltage fuses up to 30kV.

Power Fuses  
Clip-fitting and under-oil power fuses for system and asset protection.

QR код

[Предохранители \(вставки плавкие\)](#)

[Предохранители \(вставки плавкие\)](#)

[Предохранители керамические](#)

[Предохранители стеклянные](#)

[Чип - SMD предохранители](#)

[Самовосстанавливающиеся предохранители](#)

[Термопредохранители](#)

[Держатели предохранителей](#)

[Электронные компоненты, радиодетали](#)

[Предохранитель, вставка плавкая](#)

### **где и как купить в Минске?**

Мы не работаем с частными (физическими) лицами.

Мы работаем только с юридическими лицами(организациями) и ИП и только по безналичному расчёту.

Сделать заявку или запрос можно по телефону факсу или по электронной почте  
Просим Вас указывать в заявке:

- название предприятия, факс, контактный телефон, контактное лицо;
- полное наименование и количество товара;
- возможность замены или аналоги;

**Компания Ferraz, Shawmut**

**Компания Mersen**

abc, gab, fwp, a70qs, les-rk, a6d-r, ss1, ggc-v  
 agc, ggc, fwx, a30qs, lgr, slr, ss2, ggc  
 anl, cnl, gdc, gdg, lhr, shr, ss5, ggc-v  
 ann, cnn, gdv, gdl-v, llnrk, a2d-r, ss6, ggc  
 ax1, gms, ggi; ggc-v, llsrk, a6d-r, t, gt  
 baf, otm, ggl, ggc, lon, a2d-r, tñ, a3t  
 ban, otm, giv, ggc-v, lon-r, a2d-r, tjs, a6t  
 bbc, gab, ghk, ggc, lon-rk, a2d-r, tl, gtl  
 bbs, sbs, glr, slr, los, a6d-r, trnr, tr-r  
 bdb, gsb, gma, ggm, los-r, a6d-r, trsr, trs-r  
 bdc, gdp, gma-v, ggm-v, los-rk, a6d-r, tscr, gga-v  
 bdl, gdl, gmc, gsc, lpcc, atdr, w, gw  
 bgc, ggc, gmc-v, gsc-v, lpj, aij, wcl, a4by  
 bgx, ggx, gmd, gsc, lpn, a2d-r, x150f, a50qs  
 blf, otm, gmd-v, gsc-v, lpmr, a2d-r, x150p, a50qs  
 bln, otm, gma, gms, lpn-rk, a2d-r, x170f, a70qs  
 bls, sbs, gth, ggc, lps, a6d-r, x170p, a70qs  
 bma, ggm, ha, a6k-r, lpsr, a6d-r, 10kots, ot  
 c-hg, a2k-r, hb, a2k-r, lpsrk, a6d-r, 10kots, ots  
 c-hr, a6k-r, hclr, atm, lslk, feb-11-11, 217, gsb  
 c-j, a4j, hctr, atdr, l13s, a15qs, 218, gdg  
 c-l, a4by, heb-, feb-, l25s, a30qs, 235, ggm  
 ccmr, atdr, het-, febn-, l50s, a50qs, 236, ggm-v  
 ces4, gab, hkp, gpm-g, l60n, a70qs, 238, gsc-v  
 ces6, gsa, hlr, shr-1, l60s, a60x, 239, gsc  
 cgmm, ggm, hnr, a2k-r, mcl, atm, 251, gsr-v  
 cj, a4j, hpf, gpm-s, mcr, gsr-v, 3ab, gab  
 cjs, a4j, hps, gpm-b, mda, gsa, 3ag, ggc  
 cl, a4by, hsr, a6k-r, mdc, gdl, 3ag-sb, gdl  
 cll, a4by, ldsr, trs, mdq, gdl, 3ap, ggc-v  
 clu, a4by, j, a4j, mdv, gdl-v, 3sb, gdl  
 cm, otm, ja, a4j, mdx, gdl, 3sbp, gdl-v  
 cmc, otm, jcd, a240t, men, trm, 3wo, gdl  
 cmfl, otm, jce, a480r, meq, atq, 3wop, gdl-v  
 cnm, trm, jck, a240r, mid, gfn, 311, ggc  
 cnq, atq, jcl(4.8kv), a480r, mof, otm, 312, ggc  
 crn-r, tr-r, jcl(600v), a4j, mol, otm, 313, gdl  
 crs-r, trs-r, jdl, aji, mq, gsr-v, 314, gab  
 csft3x, a15qs, jfh, a4j, mq3, ggm-v, 315, gdl-v  
 csf25x, a30qs, jhc, aji, mq4, ggm, 318, ggc-v  
 csf50p, a50qs, jin, a3t, mth, ggc, 326, gsa  
 csf60c, a60x, jjs, a6t, mt3, gga-v, 36, a4j  
 csf60x, a60x, jks, a4j, ncl, a2k-r, 361, ggx  
 csf70p, a70qs, jlin, a3t, ncl-r, a2k-r, 362, ggx  
 csf100p, a100p, jls, a6t, ncl-rs, a2d-r, 3740, gtl  
 csn-r, tr-r, jls, a4j, nln, ot, 3765, gw  
 css-r, trs-r, jtd, aji, nls, ots, 3770, gsl  
 ctk-r, atm, kaa, a15qs, non, ot, 401, gms  
 ctn-r, a2k-r, kab, a30qs, nos, ots, 49498-5, ti-600  
 cts-r, a6k-r, kah, a15qs, nsd10, gdl, 49498-6, ti-1500  
 denr, tr-r, kax, a30qs, nsd9, gdl-v, 5ag, ggu  
 desr, trs-r, kaz, ti-600, nssa2, ggc, 5mf, ggm  
 dlnr, tr-r, kbc, a60x, pon, otm, 5mfp, ggm-v  
 dlsr, trs-r, kbh, a50qs, ren, rf, 5mtp, gga-v  
 ebs, sbs, kbp, a70qs, res, rfs, 5sf, gsb  
 ecn, tr-r, kby, ti-1500, rfa, a15qs, 5st, ggd  
 ecn-r, tr-r, kla, a15qs, rfl, a70qs, 5tt, gsc  
 ecs, trs-r, kbl, a30qs, rfn, a30qs, 5tp, gsc-v  
 ecs-r, trs-r, kldr, atqr, rvf, a50qs, 50f, gsb  
 elr, slr, klh, a50qs, r fz, ti-600, 50kots, ot  
 enl, cnl, klr, atm, rhn, a2k-r, 50kots, ots  
 enn, cnn, clk-r, atm, rhs, a6k-r, 5ot, gdg  
 eon, ot, klu, a4bt, rln, rf, 51nm, ggm  
 eos, ots, klmr, atrd, rls, rfs, 51s, gsc  
 eq, gsb, klnr, a2k-r, r3-12, gpm-a, 511, ggu  
 ern, rf, klp-c, a4bq, r3-13, gpm-g, 512, ggu  
 ers, rfs, klsr, a6k-r, r3-18, gpm-b, 52, tr-r  
 et, gdg, klu, a4bt, r640, tr-r, 52nm, ggm-v  
 e13s, a15qs, kn, a2k-r, r641, trs-r, 52s, gsc-v  
 e13sf, a15qs, kon, ot, sami-i, dfc-i, 56, trs-r  
 e25s, a30qs, kos, ots, sami-n, dfc-n, 6jx, atm  
 e50s, a50qs, krp-c, a4bq, sc, ag, 61nm, ggc  
 e70s, a70qs, ks, a6k-r, scl, a6k-r, 61s, gdl  
 fbp, a70qs, ktk, atm, scl-r, a6k-r, 62, ot  
 fh042, gpm-g, ktk-r, atm, scl-r, a6d-r, 62nm, ggc-v  
 fh043, gpm-a, ktn, a2k-r, s4d, gdl, 62s, gdl-v  
 fla, gfn, ktn-r, a2k-r, sd5, gsr-v, 640, tr-r  
 flm, trm, kts, a6k-r, sd6, gsc, 65nm, gab  
 flnr, tr-r, kts-r, a6k-r, sec, ag, 65ts, gsa  
 flq, atq, ktu, a4by, sf100p, a100p, 655, ot  
 flsr, trs-r, kwn-r, a2k-r, sf13s, a15qs, 656, ots  
 fna, gfn, kws-r, a6k-r, sf25x, a30qs, 66, ots  
 fnm, trm, l, a4by, sf50p, a50qs, 660, rf  
 fnq, atq, lck, a240r, sf60, a60x, 670, gt  
 fnqr, atqr, lcl, a4bt, sf70p, a70qs, 675, gsl  
 fnw, trm, lcu, a4by, sj, a4j, 680, rfs  
 frm, tr-r, leb-, feb-, skm, ggu, 690, gw  
 frm, tr-r, len, a2d-r, sl, gsr, 72, rf  
 frs, trs-r, len-r, a2d-r, scl, ag, 76, rfs  
 frsr, trs-r, len-rk, a2d-r, sl2, ggx, 8ag, ggx  
 fwa, a15qs, les, a6d-r, sl4, ggx, 92, rf  
 fwh, a50qs, les-r, a6d-r, sp5, gsr-v, 96, rfs

Bussmann	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy
<b>1AG, ( A, amper ), ,</b> <b>AGA, ( A, amper ), ,</b>	301, ( A, amper ),				

213

<b>216, ( A, amper ),</b>						
<b>226, ( A, amper ),</b>						
<b>263, ( A, amper ),</b>						
<b>3AB, ( A, amper ), ,</b> ABC, ( A, amper ), ,	314, ( A, amper ),	GAB, ( A, amper ),				
<b>3AG, ( A, amper ), ,</b> AGC, ( A, amper ), , GLH, ( A, amper ), , MBW, ( A, amper ), , MMB, ( A, amper ), , MTH, ( A, amper ),	311, ( A, amper ), , 312, ( A, amper ), , amper ),	GGC, ( A, amper ), , GGL, ( A, amper ), , GTH, ( A, amper ),				
<b>4164</b>						
<b>4AB, ( A, amper ), ,</b> ABS, ( A, amper ),						
<b>4AG, ( A, amper ), ,</b> AGS, ( A, amper ),						
<b>5AB, ( A, amper ), ,</b> ABU, ( A, amper ), , AGU, ( A, amper ), , BAF, ( A, amper ), , BAN, ( A, amper ),	512, ( A, amper ), , BLF, ( A, amper ), , AGU, ( A, amper ), , BAF, ( A, amper ), , BAN, ( A, amper ),	GGU, ( A, amper ), , OTM, ( A, amper ), , BLN, ( A, amper ),	MOF, ( A, amper ), , MOL, ( A, amper ),			
<b>5AG, ( A, amper ), ,</b> 5AB, ( A, amper ), , ABU, ( A, amper ), , AGU, ( A, amper ), , BAF, ( A, amper ), , BAN, ( A, amper ),	512, ( A, amper ), , BLF, ( A, amper ), , AGU, ( A, amper ), , BAF, ( A, amper ), , BAN, ( A, amper ),	GGU, ( A, amper ), , OTM, ( A, amper ), , BLN, ( A, amper ),	MOF, ( A, amper ), , MOL, ( A, amper ),			
<b>616</b>						
<b>663</b>						
<b>70N-10A</b>	70N	70N				
<b>7AG, ( A, amper ), ,</b> AGW, ( A, amper ),	303, ( A, amper ),					
<b>8AG, ( A, amper ), ,</b> AGX, ( A, amper ), , MJB, ( A, amper ), , MJW, ( A, amper ), , MKB, ( A, amper ),	361, ( A, amper ), , 362, ( A, amper ), ,	GGX, ( A, amper ),				
<b>ABC, ( A, amper ), ,</b> ABS, ( A, amper ),	314, ( A, amper ),	GAB, ( A, amper ),				
<b>ABU, ( A, amper ), ,</b> BAF, ( A, amper ), , BAN, ( A, amper ),	BLF, ( A, amper ), , BLN, ( A, amper ),	OTM, ( A, amper ),	MOF, ( A, amper ), , MOL, ( A, amper ),			
<b>ACF, ( A, amper ), ,</b> <b>ACH, ( A, amper ), ,</b> <b>ACK, ( A, amper ), ,</b> <b>ACL, ( A, amper ), ,</b>	CCK, ( A, amper ), CCL, ( A, amper ),	ACK, ( A, amper ), ACL, ( A, amper ),	ECK, ( A, amper ), ECL, ( A, amper ),	CCL, ( A, amper ), [30-100A]		
Bussmann	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy	
<b>ACT, ( A, amper ), ,</b> <b>ADD, ( A, amper ), ,</b> <b>to AFZ, ( A, amper ), ,</b> <b>AF, ( A, amper ), ,</b> <b>AFJ, ( A, amper ), ,</b> <b>AFS, ( A, amper ), ,</b> <b>AFX, ( A, amper ), ,</b> <b>AFZ, ( A, amper ), ,</b> <b>AGA, ( A, amper ), ,</b> <b>AGC, ( A, amper ), ,</b> MMB, ( A, amper ), , <b>AGC-V</b>	301, ( A, amper ), , 311, ( A, amper ), , 312, ( A, amper ), , 318, ( A, amper ), ,	GGC, ( A, amper ), , BLF, ( A, amper ), , OTM, ( A, amper ), , BLN, ( A, amper ), , GGC-V				
<b>AGS, ( A, amper ), ,</b> <b>AGU, ( A, amper ), ,</b> ABU, ( A, amper ), , BAF, ( A, amper ), , BAN, ( A, amper ), , <b>AGW, ( A, amper ), ,</b> <b>AGX, ( A, amper ), ,</b> MKB, ( A, amper ), ,	512, ( A, amper ), , BLF, ( A, amper ), , BLN, ( A, amper ), ,	GGU, ( A, amper ), , OTM, ( A, amper ), , BLN, ( A, amper ), , GGX, ( A, amper ), , 362, ( A, amper ), ,	MOF, ( A, amper ), , MOL, ( A, amper ),			

<b>ALS, ( A, amper ), , AFX, ( A, amper ),</b>	ALS, ( A, amper ),	AOK, ( A, amper ),		
<b>ANL, ( A, amper ), , CNL, ( A, amper ), , CNL, ( A, amper ),</b>		ENL, ( A, amper ), , ENLE, ( A, amper ),		
<b>ANN, ( A, amper ), , CNN, ( A, amper ), , CNN, ( A, amper ),</b>		ENN, ( A, amper ), , ENNE, ( A, amper ),		
<b>ARD, ( A, amper ), , to ASX, ( A, amper ), , ATC, ( A, amper ), , ATO, ( A, amper ), , AX1, ( A, amper ), , AX1B, ( A, amper ), , GMT, ( A, amper ), , GMT, ( A, amper ), , AX1B, ( A, amper ), , AX1, ( A, amper ), , GMT, ( A, amper ), , GMT, ( A, amper ), , BAF, ( A, amper ), , BAN, ( A, amper ), , BAN, ( A, amper ), , BBS, ( A, amper ), , KTQ, ( A, amper ), , BCA, ( A, amper ), , to BTX, ( A, amper ), , Bussmann</b>	257, ( A, amper ), , AF, ( A, amper ), , 401, ( A, amper ), , GMS, ( A, amper ), , 481, ( A, amper ), , 401, ( A, amper ), , GMS, ( A, amper ), , 481, ( A, amper ), , BLF, ( A, amper ), , OTM, ( A, amper ), , BLN, ( A, amper ), , BLS, ( A, amper ), , SBS, ( A, amper ), , KLQ, ( A, amper ), , Littelfuse	MOF, ( A, amper ), , MOL, ( A, amper ), , MOF, ( A, amper ), , EBS, ( A, amper ), , KEG, ( A, amper ), , Gould / Ferraz / Shawmut	Edison / Bullet	Cefco Economy
<b>BRB, ( A, amper ), , C, ( A, amper ), , CAB, ( A, amper ), , to CAJ, ( A, amper ), , CGL, ( A, amper ), , DLN-R, ( A, amper ), , FRN-R, ( A, amper ), , DLS-R, ( A, amper ), , FRS-R, ( A, amper ), , FBP, ( A, amper ), [0-30A], FWP, ( A, amper ), , FM01, ( A, amper ), , FNA, ( A, amper ), , FNJ, ( A, amper ), , FNM, ( A, amper ), [0-10A]</b>	332, ( A, amper ), , C, ( A, amper ), , FLNR, ( A, amper ), , TR, ( A, amper ), , R	FES, ( A, amper ), , FLNR, ( A, amper ), , TRS, ( A, amper ), , R	ECNR, ( A, amper ), , CRN-R, ( A, amper ), , ECSR, ( A, amper ), , CRS-R, ( A, amper ), ,	
<b>FNM, ( A, amper ), [12-15A], FNM, ( A, amper ), [0-10A]</b>	523, ( A, amper ), , FLM, ( A, amper ), ,	TRM, ( A, amper ), , TRM, ( A, amper ), ,	MEN, ( A, amper ), , MEN, ( A, amper ), ,	
<b>FNM, ( A, amper ), [20-30A], FNM, ( A, amper ), [0-10A], FNM, ( A, amper ), [12-15A]</b>	523, ( A, amper ), , FLM, ( A, amper ), ,	TRM, ( A, amper ), , TRM, ( A, amper ), ,	MEN, ( A, amper ), , MEN, ( A, amper ), ,	
<b>FNQ, ( A, amper ), , FNQ-R, ( A, amper ), , FNQ-R, ( A, amper ), , FNW, ( A, amper ), , FRN, ( A, amper ), ,</b>	FLQ, ( A, amper ), , KLDR, ( A, amper ), , KLDR, ( A, amper ), , FLN, ( A, amper ), ,	ATQ, ( A, amper ), , ATQR, ( A, amper ), , ATQR, ( A, amper ), , TR, ( A, amper ), , TR, ( A, amper ), , ECN, ( A, amper ), ,	MEQ, ( A, amper ), , ATQR, ( A, amper ), , CRN, ( A, amper ), ,	

<b>DLN-R, ( A, amper ), , FRN-R, ( A, amper ), ,</b>	FLNR, ( A, amper ), A, amper ), R		amper ), , amper ), , ECNR, ( A, CRN-R, ( amper ), A, amper ),
<b>FRN-R, ( A, amper ), , DLN-R, ( A, amper ), ,</b>	FLNR, ( A, amper ), TR, ( A, amper ), R		ECNR, ( A, CRN-R, ( amper ), A, amper ),
<b>FRS, ( A, amper ), , DLS-R, ( A, amper ), , FRS-R, ( A, amper ), ,</b>	FLS, ( A, amper ), , TRS, ( A, amper ), , FLSR, ( A, amper ), TRS, ( A, amper ), R		ECS, ( A, CRS, ( A, amper ), , amper ), , ECSR, ( A, CRS-R, ( amper ), A, amper ),
<b>FRS-R, ( A, amper ), , DLS-R, ( A, amper ), ,</b>	FLSR, ( A, amper ), TRS, ( A, amper ), R		ECSR, ( A, CRS-R, ( amper ), A, amper ),
<b>FWA-, ( A, amper ), A [70-1000A],</b>	L15S, ( A, amper ), [70-800A]	A15QS, ( A, amper ), -4	
<b>FWA-, ( A, amper ), B [70-1000A]</b>	L15S, ( A, amper ), [1-30A]	A15QS, ( A, amper ), -2	
<b>FWA-, ( A, amper ), A10F [5-30A]</b>	L15S, ( A, amper ), [35-60A]	A15QS, ( A, amper ), -1	
<b>FWA-, ( A, amper ), AH</b>		A13X, ( A, amper ), -128	RFA, ( A, amper ), [1000-4000A]
<b>FWA-, ( A, amper ), B [70-1000A],</b>	L15S, ( A, amper ), [70-800A]	A15QS, ( A, amper ), -4	
<b>FWA-, ( A, amper ), A [70-1000A]</b>			
<b>Bussmann</b>	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet Cefco Economy
<b>FWH, ( A, amper ),</b>	L50S, ( A, amper ),	A50P, ( A, amper ), , A50QS, ( A, amper ),	REV, ( A, amper ),
<b>FWP, ( A, amper ), , FBP, ( A, amper ), , [0-30A]</b>	L70S, ( A, amper ),	A70P, ( A, amper ), , A70QS, ( A, amper ),	
<b>FWX-, ( A, amper ), A</b>	L25S, ( A, amper ), [35-800A]	A25X, ( A, amper ), 4, A30QS, ( A, amper ), -4	
<b>FWX-, ( A, amper ), A14F</b>	L25S, ( A, amper ), [1-30A]	A25X, ( A, amper ), 1 [10-30A], A25X, ( A, amper ), 1 [1-9A], A30QS, ( A, amper ), -1	
<b>FWX-, ( A, amper ), AH</b>		A25X, ( A, amper ), 128, A30QS, ( A, amper ), -128	
<b>GBA, ( A, amper ),</b>	336, ( A, amper ),	3ABSRI, ( A, amper ),	
<b>GBB, ( A, amper ),</b>	322, ( A, amper ),		GBB, ( A, amper ),
<b>GBC, ( A, amper ), GDA, ( A, amper ),</b>	GBC, ( A, amper ), 216, ( A, amper ),	GSD, ( A, amper ),	
<b>GDA-V, ( A, amper ),</b>	216, ( A, amper ), XE, 266, ( A, amper ),	GSD-V, ( A, amper ),	
<b>GDB, ( A, amper ),</b>	217, ( A, amper ),	GSB, ( A, amper ),	
<b>GDB-V, ( A, amper ),</b>	217, ( A, amper ), XE, 227, ( A, amper ),	GSB-V, ( A, amper ),	
<b>GDC, ( A, amper ),</b>	218, ( A, amper ),	GDG, ( A, amper ),	
<b>GDC-V, ( A, amper ),</b>	218, ( A, amper ), XE, 228, ( A, amper ),	GDG-V, ( A, amper ),	
<b>GJU, ( A, amper ), , GMA, ( A, amper ), , [0-3A], GMA, ( A, amper ), , [3.15-15A]</b>	235, ( A, amper ), [0-3A], 235, ( A, amper ), [4-6A]	GGM, ( A, amper ), [0-3A], GGM, ( A, amper ), [10-15A], GGM, ( A, amper ), [4-8A]	
<b>GJV, ( A, amper ), , AGC-V</b>	318, ( A, amper ),	GGC-V, GJ, ( A, amper ),	RGJV
<b>GKB, ( A, amper ), , 70N-10A</b>	70N	70N	
<b>GLD, ( A, amper ),</b>	334, ( A, amper ),		
<b>GLH, ( A, amper ), ,</b>	311, ( A, amper ), ,	GGC, ( A, amper ), ,	

<b>AGC, ( A, amper ),</b>	312, ( A, amper ),	GGL, ( A, amper ),			
<b>MBW, ( A, amper ),</b>					
<b>, MMB, ( A, amper ),</b>					
<b>GLN, ( A, amper ), ,</b>	251, 252, ( A, amper ), , 256, ( A, GSR-V amper ),				
<b>MCR</b>					
<b>GLQ, ( A, amper ),</b>					
<b>GLR, ( A, amper ),</b>	LGR, ( A, amper ),	SLR, ( A, amper ),			
<b>GLX, ( A, amper ),</b>		GLR, ( A, amper ), -V			
<b>GMA, ( A, amper ), [0-3A]</b>	235, ( A, amper ), [0-3A]	GGM, ( A, amper ), [0-3A], GGM, ( A, amper ), [10-15A]			
<b>GMA, ( A, amper ), [3.15-15A], GMA, ( A, amper ), [0-3A]</b>	235, ( A, amper ), [0-3A], 235, ( A, amper ), [4-6A]	GGM, ( A, amper ), [0-3A], GGM, ( A, amper ), [10-15A], GGM, ( A, amper ), [4-8A]			

Bussmann	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy
<b>GMA-V, ( A, amper ), [0-3A]</b>	235, ( A, amper ), XE [0-3A], 236, ( A, amper ), [0-3A]	GGM-V, ( A, amper ), [0-3A], GGM-V, ( A, amper ), [10-15A]			
<b>GMA-V, ( A, amper ), [3.15-15A], GMA-V, ( A, amper ), [0-3A]</b>	235, ( A, amper ), XE [0-3A], 235, ( A, amper ), XE [4-6A], 236, ( A, amper ), [0-3A], 236, ( A, amper ), [4-6A]	GGM-V, ( A, amper ), [0-3A], GGM-V, ( A, amper ), [10-15A], GGM-V, ( A, amper ), [4-8A]			
<b>GMF, ( A, amper ),</b>	LMF, ( A, amper ),	SMF, ( A, amper ),			
<b>GMQ, ( A, amper ),</b>					
<b>GMT, ( A, amper ), , GMT, ( A, amper ), A</b>	401, ( A, amper ), , 481, ( A, amper ),	GMS, ( A, amper ),			
<b>GMT, ( A, amper ), A, GMT, ( A, amper ),</b>	401, ( A, amper ), , 481, ( A, amper ),	GMS, ( A, amper ),			
<b>GMW, ( A, amper ),</b>		FAMC, ( A, amper ),			
<b>GRF, ( A, amper ), , GMF, ( A, amper ),</b>	LMF, ( A, amper ),	SMF, ( A, amper ),			
<b>GRR, ( A, amper ),</b>					
<b>HAF, ( A, amper ),</b>					
<b>HAG, ( A, amper ),</b>					
<b>HBO, ( A, amper ),</b>	CBO, ( A, amper ),		OBH, ( A, amper ),		
<b>HC, ( A, amper ), , CGL, ( A, amper ),</b>		FES, ( A, amper ),			
<b>HKL, ( A, amper ),</b>	344404, 344405				
<b>HKP</b>					
<b>HLQ, ( A, amper ),</b>					
<b>HLR</b>	LHR	SHR			
<b>HPF</b>	571007	GPM-S			
<b>HPS</b>		GPM-B			
<b>HR</b>	155	SFR			
<b>HRK</b>	150145	SFRG			
<b>HSK, ( A, amper ),</b>					
<b>HTB-22I</b>	3453LF2				
<b>HTB-42I</b>	342012	GPM-G			
<b>HVA, ( A, amper ),</b>					
<b>Bussmann</b>	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy
<b>HVB, ( A, amper ),</b>					
<b>HVJ, ( A, amper ),</b>					
<b>HVL, ( A, amper ),</b>					
<b>HVR, ( A, amper ),</b>					
<b>HVT, ( A, amper ),</b>					
<b>HVU, ( A, amper ),</b>					
<b>Hvw, ( A, amper ),</b>					
<b>Hvx, ( A, amper ),</b>					

<b>IBM, ( A, amper ), , 70N-10A, GKB, ( A, amper ),</b>	70N	70N			
<b>JCK, ( A, amper ), R</b>		A240R-, ( A, amper ), R			
<b>JCK-A, ( A, amper ), R</b>		A240R-, ( A, amper ), R-HS			
<b>JCM, ( A, amper ),</b>					
<b>JCP, ( A, amper ),</b>					
<b>JCW, ( A, amper ),</b>					
<b>JHC, ( A, amper ), , LPJ, ( A, amper ), , LPJ, ( A, amper ), SP</b>	JTD, ( A, amper ), , JTD, ( A, amper ), ID	AJT, ( A, amper ), , AJT, ( A, amper ), Smart Spot			
<b>JJN, ( A, amper ),</b>	JLLN, ( A, amper ),	A3T, ( A, amper TJN, ( A, ), amper ),			
<b>JJS, ( A, amper ),</b>	JLLS, ( A, amper ),	A6T, ( A, amper TJS, ( A, amper ), ),			
<b>JKS, ( A, amper ),</b>	JLS, ( A, amper ),	A4J, ( A, amper JCL, ( A, amper ),			
<b>KAA, ( A, amper ), , FWA-, ( A, amper ), A10F [5-30A], KAW, ( A, amper ),</b>	KLA, ( A, amper ), [1-30A], KLW, ( A, amper ), , L13S, ( A, amper ), [1-30A], L15S, ( A, amper ), [1-30A]	A13X, ( A, amper ), -2, A15QS, ( A, amper ), -2	RFA, ( A, amper ), [1-30A]		
<b>KAB, ( A, amper ), [1-30A], FWX-, ( A, amper ), A14F, KAX, ( A, amper ), [1-30A]</b>	KLB, ( A, amper ), [1-30A], L25S, ( A, amper ), [1-30A]	A25X, ( A, amper ), 1 [10-30A], A25X, ( A, amper ), 1 [1-9A], A30QS, ( A, amper ), -1	RFN, ( A, amper ), [1-30A]	E25S, ( A, amper ), [1-30A]	
<b>KAB, ( A, amper ), [35-800A], FWX-, ( A, amper ), A, KAX, ( A, amper ), [35-800A]</b>	KLB, ( A, amper ), [35-800A], L25S, ( A, amper ), [35-800A]	A25X, ( A, amper ), 4, A30QS, ( A, amper ), -4	RFN, ( A, amper ), [35-800A]	E25S, ( A, amper ), [30-999A]	
<b>KAC, ( A, amper ),</b>	KLC, ( A, amper ),	A60X, ( A, amper ), type 4K	RFC, ( A, amper ),		
<b>KAF, ( A, amper ),</b>					
<b>KAF-C, ( A, amper ),</b>					
<b>KAG, ( A, amper ), , FWX-, ( A, amper ), AH</b>		A25X, ( A, amper ), 128, A30QS, ( A, amper ), -128	RFN, ( A, amper ), HP	E25S, ( A, amper ), [1000-1200A]	

Bussmann	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy
<b>KAJ35-60, ( A, amper ),</b>			RFJ35-60		
<b>KAW, ( A, amper ), , FWA-, ( A, amper ), A10F [5-30A], KAA, ( A, amper ), ,</b>	KLA, ( A, amper ), [1-30A], KLW, ( A, amper ), , L13S, ( A, amper ), [1-30A], L15S, ( A, amper ), [1-30A]	A13X, ( A, amper ), -2, A15QS, ( A, amper ), -2	RFA, ( A, amper ), [1-30A]		
<b>KAX, ( A, amper ), [1-30A], FWX-, ( A, amper ), A14F, KAB, ( A, amper ), [1-30A]</b>	KLB, ( A, amper ), [1-30A], L25S, ( A, amper ), [1-30A]	A25X, ( A, amper ), 1 [10-30A], A25X, ( A, amper ), 1 [1-9A], A30QS, ( A, amper ), -1	RFN, ( A, amper ), [1-30A]	E25S, ( A, amper ), [1-30A]	
<b>KAX, ( A, amper ), [35-800A], FWX-, ( A, amper ), A, KAB, ( A, amper ), [35-800A]</b>	KLB, ( A, amper ), [35-800A], L25S, ( A, amper ), [35-800A]	A25X, ( A, amper ), 4, A30QS, ( A, amper ), -4	RFN, ( A, amper ), [35-800A]	E25S, ( A, amper ), [30-999A]	
<b>KAZ, ( A, amper ),</b>		T1600	RFZ, ( A, amper ),		
<b>KBC, ( A, amper ),</b>	L60S, ( A, amper ),	A60X, ( A, amper ),	RFS, ( A, amper ),		
<b>KBH, ( A, amper ), , FWH, ( A, amper ),</b>	L50S, ( A, amper ),	A50P, ( A, amper ), , A50QS, ( A, amper ),	REV, ( A, amper ),		

<b>KBF, ( A, amper ), , FBP,</b>	( A, amper ), [0-30A], FWP, ( A, amper ),	L70S, ( A, amper ), A70P, ( A, amper ), , A70QS, ( A, amper ),	RFL, ( A, amper ),	
<b>KC, ( A, amper ),</b>				
<b>KD, ( A, amper ),</b>				
<b>KGA, ( A, amper ),</b>				
<b>KGC, ( A, amper ),</b>				
<b>KLA, ( A, amper ), to KLF, ( A, amper ),</b>				
<b>KLP, ( A, amper ),</b>			DCL, ( A, amper ),	
<b>KLU, ( A, amper ), , KRP-C, ( A, amper ), , KRP-C, ( A, amper ), SP</b>	KLLU, ( A, amper ), , KLP, ( A, amper ), , KLPC, ( A, amper ),	A4BQ, ( A, amper ), , A4BT, ( A, amper ), , A4BY, ( A, amper ),	LCL, ( A, amper ), , LKU, ( A, amper ),	CLU
<b>KP, ( A, amper ),</b>				
<b>KRP-C, ( A, amper ), , KRP-C, ( A, amper ), SP</b>	KLPC, ( A, amper ),	A4BQ, ( A, amper ),	LCL, ( A, amper ),	
<b>KRP-C, ( A, amper ), SP</b>		A4BQ, ( A, amper ),		
<b>KRR, ( A, amper ),</b>				
<b>KTE, ( A, amper ), , KTJ, ( A, amper ),</b>				
<b>KTJ, ( A, amper ), , KTE, ( A, amper ),</b>				
<b>KTK, ( A, amper ), , KTK-R, ( A, amper ),</b>	KLK, ( A, amper ), , KLKR, ( A, amper ),	A6Y, ( A, amper ), type2, ATM, ( A, amper ), , ATM-R, ( A, amper ),	HCLR, ( A, amper ), , MCL, ( A, amper ),	
<b>KTN, ( A, amper ),</b>	KLN, ( A, amper ),	A2K, ( A, amper ),	HCLR, ( A, amper ),	
<b>KTN-A, ( A, amper ), canadian</b>			NCL, ( A, amper ),	CTN, ( A, amper ),

Bussmann

Littelfuse

Gould / Ferraz / Shawmut

Edison / Bullet

Cefco

Economy

**KTN-R, ( A, amper ), KLN-R, ( A, amper ), A2K, ( A, amper ), RNCLR, ( A, amper ), CTNR, ( A, amper ), KTQ, ( A, amper ), KLO, ( A, amper ), KEG, ( A, amper ), KTS, ( A, amper ), KLS, ( A, amper ), A6K, ( A, amper ), SCL, ( A, amper ), KTS-R, ( A, amper ), KLSR, ( A, amper ), A6K, ( A, amper ), RSCLR, ( A, amper ), KTU, ( A, amper ), LAA, ( A, amper ), LAA-F, ( A, amper ), LAR, ( A, amper ), LHA, ( A, amper ), LKB, ( A, amper ), LKC, ( A, amper ), LKI, ( A, amper ), LKN, ( A, amper ), LKN, ( A, amper ), RL, ( A, amper ), ELNE, ( A, amper ), LKO, ( A, amper ), LKS, ( A, amper ), , KLU, ( A, amper ), , KRP-C, ( A, amper ), , KRP-C, ( A, amper ), SP, LKU, ( A, amper ), KLL, ( A, amper ), , KLLU, ( A, amper ), , KLP, ( A, amper ), , KLPC, ( A, amper ), , LKUA4BQ, ( A, amper ), , A4BT, ( A, amper ), , A4BY, ( A, amper ), LCL, ( A, amper ), , LKU, ( A, amper ), CLL, CLULKA, ( A, amper ), , KLU, ( A, amper ), , KRP-C, ( A, amper ), , KRP-C, ( A, amper ), SP, LKS, ( A, amper ), KLL, ( A, amper ), , KLLU, ( A, amper ), , KLP, ( A, amper ), , KLPC, ( A, amper ), , LKUA4BQ, ( A, amper ), , A4BT, ( A, amper ), , A4BY, ( A, amper ), LCL, ( A, amper ), , LKU, ( A, amper ), CLL, CLULPA, ( A, amper ), to LPI, ( A, amper ), LP-CC, ( A, amper ), CCMR, ( A, amper ), ATD-R, ( A, amper ), EPCC, ( A, amper ), LPJ, ( A, amper ), , LPJ, ( A, amper ), SPJTD, ( A, amper ), , JTD, ( A, amper ), IDAJT, ( A, amper ), , AJT, ( A, amper ), Smart SpotLPJ, ( A, amper ), SPJTD, ( A, amper ), , JTD, ( A, amper ), IDAJT, ( A, amper ), , AJT, ( A, amper ), Smart SpotLPN, ( A, amper ), LLN, ( A, amper ), A2D, ( A, amper ), LPN-R, ( A, amper ), LLNR, ( A, amper ), AT-DE-RLPN-RK, ( A, amper ), , LPN-RK, ( A, amper ), SPLNRK, (**

A, amper ), A2D, ( A, amper ), RLENRK, ( A, amper ), LON-RK, ( A, amper ), LPN-RK, ( A, amper ), SPLNRK, ( A, amper ), A2D, ( A, amper ), RLENRK, ( A, amper ), LPO, ( A, amper ),

Bussmann

Littelfuse

Gould / Ferraz / Shawmut

Edison / Bullet

Cefco

Economy

**LPS, ( A, amper ), , LPS-R, ( A, amper ), LLS, ( A, amper ), ATS-DE-RLLSRLPS-R, ( A, amper ), LLS, ( A, amper ), ATS-DE-RLLSRLPS-RK, ( A, amper ), , LPS-RK, ( A, amper ), SPLLSRK, ( A, amper ), A6D, ( A, amper ), , A6D, ( A, amper ), RLESRK, ( A, amper ), LPS-RK, ( A, amper ), SPLLSRK, ( A, amper ), A6D, ( A, amper ), RLESRK, ( A, amper ), LRA, ( A, amper ), to LRU, ( A, amper ), MBB, ( A, amper ), MBO, ( A, amper ), MBW, ( A, amper ), , AGC, ( A, amper ), , MMB, ( A, amper ), 311, ( A, amper ), , 312, ( A, amper ), GGC, ( A, amper ), MCR251GSR-VMD, ( A, amper ), 3425, ( A, amper ), MDA, ( A, amper ), 326, ( A, amper ), GSA, ( A, amper ), MDC, ( A, amper ), MDF, ( A, amper ), MDL, ( A, amper ), , MDQ, ( A, amper ), , MDV, ( A, amper ), , MDX, ( A, amper ), 313, ( A, amper ), , 315, ( A, amper ), GDL, ( A, amper ), , GDV, ( A, amper ), MDL-V, ( A, amper ), 315, ( A, amper ), MDM, ( A, amper ), MDQ, ( A, amper ), , MDL, ( A, amper ), , MDV, ( A, amper ), , MDX, ( A, amper ), 313, ( A, amper ), , 315, ( A, amper ), GDL, ( A, amper ), , GDV, ( A, amper ), MDR, ( A, amper ), MDV, ( A, amper ), , MDL, ( A, amper ), , MDQ, ( A, amper ), , MDX, ( A, amper ), , MDL, ( A, amper ), , MDQ, ( A, amper ), , MDV, ( A, amper ), 313, ( A, amper ), , 315, ( A, amper ), GDL, ( A, amper ), , GDV, ( A, amper ), MGB, ( A, amper ), MIC, ( A, amper ), , MIJ, ( A, amper ), MIJ, ( A, amper ), , MIC, ( A, amper ), MIN, ( A, amper ), 1812, ( A, amper ), MIDR, ( A, amper ), MIS, ( A, amper ), , MS, ( A, amper ), 473, ( A, amper ),**

Bussmann	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy
<b>MJB, ( A, amper ), , AGX, ( A, amper ), , MJW, ( A, amper ), , MKB, ( A, amper ), ,</b>	361, ( A, amper ), , 362, ( A, amper ), ,	GGX, ( A, amper ),			
<b>MJW, ( A, amper ), , AGX, ( A, amper ), , MJB, ( A, amper ), , MKB, ( A, amper ), ,</b>	361, ( A, amper ), , 362, ( A, amper ), ,	GGX, ( A, amper ),			
<b>MKB, ( A, amper ), , AGX, ( A, amper ), ,</b>	361, ( A, amper ), , 362, ( A, amper ), ,	GGX, ( A, amper ),			
<b>MMB, ( A, amper ),</b>					
<b>MS, ( A, amper ), , MIS, ( A, amper ),</b>	473, ( A, amper ),				
<b>MTH, ( A, amper ), , AGC, ( A, amper ), , GLH, ( A, amper ), , MBW, ( A, amper ), , MMB, ( A, amper ), ,</b>	311, ( A, amper ), , 312, ( A, amper ), ,	GGC, ( A, amper ), , GGL, ( A, amper ), , GTH, ( A, amper ),			
<b>N, ( A, amper ),</b>					
<b>NAA, ( A, amper ), to NAM, ( A, amper ),</b>					
<b>NO.263</b>					CFR-263
<b>NO.2642</b>					CFR-642
<b>NO.2664</b>					CFR-264
<b>NON, ( A, amper ),</b>	NLN, ( A, amper ), OT, ( A, amper ),	KON, ( A, amper ), , 50KOTN, ( A, amper ), [0-60A]			10KOTN, ( A, amper ), , 50KOTN, ( A, amper ), [0-60A]

<b>NOS, ( A, amper ),</b>	NLS, ( A, amper ),	OTS, ( A, amper ),	KOS, ( A, amper ),	50KOTS, ( A, amper ), [0-60A]
<b>ODA, ( A, amper ), to OWZ, ( A, amper ),</b>				
<b>REN, ( A, amper ),</b>	RLN, ( A, amper ),	RF, ( A, amper ),	ERN, ( A, amper ),	R, ( A, amper ),
<b>RES, ( A, amper ),</b>	RLS, ( A, amper ),	RFS, ( A, amper ),	ERS, ( A, amper ),	
<b>RHA, ( A, amper ), to RRU, ( A, amper ),</b>				
	S, ( A, amper ), ,			
<b>S, ( A, amper ),</b>	SLO, ( A, amper ), ,		S, ( A, amper ),	
	SOO, ( A, amper ), ,			
	) ,			
<b>SA, ( A, amper ),</b>	SAO, ( A, amper ),			
<b>SC, ( A, amper ),</b>	SLC, ( A, amper ),	AG, ( A, amper ),		
<b>SCY, ( A, amper ),</b>				
	307, ( A, amper ),			
<b>SFE, ( A, amper ),</b>	, SFE, ( A, amper ),			
	) ,			
<b>SKA, ( A, amper ),</b>				
<b>SKG, ( A, amper ),</b>				
<b>SL, ( A, amper ),</b>				
<b>T, ( A, amper ),</b>	TOO, ( A, amper ),	GT, ( A, amper ),	T, ( A, amper ),	
<b>TAA, ( A, amper ),</b>				
<b>TFA, ( A, amper ),</b>				
<b>TFC, ( A, amper ),</b>				
<b>TFL, ( A, amper ),</b>				
<b>TFS, ( A, amper ),</b>				
<b>TL, ( A, amper ),</b>	TLO, ( A, amper ),	GTL, ( A, amper ),		
<b>UHA, ( A, amper ), , UHC, ( A, amper ),</b>				
<b>UHC, ( A, amper ), , UHA, ( A, amper ),</b>				
<b>W, ( A, amper ),</b>	WOO, ( A, amper ),	GW, ( A, amper ),	W, ( A, amper ),	P, ( A, amper ),
<b>WAA, ( A, amper ), to WHA, ( A, amper ),</b>				
<b>WER, ( A, amper ),</b>				
<b>WIRE, ( A, amper ),</b>				
<b>WKF, ( A, amper ),</b>				
<b>WKH, ( A, amper ),</b>				
<b>WKJ, ( A, amper ),</b>				
<b>WKK, ( A, amper ),</b>				
<b>WKO, ( A, amper ),</b>				
<b>WKU, ( A, amper ),</b>				
<b>WPA, ( A, amper ),</b>				
<b>WQL, ( A, amper ),</b>				
<b>WTK, ( A, amper ),</b>				
<b>WWE, ( A, amper ),</b>				
<b>WWX, ( A, amper ),</b>				

Предохранитель, вставка плавкая Минск viber и т.80447584780 Viber  
[www.fotorele.net](http://www.fotorele.net) [www.tiristor.by](http://www.tiristor.by) радиодетали, электронные компоненты  
 email minsk17@tut.by tel.+375 29 758 47 80 мтс

[\*\*где и как купить в Минске?\*\*](#)